Instruction Set

Purpose: A middleman between the software and the hardware

- Instruction set can be converted to machine code through an assembler
- Different sets of hardware require different sets of assembly instructions



Types of Instructions

- Expressions
 - o ADD, NAND
- Assignments
- Conditionals and Loops
 - BEQ
- Functions
 - Jalr

Addressing Modes

- How operands are specified
- Addressability: smallest space in memory that can be addressed
 - o Our ISA will be word-adddressable
 - o Other types may be byte addressable
- Three types
 - Register
 - Base + Offset
 - PC Relative

R-type Instructions

- Operands that we manipulate are within the register file itself
- Examples: add, nand

I-type Instructions

- Contains two operands for registers and one for immediate value
- Examples: addi, lw, sw
 - Add immediate, load word, store word
 - o addi \$v0, \$a0, 25
 - Translates to x = y + 25 where \$v0 is register x and \$a0 is register y

J-type Instructions

- Two registers, the rest is unused
- Examples: jalr, beq

O-type Instructions

- Opcode only, doesn't specify any operands
- Example: halt
 - o (halt
 - opcode 0b111

Data Types

There is variation in what kinds of data we can load, store, and manipulate

Word size = max. precision supported in an architecture

• For our datapath, this is 4 bytes = 32 bits

Endianness

Endianness deals with how this data is placed at a specific location in memory



- Quick recap:
 - Rightmost two hex values = least significant byte
 - Leftmost two hex values = most significant byte

Big Endian

- Most significant bit is stored first
- Example: OxABCDEFGH

0x100	0x101	0x102	0x103
0xAB	0xCD	0xEF	0xGH

Little Endian


- Least significant bit is stored first
- Example: **0xABCDEFGH**

0x100	0x101	0x102	0x103
0xGH	0xER	0xCD	0xAB

Endianness only affects the order of bytes within a single value, not the value itself

Packing

- Data alignment matters
- Want the least amount of memory access (memory slow)



• Bottom one is Little Endian

Unaligned memory access is very expensive

Example:

```
struct {
     int a;
     char b;
     short d;
     short e;
 }
+3
     +2
          +1
               +0
a4
     a3
          a2
               a1
d2
     d1
               b
          e2
               e1
```

Note that we leave the space between b and d, so it becomes clearer to the compiler what is what