Network-related Synchronization

- sync/control
 - control[29] is the "Arm MCNT" bit (0x20000000). This bit needs to be set on both ROACH2's pretty close to each other (within one sync cycle). The MCNT counter resets on the first sync pulse after a rising edge of this bit.

Network-related Scope Configuration

• scope/ctrl

This register controls the behavior of the "scope" functionality.

- ctrl[23:16] Sync out select. A value of 31 (16+15) selects the network's [recevied?] sync out signal. [Really? Maybe it's just 15?]
- ctrl[15:08] Snap select 1. A value of 12 selects the network [received?] data signals for snapshotting in scope/snap1.
- ctrl[07:00] Snap select 0. A value of 12 selects the network [received?] data signals for snapshotting in scope/snap0.

Network Configuration and Control

• network/ctrl

Control register for network related logic.

- ctrl[31] = 10 GbE Core Reset
- ctrl[30] = RX FIFO Reset
- ctrl[5] = Network TX Enable
- ctrl[4] = Network RX Enable
- ctrl[0] = Bypass control (0=normal; 1=bypass)
- network/eth/0 to network/eth/3

These are the 10 GbE cores. They must have the low byte of their IP address set to this 8 bit binary value: ORRR11EE, where RRR is the ROACH2 ID (0-7, i.e. basically the same thing as FID) and EE is the two bit core number (0-3). For example, eth2 (EE=10) on FID=3 (RRR=011) would need to have the low byte of its IP address set to: O0111110 = 0x3e = 62. The high three bytes of a core's IP address must be set to the same value as the high three bytes of network/ipbase. MAC addresses and ARP tables must also be setup accordingly.

FID	eth0	eth1	eth2	eth3
0	12	13	14	15
1	28	29	30	31
2	44	45	46	47
3	60	61	62	63
4	76	77	78	79
5	92	93	94	95
6	108	109	110	111
7	124	125	126	127

Table 1: Last octect of 10 GbE IP addresses for each F engine.

• network/fid

The low 3 bits of this register sets the FID (F engine ID) of the ROACH2. This is basically input/antenna number. Each ROACH2 must have a unique value from 0 to 7.

• network/ipbase

The high 24 bits set the first three octets of the destination IP address that packets are sent to. This must match the high 24 bits of the 10 GbE cores' IP addresses.

Network Monitoring

• network/eth/status

Each byte contains 6 status bits from each ethernet core. The least significant byte is port 0. the most significant byte is port 3. Within each byte, the bits are:

- status[5]: rx overrun
- status[4]: led up (maybe always up since it only reflects status to SFP+ phy?)
- status[3]: led rx
- status[2]: led_tx
- status[1]: tx_afull
- status[0]: tx oflow

• network/mcnt/rx

The 8 least significant bits of the received MCNTs on each interface all in one 32 bit register.

- rx[07:00] is 8 LSbs of mcnt received on eth0
- rx[15:08] is 8 LSbs of mcnt received on eth1
- rx[23:16] is 8 LSbs of mcnt received on eth2
- rx[31:24] is 8 LSbs of mcnt received on eth3

• network/mcnt/rx0 to network/mcnt/rx3

Contains the 32 least significant bits of the received MCNTs on each interface.

- rx0 is 32 LSbs of mcnt received on eth0
- rx1 is 32 LSbs of mcnt received on eth1
- rx2 is 32 LSbs of mcnt received on eth2
- rx3 is 32 LSbs of mcnt received on eth3

• network/mcnt/tx

Contains the 32 LSbs of mcnt that is being sent over net interfaces.

• network/pcnt

Each byte is a count (0-31) of packets buffered in each of the four packet buffers (one per 10 GbE core). The low byte is eth0.

• network/sowf/cnt0 to network/sowf/cnt3

Received Start of Walsh Frame counters for each interface. The "RX FIFO Reset" bit (network/ctrl[30]) resets the counters.

- cnt0 is count of SOWF rising edges received on eth0
- cnt1 is count of SOWF rising edges received on eth1
- cnt2 is count of SOWF rising edges received on eth2
- cnt3 is count of SOWF rising edges received on eth3

• network/sync_count

Count of sync pulses sent to the X engines. This register should increment exactly once per Walsh frame.

• network/xid

Each byte is bits 12 downto 5 of the most recently received XID on each 10 Gbe core. The low byte is eth0. This is essentially the same thing as bits 13 downto 6 of the most recently received channel number. Bits 4 downto 0 of the received XID should be constant for each 10 GbE core.

Data distribution

I think the channels going into the X engine on ROACH2 #0 (FID=0) will be:

```
First 8 channels in parallel: 0 1 2 3 4 5 6 7 Next 8 channels in parallel: 64 65 66 67 68 69 70 71 Next 8 channels in parallel: 128 129 130 131 132 133 134 135 And so on...
```

The channels for FID=1 will be the same pattern as for FID=0, but 8 channels higher. The channels for FID=2 will be the same pattern as for FID=0, but 16 channels higher. And so on...