# 1 Description of State Space

#### 1.1 Definition

# 1. Input variables

We usually use 
$$u_t = \begin{bmatrix} u_1(t) \\ u_2(t) \\ \vdots \\ u_{n(t)} \end{bmatrix}$$
 to represent input variables.

#### 2. State variables

We usually use 
$$m{x}_t = \begin{bmatrix} x_1(t) \\ x_2(t) \\ \vdots \\ x_{n(t)} \end{bmatrix}$$
 to represent state variables.  
It is a least set to describe state of system.

# 3. Output variables

We usually use 
$$m{y}_t = egin{bmatrix} y_1(t) \\ y_2(t) \\ \vdots \\ y_{n(t)} \end{bmatrix}$$
 to represent output variables.

#### 4. State equation

State equation is a first order differential equation that describe relationship between input variables and state variables. We can write it as:

$$\begin{cases} \dot{x}_1 = f_1 \left( x_1, x_2, ..., x_n; u_1, u_2, ..., u_p, t \right) \\ \dot{x}_2 = f_2 \left( x_1, x_2, ..., x_n; u_1, u_2, ..., u_p, t \right) \\ \vdots \\ \dot{x}_n = f_n \left( x_1, x_2, ..., x_n; u_1, u_2, ..., u_p, t \right) \end{cases}$$

$$(1.1.1)$$

Rewrite it as vector form:

$$\dot{\boldsymbol{x}}_t = \boldsymbol{f}(\boldsymbol{x}_t, \boldsymbol{u}_t, t) \tag{1.1.2}$$

# 5. Output equation

Output equation is a equation that describe relationship between state variables and output variables. We can write it as:

$$\begin{cases} y_1 = g_1(x_1, x_2, ..., x_n; u_1, u_2, ..., u_p, t) \\ y_2 = g_2(x_1, x_2, ..., x_n; u_1, u_2, ..., u_p, t) \\ \vdots \\ y_n = g_n(x_1, x_2, ..., x_n; u_1, u_2, ..., u_p, t) \end{cases}$$

$$(1.1.3)$$

Rewrite it as vector form:

$$\mathbf{y}_t = \mathbf{g}(\mathbf{x}_t, \mathbf{u}_t, t) \tag{1.1.4}$$

### 6. Description of State space of System

We can describe state space of system by equations as:

$$\begin{cases} \dot{\boldsymbol{x}}_t = \boldsymbol{f}(\boldsymbol{x}_t, \boldsymbol{u}_t, t) \\ \boldsymbol{y}_t = \boldsymbol{g}(\boldsymbol{x}_t, \boldsymbol{u}_t, t) \end{cases}$$
 (1.1.5)

When the system is linear, we can write it as:

$$\begin{cases} \dot{x} = A(t)x + B(t)u \\ y = C(t)x + D(t)u \end{cases}$$
(1.1.6)

## 1.2 Transfer function

Transfer function is a function that describe relationship between input and output of system. Given a system with different state, the transfer function is still the same which means it is not related to state of system in other words state variables.

#### Single input – Single output system

Given a single input-single output, we have state space representation as:

$$\begin{cases} \dot{x} = Ax + Bu \\ y = Cx + Du \end{cases}$$
 (1.2.1)

To get transfer function, we can use Laplace transform to get:

$$sX - x(0) = AX + BU(s)$$
$$Y(s) = CX(s) + DU(s)$$

# $$\begin{split} \textbf{Laplace transfer:} \\ \mathcal{L}[af(t)+bg(t)] &= a\mathcal{L}[f(t)] + b\mathcal{L}[g(t)] \\ \mathcal{L}[f^n(t)] &= s^n\mathcal{L}[f(t)] - s^{\{n-1\}}f(0) - s^{\{n-2\}}f^{\{(1)\}}(0) - \ldots - f^{\{(n-1)\}}(0) \\ \\ \mathcal{L}\left[\int_0^t \mathrm{d}t \int_0^t \mathrm{d}t \ldots \int_0^t f(t) \, \mathrm{d}t \right] &= \frac{1}{s^n}\mathcal{L}[f(t)] \end{split}$$ To be continued...

The equations are organized as follows:

$$\boldsymbol{X}(s) = (s\boldsymbol{I} - \boldsymbol{A})^{-1}[\boldsymbol{x}(0) + \boldsymbol{B}\boldsymbol{U}(s)]$$
  
$$\boldsymbol{Y}(s) = \boldsymbol{C}(s\boldsymbol{I} - \boldsymbol{A})^{-1}[\boldsymbol{x}(0) + \boldsymbol{B}\boldsymbol{U}(s)] + D\boldsymbol{U}(s)$$

Let initial condition be zero(x(0) = 0), we can get:

$$Y(s) = \left[ \boldsymbol{C}(s\boldsymbol{I} - \boldsymbol{A})^{-1}\boldsymbol{B} + \boldsymbol{D} \right] \boldsymbol{U}(s)$$

Thus, we can get transfer function as:

$$g(s) = \frac{Y(s)}{U(s)} = \mathbf{C}(s\mathbf{I} - \mathbf{A})^{-1}\mathbf{B} + D$$
(1.2.2)

Let D = 0, we can get:

$$g(s) = \frac{C \operatorname{adj}(sI - A)B}{\det(sI - A)}$$
(1.2.3)

#### Multi input - Multi output system