

## SE350 RTX LAB 2

P2-A Interprocess Communications (IPC)

P2-B Timing Service

Irene Yiqing Huang
Electrical and Computer Engineering Department

### Reading the Lab Manual

	Section	Topics	How to Read
	1.2	Summary of RTX Requirements	Review
P2-A	2.5	Interprocess Communications	Study
P2-B	2.6	Timing Service	Study
	3.2.1	The Timer I-Process	Study
	3.4	Process ID Assignment	Skim
	4	RTX initialization	Review
	5.1.2	RTX P2 Requirements	Study
	5.2	Demo Procedure	Review
	5.3	Third-party testing framework	Review
	6.3 - 6.5	FAQ – IPC and Interrupts	Skim
	9.4	C and Assembly Programming	Study
	9.7	Timer Programming	Skim

### P2 Highlights

- Message Passing API
  - Message-based interprocess communication (IPC)
  - New process state of BLK\_MSG
- Timing Service
  - Timer Interrupt Handling
  - Interrupt Process
  - New process state of IPROC





#### P2 User API

Message Passing

```
/* non-blocking send */
  int send_message(int process_id, void *message_envelope)
                                                                       P2-A
 /* blocking receive */
 void *receive_message(int *sender_id)
                                      This is an output parameter!
• Timing Service
                                                                       P2-B
 int delayed_send(int process_id, \
                   void *message_envelope,\
                   int delay)
                                       In milliseconds
```

#### P2 Assumptions

- Processes are non-malicious
- All processes are known
  - created at start-up
  - know each other

```
/* common.h */
#define PID_NULL
#define PID_P1
#define PID_P2
#define PID P3
#define PID P4
#define PID P5
#define PID_P6
                        6
#define PID_A
#define PID B
#define PID_C
#define PID_SET_PRIO
#define PID_CLOCK
#define PID_KCD
#define PID_CRT
                        13
#define PID_TIMER_IPROC 14
#define PID_UART_IPROC
```

#### P2 Processes

- System Processes
  - Null process with PID = 0
- User Processes
  - Six test processes with PIDs = 1,2, ..., 6
  - User level processes, only calls the user APIs
- Interrupt Processes
  - Timer i-process, pid = 14



**P2-B** 

- What processor mode should each process be in?
- What privilege level should each process be at?

#### P2 Processes

PID	PID Macro	Process		Privilege Level
14	PID_TIMER_IPROC	Timer I Process	Handler	Privileged
0	PID_NULL	Null Process	User	Unprivileged
1-6	PID_P[1-6]	Test Processes	User	Unprivileged

# P2-A IPC

Interprocess Communications

#### **IPC Overview**

- Requirement specification:
  - message-based, asynchronous IPC
  - messages carried in shared message blocks (msg envelopes)
- Each process writes a message into a message envelope
- A process invokes send\_message(pid, msg\_envelope)
- Issues:
  - what is the format of the message envelope (i.e. envelope memory block)?
  - where do these envelope memory blocks come from?

### IPC: Message Envelopes

- Memory blocks are managed by the kernel
  - a process allocates a memory block and turns it into a message envelope by casting.
  - a process deallocates an envelope when it is no longer needed (current owner of the envelope!)
  - a process owns a message envelope that it receives or allocates (until it is sent)


Note the ownership requirement of message envelopes!

### IPC: Message Envelope Format

#### Design issues:

- Kernel updates the header
- Can user access the header?

```
struct msgbuf {
#ifdef K_MSG_ENV
  void *mp_next; /* ptr to the next message */
  int m_send_pid; /* sender pid */
  int m_recv_pid; /* receiver pid */
  int m_kdata[5]; /* extra kernel data place holder */
#endif
  int mtype; /* user defined message type */
  char mtext[1]; /* body of the message */
};
```



### IPC: Message Buffering

- Problem
  - Multiple processes send messages to a process but that process does not do a receive for some time.
  - How does kernel keep track of such messages?
- Design issue:
  - How are messages buffered by kernel?

### **IPC: Waiting Messages**

- Design: let each process have a queue of waiting messages
  - extend the PCB to include:




Image Courtesy of [1]

#### IPC: Blocked on Receive

- What happens to a process that executes receive but no message available?
  - it blocks
  - its state is set to blocked\_on\_receive
- Design issue: should processes in this state be kept somewhere (queue, set ?)
  - why put on some Q?
  - no real need to do so.
  - just set its status to "blocked\_on\_receive" and that's all

#### P2 Process State Transition

```
/* k_inc.h starter code */
typedef enum {NEW = 0, RDY, RUN, BLK_MEM, BLK_MSG} PROC_STATE_E;
BLK MSG state
```

higher-priority process scheduled

Add BLK\_MSG state Message Resource Blocked Request: receive\_message Release: send message release resource resource available rtx init() scheduled scheduled RUN NEW **RDY** release\_processor() or

### IPC: send\_message

```
int send_message(int recv_pid, void *msg_env) {
    atomic(on);
    set sender pid, destination_pid fields in env
    recv pcb ← convert recv pid to process obj/PCB reference
    enqueue env onto the msg_queue of recv_pcb
    if ( recv_pcb.state is blocked_on_receive ) {
        set recv_pcb state to ready
        rpq enqueue( recv_pcb);
    atomic(off);
                      How to change this for a preemptive system?
    return RTX_OK;
```

It is a non-blocking call!

### IPC: receive\_message

```
void *receive_message(int *sender id) {
    atomic(on)
    while (current process's msg queue is empty) {
        set state of current_process to blocked_on_receive
        process switch
        *** return here when this process executes again
    env ← dequeued envelope from the process' message queue
    *sender_id ← get the sender ID info from the env
    atomic(off)
    return env
                     How to change this for a preemptive system?
```

It is a blocking call.

We also need a non-blocking version of it.

### IPC: Code Excerpt

- Check Section 6.3 of Lab manual for IPC FAQs
- Code excerpt of a user process to send a message (page 36 of the lab manual)

```
struct msgbuf *p_msg_env = (struct msgbuf *) request_memory_block();
p_msg_env->mtype = KCD_REG;
p_msg_env->mtext[0] = '%';
p_msg_env->mtext[1] = 'W';
p_msg_env->mtext[2] = '\0';
send_message(PID_KCD, (void *)p_msg_env);
```

#### **RTX** Initialization

- What operations need to be carried out at start-up?
- Initialize all hardware, incl.
  - Board system Initialization
  - Interrupts (hardware and software: vector table & traps )
  - Timer(s) and Serial port(s)
- Create all kernel data structures
  - Memory management kernel data structure
  - Process-control kernel data structure: PCB, kernel stacks
- Create PCBs of all processes
  - allocate stacks
  - privilege level setting using CONTROL register
  - Exception stack frame creation for new processes

#### Starter Code

- Use your existing P1
- Create a directory called P2
  - Copy existing P1/Context\_Switching Project to P2

```
P1
Context_Switching
P2
Context_Switching
README.md
```

#### References

- 1. Dasiewicz, Paul, A non-preemptive RTX Design Documentation
- 2. LPC17xx User's Manual
- 3. ARM Compilation Tools Version 5.0 Developer Guide
- 4. Software Interface Standard for Arm Cortex-based Microcontrollers, CMSIS Version 5.7.0

### Acknowledgement

#### Slides modified from

- P. Dasiewicz
- J.C. Petkovich

## Thank you!

Electrical and Computer Engineering Department