

# Wireless Communication with LoRa for the IoT



THE UNIVERSITY OF  
**WESTERN**  
AUSTRALIA

Rachel Cardell-Oliver

Guest Lecture

CITS5506 Internet of Things

# Three Things

- 
1. Wireless Communications
  2. LoRa
  3. Link Quality Experiments



# Wireless Communications

# Wireless Networks

- No cables to connect the network
- Communication uses radio waves
- Many technologies from WiFi to bespoke radios and protocols

# Signal propagation (in theory)

- ▶ Signal decreases with  $1/d^2$



# Signal Propagation in Practice




Fig. 4. Contour of PRR from a central node: anisotropy of link quality [Ganesan et al. 2002].

# The Grey Zone

Packet reception has a **transitional (grey) zone** where packet reception is hard to predict





Fig. 6. The PRR/SNR curve. For  $SNR$  greater than 8 dBm, the  $PRR$  is equal to 100%, and for  $SNR$  less than 1 dBm, the  $PRR$  is less than 25%. In between, a small variation in the  $SNR$  can cause a big difference in the  $PRR$ ; links are typically in the transitional region. Outdoor environment, using TelosB sensor motes and  $-25$  dBm as output power (using the RadiaLE testbed [Baccour et al. 2011]).

# Time varying link quality

Jingbo Sun PhD 2009



- Wireless links are dynamic and lossy
  - Time
  - Space
- Energy is limited for communication

# Communication Link Characteristics

1. Path Loss
2. Noise: probabilistic packet reception
3. Time varying link quality
4. Asymmetric links
5. Packet Collisions
6. Limited communication range (hidden terminal problem)

# Link Budget

- A simple link budget equation:

Received Power (dBm) =

Transmit Power (dBm) + Gains (dB) – Losses (dB)

- Note that decibels are logarithmic measurements, so adding decibels is equivalent to multiplying the actual numeric ratios.

# Plane Earth Path Loss Model

$$L_{PE}(dB) = 10n \log_{10}(d) - 20 \log_{10}(h_T) - 20 \log_{10}(h_R)$$


$n$  = 4 standard,  $n > 4$  foliage or buildings

$d$  = distance in meters

$h$  = height of transmitter and receiver antennas

LPE is independent of frequency

# Bushland LPE Model ( $n=4.45$ )




# Log distance model

- Constants B and n and reference distance  $d_0 = 1$  meter

$$L_{\text{log-distance}}(\text{dB}) = B + 10n \log_{10}\left(\frac{d}{d_0}\right)$$

# LoRa tx path loss observed



# Link Quality Metrics (1) PRR

How good is my wireless channel?

Packet Reception Rate = Rx/Tx

PRR Proportion of transmitted packets that are correctly received

Bit Error Rate (BER) Proportion of transmitted bits that are corrupted

++ Application-relevant result

-- Does not explain **why** the channel is good or not

++ Low BER can be addressed with error correcting codes

# Link Quality Metrics (2) RSSI

## Received Signal Strength Indicator

Defn Physical layer measurement of the signal quality at the receiver

- ++ Direct measure of channel quality
- Can be hardware and vendor specific
- Weakly correlated with PPR, so usually used with other metrics


# Link Quality Metrics (3) SNR

Signal to Noise Ratio (not actually a ratio)

Defn Difference in decibels between the received signal and background noise (noise floor)

- ++ Direct measure of channel quality
- Weakly correlated with PPR, so usually used with other metrics
- Quantifies how good/bad the channel is


# Signal to Noise Ratio



Source: [https://documentation.meraki.com/MR/WiFi\\_Basics\\_and\\_Best\\_Practices](https://documentation.meraki.com/MR/WiFi_Basics_and_Best_Practices)

# LoRa

[www.semtech.com/lora/why-lora](http://www.semtech.com/lora/why-lora)



# LoRa

- Spreads the signal over a wider frequency band
- This make LoRa resilient to jamming and interference
- LoRa proprietary PHY layer from Semtech
- You can fine tune performance by selecting from over 6000 parameter settings



# Which LoRa

- LoRa Physical Layer
  - Patented Technology by Semtech (2012)
  - Settable parameters to trade throughput with range
- LoRa MAC Layer = LoRaWAN
  - LoRa Alliance [lora-alliance.org](http://lora-alliance.org)
  - 500 companies, Standardisation of LoRaWAN
  - Open source
  - Eg. The Things Network: globally distributed, crowd sourced network

# Lora Physical Parameters

<b>Bandwidth (BW)</b>	Frequency range swept during a chirp. $\uparrow \text{BW} = \uparrow \text{Data Rate} \downarrow \text{Sensitivity} \downarrow \text{Energy Usage}$
<b>Coding Rate (CR)</b>	Inbuilt Forward Error Correction $\uparrow \text{CR} = \uparrow \text{Reliability} \uparrow \text{Energy Usage}$
<b>Spreading Factor (SF)</b>	Controls the chirp rate $\uparrow \text{SF} = \downarrow \text{Data Rate} \uparrow \text{Sensitivity} \uparrow \text{Energy Usage}$
<b>Transmission Power (TP)</b>	Power level the signal is transmitted in $\uparrow \text{TP} = \uparrow \text{Sensitivity} \uparrow \text{Energy Usage}$

# LoRa Carrier Frequencies

- 137 MHz, 433, 868 and 915 MHz (depends on country)
- Country regulations define useable channels
- For Australia: 433 and 915

# Transmission Power

- HW dependent, but typically -2 to 20 dBm
- Increasing Tx power increases energy use
- Increasing Tx power also increases range
- For Tx power > 17 dBm, hardware limitations and legal regulations limit duty cycle (<1%)

# Bandwidth

- LoRa bandwidth can be set to 125 kHz, 250 kHz or 500 kHz
- Also allowed 62.5 and others
- Higher bandwidth gives lower receiver sensitivity (so weaker pkt signal can be received)
- Higher bandwidth increases the data rate
- So increasing bandwidth reduces time on air and energy use

```
# Receiver sensitivity floor depends on bandwidth
if(BWidth==125):
    RSF={6:-121,7:-124,8:-127,9:-130,10:-133,11:-135,12:-137}
elif(BWidth==250):
    RSF={6:-118,7:-122,8:-125,9:-128,10:-130,11:-132,12:-135}
else: #500
    RSF={6:-111,7:-116,8:-119,9:-122,10:-125,11:-128,12:-129}
```


# Coding Rate

- Inbuilt Forward Error Correction
- For protection from bursts of interference
- Adds from 1..4 redundant bits
- Called SF 4/5, 4/6, 4/7 and 4/8
- Increasing CR provides protection against burst interference
- Increased CR increases the message length, so time on air and so energy use

# Spreading Factor

- Spreading factor values from 6 to 12
- Each symbol has  $2^{SF}$  chirps
- Bit rate depends on SF, BW and Coding rate
- Increase SF halves the tx rate, so increases (doubles) tx time and so energy use
- Channels with different SF are orthogonal, so can tx at the same time

# LoRa Parameter Choices



# LoRa Parameter Choice for Minimal Energy Usage

Ben Dix-Matthews, Rachel Cardell-Oliver  
Christof Huebner

University of Western Australia  
University of Applied Sciences Mannheim

RealWSN, Shenzhen, China  
November 2018



# Link Quality Experiments

# Link Quality Experiments






Fig. 6. LoRa coverage for different environments with PRR >70% and CR4/8. LoRa coverages are severely impacted on the east side of the map due to high density of buildings obstructing LoS.

Fig. 8. Steps for link quality estimation.

# Hardware

- ESP32 TTGO T-Beam
  - Low-cost, low power microcontroller
  - Wi-Fi, Bluetooth, GPS, LoRa Chip, USB Controller, Battery Operated



# <https://github.com/jordz3/LoRa-Lab>

## LoRa-Lab Set-Up Instructions

The aim of this lab is to explore the behaviour of wireless channels and LoRa physical parameters in an experimental setting using TTGO T-beams.

The software for this lab was developed as part of a UWA Master's of Professional Engineering (MPE) Thesis Project.

The software is a LoRa toolkit for creating and recreating experiments with simple configuration.

To setup an experimental LoRa parameter configuration to test, edit the `my_library.cpp` file as needed.

A screenshot of a web browser displaying a GitHub repository page. The URL in the address bar is [github.com/jordz3/LoRa-Lab](https://github.com/jordz3/LoRa-Lab). The repository name is **jordz3 / LoRa-Lab** (Public). The **Code** tab is selected. Below the tabs, it shows **main**, **1 branch**, and **0 tags**. The repository contains the following files and their actions:

File	Action
websense PDF of lecture slides introducing this lab	
Lab_Reports	rename
Lab_Tasks	Update README.md
LoRa_Tool	Push to Public Github
LoRa_ipynb	Update LoRa-Analysis.ipynb
Log_Files	Create README.md
My_Library	Push to Public Github
.gitignore	Create .gitignore
LICENSE	Create LICENSE
RCO-GuestLecture-6Oct2021.pdf	PDF of lecture slides introducing this lab
README.md	Update README.md

# Summary

1. Wireless Communications
2. LoRa
3. Link Quality Experiments

# Further Reading

- Radio link quality estimation in wireless sensor networks, Baccour et al, ToSN 8(4) 2012, doi: [10.1145/2240116.2240123](https://doi.org/10.1145/2240116.2240123)
- Known and Unknown Facts of LoRa, Liando et al, ToSN 15(2) 2019 doi: [10.1145/3293534](https://doi.org/10.1145/3293534)
- An Experimental Evaluation of the Reliability of LoRa Long-Range Low-Power Wireless Communication, Cattani et al, J Sensor and Actuator Networks 6(2) 2017, doi: [10.3390/jsan6020007](https://doi.org/10.3390/jsan6020007)
- LoRa from the City to the Mountains: Exploration of Hardware and Environmental Factors, Iova et al, Int. Conf. on Embedded Wireless Systems and Networks (EWSN), 2017. doi: [10.5555/3108009.3108091](https://doi.org/10.5555/3108009.3108091)