
# Principles of designing memory hierarchy and Caches


Slides adapted by: Dr Sparsh Mittal

#### **Examples of processor chip**




L1, L2, L3 cache => L1 is closest and L3 is farthest from core

### **Examples of processor chip**



Intel's 32nm Sandy Bridge Core i7-3960X 15MB L3 cache

# Why memory "hierarchy"?



# **Example of Memory Hierarchy**

Register File 32 words, sub-nsec

L1 cache ~32 KB, ~nsec

L2 cache 512 KB ~ 1MB, many nsec

L3 cache,

....

Main memory (DRAM), GB, ~100 nsec

> Disk 100 GB, ~10 msec

#### **Principle of Locality**

- Programs access a small proportion of their address space at any time
- Temporal locality
  - Items accessed recently are likely to be accessed again soon
  - e.g., instructions in a loop, induction variables
- Spatial locality
  - Items near those accessed recently are likely to be accessed soon
  - E.g., sequential instruction access, array data


### **Question on spatial locality**

- We have multiple numbers which can be stored in array or dynamic linked-list. If we access these numbers sequentially, which of the two data-structures gives higher spatial locality in memory?
- Answer: Array.

#### **Memory Technology**


- Static RAM (SRAM)
  - 0.5ns 2.5ns
- Dynamic RAM (DRAM)
  - 50ns 70ns
- Magnetic disk
  - 5ms 20ms
- Ideal memory
  - Access time of SRAM
  - Capacity and cost/GB of disk

#### **Memory Hierarchy Levels**



- Block (aka line): unit of copying
  - May be multiple words
- If accessed data is present in upper level
  - Hit: access satisfied by upper level
    - Hit ratio: hits/accesses
- If accessed data is absent
  - Miss: block copied from lower level
    - Time taken: miss penalty
    - Miss ratio: misses/accesses
      - = 1 hit ratio
  - Then accessed data supplied from upper level


### Why memory "hierarchy"?



Main memory Latency = 1us Assume 1 million requests

Total time = 1 million \* 1us = 1 sec


#### Why memory hierarchy



L1\$ Lat = 1ns


Main memory Lat = 1us

#### Assume 1 million requests



With increasing hit-rate, total access time approaches that of L1\$

## Why memory hierarchy



It appears to be a memory

- As fast as L1 cache
- As large as main memory

Approaches the characteristic of Ideal memory

#### **Cache Misses**

- On cache hit, CPU proceeds normally
- On cache miss
  - Stall the CPU pipeline
  - Fetch block from next level of hierarchy
  - Instruction cache miss
    - Restart instruction fetch
  - Data cache miss
    - Complete data access

#### Cache Performance Example

#### Given

- I-cache miss rate = 2%
- D-cache miss rate = 4%
- Miss penalty = 100 cycles
- Base CPI (ideal cache) = 2
- Load & stores are 36% of instructions
- Miss cycles per instruction
  - I-cache:  $0.02 \times 100 = 2$
  - D-cache:  $0.36 \times 0.04 \times 100 = 1.44$
- Actual CPI = 2 + 2 + 1.44 = 5.44
  - Ideal CPU is 5.44/2 =2.72 times faster

# **Multilevel Caches**

#### **Multilevel Caches**

- Primary cache attached to CPU
  - Small, but fast
- Level-2 cache services misses from primary cache
  - Larger, slower, but still faster than main memory
- Main memory services L-2 cache misses
- Some systems include L-3 and L-4 cache

#### Multilevel Cache Example

- Given
  - CPU base CPI = 1, clock rate = 4GHz
  - Miss rate/instruction = 2%
  - Main memory access time = 100ns
- With just primary cache
  - Miss penalty = 100ns/0.25ns = 400 cycles
  - Effective CPI =  $1 + 0.02 \times 400 = 9$

#### **Example (cont.)**


- Now add L-2 cache
  - Access time = 5ns
  - Global miss rate to main memory = 0.5%
- Primary miss with L-2 hit
  - Penalty = 5ns/0.25ns = 20 cycles
- Primary miss with L-2 miss
  - Extra penalty = 400 cycles
- $\blacksquare$  CPI = 1 + 0.02 × 20 + 0.005 × 400 = **3.4**
- Performance ratio = 9/3.4 = 2.6

#### **Multilevel Cache Considerations**

- Primary cache
  - Focus on minimal hit time
- L-2 cache
  - Focus on low miss rate to avoid main memory access
  - Hit time has less overall impact
- Results
  - L-1 block size smaller than L-2 block size

#### Tags and Valid Bits

- How do we know which particular block is stored in a cache location?
  - Store block address as well as the data
  - We only need the high-order bits called tag




- What if there is no data in a location?
  - Valid bit: 1 = present, 0 = not present
  - Initially 0

# Cache organization: associativity

#### An example: bookshelf

- Assume I have a bookshelf with N spaces
- I can organize it differently
- Organization 1: Keep a book anywhere



- Plus: ease of arranging
- Minus: more time in retrieving (searching)

- Organization 2: Make two partitions
- Partition 1: research books
- Parition 2: teaching books



- Plus: time required for searching reduced
- Minus: >N/2 research books cannot fit

- Organization 3: Make N partitions
- A book can go to only one space, belonging to its topic.

- Plus: time required for searching constant
- Minus: >1 book on any topic cannot fit

#### **Spectrum of Associativity**

- Direct-mapped (1 way, k-sets)
- Set-associative (m way, k/m sets)
- Fully-associative (1 set, k-way)

### **Spectrum of Associativity**

#### For a cache with 8 entries

#### One-way set associative (direct mapped)

Block	Tag	Data
0		
1		
2		
3		
4		
5		
6		
7		

#### Two-way set associative

Set	Tag	Data	Tag	Data
0				
1				
2				
3				


#### Four-way set associative

Set	Tag	Data	Tag	Data	Tag	Data	Tag	Data
0								
1								

#### **Eight-way set associative (fully associative)**

Tag	Data														

# **Associative Cache Example**



#### Cache organization


- Cache size
- = (# of blocks) \* (block size)
- = (# of sets) \* (# of ways) \* (block size)

Example: block size = 64B, # of ways =16, cache size = 4MB

=> # of sets = 4096

#### **Direct Mapped Cache**

- Location determined by address
- Direct mapped: only one choice
  - (Block address) modulo (#Blocks in cache)




- #Blocks is a power of 2
- Use low-order address bits


#### **Associative Caches**

- Fully associative
  - Allow a given block to go in any cache entry
  - Requires all entries to be searched at once
  - 1 Comparator per entry (expensive)
- n-way set associative
  - Each set contains n entries
  - Block number determines which set
    - (Block number) modulo (#Sets in cache)
  - Search all entries in a given set at once
  - n comparators (less expensive)

#### **Direct-mapped Cache**



#### **Set Associative Cache**



#### **Associativity Example**

- Compare 4-block caches
  - Direct mapped, 2-way set associative, fully associative
  - Block access sequence: 0, 8, 0, 6, 8
- Direct mapped

Block	Cache	Hit/miss	Cache content after access						
address	index		0	1	2	3			
0	0	miss	Mem[0]						
8	0	miss	Mem[8]						
0	0	miss	Mem[0]						
6	2	miss	Mem[0]		Mem[6]				
8	0	miss	Mem[8]		Mem[6]				

#### **Associativity Example**

#### 2-way set associative

Block	Cache	Hit/miss	(	nt after access	
address	index		Se	et O	Set 1
0	0	miss	Mem[0]		
8	0	miss	Mem[0]	Mem[8]	
0	0	hit	Mem[0]	Mem[8]	
6	0	miss	Mem[0]	Mem[6]	
8	0	miss	Mem[8]	Mem[6]	

#### Fully associative

Block	Hit/miss	Cache content after access					
address							
0	miss	Mem[0]					
8	miss	Mem[0]	Mem[8]				
0	hit	Mem[0]	Mem[8]				
6	miss	Mem[0]	Mem[8]	Mem[6]			
8	hit	Mem[0]	Mem[8]	Mem[6]			

#### **How Much Associativity**

- Increased associativity decreases miss rate
  - But with diminishing returns
- Simulation of a system with 64KB
  D-cache, 16-word blocks, SPEC2000

1-way: 10.3%


2-way: 8.6%

4-way: 8.3%

8-way: 8.1%

#### **Example of cache parameters**

- Direct-mapped, write-back, write allocate
- Block size: 4 words (16 bytes)
- Cache size: 16 KB (1024 blocks)
- 32-bit byte addresses
- Valid bit and dirty bit per block
- Blocking cache
  - CPU waits until access is complete



#### **Basic Cache Operations**

- lookup → Check if the memory location is present
- data read → read data from the cache
- data write → write data to the cache
- insert → insert a block into a cache
- replace → find a candidate for replacement
- evict → throw a block out of the cache

#### **Definitions**

local miss rate

It is equal to the number of misses in a cache at level *i* divided by the total number of accesses at level *i*.

global miss rate

It is equal to the number of misses in a cache at level *i* divided by the total number of memory accesses.

working set

The amount of memory, a given program requires in a time interval.

#### Types of Misses

#### Compulsory Misses

 Misses that happen when we read in a piece of data for the first time.

#### Conflict Misses

• Misses that occur due to the limited amount of associativity in a set associative or direct mapped cache. Example: Assume that 5 blocks (accessed by the program) map to the same set in a 4-way associative cache. Only 4 out of 5 can be accommodated.

#### Capacity Misses

Misses that occur due to the limited size of a cache.
 Example: Assume the working set of a program is 10 KB, and the cache size is 8 KB.


#### Mitigating Compulsory Misses

- Increase the block size. We can bring in more data in one go, and due to spatial locality the number of misses might go down.
- Try to guess the memory locations that will be accessed in the near future. Prefetch (fetch in advance) those locations. We can do this for example in the case of array accesses.

#### Mitigating Conflict Misses

- Increase the associativity of the cache (at the cost of latency and power)
- We can use a smaller fully associative cache called the *victim cache*. Any line that gets displaced from the main cache can be put in the victim cache. The processor needs to check both the L1 and victim cache, before proceeding to the L2 cache.
- Write programs in a cache friendly way.

#### Victim Cache



#### Mitigating Capacity Misses

Increase the size of the cache

# Understanding working of cache with an example

- 8-blocks, 1 word/block, direct mapped
- Initial state

Index	V	Tag	Data
000	N		
001	N		
010	N		
011	N		
100	N		
101	N		
110	N		
111	N		

Word addr	Binary addr	Hit/miss	Cache block
22	10 110	Miss	110

Index	V	Tag	Data
000	N		
001	N		
010	N		
011	N		
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		

Word addr	Binary addr	Hit/miss	Cache block
26	11 010	Miss	010

Index	V	Tag	Data
000	N		
001	N		
010	Υ	11	Mem[11010]
011	N		
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		

Word addr	Binary addr	Hit/miss	Cache block
22	10 110	Hit	110
26	11 010	Hit	010

Index	V	Tag	Data
000	N		
001	N		
010	Υ	11	Mem[11010]
011	N		
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		

Word addr	Binary addr	Hit/miss	Cache block
16	10 000	Miss	000
3	00 011	Miss	011
16	10 000	Hit	000

Index	V	Tag	Data
000	Y	10	Mem[10000]
001	N		
010	Υ	11	Mem[11010]
011	Y	00	Mem[00011]
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		

Word addr	Binary addr	Hit/miss	Cache block
18	10 010	Miss	010

Index	V	Tag	Data
000	Υ	10	Mem[10000]
001	N		
010	Υ	10	Mem[10010]
011	Υ	00	Mem[00011]
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		

# Cache write hit policies

#### 1. Write-Through

- On data-write hit, could just update the block in cache
  - But then cache and memory would be inconsistent
- Write through: also update memory
- But makes writes take longer
  - e.g., if base CPI = 1, 10% of instructions are stores,
    write to memory takes 100 cycles
    - Effective CPI =  $1 + 0.1 \times 100 = 11$
- Solution: write buffer
  - Holds data waiting to be written to memory
  - CPU continues immediately
    - Only stalls on write if write buffer is already full

#### 2. Write-Back

- On data-write hit, just update the block in cache
  - Keep track of whether each block is dirty
- When a dirty block is replaced
  - Write it back to memory
  - Can use a write buffer to allow replacing block to be read first

#### **Summary of Write Policies**

- Write-through
  - Update both upper and lower levels
  - Simplifies replacement, but may require write buffer
- Write-back
  - Update upper level only
  - Update lower level when block is replaced
  - Need to keep more state

# Cache replacement policies

#### Replacement Policy

- Direct mapped: no choice
- Set associative
  - Prefer non-valid entry, if there is one
  - Otherwise, choose among entries in the set
- Least-recently used (LRU)
  - Choose the one unused for the longest time
    - Simple for 2-way, manageable for 4-way, too hard beyond that
- Random
  - Gives approximately the same performance as LRU for high associativity

#### **Cache Design Trade-offs**

Design change	Effect on miss rate	Negative performance effect
Increase cache size	Decrease capacity misses	May increase access time
Increase associativity	Decrease conflict misses	May increase access time
Increase block size	Decrease compulsory misses	Increases miss penalty. For very large block size, may increase miss rate due to pollution.

#### 3-Level Cache Organization

	Intel Nehalem	AMD Opteron X4
L1 caches (per core)	L1 I-cache: 32KB, 64-byte blocks, 4-way, approx LRU replacement, hit time n/a L1 D-cache: 32KB, 64-byte blocks, 8-way, approx LRU replacement, write-back/allocate, hit time n/a	L1 I-cache: 32KB, 64-byte blocks, 2-way, LRU replacement, hit time 3 cycles L1 D-cache: 32KB, 64-byte blocks, 2-way, LRU replacement, write-back/allocate, hit time 9 cycles
L2 unified cache (per core)	256KB, 64-byte blocks, 8-way, approx LRU replacement, write-back/allocate, hit time n/a	512KB, 64-byte blocks, 16-way, approx LRU replacement, write-back/allocate, hit time n/a
L3 unified cache (shared)	8MB, 64-byte blocks, 16-way, replacement n/a, write-back/allocate, hit time n/a	2MB, 64-byte blocks, 32-way, replace block shared by fewest cores, write-back/allocate, hit time 32 cycles

n/a: data not available