CISC versus RISC

CISC RISC

Emphasis on hardware

Includes multi-clock complex instructions

Memory-to-memory:
"LOAD" and "STORE"
incorporated in instructions

Small code sizes, high cycles per second

Transistors used for storing complex instructions

Emphasis on software

Single-clock, reduced instruction only

Register to register:

"LOAD" and "STORE"

are independent instructions


Low cycles per second, large code sizes

Spends more transistors on memory registers


Microprocessor and microcontroller

- Micro Controller
 - It is a single chip
 Consists Memory,
 I/o ports


- Micro Processor
 - It is a CPU
 - Memory, I/O Ports to be connected externally



Computers Design: Hybrid Technologies



Computers: Developm't Process/Managem't Perspectives



Micro-architectures

Topics

- Introduction
- Assembly Language
- Machine Language
- Programming
- Addressing Modes

ARCHITECTURE A QUANTITATIVE A P P R O A C H



DAVID A PATTERSON

Introduction

- Jumping up a few levels of abstraction.
- Architecture: the programmer's view of the computer
 - Defined by instructions (operations) and operand locations
- Microarchitecture: how to implement an architecture in hardware

Application Software	programs
Operating Systems	device drivers
Architecture	instructions registers
Micro- architecture	datapaths controllers
Logic	adders memories
Digital Circuits	AND gates NOT gates
Analog Circuits	amplifiers filters
Devices	transistors diodes
Physics	electrons

John Hennessy

- President of Stanford University
- Professor of Electrical Engineering and Computer Science at Stanford since 1977
- Coinvented the Reduced Instruction Set Computer (RISC)
- Developed the MIPS architecture at Stanford in 1984 and cofounded MIPS Computer Systems
- As of 2004, over 300 million MIPS microprocessors have been sold



Architecture Design Principles

Underlying design principles, as articulated by Hennessy and Patterson:

- 1. Simplicity favors regularity
- 2. Make the common case fast
- 3. Smaller is faster
- 4. Good design demands good compromises

Instructions: Addition

High-level code

$$a = b + c;$$

MIPS assembly code

add a, b, c

- add: mnemonic indicates what operation to perform
- b, c: source operands on which the operation is performed
- a: destination operand to which the result is written

Instructions: Subtraction

• Subtraction is similar to addition. Only the mnemonic changes.

High-level code

$$a = b - c;$$

MIPS assembly code

sub a, b, c

- sub: mnemonic indicates what operation to perform
- b, c: source operands on which the operation is performed
- a: destination operand to which the result is written

Design Principle 1

Simplicity favors regularity

- Consistent instruction format
- Same number of operands (two sources and one destination)
 - easier to encode and handle in hardware

Instructions: More Complex Code

• More complex code is handled by multiple MIPS instructions.

High-level code

```
a = b + c - d;
// single line comment
/* multiple line
  comment */
```

MIPS assembly code

```
add t, b, c \# t = b + c sub a, t, d \# a = t - d
```

Design Principle 2

Make the common case fast

- MIPS includes only simple, commonly used instructions.
- Hardware to decode and execute the instruction can be simple, small, and fast.
- More complex instructions (that are less common) can be performed using multiple simple instructions.
- MIPS is a *reduced instruction set computer* (RISC), with a small number of simple instructions.
- Other architectures, such as Intel's IA-32 found in many PC's, are *complex instruction set computers* (CISC). They include complex instructions that are rarely used, such as the "string move" instruction that copies a string (a series of characters) from one part of memory to another.

Operands

- A computer needs a physical location from which to retrieve binary operands
- A computer retrieves operands from:
 - Registers
 - Memory
 - Constants (also called *immediates*)

Operands: Registers

- Memory is slow.
- Most architectures have a small set of (fast) registers.
- MIPS has thirty-two 32-bit registers.
- MIPS is called a 32-bit architecture because it operates on 32-bit data.

(A 64-bit version of MIPS also exists, but we will consider only the 32-bit version.)

Design Principle 3

Smaller is Faster

- MIPS includes only a small number of registers
- Just as retrieving data from a few books on your table is faster than sorting through 1000 books, retrieving data from 32 registers is faster than retrieving it from 1000 registers or a large memory.

The MIPS Register Set

Name	Register Number	Usage
\$0	0	the constant value 0
\$at	1	assembler temporary
\$v0-\$v1	2-3	procedure return values
\$a0 - \$a3	4-7	procedure arguments
\$t0-\$t7	8-15	temporaries
\$s0 - \$s7	16-23	saved variables
\$t8 - \$t9	24-25	more temporaries
\$k0-\$k1	26-27	OS temporaries
\$gp	28	global pointer
\$sp	29	stack pointer
\$fp	30	frame pointer
\$ra	31	procedure return address

Operands: Registers

- Registers:
 - Written with a dollar sign (\$) before their name
 - For example, register 0 is written "\$0", pronounced "register zero" or "dollar zero".
- Certain registers used for specific purposes:
 - For example,
 - \$0 always holds the constant value 0.
 - the *saved registers*, \$s0-\$s7, are used to hold variables
 - the *temporary registers*, \$t0 \$t9, are used to hold intermediate values during a larger computation.
- For now, we only use the temporary registers (\$t0 \$t9) and the saved registers (\$s0 \$s7).
- We will use the other registers in later slides.

Instructions with registers

• Revisit add instruction

High-level code

$$a = b + c$$

MIPS assembly code

```
\# $s0 = a, $s1 = b, $s2 = c add $s0, $s1, $s2
```

Operands: Memory

- Too much data to fit in only 32 registers
- Store more data in memory
- Memory is large, so it can hold a lot of data
- But it's also slow
- Commonly used variables kept in registers
- Using a combination of registers and memory, a program can access a large amount of data fairly quickly

Word-Addressable Memory

• Each 32-bit data word has a unique address

Word Address				Da	ta				
•				•					•
•				•					•
•				•					•
0000003	4	0	F	3	0	7	8	8	Word 3
0000002	0	1	Е	Ε	2	8	4	2	Word 2
0000001	F	2	F	1	Α	С	0	7	Word 1
00000000	Α	В	С	D	Ε	F	7	8	Word 0

Reading Word-Addressable Memory

- Memory reads are called *loads*
- Mnemonic: *load word* (lw)
- Example: read a word of data at memory address 1 into \$s3
- Memory address calculation:
 - add the *base address* (\$0) to the *offset* (1)
 - address = (\$0 + 1) = 1
- Any register may be used to store the base address.
- \$s3 holds the value 0xF2F1AC07 after the instruction completes.

Assembly code

lw \$s3, 1(\$0) # read memory word 1 into \$s3

Data		
•	•	
•		•
•		•
4 0 F 3 0 7	8 8	Word 3
0 1 E E 2 8	4 2	Word 2
F 2 F 1 A C	0 7	Word 1
ABCDEF	7 8	Word 0
	: 4 0 F 3 0 7 0 1 E E 2 8 F 2 F 1 A C	Data : 4 0 F 3 0 7 8 8 0 1 E E 2 8 4 2 F 2 F 1 A C 0 7 A B C D E F 7 8

Writing Word-Addressable Memory

- Memory writes are called *stores*
- Mnemonic: *store word* (sw)
- **Example:** Write (store) the value held in \$\pm 4\$ into memory address 7
- Offset can be written in decimal (default) or hexadecimal
- Memory address calculation:
 - add the base address (\$0) to the offset (0x7)
 - address: (\$0 + 0x7) = 7
- Any register may be used to store the base address


Assembly code

```
sw $t4, 0x7($0) # write the value in $t4 # to memory word 7
```

Word Address				Da	ta					
•	. •							•		
•	•							•		
•				•					•	
0000003	4	0	F	3	0	7	8	8	Word 3	
00000002	0	1	Ε	Ε	2	8	4	2	Word 2	
00000001	F	2	F	1	Α	С	0	7	Word 1	
00000000	Α	В	С	D	Ε	F	7	8	Word 0	

Byte-Addressable Memory

- Each data byte has a unique address
- Load/store words or single bytes: load byte (1b) and store byte (sb)
- Each 32-bit words has 4 bytes, so the word address increments by 4




Reading Byte-Addressable Memory

- The address of a memory word must now be multiplied by 4. For example,
 - the address of memory word 2 is $2 \times 4 = 8$
 - the address of memory word 10 is $10 \times 4 = 40 \text{ (0x28)}$
- Load a word of data at memory address 4 into \$s3.
- \$s3 holds the value 0xF2F1AC07 after the instruction completes.
- MIPS is byte-addressed, not word-addressed

MIPS assembly code

lw \$s3, 4(\$0) # read word at address 4 into \$s3




Writing Byte-Addressable Memory

• **Example:** stores the value held in \$\pm 7\$ into memory address 0x2C (44)


MIPS assembly code

```
sw $t7, 44($0) # write $t7 into address 44
```



Big-Endian and Little-Endian Memory

- How to number bytes within a word?
- Word address is the same for big- or little-endian
- Little-endian: byte numbers start at the little (least significant) end
- Big-endian: byte numbers start at the big (most significant) end



Big- and Little-Endian Example

• Suppose \$\pmu0\$ initially contains 0x23456789. After the following program is run on a big-endian system, what value does \$\pmu0\$ contain? In a little-endian system?

```
sw $t0, 0($0)
lb $s0, 1($0)
```

Big- and Little-Endian Example

• Suppose \$\pmu0\$ initially contains 0x23456789. After the following program is run on a big-endian system, what value does \$\pmu0\$ contain? In a little-endian system?

sw
$$$t0, 0($0)$$

lb $$s0, 1($0)$

- Big-endian: 0x00000045
- Little-endian: 0x00000067



Design Principle 4

Good design demands good compromises

- Multiple instruction formats allow flexibility
 - add, sub: use 3 register operands
 - lw, sw: use 2 register operands and a constant
- Number of instruction formats kept small
 - to adhere to design principles 1 and 3 (simplicity favors regularity and smaller is faster).

Operands: Constants/Immediates

- lw and sw illustrate the use of constants or *immediates*
- Called immediates because they are *immediate*ly available from the instruction
- Immediates don't require a register or memory access.
- The add immediate (addi) instruction adds an immediate to a variable (held in a register).
- An immediate is a 16-bit two's complement number.
- Is subtract immediate (subi) necessary?

High-level code

$$a = a + 4;$$

 $b = a - 12;$

MIPS assembly code

$$$s0 = a$$
, $$s1 = b$ addi $$s0$, $$s0$, 4 addi $$s1$, $$s0$, -12

Machine Language

- Computers only understand 1's and 0's
- Machine language: binary representation of instructions
- 32-bit instructions
 - Again, simplicity favors regularity: 32-bit data and instructions
- Three instruction formats:
 - R-Type: register operands
 - I-Type: immediate operand
 - J-Type: for jumping

R-Type

- Register-type
- 3 register operands:

- rs, rt: source registers

- rd: destination register

- Other fields:
 - op: the *operation code* or *opcode* (0 for R-type instructions)
 - funct: the function
 together, the opcode and function tell the computer
 what operation to perform
 - shamt: the *shift amount* for shift instructions, otherwise it's 0

R-Type

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

R-Type Examples

Assembly Code

add \$s0, \$s1, \$s2 sub \$t0, \$t3, \$t5

Field Values

ор	rs	rt	rd	shamt	funct
0	17	18	16	0	32
0	11	13	8	0	34
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

Machine Code

ор	rs	rt	rd	shamt	funct	
000000	10001	10010	10000	00000	100000	(0x02328020)
000000	01011	01101	01000	00000	100010	(0x016D4022)
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits	

Note the order of registers in the assembly code:

I-Type

- Immediate-type
- 3 operands:
 - rs, rt: register operands
 - imm: 16-bit two's complement immediate
- Other fields:
 - op: the opcode
 - Simplicity favors regularity: all instructions have opcode
 - Operation is completely determined by the opcode

I-Type

op	rs	rt	imm
6 bits	5 bits	5 bits	16 bits

I-Type Examples

Assembly Code

addi \$s0, \$s1, 5 addi \$t0, \$s3, -12 lw \$t2, 32(\$0) sw \$s1, 4(\$t1)

Field Values

	ор	rs	rt	imm
	8	17	16	5
2	8	19	8	-12
	35	0	10	32
	43	9	17	4
	6 bits	5 bits	5 bits	16 bits

Note the differing order of registers in the assembly and machine codes:

Machine Code

ор	rs	rt	imm	
001000	10001	10000	0000 0000 0000 0101	(0x22300005)
001000	10011	01000	1111 1111 1111 0100	(0x2268FFF4)
100011	00000	01010	0000 0000 0010 0000	(0x8C0A0020)
101011	01001	10001	0000 0000 0000 0100	(0xAD310004)
6 bits	5 bits	5 bits	16 bits	

Machine Language: J-Type

- Jump-type
- 26-bit address operand (addr)
- Used for jump instructions (j)

J-Type

op	addr
6 bits	26 bits

Review: Instruction Formats

R-Type

op	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

I-Type

op	rs	rt	imm
6 bits	5 bits	5 bits	16 bits

J-Type

op	addr
6 bits	26 bits


The Power of the Stored Program

- 32-bit instructions and data stored in memory
- Sequence of instructions: only difference between two applications (for example, a text editor and a video game)
- To run a new program:
 - No rewiring required
 - Simply store new program in memory
- The processor hardware executes the program:
 - fetches (reads) the instructions from memory in sequence
 - performs the specified operation
- The program counter (PC) keeps track of the current instruction
- In MIPS, programs typically start at memory address 0x00400000

The Stored Program


As	sembl	y Code	Machine Code
lw	\$t2,	32(\$0)	0x8C0A0020
add	\$s0,	\$s1, \$s2	0x02328020
addi	\$t0,	\$s3, -12	0x2268FFF4
sub	\$t0,	\$t3, \$t5	0x016D4022

Stored Program



Interpreting Machine Language Code

- Start with opcode
- Opcode tells how to parse the remaining bits
- If opcode is all 0's
 - R-type instruction
 - Function bits tell what instruction it is
- Otherwise
 - opcode tells what instruction it is



Programming

- High-level languages:
 - e.g., C, Java, Python
 - Written at more abstract level
- Common high-level software constructs:
 - if/else statements
 - for loops
 - while loops
 - array accesses
 - procedure calls
- Other useful instructions:
 - Arithmetic/logical instructions
 - Branching

Logical Instructions

- and, or, xor, nor
 - and: useful for masking bits
 - Masking all but the least significant byte of a value: 0xF234012F AND 0x000000FF = 0x0000002F
 - or: useful for combining bit fields
 - Combine 0xF2340000 with 0x000012BC: 0xF2340000 OR 0x000012BC = 0xF23412BC
 - nor: useful for inverting bits:
 - A NOR \$0 = NOT A
- andi, ori, xori
 - 16-bit immediate is zero-extended (not sign-extended)
 - nori not needed

Source Registers

\$ s1	1111	1111	1111	1111	0000	0000	0000	0000
\$ s2	0100	0110	1010	0001	1111	0000	1011	0111

Assembly Code

and \$s3, \$s1, \$s2 or \$s4, \$s1, \$s2 xor \$s5, \$s1, \$s2 nor \$s6, \$s1, \$s2

Result

\$ s3				
\$ s4				
\$ s5				
\$ s6				

Source Registers

\$ s1	1111	1111	1111	1111	0000	0000	0000	0000
\$ s2	0100	0110	1010	0001	1111	0000	1011	0111

Assembly Code

and	\$s3,	\$s1,	\$s2
or	\$s4,	\$s1,	\$s2
xor	\$s5,	\$s1,	\$s2
nor	\$s6,	\$s1,	\$s2

Result

\$ s3	0100	0110	1010	0001	0000	0000	0000	0000
\$ s4	1111	1111	1111	1111	1111	0000	1011	0111
\$ s5	1011	1001	0101	1110	1111	0000	1011	0111
\$ s6	0000	0000	0000	0000	0000	1111	0100	1000

Source Values

				\$ s1	0000	0000	0000	0000	0000	0000	1111	1111
				imm	0000	0000	0000	0000	1111	1010	0011	0100
					▼	zero-ex	ktended			<u>'</u>		
Α	ssemb	ly Code	Э					Resu	ult			
andi	\$s2,	\$s1,	0xFA34	\$ s2								
ori	\$s3,	\$s1,	0xFA34	\$ s3								
xori	\$s4,	\$s1,	0xFA34	\$ s4								

Source Values

\$ s1	0000	0000	0000	0000	0000	0000	1111	1111
imm	0000	0000	0000	0000	1111	1010	0011	0100
	•	zero-ex	ktended					

Assembly Code

Result

andi	\$s2,	\$s1,	0xFA34	\$ s2	0000	0000	0000	0000	0000	0000	0011	0100
ori	\$s3,	\$s1,	0xFA34	\$ s3	0000	0000	0000	0000	1111	1010	1111	1111
xori	\$s4,	\$s1,	0xFA34	\$ s4	0000	0000	0000	0000	1111	1010	1100	1011

Shift Instructions

- sll: shift left logical
 - Example: sll \$t0, \$t1, 5 # \$t0 <= \$t1 << 5</pre>
- srl: shift right logical
 - Example: srl \$t0, \$t1, 5 # \$t0 <= \$t1 >> 5
- sra: shift right arithmetic
 - Example: sra \$t0, \$t1, 5 # \$t0 <= \$t1 >>> 5

Variable shift instructions:

- sllv: shift left logical variable
 - Example: sllv \$t0, \$t1, \$t2 # \$t0 <= \$t1 << \$t2</pre>
- srlv: shift right logical variable
 - Example: srlv \$t0, \$t1, \$t2 # \$t0 <= \$t1 >> \$t2
- srav: shift right arithmetic variable
 - Example: srav \$t0, \$t1, \$t2 # \$t0 <= \$t1 >>> \$t2

Shift Instructions

Assembly Code

Field Values

sll	\$t0,	\$s1,	2
srl	\$s2,	\$s1,	2
sra	\$s3,	\$s1,	2

ор		rs	rt	rd	shamt	funct
	0	0	17	8	2	0
	0	0	17	18	2	2
	0	0	17	19	2	3
6 bi	ts	5 bits	5 bits	5 bits	5 bits	6 bits

Machine Code

	ор	rs	rt	rd	shamt	funct	
	000000	00000	10001	01000	00010	000000	(0x00114080)
	000000	00000	10001	10010	00010	000010	(0x00119082)
	000000	00000	10001	10011	00010	000011	(0x00119883)
٠	6 bits	5 bits	5 bits	5 bits	5 bits	6 bits	

Generating Constants

16-bit constants using addi:

High-level code

```
// int is a 32-bit signed word # $s0 = a int a = 0x4f3c; addi $s0,
```

MIPS assembly code

```
# $s0 = a addi $s0, $0, 0x4f3c
```

• 32-bit constants using load upper immediate (lui) and ori: (lui loads the 16-bit immediate into the upper half of the register and sets the lower half to 0.)

High-level code

```
int a = 0xFEDC8765;
```

Multiplication, Division

- Special registers: lo, hi
- 32×32 multiplication, 64 bit result
 - mult \$s0, \$s1
 - Result in {hi, lo}
- 32-bit division, 32-bit quotient, 32-bit remainder
 - div \$s0, \$s1
 - Quotient in 10
 - Remainder in hi
- Moves from lo/hi special registers
 - mflo \$s2
 - mfhi \$s3


Branching

- Allows a program to execute instructions out of sequence.
- Types of branches:
 - Conditional branches
 - branch if equal (beq)
 - branch if not equal (bne)
 - Unconditional branches
 - jump (j)
 - jump register (jr)
 - jump and link (jal)

Review: The Stored Program

As	ssembl	Machine Code		
lw	\$t2,	32 (\$0))	0x8C0A0020
add	\$s0,	\$s1,	\$s2	0x02328020
addi	\$t0,	\$s3,	-12	0x2268FFF4
sub	\$t0,	\$t3,	\$t5	0x016D4022

Stored Program



Conditional Branching (beq)

MIPS assembly

```
addi $s0, $0, 4  # $s0 = 0 + 4 = 4 addi $s1, $0, 1  # $s1 = 0 + 1 = 1 s11 $s1, $s1, 2  # $s1 = 1 << 2 = 4 beq $s0, $s1, target # branch is taken addi $s1, $s1, 1  # not executed sub $s1, $s1, $s0  # not executed target:

add $s1, $s1, $s0  # $s1 = 4 + 4 = 8
```

Labels indicate instruction locations in a program. They cannot use reserved words and must be followed by a colon (:).

The Branch Not Taken (bne)

MIPS assembly

add

```
$s0, $0, 4
 addi
                               \# \$\$0 = 0 + 4 = 4
           $s1, $0, 1
                               \# \$s1 = 0 + 1 = 1
 addi
 sll
           $s1, $s1, 2
                               \# $s1 = 1 << 2 = 4
                               # branch not taken
           $s0, $s1, target
 bne
 addi
           $s1, $s1, 1
                               \# \$s1 = 4 + 1 = 5
 sub
           $s1, $s1, $s0
                               # \$s1 = 5 - 4 = 1
target:
```

\$s1 = 1 + 4 = 5

\$s1, \$s1, \$s0

Unconditional Branching / Jumping (j)

MIPS assembly

Unconditional Branching (jr)

```
# MIPS assembly
```

 0×00002010

```
0x00002000 addi $s0, $0, 0x2010
0x00002004 jr $s0
0x00002008 addi $s1, $0, 1
0x0000200C sra $s1, $s1, 2
```

lw \$s3, 44(\$s1)

High-Level Code Constructs

- if statements
- if/else statements
- while loops
- for loops

If Statement

High-level code

```
# $s0 = f, $s1 = g, $s2 = h
# $s3 = i, $s4 = j
```

If Statement

High-level code

$$f = f - i;$$

MIPS assembly code

```
# $s0 = f, $s1 = g, $s2 = h
# $s3 = i, $s4 = j
bne $s3, $s4, L1
add $s0, $s1, $s2
```

L1: sub \$s0, \$s0, \$s3

Notice that the assembly tests for the opposite case (i != j) than the test in the high-level code (i == j).

If / Else Statement

High-level code

```
if (i == j)
  f = g + h;
else
  f = f - i;
```

```
# $s0 = f, $s1 = g, $s2 = h
# $s3 = i, $s4 = j
```

If / Else Statement

High-level code

```
if (i == j)
  f = g + h;
else
  f = f - i;
```

While Loops

High-level code

```
// determines the power \# \$s0 = pow, \$s1 = x
// of x such that 2^{x} = 128
int pow = 1;
int x = 0;
while (pow != 128) {
 pow = pow * 2;
 x = x + 1;
```

While Loops

High-level code

```
// determines the power \# \$s0 = pow, \$s1 = x
// of x such that 2^x = 128
int pow = 1;
int x = 0;
 pow = pow * 2;
 x = x + 1;
```

MIPS assembly code

```
addi $s0, $0, 1
                                  add $s1, $0, $0
                                  addi $t0, $0, 128
while (pow != 128) { while: beq $s0, $t0, done
                                  sll $s0, $s0, 1
                                  addi $s1, $s1, 1
                                  i while
                            done:
```

Notice that the assembly tests for the opposite case (pow == 128) than the test in the high-level code (pow! = 128).

For Loops

The general form of a for loop is:

```
for (initialization; condition; loop operation) loop body
```

- initialization: executes before the loop begins
- condition: is tested at the beginning of each iteration
- loop operation: executes at the end of each iteration
- loop body: executes each time the condition is met

For Loops

High-level code

```
// add the numbers from 0 to 9 \# $s0 = i, $s1 = sum
int sum = 0;
int i;
for (i=0; i!=10; i = i+1) {
 sum = sum + i;
```

For Loops

High-level code

```
// add the numbers from 0 to 9
int sum = 0;
int i;

for (i=0; i!=10; i = i+1) {
   sum = sum + i;
}
```

MIPS assembly code

Notice that the assembly tests for the opposite case (i == 128) than the test in the high-level code (i != 10).

Less Than Comparisons

High-level code

```
// add the powers of 2 from 1 \# $s0 = i, $s1 = sum
// to 100
int sum = 0;
int i;
for (i=1; i < 101; i = i*2) {
 sum = sum + i;
```

Less Than Comparisons

High-level code

```
// add the powers of 2 from 1
// to 100
int sum = 0;
int i;

for (i=1; i < 101; i = i*2) {
   sum = sum + i;
}</pre>
```

MIPS assembly code

done:

t1 = 1 if i < 101.

Arrays

- Useful for accessing large amounts of similar data
- Array element: accessed by *index*
- Array *size*: number of elements in the array

Arrays

- 5-element array
- Base address = 0x12348000 (address of the first array element, array [0])
- First step in accessing an array: load base address into a register

0x12340010	array[4]
0x1234800C	array[3]
0x12348008	array[2]
0x12348004	array[1]
0x12348000	array[0]
	1

Arrays

```
// high-level code
  int array[5];
  array[0] = array[0] * 2;
  array[1] = array[1] * 2;

# MIPS assembly code
# array base address = $s0
```

Arrays

```
// high-level code
  int array[5];
  array[0] = array[0] * 2;
  array[1] = array[1] * 2;
# MIPS assembly code
# array base address = $s0
 lui $s0, 0x1234
                            # put 0x1234 in upper half of $S0
                            # put 0x8000 in lower half of $s0
 ori $s0, $s0, 0x8000
 lw $t1, 0($s0)
                         # $t1 = array[0]
                            # $t1 = $t1 * 2
  sll $t1, $t1, 1
  sw $t1, 0($s0)
                            # array[0] = $t1
 1w $t1, 4($s0) # $t1 = array[1]
 sll $t1, $t1, 1
                           # $t1 = $t1 * 2
  sw $t1, 4($s0)
                           \# \operatorname{array}[1] = \$t1
```

Arrays Using For Loops

```
// high-level code
  int array[1000];
  int i;

for (i=0; i < 1000; i = i + 1)
      array[i] = array[i] * 8;

# MIPS assembly code
# $s0 = array base address, $s1 = i</pre>
```

Arrays Using For Loops

```
# MIPS assembly code
\# $s0 = array base address, $s1 = i
# initialization code
 ori $s0, $s0, 0xF000 # $s0 = 0x23B8F000
 addi $s1, $0, 0 # i = 0
 addi $t2, $0, 1000 # $t2 = 1000
loop:
 slt $t0, $s1, $t2 # i < 1000?
 beg $t0, $0, done # if not then done
 sll $t0, $s1, 2 $\sharp $t0 = i * 4 (byte offset)
 add $t0, $t0, $s0  # address of array[i]
 lw $t1, 0($t0) # $t1 = array[i]
 $11 $1, $1, $1, 3 $$ # $1 = array[i] * 8
 sw $t1, 0($t0) # array[i] = array[i] * 8
 addi $s1, $s1, 1 # i = i + 1
 i loop
                     # repeat
done:
```

ASCII Codes

- American Standard Code for Information Interchange
 - assigns each text character a unique byte value
- For example, S = 0x53, a = 0x61, A = 0x41
- Lower-case and upper-case letters differ by 0x20 (32).

Cast of Characters

#	Char	#	Char	#	Char	#	Char	#	Char	#	Char
20	space	30	0	40	@	50	Р	60	,	70	Р
21	!	31	1	41	Α	51	Q	61	a	71	q
22		32	2	42	В	52	R	62	Ь	72	r
23	#	33	3	43	С	53	S	63	С	73	s
24	\$	34	4	44	D	54	T	64	d	74	t
25	%	35	5	45	Ε	55	U	65	е	75	u
26	&	36	6	46	F	56	٧	66	f	76	v
27	,	37	7	47	G	57	W	67	g	77	W
28	(38	8	48	Н	58	χ	68	h	78	х
29)	39	9	49	I	59	Υ	69	i	79	у
2A	*	3A	:	4A	J	5A	Z	6A	j	7A	z
2B	+	3B	:	4B	K	5B	[6B	k	7 B	{
2C	,	3C	<	4C	L	5C	\	6C	1	7C	1
2D	-	3D	=	4D	М	5D]	6D	m	7D	}
2E		3E	>	4E	N	5E	^	6E	n	7E	~
2F	/	3F	?	4F	0	5F	_	6F	0		

Definitions

- Caller: calling procedure (in this case, main)
- Callee: called procedure (in this case, Sum)

High-level code

```
void main()
{
   int y;
   y = sum(42, 7);
   ...
}
int sum(int a, int b)
{
   return (a + b);
}
```

Procedure calling conventions:

- Caller:
 - passes arguments to callee.
 - jumps to the callee
- Callee:
 - performs the procedure
 - returns the result to caller
 - returns to the point of call
 - must not overwrite registers or memory needed by the caller

MIPS conventions:

- Call procedure: jump and link (jal)
- Return from procedure: jump register (jr)
- Argument values: \$a0 \$a3
- Return value: \$v0

High-level code

```
int main() {
    simple();
    a = b + c;
}

void simple() {
    return;
}
```

MIPS assembly code

```
0x00400200 main: jal simple
0x00400204 add $s0, $s1, $s2
...
0x00401020 simple: jr $ra
```

void means that simple doesn't return a value.

High-level code int main() { simple(); a = b + c; void simple() { return; } MIPS assembly code 0x00400200 main: jal simple add \$s0, \$s1, \$s2 ... 0x00400204 add \$s0, \$s1, \$s2 ... 0x00401020 simple: jr \$ra

jal: jumps to simple and saves PC+4 in the return address register (\$ra). In this case, \$ra = 0x00400204 after jal executes.

jr \$ra: jumps to address in \$ra, in this case 0x00400204.

MIPS conventions:

• Argument values: \$a0 - \$a3

• Return value: \$v0

High-level code

```
int main()
  int y;
 y = diffofsums(2, 3, 4, 5); // 4 arguments
int diffofsums (int f, int q, int h, int i)
  int result;
  result = (f + g) - (h + i);
                             // return value
  return result;
```

MIPS assembly code

```
# $s0 = y
main:
  addi $a0, $0, 2 # argument 0 = 2
  addi $a1, $0, 3  # argument 1 = 3
  addi $a2, $0, 4  # argument 2 = 4
  addi $a3, $0, 5  # argument 3 = 5
  jal diffofsums # call procedure
  add $s0, $v0, $0 # y = returned value
# $s0 = result
diffofsums:
  add $t0, $a0, $a1 # $t0 = f + g
  add $t1, $a2, $a3 # $t1 = h + i
  sub $s0, $t0, $t1 # result = (f + g) - (h + i)
  add $v0, $s0, $0  # put return value in $v0
  ir $ra
              # return to caller
```

MIPS assembly code

```
# $s0 = result
diffofsums:
  add $t0, $a0, $a1  # $t0 = f + g
  add $t1, $a2, $a3  # $t1 = h + i
  sub $s0, $t0, $t1  # result = (f + g) - (h + i)
  add $v0, $s0, $0  # put return value in $v0
  jr $ra  # return to caller
```

- diffofsums overwrote 3 registers: \$t0, \$t1, and \$s0
- diffofsums can use the *stack* to temporarily store registers

The Stack

- Memory used to temporarily save variables
- Like a stack of dishes, last-in-firstout (LIFO) queue
- *Expands*: uses more memory when more space is needed
- *Contracts*: uses less memory when the space is no longer needed



The Stack

- Grows down (from higher to lower memory addresses)
- Stack pointer: \$sp, points to top of the stack

Address	Data		Address	Data	
7FFFFFC	12345678	← \$sp	7FFFFFC	12345678	
	12343070	Ψορ			<u> </u>
7FFFFF8			7FFFFF8	AABBCCDD	-
7FFFFF4			7FFFFF4	11223344	← \$sp
7FFFFF0			7FFFFF0		
•	•		•	•	
•	•		•	•	

How Procedures use the Stack


- Called procedures must have no other unintended side effects.
- But diffofsums overwrites 3 registers: \$t0, \$t1, \$s0

```
# MIPS assembly
# $s0 = result
diffofsums:
   add $t0, $a0, $a1  # $t0 = f + g
   add $t1, $a2, $a3  # $t1 = h + i
   sub $s0, $t0, $t1  # result = (f + g) - (h + i)
   add $v0, $s0, $0  # put return value in $v0
   jr $ra  # return to caller
```

Storing Register Values on the Stack

```
# $s0 = result
diffofsums:
 addi $sp, $sp, -12 # make space on stack
                    # to store 3 registers
 sw $s0, 8($sp) # save $s0 on stack
 sw $t0, 4($sp) # save $t0 on stack
 sw $t1, 0($sp) # save $t1 on stack
 add $t0, $a0, $a1 # <math>$t0 = f + g
 add $t1, $a2, $a3 # $t1 = h + i
 sub $s0, $t0, $t1 # result = (f + g) - (h + i)
 add $v0, $s0, $0 # put return value in $v0
 lw $t1, 0($sp) # restore $t1 from stack
 lw $t0, 4($sp) # restore $t0 from stack
 lw $s0, 8($sp) # restore $s0 from stack
 addi $sp, $sp, 12 # deallocate stack space
 jr $ra
                    # return to caller
```

The Stack during diffofsums Call



Registers

Preserved	Nonpreserved
Callee-Saved	Caller-Saved
\$s0 - \$s7	\$t0 - \$t9
\$ra	\$a0 - \$a3
\$sp	\$v0 - \$v1
stack above \$sp	stack below \$sp

Multiple Procedure Calls

```
proc1:
  addi $sp, $sp, -4  # make space on stack
  sw $ra, 0($sp)  # save $ra on stack
  jal proc2
  ...
  lw $ra, 0($sp)  # restore $s0 from stack
  addi $sp, $sp, 4  # deallocate stack space
  jr $ra  # return to caller
```

Storing Saved Registers on the Stack

```
# $s0 = result
diffofsums:
 addi $sp, $sp, -4 # make space on stack to
                    # store one register
 sw $s0, 0($sp) # save $s0 on stack
                     # no need to save $t0 or $t1
 add $t0, $a0, $a1 # <math>$t0 = f + q
 add $t1, $a2, $a3 # $t1 = h + i
  sub $s0, $t0, $t1 # result = (f + g) - (h + i)
 add $v0, $s0, $0 # put return value in $v0
  lw $s0, 0($sp) # restore $s0 from stack
 addi $sp, $sp, 4 # deallocate stack space
 jr $ra
                    # return to caller
```

Recursive Procedure Call

High-level code

```
int factorial(int n) {
  if (n <= 1)
    return 1;
  else
    return (n * factorial(n-1));
}</pre>
```

Recursive Procedure Call


MIPS assembly code

Recursive Procedure Call

MIPS assembly code

```
0x90 factorial: addi $sp, $sp, -8 # make room
              sw $a0, 4($sp) # store $a0
0x94
            sw $ra, 0($sp) # store $ra
0 \times 98
           addi $t0, $0, 2
0x9C
0xA0
           slt $t0, $a0, $t0 # a <= 1 ?
             beg $t0, $0, else # no: go to else
0xA4
         addi $v0, $0, 1  # yes: return 1
8Ax0
              addi $sp, $sp, 8  # restore $sp
0xAC
0xB0
              ir $ra  # return
0xB4 else: addi a0, a0, -1 # n = n - 1
              jal factorial # recursive call
0xB8
              lw $ra, 0($sp) # restore $ra
0xBC
              lw $a0, 4($sp) # restore $a0
0xC0
0xC4
              addi $sp, $sp, 8 # restore $sp
          mul $v0, $a0, $v0 # n * factorial(n-1)
0xC8
              jr $ra  # return
0xCC
```

Stack during Recursive Call



Procedure Call Summary

Caller

- Put arguments in \$a0-\$a3
- Save any registers that are needed (\$ra, maybe \$t0-t9)
- jal callee
- Restore registers
- Look for result in \$v0

Callee

- Save registers that might be disturbed (\$s0-\$s7)
- Perform procedure
- Put result in \$v0
- Restore registers
- jr \$ra

How do we address the operands?

- Register Only
- Immediate
- Base Addressing
- PC-Relative
- Pseudo Direct

Register Only Addressing

- Operands found in registers
 - Example: add \$s0, \$t2, \$t3
 - Example: sub \$t8, \$s1, \$0

Immediate Addressing

- 16-bit immediate used as an operand
 - Example: addi \$s4, \$t5, −73
 - Example: ori \$t3, \$t7, 0xFF

Base Addressing

Address of operand is:

```
base address + sign-extended immediate
```

- Example: lw \$s4, 72(\$0)
 - Address = \$0 + 72
- Example: sw \$t2, -25(\$t1)
 - Address = \$t1 25

PC-Relative Addressing

Assembly Code

beq \$t0, \$0, else (beq \$t0, \$0, 3)


Field Values

ор	rs	rt	imm		
4	8	0		3	
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

Pseudo-direct Addressing

```
0x0040005C
                           jal
                                    sum
0 \times 004000 A0
               sum: add
                                    $v0, $a0, $a1
         JTA 0000 0000 0100 0000 0000 0000 1010 0000 (0x004000A0)
   26-bit addr 0000 0000 0100 0000 0000 0000 1010 0000
                                                           (0x0100028)
                              0
                                   0
                                                    8
                                         0
                                            Machine Code
          Field Values
       imm
                                         addr
op
                                   op
                                    000011 00 0001 0000 0000 0000 0010 1000 (0x0C100028)
              0x0100028
  3
                                         26 bits
      26 bits
                                   6 bits
6 bits
```

How do we compile & run an application?



What needs to be stored in memory?

- Instructions (also called *text*)
- Data
 - Global/static: allocated before program begins
 - Dynamic: allocated within program
- How big is memory?
 - At most $2^{32} = 4$ gigabytes (4 GB)
 - From address 0x00000000 to 0xFFFFFFF

The MIPS Memory Map

Address	Segment
0xFFFFFFC	
	Reserved
0x80000000	
0x7FFFFFC	Stack
	Dynamic Data
	<u></u>
0x10010000	Heap
0x1000FFFC	
	Static Data
0x10000000	
0x0FFFFFC	
	Text
0x00400000	
0x003FFFFC	
	Reserved
0x00000000	

Example Program: C Code

```
int f, g, y; // global variables
int main(void)
 f = 2;
 q = 3;
  y = sum(f, g);
  return y;
int sum(int a, int b) {
 return (a + b);
```

Example Program: Assembly Code

```
.data
int f, q, y; // global
                          f:
                          q:
                          у:
int main(void)
                          .text
                          main:
                            addi $sp, $sp, -4 # stack frame
                            sw $ra, 0($sp) # store $ra
                            addi $a0, $0, 2  # $a0 = 2
 f = 2;
                            sw $a0, f # f = 2
 a = 3;
                            addi $a1, $0, 3  # $a1 = 3
                            sw $a1, q # q = 3
 y = sum(f, q);
                            jal sum # call sum
 return y;
                            sw $v0, y # y = sum()
                            lw $ra, 0($sp) # restore $ra
                            addi $sp, $sp, 4 # restore $sp
int sum(int a, int b) {
                            jr $ra
                                      # return to OS
 return (a + b);
                          sum:
                            add $v0, $a0, $a1 $v0 = a + b
                            jr
                                $ra
                                       # return
```

Example Program: Symbol Table

Symbol	Address		

Example Program: Symbol Table


Symbol	Address		
f	0x10000000		
g	0x10000004		
У	0x10000008		
main	0x00400000		
sum	0x0040002C		

Example Program: Executable

Executable file header	Text Size	Data Size
	0x34 (52 bytes)	0xC (12 bytes)
Text segment	Address	Instruction
	0x00400000	0x23BDFFFC
	0x00400004	0xAFBF0000
	0x00400008	0x20040002
	0x0040000C	0xAF848000
	0x00400010	0x20050003
	0x00400014	0xAF858004
	0x00400018	0x0C10000B
	0x0040001C	0xAF828008
	0x00400020	0x8FBF0000
	0x00400024	0x23BD0004
	0x00400028	0x03E00008
	0x0040002C	0x00851020
	0x00400030	0x03E0008
Data segment	Address	Data
	0x10000000	f
	0x10000004	g
	0x10000008	У

addi \$sp, \$sp, -4
sw \$ra, 0 (\$sp)
addi \$a0, \$0, 2
sw \$a0, 0x8000 (\$gp)
addi \$a1, \$0, 3
sw \$a1, 0x8004 (\$gp)
jal 0x0040002C
sw \$v0, 0x8008 (\$gp)
lw \$ra, 0 (\$sp)
addi \$sp, \$sp, -4
jr \$ra
add \$v0, \$a0, \$a1
jr \$ra

Example Program: In Memory



Odds and Ends

- Pseudoinstructions
- Exceptions
- Signed and unsigned instructions
- Floating-point instructions

Pseudoinstruction Examples

Pseudoinstruction	MIPS Instructions		
li \$s0, 0x1234AA77	lui \$s0, 0x1234		
	ori \$s0, 0xAA77		
mul \$s0, \$s1, \$s2	mult \$s1, \$s2		
	mflo \$s0		
clear \$t0	add \$t0, \$0, \$0		
move \$s1, \$s2	add \$s2, \$s1, \$0		
nop	sll \$0, \$0, 0		

Exceptions

- Unscheduled procedure call to the *exception handler*
- Casued by:
 - Hardware, also called an *interrupt*, e.g. keyboard
 - Software, also called *traps*, e.g. undefined instruction
- When exception occurs, the processor:
 - Records the cause of the exception
 - Jumps to the exception handler at instruction address 0x80000180
 - Returns to program

Exception Registers

- Not part of the register file.
 - Cause
 - Records the cause of the exception
 - EPC (Exception PC)
 - Records the PC where the exception occurred
- EPC and Cause: part of Coprocessor 0
- Move from Coprocessor 0
 - mfc0 \$t0, EPC
 - Moves the contents of EPC into \$t0

Exception Causes

Exception	Cause
Hardware Interrupt	0x0000000
System Call	0x00000020
Breakpoint / Divide by 0	0x00000024
Undefined Instruction	0x00000028
Arithmetic Overflow	0x00000030

Exceptions

- Processor saves cause and exception PC in Cause and EPC
- Processor jumps to exception handler (0x80000180)
- Exception handler:
 - Saves registers on stack
 - Reads the Cause register
 mfc0 \$t0, Cause
 - Handles the exception
 - Restores registers
 - Returns to program

```
mfc0 $k0, EPC jr $k0
```

Signed and Unsigned Instructions

- Addition and subtraction
- Multiplication and division
- Set less than

Addition and Subtraction

- Signed: add, addi, sub
 - Same operation as unsigned versions
 - But processor takes exception on overflow
- Unsigned: addu, addiu, subu
 - Doesn't take exception on overflow
 - Note: addiu sign-extends the immediate

Multiplication and Division

- Signed: mult, div
- Unsigned: multu, divu

Set Less Than

- Signed: slt, slti
- Unsigned: sltu, sltiu
 - Note: sltiu sign-extends the immediate before comparing it to the register

Loads

- Signed:
 - Sign-extends to create 32-bit value to load into register
 - Load halfword: 1h
 - Load byte: 1b
- Unsigned: addu, addiu, subu
 - Zero-extends to create 32-bit value
 - Load halfword unsigned: 1hu
 - Load byte: 1bu

Floating-Point Instructions

- Floating-point coprocessor (Coprocessor 1)
- 32 32-bit floating-point registers (\$f0 \$f31)
- Double-precision values held in two floating point registers
 - e.g., \$f0 and \$f1, \$f2 and \$f3, etc.
 - So, double-precision floating point registers: \$f0, \$f2,
 \$f4, etc.

Floating-Point Instructions

Name	Reg	ister Number	Usage
\$fv0 - \$:	fv1	0, 2	return values
\$ft0 - \$ft3		4, 6, 8, 10	temporary variables
\$fa0 - \$:	fa1	12, 14	procedure arguments
\$ft4 - \$:	ft8	16, 18	temporary variables
\$fs0 - \$:	fs5	20, 22, 24, 26, 28, 30	saved variables

F-Type Instruction Format

- Opcode = $17 (010001_2)$
- Single-precision:
 - $cop = 16 (010000_2)$
 - add.s, sub.s, div.s, neg.s, abs.s, etc.
- Double-precision:
 - $cop = 17 (010001_2)$
 - add.d, sub.d, div.d, neg.d, abs.d, etc.
- 3 register operands:
 - fs, ft: source operands
 - fd: destination operandsF-Type

ор	cop	ft	fs	fd	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

Floating-Point Branches

- Set/clear condition flag: fpcond
 - Equality: c.seq.s, c.seq.d
 - Less than: c.lt.s, c.lt.d
 - Less than or equal: c.le.s, c.le.d
- Conditional branch
 - bclf: branches if fpcond is FALSE
 - bclt: branches if fpcond is TRUE
- Loads and stores
 - lwc1: lwc1 \$ft1, 42(\$s1)
 - swc1:swc1 \$fs2, 17(\$sp)