
STN-LIA-MPU

An OLIA spinout development

Development/Discussion LOG

Nikos Chalikias

405 nm setup with 1000mW (electric) power




- StN-LIA-MCU with a NPN transistor to drive the 1W laser
- BPW34 general purpose Photodiode
- We used a 405nm Laser instead an infrared
- Output is high: 2000mV (direct laser beam to Photodiode
- Can see consistently a 5mV variation when exhale
- Will work with similar size/power/lens Infrared Laser
- Need for a 2nd Photodiode for liquid tests
- It is easier to multiplex and use a 2nd laser, [...if this works with the liquid project]


2000nm setup

- Proposed to setup a photodiode experiment only with PCBs
 - This is our goal, but many little details can block the operation for ... some time
- Chinna proposal: **to use existing instrumentation and only PCB LIA (StN-LIA-MCU),** seems much better, as a 1st step
 - Then we can replace:
 - TEC with PCB (2nd step)
 - LDD with PCB (3d step)
 - Generator with PCB (4d step)
 - Add a microcontroller with LCD/buttons as experiment administrator (5th step)
 - Add A PC or R-Pi as experiment administrator (6th step)
 - Evaluate Preamplifier performance
 - Develop and evaluate, ultra low noise multi-output PSU
- This is scalable and sustainable, can start now
- 2000nm LED and photodiode to be delivered in a couple of days

StN-LIA-MCU



- V1 ongoing testing, works as expected
- A 2nd PCB to be assembled
- Most probably the 3d PCB will be V2



V2: Fixed PCB bugs, removed expensive connectors, Easier to use screw terminals, local SD-Card, lower cost 2 layers PCB faster to be delivered from manufacturer, clean

Plan to assess LIA performance

- Started with evaluating Standard Deviation $[\sigma]$ of the R component DC output of commercial LIA
 - Already have results for 3 COTS LIA
- Propose to expand our evaluation scope with a basic setup for a QTF characterization
 - Real problem
 - Experience on the setup
 - No need for expensive laser or optics
 - Can work with 0.5 euro 32.768 RTC crystals
 - No need for Preamplifiers
 - Can compare with Bari electronics

KNOWN ISSUES


HW and FW is based on OLIA


- Works good with internal REFERENCE signal generator but not for all Frequencies
- The external REFERENCE frequency is 64X the wanted Frequency, this is confusing for the user
- Works well with External REFERENCE at the order of 1KHz, but can't follow for order of 10KHz
- In our FW version we have updated the multiplier ratio to 32X: so it works for 12KHz range
- Not any frequency for REFERENCE is working: It has to be an integer fraction of the sampling frequency
- Sampling Frequency is 200KHz
- We should not have the Integer fraction issue with external REFERENCE, as the sampling rate is (..should) be controlled by the external REFERENCE!!!But this not resolved yet...

N2O App4Farm GAS CELL

- RUN LIA 2 UNITS AT THE SAME TIME AND SAME REFERENCE.
- TEST IF COMMON EXTERNAL REFERENCE CREATES 2 REF OUTPUTS AT CONSTANT PHASE DIFFERENCE
- BNC ARE NEEDED
- IN 2 WEEKS?? YES IT IS POSSIBLE
- DRIVE 5V 500mA LED, IS IMPORTANT
- USE EXTERNAL PSU FOR THE LED
- 3+ Boards needed
- STATUS
 - Tested Running 2 GUIs at the same time
 - 3D printing a plastic optics breadboard
 - To mount/integrate inside a Passepartout enclosure, bottle ouitside

PCBS TO BE SOLDERED






GUI

For our version of GUI: Only minor updates

Schematic



Function Calculate() runs every 5µs

```
Input is sampled 200 times for the 1ms REF period (1KHz)
```

432

433

434

435 436

```
xSig = (double)adc->analogReadContinuous(A0); //sample current adc value

Sin (0 to 2π)
in 200 steps

O to 199


For 1KHz: 200 samples per REF period

// Nikos: Below 2 lines are the core of the Lock In Amplifier
//calculate reference value and multiply (-1) because preamp is inventing) // Nikos: Sinusoidal Reference signal is created here, Is like sampling a 1000Hz sinus phasSig = -1*sin(((2.0 * (j + 1) * pi * sampleIndex) / samplesPerPeriod) - ((j + 1) * phaseDiff));
xi0 = (xSig*phasSig); //-1 because preamp is inverting // Nikos: Input sample is multiplied with Reference 'sample' here
```


Review of code for 1st harmonic lock-in OLIA firmware Function **calculate()** is called periodically every 5µs (200KHz), to

- Sample input (ADC)
- Calculate the Reference sinusoidal 'virtual-sample' (200 samples)
 - The Reference frequency is: Fsample/A, where A is integer and Fsample is 200KHz
- Multiply the input sample with the Reference 'sample' and filter
- Generate the Rectangular Reference frequency for the D.U.T.
 - This is in phase with the Internally used sinusoidal Reference

Sinus calculation



Possible upgrades



Sync the sampling


- Use main/aux SNT-LIA-MPU boards with updated firmware
- Aux LIA board sampling interrupt is driven from the main
 - Main outputs the sampling frequency on a new output pin
 - Aux receives the sampling frequency in a new input pin
- Aux sampling interrupt(200KHz) is generated from the input pin, not from internal timer

Sample an external sinusoidal reference

- Use a 2nd ADC analogue input pin
- Apply external sinusoidal external Reference to the new ADC analogue input
- Update the Firmware
 - Use the external ADC sampled sinusoidal Reference, instead the internally generated

Monitor the internally generated sinusoidal Reference

- Add a new DAC chip and connect external oscilloscope for monitoring
 - Alternatively, export the sinusoidal Reference to a PWM output, without using a new DAC
- Update the firmware to export the sinusoidal Reference to DAC, or the PWM output



LIA Sampling interrupt: Upgrade for external Reference **BLUE=CURRENT GREEN=UPGRADE** 200KHz timer Interrupt (5µs) **GUI** Serial port GUI protocol **GRAPHICAL** USE **FILTER INTERFACE** DC EXTERNAL Fsample = 200KHz (5µs) samplesPerPeriod = 200 Reference = 1KHz (1ms) Ref= $\sin(2\pi^* (1->200)/200)$ **EXT INTERNAL REF** INTERNAL SINUSOIDAL TO OSCILLOSCOPE **SINUSOIDAL** REFERENCE GENERATOR SINUSDIDAL REFERENCE **REF EXPORT** 'VIRTUAL SAMPLES' 1 KHz SYNCED 100 interrupts HIGH RECTANGULAR D.U.T. 1 KHz REFERENCE GENERATOR 100 interrupts LOW 200KHz SYNC INT IN 200KHz SYNC OUT To aux LIA, From main LIA

Higher Level Diagram for Orthogonal LIA








Figure 1. Structure of the orthogonal lock-in amplifier.








StN-LIA-E: Extended Functionality



StN-LIA-E: Two Synchronized Lock In Amplifiers



LIA Sampling interrupt, Control with external Precise generator

- Any Frequency, including QEPAS resolution
- Precise [0.0001Hz] Frequency Resolution (0.01Hz / 100)
- Can be used as External Generator for a Bench Lock In Amplifier
- Synchronized operation of multiple STN-LIAs [solves UCC setup]
- With a small addition the PCB setup can produce sinusoid output in the audio Freq Range

Synced Input ADC channels and Circular Buffer

Synchronized reading of 2 ADC channels and circular buffer for the Reference

```
result = adc->readSynchronizedContinuous();
result.result_adc0 = (double)result.result_adc0;
result.result_adc1 = (double)result.result_adc1;
xSig = result.result_adc0;
rSig = result.result_adc1;
rSig = result.result_adc1;
adcBuffer[sampleIndex] = rSig; // Nikos: Experimental Circulal buffer, collects sampleIndex samples of the sinusoid Reference Input,
417
```

[0 to 199] for 1KHz and Sampling rate 200 KHz

The circular buffer for the sinusoid Reference signal Input, is used to create the **Cosine** of the Reference

Sin and Cos implementation in C++

```
// Nikos: Below 2 lines are the core of the Lock In Amplifier
  //calculate reference value and multiply (-1* because preamp is inverting) // Nikos: Sinusoidal Reference signal is created here, Is like sampling a 1000Hz sinus
  phasSig = -1*sin(((2.0 * (j + 1) * pi * sampleIndex) / samplesPerPeriod) - ((j + 1) * phaseDiff));
  //xi0 = (xSig*phasSig); //-1 because preamp is inverting
                                                                           // Nikos: Input sample is multiplied with Reference 'sample' here
  xi0 = ( xSig * adcBuffer[sampleIndex]); // Nikos: Experimentall Multilpy the 2 ADC inputs: Signal Input / Sinusoidal Signal Input
                                    // Nikos: Experimental Circular Buffer for the sinusoid external Reference, get the sin
  //first smoothing
                                                                          SIN (in phase harmonic)
  delta = xi0 - xiFilt1[j];
  incr = alpha*delta;
  xiFilt1[j] = xiFilt1[j] + incr;
  //second smoothing
  delta = xiFilt1[i] - xiFilt2[i];
  incr = alpha*delta;
  xiFilt2[j] = xiFilt2[j] + incr;
  if (j == 0){ //skip to first higher harmonic
   j = firstHigherHarmonic - 2;
//same for quadrature harmonics
for (j = 0; j < lastHigherHarmonic; ++j){</pre>
                                                                          COS (quadrature harmonic)
 //calculate reference value and multiply
  quadSig = -1*cos(((2.0 * (j + 1) * pi * sampleIndex) / samplesPerPeriod) - ((j + 1) * phaseDiff));
 //xq0 = (xSig*quadSig);
  xq0 = (xSig * adcBuffer[sampleIndex+49]); // Nikos: Experimental Circular Buffer for the sinusoid external Reference, get the cosine after samplesPerIndex_/4
```

454

455

456

457

458

459 460

461

462

463

464 465

466

467

468

469 470

471

472 473 474

475

476

477

478

479

480

481 482

Requirements discussion

We're looking for two signal channels driven by a single modulation source, ideally produced by the LIA, to modulate a single LED.

From the LED, we get two signals by splitting the light into two separate channels that are individually detected after the light passes through the sample. These need to be separately lockin amplified.

We would ideally want to get a sensitive measurement of the channels individually, or maybe just the ratio of the channels if that was more sensitive and could be determined directly.

I think this means:

one modulation source (in the LIA)

two input channels

lockin signal processing for two channels . It might be possible to do the two channels from the same op amp etc., but maybe not.

After 31/12/2024 call


- Must measure 2 outputs from the D.U.T. in parallel
 - Implementation with 2 LIA boards that use external reference
 - Implementation with 2 signal inputs on the same LIA board, with internal reference
- Lower priority: Calibrate by measuring the PHASE Φ, at different frequencies 1 KHz to 10 KHz

UCC Requirements discussion: 31/12/2024 call


After 31/12/2024 call

- Must measure in parallel, 2 outputs from the D.U.T.
 - Implementation with 2 LIA boards that use external reference
 - This option does not need extensive GUI updates
 - Implementation with 2 signal inputs on the same LIA board, uses only internal reference
 - Need major rework for the GUI
- Lower priority: Calibrate by measuring the PHASE φ, at different frequencies 1KHz to 10KHz


Two PCBs tested in synchronization



- Both PCBs have the same signal input (Potentiometer adjusted to 16mV)
- The Reference signal is created from the main PCB and drives to Potentiometer




Two PCBs tested in synchronization




t (s)


t (s)

Two PCBs tested in synchronization






- The 2 PCBs are synchronized
- The aux PCB interrupt (sampling) has 100ns delay
- The phase difference between the main and aux sampling is stable (100ns)



OPT101 SETUP



Expand with

- 2nd OPT101 PCB
- 2nd LED ???

QUESTIONS