# LoRaWAN<sup>TM</sup> 1.1 Specification

Copyright © 2017 LoRa Alliance, Inc. All rights reserved.

4

5

6789101121314516171892212232425627289331

# NOTICE OF USE AND DISCLOSURE

Copyright © LoRa Alliance, Inc. (2017). All Rights Reserved.

The information within this document is the property of the LoRa Alliance ("The Alliance") and its use and disclosure are subject to LoRa Alliance Corporate Bylaws, Intellectual Property Rights (IPR) Policy and Membership Agreements.

Elements of LoRa Alliance specifications may be subject to third party intellectual property rights, including without limitation, patent, copyright or trademark rights (such a third party may or may not be a member of LoRa Alliance). The Alliance is not responsible and shall not be held responsible in any manner for identifying or failing to identify any or all such third party intellectual property rights.

This document and the information contained herein are provided on an "AS IS" basis and THE ALLIANCE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING BUT NOTLIMITED TO (A) ANY WARRANTY THAT THE USE OF THE INFORMATION HEREINWILL NOT INFRINGE ANY RIGHTS OF THIRD PARTIES (INCLUDING WITHOUTLIMITATION ANY INTELLECTUAL PROPERTY RIGHTS INCLUDING PATENT, COPYRIGHT OR TRADEMARK RIGHTS) OR (B) ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE OR NONINFRINGEMENT.

IN NO EVENT WILL THE ALLIANCE BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OFBUSINESS, OR FOR ANY OTHER DIRECT, INDIRECT, SPECIAL OR EXEMPLARY, INCIDENTIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES OF ANY KIND, IN CONTRACT OR IN TORT, IN CONNECTION WITH THIS DOCUMENT OR THE INFORMATION CONTAINED HEREIN, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE.

The above notice and this paragraph must be included on all copies of this document that are made.

LoRa Alliance, Inc. 3855 SW 153rd Drive Beaverton, OR 97003

Note: All Company, brand and product names may be trademarks that are the sole property of their respective owners.

39

32 33 34

35





# **LoRaWAN™ 1.1 Specification**

**Authored by the LoRa Alliance Technical Committee** 

46 Chairs

47 N.SORNIN (Semtech), A.YEGIN (Actility)

Editor:

50 N.SORNIN (Semtech)

Contributors:

A.BERTOLAUD (Gemalto), J.DELCLEF (ST Microelectronics), V.DELPORT (Microchip Technology), P.DUFFY (Cisco), F.DYDUCH (Bouygues Telecom), T.EIRICH (TrackNet), L.FERREIRA (Orange), S.GHAROUT(Orange), O.HERSENT (Actility), A.KASTTET (Homerider Systems), D.KJENDAL (Senet), V.KLEBAN (Everynet), J.KNAPP (TrackNet), T.KRAMP (TrackNet), M.KUYPER (TrackNet), P.KWOK (Objenious), M.LEGOURIEREC (Sagemcom), C.LEVASSEUR (Bouygues Telecom), M.LUIS (Semtech), M.PAULIAC (Gemalto), P.PIETRI (Orbiwise), D.SMITH (MultiTech), R.SOSS(Actility), T.TASHIRO (M2B Communications), P.THOMSEN (Orbiwise), A.YEGIN (Actility)

 Version: 1.1

Date: October 11, 2017 Status: Final release



#### **Contents** Conventions 9 1.2 Uplink Messages......12 3.2 3.3 3.3.1 3.3.2 Receive window duration......14 3.3.3 MAC Layer (PHYPayload)......16 4.1 4.2 5.1 5.2 5.3 5.4 Receive Windows Parameters (RXParamSetupReg, RXParamSetupAns) ............ 36 5.5 5.6 Creation / Modification of a Channel (NewChannelReg, NewChannelAns, 5.7 Setting delay between TX and RX (RXTimingSetupReq, RXTimingSetupAns) ..... 40 5.8 End-device transmission parameters (TxParamSetupReg, TxParamSetupAns) .... 41 5.9 5.10 Rekey indication commands (RekeyInd, RekeyConf)......42 Before Activation 47

# LoRa Alliance™

119	6.2.1 Join procedure	
120	6.2.2 Join-request message	. 52
121	6.2.3 Join-accept message	. 53
122	6.2.4 ReJoin-request message	. 57
123	6.2.5 Key derivation diagram	. 61
124	6.3 Activation by Personalization	
125	7 Retransmissions back-off	
126	Class B – Beacon	
127	8 Introduction to Class B	
128	9 Principle of synchronous network initiated downlink (Class-B option)	
129	10 Uplink frame in Class B mode	
130	11 Downlink Ping frame format (Class B option)	 72
131	11.1 Physical frame format	
132	11.2 Unicast & Multicast MAC messages	72
133	11.2.1 Unicast MAC message format	
134	11.2.2 Multicast MAC message format	
135	12 Beacon acquisition and tracking	
136	12.1 Minimal beacon-less operation time	
137	12.2 Extension of beacon-less operation upon reception	. 73
138	12.3 Minimizing timing drift	. 73
139	13 Class B Downlink slot timing	
140	13.1 Definitions	
141	13.2 Slot randomization	
142	14 Class B MAC commands	
143	14.1 PingSlotInfoReq	
144	14.2 BeaconFreqReq	
145	14.3 PingSlotChannelReq	
146	14.4 BeaconTimingReq & BeaconTimingAns	
147	15 Beaconing (Class B option)	
148	15.1 Beacon physical layer	
149	15.2 Beacon frame content	
150	15.3 Beacon GwSpecific field format	
151	15.3.1 Gateway GPS coordinate:InfoDesc = 0, 1 or 2	
152	15.4 Beaconing precise timing	
153	15.5 Network downlink route update requirements	
154	16 Class B unicast & multicast downlink channel frequencies	
155	16.1 Single channel beacon transmission	
156	16.2 Frequency-hopping beacon transmission	
157	Class C – Continuously listening	
158	17 Class C: Continuously listening end-device	
159	17.1 Second receive window duration for Class C	
160	17.2 Class C Multicast downlinks	
161	18 Class C MAC command	
162	18.1 Device Mode (DeviceModeInd, DeviceModeConf)	
163	Support information	
164	19 Examples and Application Information	
165	19.1 Uplink Timing Diagram for Confirmed Data Messages	
166	19.2 Downlink Diagram for Confirmed Data Messages	
167	19.3 Downlink Timing for Frame-Pending Messages	
168	20 Recommendation on contract to be provided to the network server by the end-	
169	device provider at the time of provisioning	QЗ
170	21 Recommendation on finding the locally used channels	
171	22 Revisions	

# LoRa Alliance™

172	22.1 Revision 1.0	95
173	22.2 Revision 1.0.1	
174	22.3 Revision 1.0.2	
175	22.4 Revision 1.1	
176	22.4.1 Clarifications	
177	22.4.2 Functional modifications	
178 179	22.4.3 Examples	
179 180	23 Glossary	
181	24.1 References	
182	25 NOTICE OF USE AND DISCLOSURE	
183		
184	Tables	
185	Table 1: MAC message types	17
186	Table 2: Major list	18
187	Table 3: FPort list	
188	Table 4: MAC commands	
189	Table 5: Channel state table	
190	Table 6: LinkADRAns status bits signification	
191 192	Table 7: RXParamSetupAns status bits signification	37
192	Table 9: NewChannelAns status bits signification	
193	Table 10: DIChannelAns status bits signification	
195	Table 11: RXTimingSetup Delay mapping table	
196	Table 12 : TxParamSetup EIRP encoding table	
197	Table 13 : JoinRegType values	
198	Table 14 : Join-Accept encryption key	55
199	Table 15 : summary of RejoinReq messages	
200	Table 18: transmission conditions for RejoinReq messages	
201	Table 19 : Join-request dutycycle limitations	
202	Table 20: Beacon timing	
203 204	Table 21: classB slot randomization algorithm parameters	
20 <del>4</del> 205	Table 22 : classB MAC command table  Table 23 : beacon infoDesc index mapping	
205 206	Table 24 : Class C MAC command table	
207	Table 25 : DeviceModInd class mapping	
208	Table 20 1 2 0 100 med order mapping	
209	Figures	
210	Figure 1: LoRaWAN Classes	10
211	Figure 2: Uplink PHY structure	
212	Figure 3: Downlink PHY structure	12
213	Figure 4: End-device receive slot timing	
214	Figure 5: Radio PHY structure (CRC* is only available on uplink messages)	
215	Figure 6: PHY payload structure	
216	Figure 7: MAC payload structure	
217 218	Figure 8: Frame header structure	
218 219	Figure 9: PHY paylod format  Figure 10: MAC header field content	
_ 1,7	LINGLE IV. IVI IV HOUGH HOU VOILUIL	



220	Figure 11 : Frame header format	
221	Figure 12 : downlink FCtrl fields	
222	Figure 13 : uplink FCtrl fields	
223	Figure 14 : data rate back-off sequence example	20
224	Figure 15 : Encryption block format	
225	Figure 16 : MACPayload field size	25
226	Figure 17 : Encryption block format	
227	Figure 18 : downlink MIC computation block format	27
228	Figure 19 : uplink B <sub>0</sub> MIC computation block format	
229	Figure 20: uplink B <sub>1</sub> MIC computation block format	
230	Figure 34 : ResetInd payload format	
231	Figure 35 : ResetConf payload format	
232	Figure 21: LinkCheckAns payload format	
233	Figure 22 : LinkADRReq payload format	
234	Figure 23 : LinkADRAns payload format	
235	Figure 24 : DutyCycleReq payload format	
236	Figure 25 : RXParamSetupReq payload format	
237	Figure 26 : RXParamSetupAns payload format	
238	Figure 27 : DevStatusAns payload format	
239	Figure 28 : NewChannelReq payload format	
240	Figure 29 : NewChannelAns payload format	
241	Figure 30 : DLChannelReq payload format	
242	Figure 31 : DLChannelAns payload format	
243	Figure 32 : RXTimingSetupReq payload format	
244	Figure 33 : TxParamSetupReq payload format	
245	Figure 36 : RekeyInd payload format	
246	Figure 37 : RekeyConf payload format	
247	Figure 38 : ADRParamSetupReq payload format	<del>7</del> 3
248	Figure 39 : DeviceTimeAns payload format	
249	Figure 40 : ForceRejoinReq payload format	
250	Figure 41 : RejoinParamSetupReq payload format	
251	Figure 42 : RejoinParamSetupAns payload format	46 46
252	Figure 43 : DevAddr fields	
253	Figure 44 : Join-request message fields	
254	Figure 45 : Join-accept message fields	
255	Figure 46: Rejoin-request type 0&2 message fields	
256	Figure 47: Rejoin-request type 1 message fields	
257	Figure 48 : LoRaWAN1.0 key derivation scheme	
258	Figure 49 : LoRaWAN1.1 key derivation scheme	
259	Figure 50: Beacon reception slot and ping slots	
260	Figure 51 : classB FCtrl fields	
261	Figure 52 : beacon-less temporary operation	73
262	Figure 53: Beacon timing	
263	Figure 54 : PingSlotInfoReq payload format	76
264	Figure 55 : BeaconFreqReq payload format	
265	Figure 56 : BeaconFreqAns payload format	
266	Figure 57 : PingSlotChannelReq payload format	
267	Figure 58 : PingSlotFreqAns payload format	
268	Figure 59 : beacon physical format	
269	Figure 60 : beacon frame content	
270	Figure 61 : example of beacon CRC calculation (1)	
271	Figure 62 : example of beacon CRC calculation (2)	
272	Figure 63 : beacon GwSpecific field format	
	- 19410 00 1 2000011 On Opoullo Iloia formatiminiminiminiminiminiminiminiminiminimi	J .

# LoRaWAN 1.1 Specification



273	Figure 64: beacon Info field format	82
274	Figure 65: Class C end-device reception slot timing	
275	Figure 66: DeviceModeInd payload format	88
276	Figure 67: Uplink timing diagram for confirmed data messages	90
277	Figure 68: Downlink timing diagram for confirmed data messages	91
278	Figure 69: Downlink timing diagram for frame-pending messages, example 1	91
279	Figure 70: Downlink timing diagram for frame-pending messages, example 2	92
280	Figure 71: Downlink timing diagram for frame-pending messages, example 3	92
281		



### 1 Introduction

- This document describes the LoRaWAN™ network protocol which is optimized for battery-powered end-devices that may be either mobile or mounted at a fixed location.
- LoRaWAN networks typically are laid out in a star-of-stars topology in which **gateways**<sup>1</sup> relay messages between **end-devices**<sup>2</sup> and a central **Network Server** the Network Server
- routes the packets from each device of the network to the associated **Application Server**.
- To secure radio transmissions the LoRaWAN protocol relies on symmetric cryptography using session keys derived from the device's root keys. In the backend the storage of the
- 290 device's root keys and the associated key derivation operations are insured by a Join
- 291 **Server.**

282

308

309

310

311 312

313

314

315

316

317

- This specification treats the Network Server, Application Server, and Join Server as if they are always co-located. Hosting these functionalities across multiple disjoint network nodes is
- 294 outside the scope of this specification but is covered by [BACKEND].
- 295 Gateways are connected to the Network Server via secured standard IP connections while
- 296 end-devices use single-hop LoRa™ or FSK communication to one or many gateways.<sup>3</sup> All
- 297 communication is generally bi-directional, although uplink communication from an end-
- 298 device to the Network Server is expected to be the predominant traffic.
- 299 Communication between end-devices and gateways is spread out on different frequency
- channels and data rates. The selection of the data rate is a trade-off between
- 301 communication range and message duration, communications with different data rates do
- not interfere with each other. LoRa data rates range from 0.3 kbps to 50 kbps. To maximize both battery life of the end-devices and overall network capacity, the LoRa network
- infrastructure can manage the data rate and RF output for each end-device individually by
- means of an **adaptive data rate** (ADR) scheme.
- End-devices may transmit on any channel available at any time, using any available data rate, as long as the following rules are respected:
  - The end-device changes channel in a pseudo-random fashion for every transmission. The resulting frequency diversity makes the system more robust to interferences.
    - The end-device respects the maximum transmit duty cycle relative to the sub-band used and local regulations.
    - The end-device respects the maximum transmit duration (or dwell time) relative to the sub-band used and local regulations.

**Note:** Maximum transmit duty-cycle and dwell time per sub-band are region specific and are defined in [PHY]

#### 1.1 LoRaWAN Classes

All LoRaWAN devices MUST implement at least the Class A functionality as described in this document. In addition they MAY implement options named Class B or Class C as also

<sup>&</sup>lt;sup>1</sup> Gateways are also known as **concentrators** or **base stations**.

<sup>&</sup>lt;sup>2</sup> End-devices are also known as **motes**.

<sup>&</sup>lt;sup>3</sup> Support for intermediate elements – repeaters – is not described in the document, however payload restrictions for encapsulation overhead are included in this specification. A repeater is defined as using LoRaWAN as its backhaul mechanism.



described in this document or others to be defined. In all cases, they MUST remain compatible with Class A.

#### 1.2 Conventions

323

- The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be
- 326 interpreted as described in RFC 2119.
- 327 MAC commands are written *LinkCheckReq*, bits and bit fields are written **FRMPayload**, 328 constants are written RECEIVE DELAY1, variables are written *N*.
- 329 In this document,
- The over-the-air octet order for all multi-octet fields is little endian
- EUI are 8 bytes multi-octet fields and are transmitted as little endian.
- By default, RFU bits SHALL be set to zero by the transmitter of the message and SHALL be ignored by the receiver



# 2 Introduction on LoRaWAN options

LoRa<sup>™</sup> is a wireless modulation for long-range low-power low-data-rate applications developed by Semtech. Devices implementing more than Class A are generally named "higher Class end-devices" in this document.

#### 2.1 LoRaWAN Classes

A LoRa network distinguishes between a basic LoRaWAN (named Class A) and optional features (Class B, Class C):




Figure 1: LoRaWAN Classes

- Bi-directional end-devices (Class A): End-devices of Class A allow for bi-directional communications whereby each end-device's uplink transmission is followed by two short downlink receive windows. The transmission slot scheduled by the end-device is based on its own communication needs with a small variation based on a random time basis (ALOHA-type of protocol). This Class A operation is the lowest power end-device system for applications that only require downlink communication from the server shortly after the end-device has sent an uplink transmission. Downlink communications from the server at any other time will have to wait until the next scheduled uplink.
- Bi-directional end-devices with scheduled receive slots (Class B): End-devices
  of Class B allow for more receive slots. In addition to the Class A random receive
  windows, Class B devices open extra receive windows at scheduled times. In order
  for the End-device to open its receive window at the scheduled time, it receives a
  time synchronized Beacon from the gateway.
- Bi-directional end-devices with maximal receive slots (Class C): End-devices of Class C have nearly continuously open receive windows, only closed when transmitting. Class C end-device will use more power to operate than Class A or Class B but they offer the lowest latency for server to end-device communication.



362

# CLASS A - ALL END-DEVICES

All LoRaWAN end-devices MUST implement Class A features.



# 363 3 Physical Message Formats

The LoRa terminology distinguishes between uplink and downlink messages.

# 3.1 Uplink Messages

- 366 **Uplink messages** are sent by end-devices to the Network Server relayed by one or many gateways.
- Uplink messages use the LoRa radio packet explicit mode in which the LoRa physical header (PHDR) plus a header CRC (PHDR\_CRC) are included. The integrity of the payload is protected by a CRC
- is protected by a CRC.
- The PHDR, PHDR\_CRC and payload CRC fields are inserted by the radio transceiver.
- 372 Uplink PHY:

365

373

374

380

Preamble PHDR PHDR\_CRC PHYPayload CRC

Figure 2: Uplink PHY structure

# 3.2 Downlink Messages

- Each **downlink message** is sent by the Network Server to only one end-device and is relayed by a single gateway.<sup>2</sup>
- Downlink messages use the radio packet explicit mode in which the LoRa physical header (PHDR) and a header CRC (PHDR CRC) are included.<sup>3</sup>
- 379 Downlink PHY:

Preamble PHDR PHDR\_CRC PHYPayload

Figure 3: Downlink PHY structure

\_

<sup>&</sup>lt;sup>1</sup> See the LoRa radio transceiver datasheet for a description of LoRa radio packet implicit/explicit modes

<sup>&</sup>lt;sup>2</sup> This specification does not describe the transmission of multicast messages from a network server to many end-devices.

<sup>&</sup>lt;sup>3</sup> No payload integrity check is done at this level to keep messages as short as possible with minimum impact on any duty-cycle limitations of the ISM bands used.



382

383 384

385 386

## 3.3 Receive Windows

Following each uplink transmission the end-device MUST open two short receive windows. The receive window start times are defined using the end of the transmission as a reference.




Figure 4: End-device receive slot timing.



#### 3.3.1 First receive window channel, data rate, and start

- 388 The first receive window RX1 uses a frequency that is a function of the uplink frequency and
- 389 a data rate that is a function of the data rate used for the uplink. RX1 opens
- 390 RECEIVE\_DELAY1<sup>1</sup> seconds (+/- 20 microseconds) after the end of the uplink modulation.
- 391 The relationship between uplink and RX1 slot downlink data rate is region specific and
- detailed in [PHY]. By default, the first receive window datarate is identical to the datarate of
- 393 the last uplink.

387

394

400

403

409

414

## 3.3.2 Second receive window channel, data rate, and start

- 395 The second receive window RX2 uses a fixed configurable frequency and data rate and
- 396 opens RECEIVE\_DELAY21 seconds (+/- 20 microseconds) after the end of the uplink
- 397 modulation. The frequency and data rate used can be modified through MAC commands
- 398 (see Section 5). The default frequency and data rate to use are region specific and detailed
- 399 in [PHY].

#### 3.3.3 Receive window duration

- The length of a receive window MUST be at least the time required by the end-device's radio
- 402 transceiver to effectively detect a downlink preamble.

## 3.3.4 Receiver activity during the receive windows

- 404 If a preamble is detected during one of the receive windows, the radio receiver stays active
- 405 until the downlink frame is demodulated. If a frame was detected and subsequently
- 406 demodulated during the first receive window and the frame was intended for this end-device
- after address and MIC (message integrity code) checks, the end-device MUST not open the
- 408 second receive window.

#### 3.3.5 Network sending a message to an end-device

- 410 If the network intends to transmit a downlink to an end-device, it MUST initiate the
- 411 transmission precisely at the beginning of at least one of the two receive windows. If a
- downlink is transmitted during both windows, identical frames MUST be transmitted during
- 413 each window.

#### 3.3.6 Important notice on receive windows

- 415 An end-device SHALL NOT transmit another uplink message before it either has received a
- 416 downlink message in the first or second receive window of the previous transmission, or the
- second receive window of the previous transmission is expired.

<sup>&</sup>lt;sup>1</sup> RECEIVE DELAY1 and RECEIVE DELAY2 are described in Chapter 6.



# 3.3.7 Receiving or transmitting other protocols

- The node MAY listen or transmit other protocols or do any radio transactions between the
- 420 LoRaWAN transmission and reception windows, as long as the end-device remains
- 421 compatible with the local regulation and compliant with the LoRaWAN specification.



# 4 MAC Message Formats

All LoRa uplink and downlink messages carry a PHY payload (**Payload**) starting with a single-octet MAC header (**MHDR**), followed by a MAC payload (**MACPayload**)<sup>1</sup>, and ending with a 4-octet message integrity code (**MIC**).

425 426

422

423 424

427	Radio PHY layer:								
		Preamble	PHDR	PHDR_CRC	PHYPayload	CRC*			
428	•	Figure 5: R	adio PHY structur	re (CRC* is only av	ailable on uplink	messages)			
429	PHYPay	/load:				•			
			MHDR	MACPayload	MIC				
430				or		•			
			MHDR	Join-Request or Rejoin-Request	MIC				
431				or					
			MHDR	Join-A	ccept <sup>2</sup>				
432			Figure	6: PHY payload st	ructure				
433	MACPa	yload:				•			
			FHDR	FPort	FRMPayload				
434			Figure	7: MAC payload st	ructure				
435	FHDR:								
		DevAddr	FCtrl	FCnt	FO	pts			
436						•			

# 4.1 MAC Layer (PHYPayload)

 Size (bytes)
 1
 7..M
 4

 PHYPayload
 MHDR
 MACPayload
 MIC

 Figure 9: PHY paylod format

<sup>1</sup> Maximum payload size is detailed in the Chapter 6.

-

437

438

<sup>&</sup>lt;sup>2</sup> For Join-Accept frame, the MIC field is encrypted with the payload and is not a separate field



The maximum length (*M*) of the **MACPayload** field is region specific and is specified in Chapter 6.

442

440

441

443

444

# 4.2 MAC Header (MHDR field)

Bit#	75	42	10
MHDR bits	MType	RFU	Major

Figure 10: MAC header field content

446

445

440

450

451

452 453

The MAC header specifies the message type (**MType**) and according to which major version (**Major**) of the frame format of the LoRaWAN layer specification the frame has been encoded.

# 4.2.1 Message type (MType bit field)

The LoRaWAN distinguishes between 8 different MAC message types: **Join-request, Rejoin-request, Join-accept**, **unconfirmed data up/down**, and **confirmed data up/down** and **proprietary** protocol messages.

MType	Description
000	Join-request
001	Join-accept
010	Unconfirmed Data Up
011	Unconfirmed Data Down
100	Confirmed Data Up
101	Confirmed Data Down
110	Rejoin-request
111	Proprietary

Table 1: MAC message types

454

455

458

459

460

461 462

463

#### 4.2.1.1 Join-request and join-accept messages

The join-request, Rejoin-request and join-accept messages are used by the over-the-air activation procedure described in Chapter 6.2 and for roaming purposes.

#### 4.2.1.2 Data messages

Data messages are used to transfer both MAC commands and application data, which can be combined together in a single message. A **confirmed-data message** MUST be acknowledged by the receiver, whereas an **unconfirmed-data message** does not require an acknowledgment. Proprietary messages can be used to implement non-standard message formats that are not interoperable with standard messages but must only be used

.

<sup>&</sup>lt;sup>1</sup> A detailed timing diagram of the acknowledge mechanism is given in Section 19.



among devices that have a common understanding of the proprietary extensions. When an end-device or a Network Server receives an unknown proprietary message, it SHALL silently drop it.

Message integrity is ensured in different ways for different message types and is described per message type below.

### 4.2.2 Major version of data message (Major bit field)

Major bits	Description
00	LoRaWAN R1
0111	RFU

**Table 2: Major list** 

**Note:** The Major version specifies the format of the messages exchanged in the join procedure (see Chapter 6.2) and the first four bytes of the MAC Payload as described in Chapter 4. For each major version, end-devices may implement different minor versions of the frame format. The minor version used by an end-device must be made known to the Network Server beforehand using out of band messages (e.g., as part of the device personalization information). When a device or a Network Server receives a frame carrying an unknown or unsupported version of LoRaWAN, it SHALL silently drop it.

# 4.3 MAC Payload of Data Messages (MACPayload)

The MAC payload of the data messages, contains a frame header (**FHDR**) followed by an optional port field (**FPort**) and an optional frame payload field (**FRMPayload**).

A frame with a valid FHDR, no Fopts (FoptsLen = 0), no Fport and no FRMPayload is a valid frame.

## 4.3.1 Frame header (FHDR)

The **FHDR** contains the short device address of the end-device (**DevAddr**), a frame control octet (**FCtrl**), a 2-octets frame counter (**FCnt**), and up to 15 octets of frame options (**FOpts**) used to transport MAC commands. If present, the FOpts field shall be encrypted using the NwkSEncKey as described in section 4.3.1.6.

 Size (bytes)
 4
 1
 2
 0..15

 FHDR
 DevAddr
 FCtrl
 FCnt
 FOpts

Figure 11 : Frame header format

For downlink frames the FCtrl content of the frame header is:

Bit#	7	6	5	4	[30]
------	---	---	---	---	------



	FCtrl bits	ADR	RFU	ACK	FPending	FOptsLen					
497		Figure 12 : downlink FCtrl fields									
498	For uplink frames the FCtrl content of the frame header is:										
	Bit#	7	6	5	4	[30]					
	FCtrl bits	ADR	ADRACKReq	ACK	ClassB	FOptsLen					
499			Figure 13 : upl	ink FCtrl fields							

500

501

502

503 504

505

506

507

508

509

510

511

512

513 514

515

516

517

518

519

520

521

522

523

524 525

## 4.3.1.1 Adaptive data rate control in frame header (ADR, ADRACKReg in FCtrl)

LoRa network allows the end-devices to individually use any of the possible data rates and Tx power. This feature is used by the LoRaWAN to adapt and optimize the data rate and Tx power of static end-devices. This is referred to as Adaptive Data Rate (ADR) and when this is enabled the network will be optimized to use the fastest data rate possible.

Adaptive Data Rate control may not be possible when the radio channel attenuation changes fast and constantly. When the Network Server is unable to control the data rate of a device, the device's application layer should control it. It is recommended to use a variety of different data rates in this case. The application layer SHOULD always try to minimize the aggregated air time used given the network conditions.

If the uplink ADR bit is set, the network will control the data rate and Tx power of the enddevice through the appropriate MAC commands. If the ADR bit is not set, the network will not attempt to control the data rate nor the transmit power of the end-device regardless of the received signal quality. The network MAY still send commands to change the Channel mask or the frame repetition parameters.

When the downlink ADR bit is set, it informs the end-device that the Network Server is in a position to send ADR commands. The device MAY set/unset the uplink ADR bit.

When the downlink ADR bit is unset, it signals the end-device that due to rapid changes of the radio channel, the network temporarily cannot estimate the best data rate. In that case the device has the choice to either

- unset the ADR uplink bit, and control its uplink data rate following its own strategy. This SHOULD be the typical strategy for a mobile end-device.
- Ignore it (keep the uplink ADR bit set) and apply the normal data rate decay in the absence of ADR downlink commands. This SHOULD be the typical strategy for a stationary end-device.

526 527

528

529

530

531

The ADR bit may be set and unset by the end-device or the Network on demand. However, whenever possible, the ADR scheme SHOULD be enabled to increase the battery life of the end-device and maximize the network capacity.

532 533

**Note:** Even mobile end-devices are actually immobile most of the time. So depending on its state of mobility, an end-device can request the network to optimize its data rate using the ADR uplink bit.



535

536

537

538

539 540

541

542

543 544

545 546

547

548

549

550

551

552 553

554 555

556

557

558 559 560

561

562

563

564 565

566 567

568

569

Default Tx Power is the maximum transmission power allowed for the device considering device capabilities and regional regulatory constraints. Device shall use this power level, until the network asks for less, through the LinkADRReq MAC command.

If an end-device's data rate is optimized by the network to use a data rate higher than its default data rate, or a TXPower lower than its default TXPower, it periodically needs to validate that the network still receives the uplink frames. Each time the uplink frame counter is incremented (for each new uplink, repeated transmissions do not increase the counter), the device increments an ADR ACK CNT counter. After ADR ACK LIMIT uplinks (ADR\_ACK\_CNT >= ADR\_ACK\_LIMIT) without any downlink response, it sets the ADR acknowledgment request bit (ADRACKReq). The network is required to respond with a downlink frame within the next ADR ACK DELAY frames, any received downlink frame following an uplink frame resets the ADR ACK CNT counter. The downlink ACK bit does not need to be set as any response during the receive slot of the end-device indicates that the gateway has still received the uplinks from this device. If no reply is received within the ADR\_ACK\_DELAY uplinks (i.e., after а total of ADR\_ACK\_LIMIT ADR\_ACK\_DELAY), the end-device MUST try to regain connectivity by first stepping up the transmit power to default power if possible then switching to the next lower data rate that provides a longer radio range. The end-device MUST further lower its data rate step by step every time ADR ACK DELAY is reached. Once the device has reached the lowest data rate, it MUST re-enable all default uplink frequency channels.

The **ADRACKReq** SHALL not be set if the device uses its default data rate and transmit power because in that case no action can be taken to improve the link range.

**Note:** Not requesting an immediate response to an ADR acknowledgement request provides flexibility to the network to optimally schedule its downlinks.

**Note:** In uplink transmissions the **ADRACKReq** bit is set if ADR\_ACK\_CNT >= ADR\_ACK\_LIMIT and the current data-rate is greater than the device defined minimum data rate or its transmit power is lower than the default, or the current channel mask only uses a subset of all the default channels. It is cleared in other conditions.

The following table provides an example of data rate back-off sequence assuming ADR\_ACK\_LIMIT and ADR\_ACK\_DELAY constants are both equal to 32.

ADR_ACK_CNT	ADRACKReq bit	Data Rate	TX power	Channel Mask
0 to 63	0	SF11	Max – 9dBm	Single channel
				enabled
64 to 95	1	Keep	Keep	Keep
96 to 127	1	Keep	Max	Keep
128 to 159	1	SF12	Max	Keep
>= 160	0	SF12	MAX	All channels
				enabled

Figure 14: data rate back-off sequence example



#### 572 4.3.1.2 Message acknowledge bit and acknowledgement procedure (ACK in FCtrl)

573 When receiving a confirmed data message, the receiver SHALL respond with a data frame that has the acknowledgment bit (ACK) set. If the sender is an end-device, the network will 574 try to send the acknowledgement using one of the receive windows opened by the end-575 576 device after the send operation. If the sender is a gateway, the end-device transmits an acknowledgment at its own discretion (see note below). 577

An acknowledgement is only sent in response to the latest message received and it is never retransmitted.

580 581

582

583 584

585

586

587

588

589

590

591

578

579

**Note:** To allow the end-devices to be as simple as possible and have as few states as possible it may transmit an explicit (possibly empty) acknowledgement data message immediately after the reception of a data message requiring a confirmation. Alternatively the end-device may defer the transmission of an acknowledgement to piggyback it with its next data message.

## 4.3.1.3 Retransmission procedure

#### Downlink frames:

A downlink "confirmed" or "unconfirmed" frame SHALL not be retransmitted using the same frame counter value. In the case of a "confirmed" downlink, if the acknowledge is not received, the application server is notified and may decide to retransmit a new "confirmed" frame.

592 593 594

595

596 597

598

599

600

601

611

613

#### **Uplink frames:**

Uplink "confirmed" & "unconfirmed" frames are transmitted "NbTrans" times (see 5.3) except if a valid downlink is received following one of the transmissions. The "NbTrans" parameter can be used by the network manager to control the redundancy of the node uplinks to obtain a given Quality of Service. The end-device SHALL perform frequency hopping as usual between repeated transmissions, It SHALL wait after each repetition until the receive windows have expired. The delay between the retransmissions is at the discretion of the end-device and MAY be different for each end-device.

- 602 The device SHALL stop any further retransmission of an uplink "confirmed" frame if a corresponding downlink acknowledgement frame is received 603
- 604 Class B&C devices SHALL stop any further retransmission of an uplink "unconfirmed" frame 605 whenever a valid unicast downlink message is received during the RX1 slot window.
- 606 Class A devices SHALL stop any further retransmission of an uplink "unconfirmed" frame 607 whenever a valid downlink message is received during the RX1 or the RX2 slot window.
- 608 If the network receives more than NbTrans transmissions of the same uplink frame, this may 609 be an indication of a replay attack or a malfunctioning device, and therefore the network 610 SHALL not process the extra frames.

NOTE: The network detecting a replay attack may take additional 612 measures, such as reducing the NbTrans parameter to 1, or discarding uplink frames that are received over a channel that was already used



614 by an earlier transmission of the same frame, or by some other 615 unspecified mechanism 616 4.3.1.4 Frame pending bit (FPending in FCtrl, downlink only) 617 The frame pending bit (FPending) is only used in downlink communication, indicating that the network has more data pending to be sent and therefore asking the end-device to open 618 619 another receive window as soon as possible by sending another uplink message. 620 The exact use of **FPending** bit is described in Chapter 19.3. 621 4.3.1.5 Frame counter (FCnt) 622 Each end-device has three frame counters to keep track of the number of data frames sent 623 uplink to the Network Server (FCntUp), and sent downlink from the Network Server to the 624 device (FCntDown). 625 In the downlink direction two different frame counter scheme exists; a single counter scheme 626 in which all ports share the same downlink frame counter FCntDown when the device 627 operates as a LoRaWAN1.0 device, and a two-counter scheme in which a separate NFCntDown is used for MAC communication on port 0 and when the FPort field is missing. 628 629 and another AFCntDown is used for all other ports when the device operates as a LoRaWAN1.1 device. 630 631 In the two counters scheme the NFCntDown is managed by the Network Server, whereas the AFCntDown is managed by the application server. 632 633 Note: LoRaWAN v1.0 and earlier support only one FCntDown counter (shared across all ports) and the Network Server must take care to 634 635 support this scheme for devices prior to LoRaWAN v1.1.



638 639

640

641

642 643

644

645

646

647

648

649

650

651

652

654

655

659

660

661

662

663

664

Whenever an OTAA device successfully processes a Join-accept message, the frame counters on the end-device (FCntUp) and the frame counters on the network side (NFCntDown & AFCntDown) for that end-device are reset to 0.

ABP devices have their Frame Counters initialized to 0 at fabrication. In ABP devices the frame counters MUST NEVER be reset during the device's life time. If the end-device is susceptible of losing power during its life time (battery replacement for example), the frame counters SHALL persist during such event.

Subsequently FCntUp is incremented with each uplink. NFCntDown is incremented with each downlink on FPort 0 or when the FPort field is missing. AFCntDown is incremented with each downlink on a port different than 0. At the receiver side, the corresponding counter is kept in sync with the value received provided the value received has been incremented compared to the current counter value and the message MIC field matches the MIC value computed locally using the appropriate network session key. The FCnt is not incremented in case of multiple transmissions of a confirmed or unconfirmed frame (see NbTrans parameter). The Network Server SHALL drop the application payload of the retransmitted frames and only forward a single instance to the application server.

653 Frame counters are 32 bits wide, The FCnt field corresponds to the least-significant 16 bits of the 32-bits frame counter (i.e., FCntUp for data frames sent uplink and AFCntDown/NFCntDown for data frames sent downlink).

656 The end-device SHALL NEVER reuse the same FCntUp value with the same application or network session keys, except for retransmission of the same confirmed or unconfirmed 657 658 frame.

The end-device SHALL never process any retransmission of the same downlink frame. Subsequent retransmissions SHALL be ignored without being processed.

> **Note:** This means that the device will only acknowledge once the reception of a downlink confirmed frame, similarly the device will only generate a single uplink following the reception of a frame with the FPending bit set.

665 666

667

668

Note: Since the FCnt field carries only the least-significant 16 bits of the 32-bits frame counter, the server must infer the 16 most-significant bits of the frame counter from the observation of the traffic.



#### 4.3.1.6 Frame options (FOptsLen in FCtrl, FOpts)

- The frame-options length field (**FOptsLen**) in **FCtrl** byte denotes the actual length of the frame options field (**FOpts**) included in the frame.
- FOpts transport MAC commands of a maximum length of 15 octets that are piggybacked onto data frames; see Chapter 5 for a list of valid MAC commands.
- If **FOptsLen** is 0, the **FOpts** field is absent. If **FOptsLen** is different from 0, i.e. if MAC commands are present in the **FOpts** field, the port 0 cannot be used (**FPort** must be either
- not present or different from 0).
- 677 MAC commands cannot be simultaneously present in the payload field and the frame 678 options field. Should this occur, the device SHALL ignore the frame.
- If a frame header carries **FOpts**, **FOpts** MUST be encrypted before the message integrity code (**MIC**) is calculated.
- The encryption scheme used is based on the generic algorithm described in IEEE 802.15.4/2006 Annex B [IEEE802154] using AES with a key length of 128 bits.
- The key *K* used is the NwkSEncKey for FOpts field in both the uplink and downlink direction.
- The fields encrypted are: pld = FOpts

686

687

692

693

694

695

699

700

701

702 703

For each message, the algorithm defines a single Block **A**:

Size (bytes)	1	4	1	4	4	1	1
A	0x01	4 x 0x00	Dir	DevAddr	FCntUp or NFCntDwn	0x00	0x00

Figure 15: Encryption block format

- The direction field (**Dir**) is 0 for uplink frames and 1 for downlink frames.
- The block *A* is encrypted to get a block *S*: 690

S =  $aes128_encrypt(K, A)$ 

Encryption and decryption of the **FOpts** is done by truncating (*pld* | pad<sub>16</sub>) xor S to the first len(*pld*) octets.

#### 4.3.1.7 Class B

The Class B bit set to 1 in an uplink signals the Network Server that the device as switched to Class B mode and is now ready to receive scheduled downlink pings. Please refer to the Class B section of the document for the Class B specification.

### 4.3.2 Port field (FPort)

If the frame payload field is not empty, the port field MUST be present. If present, an **FPort** value of 0 indicates that the **FRMPayload** contains MAC commands only and any received frames with such an FPort shall be processed by the LoRaWAN implementation; see



Chapter 5 for a list of valid MAC commands. **FPort** values 1..223 (0x01..0xDF) are application-specific and any received frames with such an FPort SHALL be made available to the application layer by the LoRaWAN implementation. FPort value 224 is dedicated to LoRaWAN MAC layer test protocol. LoRaWAN implementation SHALL discard any transmission request from the application layer where the FPort value is not in the 1..224 range.

Note: The purpose of FPort value 224 is to provide a dedicated FPort to run MAC compliance test scenarios over-the-air on final versions of devices, without having to rely on specific test versions of devices for practical aspects. The test is not supposed to be simultaneous with live operations, but the MAC layer implementation of the device shall be exactly the one used for the normal application. The test protocol is normally encrypted using the AppSKey. This ensures that the Network Server cannot enable the device's test mode without involving the device's owner. If the test runs on a live network connected device, the way the test application on the network side learns the AppSKey is outside of the scope of the LoRaWAN specification. If the test runs using OTAA on a dedicated test bench (not a live network), the way the AppKey is communicated to the test bench, for secured JOIN process, is also outside of the scope of the specification.

The test protocol, running at application layer, is defined outside of the LoRaWAN spec, as it is an application layer protocol.

**FPort** values 225..255 (0xE1..0xFF) are reserved for future standardized application extensions.

Size (bytes)	722	01	0 <i>N</i>
MACPayload	FHDR	FPort	FRMPayload

Figure 16: MACPayload field size

*N* is the number of octets of the application payload. The valid range for *N* is region specific and is defined in [PHY].

735 N MUST be equal or smaller than:

 $N \le M - 1$  - (length of **FHDR** in octets)

where *M* is the maximum MAC payload length.

## 4.3.3 MAC Frame Payload Encryption (FRMPayload)

If a data frame carries a payload, **FRMPayload** MUST be encrypted before the message integrity code (**MIC**) is calculated.

The encryption scheme used is based on the generic algorithm described in IEEE 802.15.4/2006 Annex B [IEEE802154] using AES with a key length of 128 bits.

743 The key *K* used depends on the FPort of the data message:

FPort Direction K



0	Uplink/downlink	NwkSEncKey
1255	Uplink/downlink	AppSKey

**Table 3: FPort list** 

746 The fields encrypted are:

745

747

748 749

750

751

753

758

761

762

764 765

767

769

pld = FRMPayload

For each data message, the algorithm defines a sequence of Blocks  $A_i$  for i = 1..k with k = ceil(len(pld) / 16):

Size (bytes)	1	4	1	4	4	1	1
$A_i$	0x01	4 x 0x00	Dir	DevAddr	FCntUp or NFCntDwn or AFCntDnw	0x00	i

Figure 17: Encryption block format

The direction field (**Dir**) is 0 for uplink frames and 1 for downlink frames.

The blocks  $A_i$  are encrypted to get a sequence S of blocks  $S_i$ :

754
755  $S_i = aes128\_encrypt(K, A_i) \text{ for } i = 1..k$ 756  $S = S_1 \mid S_2 \mid ... \mid S_k$ 

757 Encryption and decryption of the payload is done by truncating

759 (*pld* | pad<sub>16</sub>) xor S

760 to the first len(pld) octets.

# 4.4 Message Integrity Code (MIC)

The message integrity code (**MIC**) is calculated over all the fields in the message.

msg = MHDR | FHDR | FPort | FRMPayload

whereby len(*msg*) denotes the length of the message in octets.

## 4.4.1 Downlink frames

768 The **MIC** of a downlink frame is calculated as follows [RFC4493]:

770  $cmac = aes128\_cmac(SNwkSIntKey, B_0 | msg)$ 

771 **MIC** = cmac[0..3] 772



773 whereby the block  $B_0$  is defined as follows:

Size (bytes)	1	2	2	1	4	4	1	1
$B_{\theta}$	0x49	ConfFCnt	2 x 0x00	Dir = 0x01	DevAddr	AFCntDwn or NFCntDwn	0x00	len(msg)

Figure 18: downlink MIC computation block format

If the device is connected to a LoRaWAN1.1 Network Server and the ACK bit of the downlink frame is set, meaning this frame is acknowledging an uplink "confirmed" frame, then ConfFCnt is the frame counter value modulo 2^16 of the "confirmed" uplink frame that is being acknowledged. In all other cases ConfFCnt = 0x0000.

# 4.4.2 Uplink frames

The **MIC** of uplink frames is calculated with the following process:

783 the block  $B_0$  is defined as follows:

Size (bytes)	1	4	1	4	4	1	1
$B_{\theta}$	0x49	0x0000	Dir = 0x00	DevAddr	FCntUp	0x00	len( <i>msg</i> )

Figure 19 : uplink B<sub>0</sub> MIC computation block format

the block  $B_1$  is defined as follows:

Size (bytes)	1	2	1	1	1	4	4	1	1
$B_1$	0x49	ConfFCnt	TxDr	TxCh	Dir = 0x00	DevAddr	FCntUp	0x00	len( <i>msg</i> )

Figure 20: uplink B<sub>1</sub> MIC computation block format

#### 788 Where:

774

775

776 777

778

779

780

781

782

784

785 786

787

789

790

791

792

793

798 799

800

- TxDr is the data rate used for the transmission of the uplink
- TxCh is the index of the channel used for the transmission.
- If the ACK bit of the uplink frame is set, meaning this frame is acknowledging a downlink "confirmed" frame, then ConfFCnt is the frame counter value modulo 2^16 of the "confirmed" downlink frame that is being acknowledged. In all other cases ConfFCnt = 0x0000.

```
cmacS = aes128\_cmac(SNwkSIntKey, B_1 | msg)

cmacF = aes128\_cmac(FNwkSIntKey, B_0 | msg)
```

If the device is connected to a LoRaWAN1.0 Network Server then:

801 **MIC** = cmacF(0...3)



802	
803	

If the device is connected to a LoRaWAN1.1 Network Server then:  $MIC = cmacS[0..1] \mid cmacF[0..1]$ 

804 805



833

834

835

836

837 838

839

#### 5 MAC Commands

- For network administration, a set of MAC commands may be exchanged exclusively between the Network Server and the MAC layer on an end-device. MAC layer commands are never visible to the application or the application server or the application running on the end-device.
- A single data frame can contain any sequence of MAC commands, either piggybacked in the **FOpts** field or, when sent as a separate data frame, in the **FRMPayload** field with the **FPort** field being set to 0. Piggybacked MAC commands are always sent encrypted and must not exceed 15 octets. MAC commands sent as **FRMPayload** are always encrypted and MUST
- 816 NOT exceed the maximum **FRMPayload** length.
- A MAC command consists of a command identifier (**CID**) of 1 octet followed by a possibly empty command-specific sequence of octets.
- 819 MAC Commands are answered/acknowledged by the receiving end in the same order than 820 they are transmitted. The answer to each MAC command is sequentially added to a buffer. 821 All MAC commands received in a single frame must be answered in a single frame, which 822 means that the buffer containing the answers must be sent in one single frame. If the MAC 823 answer's buffer length is greater than the maximum FOpt field, the device MUST send the 824 buffer as FRMPayload on port 0. If the device has both application payload and MAC 825 answers to send and both cannot fit in the frame, the MAC answers SHALL be sent in 826 priority. If the length of the buffer is greater than the max FRMPayload size usable, the 827 device SHALL clip the buffer to the max FRMPayload size before assembling the frame. 828 Therefore the last MAC command answers may be truncated. In all cases the full list of MAC command is executed, even if the buffer containing the MAC answers must be clipped. 829 The Network Server MUST NOT generate a sequence of MAC commands that may not be 830 831 answered by the end-device in one single uplink. The Network Server SHALL compute the 832 max FRMPayload size available for answering MAC commands as follow:
  - If the latest uplink ADR bit is 0: The max payload size corresponding to the lowest data rate MUST be considered
  - If the latest uplink ADR bit is set to 1: The max payload size corresponding to the data rate used for the last uplink of the device MUST be considered

Note: When receiving a clipped MAC answer the Network Server MAY retransmit the MAC commands that could not be answered



CID	Command	Transmitted by		Short Description
		End- device	Gateway	
0x01	ResetInd	Х		Used by an ABP device to indicate a reset to the network and negotiate protocol version
0x01	ResetConf		Х	Acknowledges ResetInd command
0x02	LinkCheckReq	Х		Used by an end-device to validate its connectivity to a network.
0x02	LinkCheckAns		X	Answer to LinkCheckReq command. Contains the received signal power estimation indicating to the end-device the quality of reception (link margin).
0x03	LinkADRReq		х	Requests the end-device to change data rate, transmit power, repetition rate or channel.
0x03	LinkADRAns	Х		Acknowledges the LinkADRReq.
0x04	DutyCycleReq		Х	Sets the maximum aggregated transmit duty-cycle of a device
0x04	DutyCycleAns	Х		Acknowledges a DutyCycleReq command
0x05	RXParamSetupReq		Х	Sets the reception slots parameters
0x05	RXParamSetupAns	Х		Acknowledges a RXParamSetupReq command
0x06	DevStatusReq		Х	Requests the status of the end-device
0x06	DevStatusAns	Х		Returns the status of the end-device, namely its battery level and its demodulation margin
0x07	NewChannelReq		Х	Creates or modifies the definition of a radio channel
0x07	NewChannelAns	Х		Acknowledges a NewChannelReq command
0x08	RXTimingSetupReq		Х	Sets the timing of the of the reception slots
0x08	RXTimingSetupAns	Х		Acknowledges RXTimingSetupReq command
0x09	TxParamSetupReq		Х	Used by the Network Server to set the maximum allowed dwell time and Max EIRP of end-device, based on local regulations
0x09	TxParamSetupAns	Х	.,	Acknowledges TxParamSetupReq command  Modifies the definition of a downlink RX1
0x0A	DIChannelReq		X	radio channel by shifting the downlink frequency from the uplink frequencies (i.e. creating an asymmetric channel)
0x0A	DIChannelAns	Х		Acknowledges DIChannelReq command
0x0B	RekeyInd	Х		Used by an OTA device to signal a security context update (rekeying)
0x0B	RekeyConf		Х	Acknowledges RekeyInd command
0x0C	ADRParamSetupReq		Х	Used by the Network Server to set the ADR_ACK_LIMT and ADR_ACK_DELAY parameters of an end-device
0x0C	ADRParamSetupAns	Х		Acknowledges ADRParamSetupReq command
0x0D	DeviceTimeReq	Х		Used by an end-device to request the current date and time
0x0D	DeviceTimeAns		х	Sent by the network, answer to the DeviceTimeReq request
0x0E	ForceRejoinReq		Х	Sent by the network, ask the device to



CID	Command		mitted y	Short Description
		End- device	Gateway	
				Rejoin immediately with optional periodic retries
0x0F	RejoinParamSetupReq		Х	Used by the network to set periodic device Rejoin messages
0x0F	RejoinParamSetupAns	Х		Acknowledges RejoinParamSetupReq
0x80	Proprietary	Х	Х	Reserved for proprietary network command
to	-			extensions
0xFF				

Table 4: MAC commands

**Note:** In general the end device will only reply one time to any Mac command received. If the answer is lost, the network has to send the command again. The network decides that the command must be resent when it receives a new uplink that doesn't contain the answer. Only the **RxParamSetupReq**, **RxTimingSetupReq** and **DIChannelReq** have a different acknowledgment mechanism described in their relative section, because they impact the downlink parameters.

**Note:** When a MAC command is initiated by the end device, the network makes its best effort to send the acknowledgment/answer in the RX1/RX2 windows immediately following the request. If the answer is not received in that slot, the end device is free to implement any retry mechanism it needs.

**Note:** The length of a MAC command is not explicitly given and must be implicitly known by the MAC implementation. Therefore unknown MAC commands cannot be skipped and the first unknown MAC command terminates the processing of the MAC command sequence. It is therefore advisable to order MAC commands according to the version of the LoRaWAN specification which has introduced a MAC command for the first time. This way all MAC commands up to the version of the LoRaWAN specification implemented can be processed even in the presence of MAC commands specified only in a version of the LoRaWAN specification newer than that implemented.

868

873

874

875

876

877 878

879

880

881

882

883

884

885

886

887

888 889

# 5.1 Reset indication commands (ResetInd, ResetConf)

This MAC command is only available to ABP devices activated on a LoRaWAN1.1 compatible Network Server. LoRaWAN1.0 servers do not implement this MAC command

OTA devices MUST NOT implement this command. The Network Server SHALL ignore the ResetInd command coming from an OTA device.

With the **ResetInd** command, an ABP end-device indicates to the network that it has been re-initialized and that it has switched back to its default MAC & radio parameters (i.e the parameters originally programmed into the device at fabrication except for the three frame counters). The **ResetInd** command MUST be added to the FOpt field of all uplinks until a **ResetConf** is received.

This command does not signal to the Network Server that the downlink frame counters have been reset. The frame counters (both uplink & downlink) SHALL NEVER be reset in ABP devices.

Note: This command is meant for ABP devices whose power might be interrupted at some point (example, battery replacement). The device might lose the MAC layer context stored in RAM (except the Frame Counters that must be stored in an NVM). In that case the device needs a way to convey that context loss to the Network Server. In future versions of the LoRaWAN protocol, that command may also be used to negotiate some protocol options between the device and the Network Server.

The **ResetInd** command includes the minor of the LoRaWAN version supported by the end device.

890 891

Size (bytes) 1

ResetInd Payload Dev LoRaWAN version

892 Figure 21 : ResetInd payload format

Size (bytes)	7:4	3:0
Dev LoRaWAN version	RFU	Minor=1

893 894

895

The minor field indicates the minor of the LoRaWAN version supported by the end-device.

Minor version	Minor
RFU	0
1 (LoRaWAN x.1)	1
RFU	2:15



898 899 When a **ResetInd** is received by the Network Server, it responds with a **ResetConf** command.

The ResetConf command contains a single byte payload encoding the LoRaWAN version supported by the Network Server using the same format than "dev LoRaWAN version".

901

900

902

Size (bytes)	1
ResetConf Payload	Serv LoRaWAN version

903

Figure 22 : ResetConf payload format

The server's version carried by the *ResetConf* must be the same than the device's version.

Any other value is invalid.

If the server's version is invalid the device SHALL discard the **ResetConf** command and retransmit the **ResetInd** in the next uplink frame

907 908

909

906

# 5.2 Link Check commands (LinkCheckReg, LinkCheckAns)

910 With the *LinkCheckReq* command, an end-device may validate its connectivity with the 911 network. The command has no payload.

When a *LinkCheckReq* is received by the Network Server via one or multiple gateways, it responds with a *LinkCheckAns* command.

913 914

912

Size (bytes)	1	1
LinkCheckAns Payload	Margin	GwCnt

915

Figure 23: LinkCheckAns payload format

The demodulation margin (**Margin**) is an 8-bit unsigned integer in the range of 0..254 indicating the link margin in dB of the last successfully received *LinkCheckReq* command. A value of "0" means that the frame was received at the demodulation floor (0 dB or no margin) while a value of "20", for example, means that the frame reached the gateway 20 dB above the demodulation floor. Value "255" is reserved.

The gateway count (**GwCnt**) is the number of gateways that successfully received the last LinkCheckReq command.

# 923 5.3 Link ADR commands (LinkADRReg, LinkADRAns)

With the *LinkADRReq* command, the Network Server requests an end-device to perform a rate adaptation.

925 926

924

Size (bytes)	1	2	1
LinkADRReq Payload	DataRate_TXPower	ChMask	Redundancy

Figure 24 : LinkADRReq payload format

928

D:4-	F= 41	10.01
Bits	[7:4]	[3:0]



DataRate_TXPower	DataRate	TXPower

The requested date rate (**DataRate**) and TX output power (**TXPower**) are region-specific and are encoded as indicated in [PHY]. The TX output power indicated in the command is to be considered the maximum transmit power the device may operate at. An end-device will acknowledge as successful a command which specifies a higher transmit power than it is capable of using and MUST, in that case, operate at its maximum possible power. A value 0xF (15 in decimal format) of either DataRate or TXPower means that the device MUST ignore that field, and keep the current parameter value. The channel mask (**ChMask**) encodes the channels usable for uplink access as follows with bit 0 corresponding to the LSB:

Bit#	Usable channels	
0	Channel 1	
1	Channel 2	
15	Channel 16	

**Table 5: Channel state table** 

A bit in the **ChMask** field set to 1 means that the corresponding channel can be used for uplink transmissions if this channel allows the data rate currently used by the end-device. A bit set to 0 means the corresponding channels should be avoided.

Bits	7	[6:4]	[3:0]
Redundancy bits	RFU	ChMaskCntl	NbTrans

In the Redundancy bits the **NbTrans** field is the number of transmissions for each uplink message. This applies to "confirmed" and "unconfirmed" uplink frames. The default value is 1 corresponding to a single transmission of each frame. The valid range is [1:15]. If **NbTrans**==0 is received the end-device SHALL keep the current NbTrans value unchanged.

The channel mask control (**ChMaskCntl**) field controls the interpretation of the previously defined **ChMask** bit mask. It controls the block of 16 channels to which the **ChMask** applies. It can also be used to globally turn on or off all channels using specific modulation. This field usage is region specific and is defined in [PHY].

The Network Server may include multiple contiguous LinkADRReq commands within a single downlink message. For the purpose of configuring the end-device channel mask, the end-device MUST process all contiguous LinkADRReq messages, in the order present in the downlink message, as a single atomic block command. The Network Server MUST NOT include more than one such atomic block command in a downlink message. The end-device MUST send a single LinkADRAns command to accept or reject an entire ADR atomic command block. If the downlink message carries more than one ADR atomic command block, the end-device SHALL process only the first one and send a NAck (a LinkADRAns command with all Status bits set to 0) in response to all other ADR command block. The device MUST only process the DataRate, TXPower and NbTrans from the last LinkADRReq command in the contiguous ADR command block, as these settings govern the end-device global state for these values. The Channel mask ACK bit of the response MUST reflect the acceptance/rejection of the final channel plan after in-order-processing of **all** the Channel Mask Controls in the contiguous ADR command block.

The channel frequencies are region-specific and they are defined [PHY]. An end-device answers to a *LinkADRReg* with a *LinkADRAns* command.

Size (bytes) 1



LinkADRAns Payload Status

Figure 25: LinkADRAns payload format

971

970

Bits	[7:3]	2	1	0
Status bits	RFU	Power ACK	Data rate ACK	Channel mask
				ACK

972 973 974

975

978

979

980

981 982 The *LinkADRAns* Status bits have the following meaning:

	Bit = 0	Bit = 1
Channel mask ACK	The channel mask sent enables a yet undefined channel or the channel mask required all channels to be disabled. The command was discarded and the enddevice state was not changed.  The channel mask some successfully interpreductive currently defined characteristics were set account to the mask.	
Data rate ACK	The data rate requested is unknown to the end-device or is not possible given the channel mask provided (not supported by any of the enabled channels). The command was discarded and the end-device state was not changed.	The data rate was successfully set or the DataRate field of the request was set to 15, meaning it was ignored
Power ACK	The device is unable to operate at or below the requested power level. The command was discarded and the end-device state was not changed.	The device is able to operate at or below the requested power level, or the TXPower field of the request was set to 15, meaning it shall be ignored

Table 6: LinkADRAns status bits signification

976 If any of those three bits equals 0, the command did not succeed and the node has kept the previous state. 977

# 5.4 End-Device Transmit Duty Cycle (DutyCycleReq, DutyCycleAns)

The **DutyCycleReq** command is used by the network coordinator to limit the maximum aggregated transmit duty cycle of an end-device. The aggregated transmit duty cycle corresponds to the transmit duty cycle over all sub-bands.



984

S	ize (bytes)		1	
DutyCycleReq Payload DutyCyclePL				
Figure 26 : DutyCycleReq payload format				
Bits	7:4		3:0	

MaxDCycle

RFU

985 986

987 988

992

993

994

995

996

997

The maximum end-device transmit duty cycle allowed is:

**DutyCyclePL** 

989 
$$aggregated\ duty\ cycle = \frac{1}{2^{\text{MaxDCycle}}}$$

The valid range for MaxDutyCycle is [0:15]. A value of 0 corresponds to "no duty cycle 990 limitation" except the one set by the regional regulation. 991

An end-device answers to a DutyCycleReq with a DutyCycleAns command. The DutyCycleAns MAC reply does not contain any payload.

# 5.5 Receive Windows Parameters (RXParamSetupReg, RXParamSetupAns)

The RXParamSetupReg command allows a change to the frequency and the data rate set for the second receive window (RX2) following each uplink. The command also allows to program an offset between the uplink and the RX1 slot downlink data rates.

998 999

1000

Size (bytes)	1	3		
RXParamSetupReq Payload	DLsettings	Frequency		
Circura 07 - DVDaram Catum Dara manda ad format				

Figure 27: RXParamSetupReq payload format

Bits	7	6:4	3:0
DLsettings	RFU	RX1DRoffset	RX2DataRate

1001 1002

1003 1004

1005

1006 1007

1008

1009

1010

1011 1012

1013

1014

The RX1DRoffset field sets the offset between the uplink data rate and the downlink data rate used to communicate with the end-device on the first reception slot (RX1). As a default this offset is 0. The offset is used to take into account maximum power density constraints for base stations in some regions and to balance the uplink and downlink radio link margins.

The data rate (RX2DataRate) field defines the data rate of a downlink using the second receive window following the same convention as the LinkADRReq command (0 means DR0/125kHz for example). The frequency (Frequency) field corresponds to the frequency of the channel used for the second receive window, whereby the frequency is coded following the convention defined in the **NewChannelReg** command.

The *RXParamSetupAns* command is used by the end-device to acknowledge the reception of RXParamSetupReg command. The RXParamSetupAns command MUST be added in the FOpt field of all uplinks until a class A downlink is received by the end-device. This guarantees that even in presence of uplink packet loss, the network is always aware of the downlink parameters used by the end-device.

successfully set



1018

1019

1020

1021

1022

1023

1024

1025

1026

1027

1028 1029

1030

1031

1032

1033

1034

1035

1017 The payload contains a single status byte.

Size (bytes)	1
RXParamSetupAns Payload	Status

Figure 28 : RXParamSetupAns payload format

The status (**Status**) bits have the following meaning.

Bits	7:3	2	1	0
Status	RFU	RX1DRoffset	RX2 Data rate	Channel ACK
bits		ACK	ACK	

Bit = 0Bit = 1Channel ACK The frequency requested is RX2 slot channel was not usable by the endsuccessfully set device. RX2DataRate ACK The data rate requested is RX2 slot data rate was unknown to the end-device. successfully set **RX1DRoffset ACK** the uplink/downlink data rate RX1DRoffset was

Table 7: RXParamSetupAns status bits signification

offset for RX1 slot is not in

the allowed range

If either of the 3 bits is equal to 0, the command did not succeed and the previous parameters MUST be kept.

## 5.6 End-Device Status (DevStatusReq, DevStatusAns)

With the **DevStatusReq** command a Network Server may request status information from an end-device. The command has no payload. If a **DevStatusReq** is received by an end-device, it MUST respond with a **DevStatusAns** command.

Size (bytes)	1	1
DevStatusAns Payload	Battery	Margin

Figure 29 : DevStatusAns payload format

The battery level (**Battery**) reported is encoded as follows:

Battery	Description
0	The end-device is connected to an external
	power source.
1254	The battery level, 1 being at minimum and
	254 being at maximum
255	The end-device was not able to measure the
	battery level.

**Table 8: Battery level decoding** 

The margin (**Margin**) is the demodulation signal-to-noise ratio in dB rounded to the nearest integer value for the last successfully received **DevStatusReq** command. It is a signed integer of 6 bits with a minimum value of -32 and a maximum value of 31.

Bits	7:6	5:0
Status	RFU	Margin



# 5.7 Creation / Modification of a Channel (NewChannelReq, NewChannelAns, DIChannelReq, DIChannelAns)

Devices operating in region where a fixed channel plan is defined shall not implement these MAC commands. The commands SHALL not be answered by the device. Please refer to [PHY] for applicable regions.

The **NewChannelReq** command can be used to either modify the parameters of an existing bidirectional channel or to create a new one. The command sets the center frequency of the new channel and the range of uplink data rates usable on this channel:

Size (bytes)	1	3	1
NewChannelReq Payload	ChIndex	Freq	DrRange
Figure 30 : NewChannelReq payload format			

The channel index (**ChIndex**) is the index of the channel being created or modified. Depending on the region and frequency band used, in certain regions ([PHY]) the LoRaWAN specification imposes default channels which must be common to all devices and cannot be modified by the **NewChannelReq** command .If the number of default channels is *N*, the default channels go from 0 to *N*-1, and the acceptable range for **ChIndex** is *N* to 15. A device must be able to handle at least 16 different channel definitions. In certain regions the device may have to store more than 16 channel definitions.

The frequency (**Freq**) field is a 24 bits unsigned integer. The actual channel frequency in Hz is 100 x **Freq** whereby values representing frequencies below 100 MHz are reserved for future use. This allows setting the frequency of a channel anywhere between 100 MHz to 1.67 GHz in 100 Hz steps. A **Freq** value of 0 disables the channel. The end-device MUST check that the frequency is actually allowed by its radio hardware and return an error otherwise.

The data-rate range (**DrRange**) field specifies the uplink data-rate range allowed for this channel. The field is split in two 4-bit indexes:

Bits	7:4	3:0
DrRange	MaxDR	MinDR

Following the convention defined in Section 5.3 the minimum data rate (**MinDR**) subfield designate the lowest uplink data rate allowed on this channel. For example using European regional parameters, 0 designates DR0 / 125 kHz. Similarly, the maximum data rate (**MaxDR**) designates the highest uplink data rate. For example, DrRange = 0x77 means that only 50 kbps GFSK is allowed on a channel and DrRange = 0x50 means that DR0 / 125 kHz to DR5 / 125 kHz are supported.

The newly defined or modified channel is enabled and can immediately be used for communication. The RX1 downlink frequency is set equal to the uplink frequency.

The end-device acknowledges the reception of a **NewChannelReq** by sending back a **NewChannelAns** command. The payload of this message contains the following information:

Size (bytes)	1
NewChannelAns Payload	Status

1077 Figure 31 : NewChannelAns payload format



The status (**Status**) bits have the following meaning:

Bits	7:2	1	0
Status	RFU	Data rate	Channel
		range ok	frequency ok

	Bit = 0	Bit = 1
Data rate range ok	The designated data rate range exceeds the ones currently defined for this end-device	The data rate range is compatible with the possibilities of the end-device
Channel frequency ok	The device cannot use this frequency	The device is able to use this frequency.

Table 9: NewChannelAns status bits signification

If either of those 2 bits equals 0, the command did not succeed and the new channel has not been created.

 The **DiChannelReq** command allows the network to associate a different downlink frequency to the RX1 slot. This command is applicable for all the physical layer specifications supporting the **NewChannelReq** command (for example EU and China physical layers, but not for US or Australia).

The command sets the center frequency used for the downlink RX1 slot, as follows:

Size (bytes)	1	3
DIChannelReq Payload	ChIndex	Freq

Figure 32 : DLChannelReq payload format

 The channel index (Chindex) is the index of the channel whose downlink frequency is modified

 The frequency (**Freq**) field is a 24 bits unsigned integer. The actual downlink frequency in Hz is 100 x **Freq** whereby values representing frequencies below 100 MHz are reserved for future use. The end-device has to check that the frequency is actually allowed by its radio hardware and return an error otherwise.

The end-device acknowledges the reception of a **DIChannelReq** by sending back a **DIChannelAns** command. The **DIChannelAns** command SHALL be added in the FOpt field of all uplinks until a downlink packet is received by the end-device. This guarantees that even in presence of uplink packet loss, the network is always aware of the downlink frequencies used by the end-device.

The payload of this message contains the following information:

Size (bytes)	1
DIChannelAns Payload	Status
Eleura 22 - Di Channal	Ann moule ed formet

Figure 33 : DLChannelAns payload format



1110 The status (**Status**) bits have the following meaning:

Bits	7:2	1	0
Status	RFU	Uplink frequency	Channel
		exists	frequency ok

1111

	Bit = 0	Bit = 1
Channel frequency ok	The device cannot use this frequency	The device is able to use this frequency.
Uplink frequency exists	The uplink frequency is not defined for this channel, the downlink frequency can only be set for a channel that already has a valid uplink frequency	The uplink frequency of the channel is valid

Table 10: DIChannelAns status bits signification

1113

1114

1115

1116

1117

1112

# 5.8 Setting delay between TX and RX (*RXTimingSetupReq*, *RXTimingSetupAns*)

The **RXTimingSetupReq** command allows configuring the delay between the end of the TX uplink and the opening of the first reception slot. The second reception slot opens one second after the first reception slot.

11181119

Size (bytes)	1
RXTimingSetupReq Payload	Settings
Figure 34 · RYTimingSetupReg	navload format

1120 Figure 34 : RXTimingSetupReq payload forma

11211122

The delay (**Delay**) field specifies the delay. The field is split in two 4-bit indexes:

Bits	7:4	3:0
Settings	RFU	Del

1123

The delay is expressed in seconds. **Del** 0 is mapped on 1 s.

11241125

Del	Delay [s]
0	1
1	1
2	2
3	3
15	15

Table 11: RXTimingSetup Delay mapping table

1127

1126

1128 An end device answers **RXTimingSetupReg** with **RXTimingSetupAns** with no payload.

The *RXTimingSetupAns* command should be added in the FOpt field of all uplinks until a class A downlink is received by the end-device. This guarantees that even in presence of



uplink packet loss, the network is always aware of the downlink parameters used by the enddevice.

1133

1134

1135

# 5.9 End-device transmission parameters (*TxParamSetupReq, TxParamSetupAns*)

1136 This MAC command only needs to be implemented for compliance in certain regulatory regions. Please refer to [PHY].

The *TxParamSetupReq* command can be used to notify the end-device of the maximum allowed dwell time, i.e. the maximum continuous transmission time of a packet over the air, as well as the maximum allowed end-device Effective Isotropic Radiated Power (EIRP).

1140 1141 1142

1143 1144

1138

1139




Figure 35: TxParamSetupReq payload format

1145 The structure of EIRP DwellTime field is described below:

Bits	7:6	5	4	3:0
MaxDwellTime	RFU	DownlinkDwellTime	UplinkDwellTime	MaxEIRP

1146 1147

Bits [0...3] of *TxParamSetupReq* command are used to encode the Max EIRP value, as per the following table. The EIRP values in this table are chosen in a way that covers a wide range of max EIRP limits imposed by the different regional regulations.

11491150

1148

Coded Value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Max EIRP (dBm)	8	10	12	13	14	16	18	20	21	24	26	27	29	30	33	36

1151

Table 12: TxParamSetup EIRP encoding table

1152 1153 The maximum EIRP corresponds to an upper bound on the device's radio transmit power. The device is not required to transmit at that power, but shall never radiate more that this specified EIRP.

1155 1156

1154

Bits 4 and 5 define the maximum uplink and downlink dwell time respectively, which is encoded as per the following table:

Coded Value	Dwell Time
0	No Limit
1	400 ms

1157

When this MAC command is implemented (region specific), the end-device acknowledges the TxParamSetupReq command by sending a *TxParamSetupAns* command. This *TxParamSetupAns* command doesn't contain any payload.

When this MAC command is used in a region where it is not required, the device does not process it and shall not transmit an acknowledgement.



1164

# 5.10 Rekey indication commands (RekeyInd, RekeyConf)

This MAC command is only available to OTA devices activated on a LoRaWAN1.1 compatible Network Server. LoRaWAN1.0 servers do not implement this MAC command.

1167 ABP devices MUST NOT implement this command. The Network Server SHALL ignore the 1168 **RekeyInd** command coming from an ABP device.

For OTA devices the *RekeyInd* MAC command is used to confirm security key update and in future versions of LoRaWAN (>1.1) to negotiate the minor LoRaWAN protocol version running between the end-device and the Network Server. The command does not signal a reset of the MAC & radio parameters (see 6.2.3).

The *RekeyInd* command includes the minor of the LoRaWAN version supported by the end device.

1174 1175

1173

Size (bytes) 1

RekeyInd Payload Dev LoRaWAN version

1176 Figure 36 : RekeyInd payload format

1177

Size (bytes)	7:4	3:0
Dev LoRaWAN version	RFU	Minor=1

1178 1179

The minor field indicates the minor of the LoRaWAN version supported by the end-device.

1181

1180

Minor version	Minor
RFU	0
1 (LoRaWAN x.1)	1
RFU	2:15

11821183

1184

1185

1186

1187

1188

1189 1190 OTA devices SHALL send the *RekeyInd* in all confirmed & unconfirmed uplink frames following the successful processing of a Join-accept (new session keys have been derived) until a *RekeyConf* is received. If the device has not received a *RekeyConf* within the first ADR\_ACK\_LIMIT uplinks it SHALL revert to the Join state. *RekeyInd* commands sent by such devices at any later time SHALL be discarded by the Network Server. The Network Server SHALL discard any uplink frames protected with the new security context that are received after the transmission of the **Join-accept** and before the first uplink frame that carries a *RekeyInd* command.

When a **RekeyInd** is received by the Network Server, it responds with a **RekeyConf** command.

The RekeyConf command contains a single byte payload encoding the LoRaWAN version supported by the Network Server using the same format than "dev LoRaWAN version".



1196 Size (bytes) Serv LoRaWAN version RekeyConf Payload 1197 Figure 37: RekeyConf payload format 1198 The server version must be greater than 0 (0 is not allowed), and smaller or equal (<=) to the 1199 device's LoRaWAN version. Therefore for a LoRaWAN1.1 device the only valid value is 1. If 1200 the server's version is invalid the device SHALL discard the RekeyConf command and retransmit the *RekeyInd* in the next uplink frame 1201 1202 5.11 ADR parameters (ADRParamSetupReg, ADRParamSetupAns) 1203 the ADR\_ACK\_LIMIT 1204 The **ADRParamSetupReg** command allows changing and 1205 ADR ACK DELAY parameters defining **ADR** back-off algorithm. The 1206 ADRParamSetupReg command has a single byte payload. 1207 Size (bytes) ADRParamSetupReg Payload **ADRparam** 1208 Figure 38: ADRParamSetupReg payload format 7:4 3:0 **Bits ADR**param Limit exp Delay\_exp 1209 1210 The Limit\_exp field sets the ADR\_ACK\_LIMIT parameter value: 1211 ADR ACK LIMIT = 2^Limit exp 1212 1213 The Limit exp valid range is 0 to 15, corresponding to a range of 1 to 32768 for 1214 ADR\_ACK\_LIMIT 1215 The Delay\_exp field sets the ADR\_ACK\_DELAY parameter value. 1216 1217 ADR ACK DELAY = 2^Delay exp 1218 1219 The Delay\_exp valid range is 0 to 15, corresponding to a range of 1 to 32768 for 1220 ADR\_ACK\_ DELAY 1221 1222 The ADRParamSetupAns command is used by the end-device to acknowledge the 1223 reception of *ADRParamSetupReq* command. The *ADRParamSetupAns* command has no

payload field.

1224



## 5.12 DeviceTime commands (DeviceTimeReq, DeviceTimeAns)

- This MAC command is only available if the device is activated on a LoRaWAN1.1 compatible Network Server. LoRaWAN1.0 servers do not implement this MAC command.
- With the **DeviceTimeReq** command, an end-device may request from the network the current network date and time. The request has no payload.
- With the **DeviceTimeAns** command, the Network Server provides the network date and time to the end device. The time provided is the network time captured at the end of the uplink transmission. The command has a 5 bytes payload defined as follows:

Size (bytes)	4	1
DeviceTimeAns	32-bit unsigned integer : Seconds since	8bits unsigned integer: fractional-
Payload	epoch*	second
		in ½^8 second steps

Figure 39 : DeviceTimeAns payload format

The time provided by the network MUST have a worst case accuracy of +/-100mSec.

1237 1238

1239

1240

1241

1242

1243

1235

1236

1234

1226

(\*) The GPS epoch (i.e Sunday January the 6<sup>th</sup> 1980 at midnight) is used as origin. The "seconds" field is the number of seconds elapsed since the origin. This field is monotonically increasing by 1 every second. To convert this field to UTC time, the leap seconds must be taken into account.

Example: Friday 12<sup>th</sup> of February 2016 at 14:24:31 UTC corresponds to 1139322288 seconds since GPS epoch. As of June 2017, the GPS time is 17seconds ahead of UTC time.

1244 1245

1246

## 5.13 Force Rejoin Command (ForceRejoinReq)

- With the Force Rejoin command, the network asks a device to immediately transmit a Rejoin-Request Type 0 or type 2 message with a programmable number of retries, periodicity and data rate. This RejoinReq uplink may be used by the network to immediately rekey a device or initiate a handover roaming procedure.
- 1251 The command has two bytes of payload.

1252 1253

Bits	15:14	13:11	10:8	7	6:4	3:0
ForceRejoinReq bits	RFU	Period	Max_Retries	RFU	RejoinType	DR

1254 Figure 40 : ForceRejoinReq payload format



- 1256 The parameters are encoded as follow:
- 1257 Period: The delay between retransmissions SHALL be equal to 32 seconds x 2<sup>Period</sup> +
- Rand32, where Rand32 is a pseudo-random number in the [0:32] range.
- 1259 Max\_Retries: The total number of times the device will retry the Rejoin-request.
- 0 : the Rejoin is sent only once (no retry)
- 1: the Rejoin MUST be sent 2 times in total (1 + 1 retry)
- 1262 ...
- 7: the Rejoin MUST be sent 8 times (1 + 7 retries)
- RejoinType: This field specifies the type of Rejoin-request that shall be transmitted by the device.
- 0 or 1 : A Rejoin-request type 0 shall be transmitted
- 2 : A Rejoin-request type 2 shall be transmitted
- 1268 3 to 7 : RFU
- DR: The Rejoin-request frame SHALL be transmitted using the data rate DR. The correspondence between the actual physical modulation data rate and the DR value follows the same convention as the *LinkADRReq* command and is defined for each region in [PHY]
- The command has no answer, as the device MUST send a Rejoin-Request when receiving the command. The first transmission of a RejoinReq message SHALL be done immediately after the reception of the command (but the network may not receive it). If the device receives a new **ForceRejoinReq** command before it has reached the number of
- transmission retries, the device SHALL resume transmission of RejoinReq with the new parameters.
- izii paramet

1278

1279

# 5.14 RejoinParamSetupReq (RejoinParamSetupAns)

- With the RejoinParamSetupReq command, the network may request the device to periodically send a RejoinReq Type 0 message with a programmable periodicity defined as
- 1282 a time or a number of uplinks.
- Both time and count are proposed to cope with devices which may not have time measurement capability. The periodicity specified sets the maximum time or number of
- 1285 uplink between two RejoinReq transmissions. The device MAY send RejoinReq more
- 1286 frequently.

1287

1289

1288 The command has a single byte payload.

Bits	7:4	3:0
RejoinParamSetupReq bits	MaxTimeN	MaxCountN

Figure 41 : RejoinParamSetupReq payload format



The parameters are defined as follow:

1291	
1292 1293	$MaxCountN = C = 0$ to 15. The device MUST send a Rejoin-request type 0 at least every $2^{C+4}$ uplink messages.
1294 1295	MaxTimeN = T = 0 to 15; the device MUST send a Rejoin-request type 0 at least every $2^{T+10}$ seconds.
1296	<ul> <li>T = 0 corresponds to roughly 17 minutes</li> </ul>
1297 1298	• T = 15 is about 1 year
1299	A RejoinReq packet is sent every time one of the 2 conditions (frame Count or Time) is met.
1300 1301	The device MUST implement the uplink count periodicity. Time based periodicity is OPTIONAL. A device that cannot implement time limitation MUST signal it in the answer
1302	The answer has a single byte payload.  Bits Bits 7:1 Bit 0
1303	Status bits RFU TimeOK Figure 42 : RejoinParamSetupAns payload format
1304 1305 1306	If Bit $0 = 1$ , the device has accepted Time and Count limitations, otherwise it only accepts the count limitation.
1307 1308 1309	Note: For devices that have a very low message rate and no time measurement capability, the mechanism to agree on the optimal count limitation is not specified in LoRaWAN.



1310	6 End-Device Activation
1311 1312	To participate in a LoRaWAN network, each end-device has to be personalized and activated.
1313 1314	Activation of an end-device can be achieved in two ways, either via <b>Over-The-Air Activation</b> (OTAA) or via <b>Activation By Personalization</b> (ABP)
1315	6.1 Data Stored in the End-device
1316	6.1.1 Before Activation
1317	6.1.1.1 JoinEUI
1318 1319 1320	The <b>JoinEUI</b> is a global application ID in IEEE EUI64 address space that uniquely identifies the Join Server that is able to assist in the processing of the Join procedure and the session keys derivation.
1321 1322	For OTAA devices, the <b>JoinEUI</b> MUST be stored in the end-device before the Join procedure is executed. The <b>JoinEUI</b> is not required for ABP only end-devices
1323	6.1.1.2 DevEUI
1324 1325	The <b>DevEUI</b> is a global end-device ID in IEEE EUI64 address space that uniquely identifies the end-device.
1326 1327	DevEUI is the recommended unique device identifier by Network Server(s), whatever activation procedure is used, to identify a device roaming across networks.
1328 1329 1330	For OTAA devices, the <b>DevEUI</b> MUST be stored in the end-device before the Join procedure is executed. ABP devices do not need the DevEUI to be stored in the device itself, but it is RECOMMENDED to do so.
1331 1332	<b>Note:</b> It is a recommended practice that the DevEUI should also be available on a device label, for device administration.



#### 6.1.1.3 Device root keys (AppKey & NwkKey)

The NwkKey and AppKey are AES-128 root keys specific to the end-device that are assigned to the end-device during fabrication. Whenever an end-device joins a network via over-the-air activation, the NwkKey is used to derive the FNwkSIntKey, SNwkSIntKey and NwkSEncKey session keys, and AppKey is used to derive the AppSKey session key

1338 1339

1340

1341 1342

1337

1333

1334

1335 1336

**Note:** When working with a v1.1 Network Server, the application session key is derived only from the AppKey, therefore the NwkKey may be surrendered to the network operator to manage the JOIN procedure without enabling the operator to eavesdrop on the application payload data.

1343 1344 1345

1346

1347

Secure provisioning, storage, and usage of root keys NwkKey and AppKey on the enddevice and the backend are intrinsic to the overall security of the solution. These are left to implementation and out of scope of this document. However, elements of this solution may include SE (Secure Elements) and HSM (Hardware Security Modules).

1348 1349 1350

1351

1352

To ensure backward compatibility with LoraWAN 1.0 and earlier Network Servers that do not support two root keys, the end-device MUST default back to the single root key scheme when joining such a network. In that case only the root NwkKey is used. This condition is signaled to the end-device by the "OptNeg" bit (bit 7) of the DLsetting field of the Join-accept message being zero. The end-device in this case MUST

1353 1354  Use the NwkKey to derive both the AppSKey and the FNwkSIntKey session keys as in LoRaWAN1.0 specification.

1355 1356 1357  Set the SNwkSIntKey & NwkSEncKey equal to FNwkSIntKey, the same network session key is effectively used for both uplink and downlink MIC calculation and encryption of MAC payloads according to the LoRaWAN1.0 specification.

1358

- 1359 A NwkKey MUST be stored on an end-device intending to use the OTAA procedure.
- 1360 A NwkKey is not required for ABP only end-devices.
- 1361 An AppKey MUST be stored on an end-device intending to use the OTAA procedure.
- 1362 An Appkey is not required for ABP only end-devices.
- Both the NwkKey and AppKey SHOULD be stored in a way that prevents extraction and reuse by malicious actors.

1365

1366

#### 6.1.1.4 JSIntKey and JSEncKey derivation

1367 1368 For OTA devices two specific lifetime keys are derived from the NwkKey root key:

- JSIntKey is used to MIC Rejoin-Request type 1 messages and Join-Accept answers
- JSEncKey is used to encrypt the Join-Accept triggered by a Rejoin-Request

<sup>1.</sup> Since all end-devices are equipped with unique application and network root keys specific for each end-device, extracting the AppKey/NwkKey from an end-device only compromises this one end-device.



#### 6.1.2 After Activation

After activation, the following additional informations are stored in the end-device: a device address (**DevAddr**), a triplet of network session key (**NwkSEncKey**/ **SNwkSIntKey**/ **FNwkSIntKey**), and an application session key (**AppSKey**).

#### 6.1.2.1 End-device address (DevAddr)

The **DevAddr** consists of 32 bits and identifies the end-device within the current network.

The DevAddr is allocated by the Network Server of the end-device.

1382 Its format is as follows:

1383

1379

1375

Bit#	[3132-N]	[31-N0]
DevAddr bits	AddrPrefix	NwkAddr

Figure 43: DevAddr fields

1385 1386

1384

Where N is an integer in the [7:24] range.

1387 1388

1389 1390

1391

1392 1393

1394

The LoRaWAN protocol supports various network address types with different network address space sizes. The variable size AddrPrefix field is derived from the Network Server's unique identifier **NetID** (see 6.2.3) allocated by the LoRa Alliance with the exception of the AddrPrefix values reserved for experimental/private network. The AddrPrefix field enables the discovery of the Network Server currently managing the end-device during roaming. Devices that do not respect this rule cannot roam between two networks because their home Network Server cannot be found.

The least significant (32-N) bits, the network address (NwkAddr) of the end-device, can be arbitrarily assigned by the network manager.

The following AddrPrefix values may be used by any private/experimental network and will not be allocated by the LoRa Aliance.



Private/experimental network reserved AddrPrefix
N = 7
AddrPrefix = 7'b0000000 or AddrPrefix = 7'b0000001
NwkAddr = 25bits freely allocated by the network manager
Please refer to [BACKEND] for the exact construction of the AddrPrefix field and the definition of the various address classes.
6.1.2.2 Forwarding Network session integrity key (FNwkSIntKey)
The FNwkSIntKey is a network session key specific for the end-device. It is used by the end-device to calculate the MIC or part of the MIC (message integrity code) of all uplink data messages to ensure data integrity as specified in 4.4.
The FNwkSIntKey SHOULD be stored in a way that prevents extraction and re-use by malicious actors.
6.1.2.3 Serving Network session integrity key (SNwkSIntKey)
The SNwkSIntKey is a network session key specific for the end-device. It is used by the end-device to verify the MIC (message integrity code) of all downlink data messages to ensure data integrity and to compute half of the uplink messages MIC.
Note: The uplink MIC calculation relies on two keys (FNwkSIntKey and SNwkSIntKey) in order to allow a forwarding Network Server in a roaming setup to be able to verify only half of the MIC field
When a device connects to a LoRaWAN1.0 Network Server the same key is used for both uplink & downlink MIC calculation as specified in 4.4. In that case SNwkSIntKey takes the same value than FNwkSIntKey.
The SNwkSIntKey SHOULD be stored in a way that prevents extraction and re-use by malicious actors.
6.1.2.4 Network session encryption key (NwkSEncKey)
The NwkSEncKey is a network session key specific to the end-device. It is used to encrypt & decrypt uplink & downlink MAC commands transmitted as payload on port 0 or in the FOpt field. When a device connects to a LoRaWAN1.0 Network Server the same key is used for both MAC payload encryption and MIC calculation. In that case <b>NwkSEncKey</b> takes the same value than <b>FNwkSIntKey</b> .



1430 The NwkSEncKey SHOULD be stored in a way that prevents extraction and re-use by 1431 malicious actors.

#### 6.1.2.5 Application session key (AppSKey)

The AppSKey is an application session key specific for the end-device. It is used by both the application server and the end-device to encrypt and decrypt the payload field of application-specific data messages. Application payloads are end-to-end encrypted between the end-device and the application server, but they are integrity protected only in a hop-by-hop fashion: one hop between the end-device and the Network Server, and the other hop between the Network Server and the application server. That means, a malicious Network Server may be able to alter the content of the data messages in transit, which may even help the Network Server to infer some information about the data by observing the reaction of the application end-points to the altered data. Network Servers are considered as trusted, but applications wishing to implement end-to-end confidentiality and integrity protection MAY use additional end-to-end security solutions, which are beyond the scope of this specification.

The **AppSKey** SHOULD be stored in a way that prevents extraction and re-use by malicious actors.

#### 6.1.2.6 Session Context

1449 Session Context contains Network Session and Application Session.

The Network Session consists of the following state:

- F/SNwkSIntKey
- 1454 NwkSEncKey
- 1455 FCntUp
  - FCntDwn (LW 1.0) or NFCntDwn (LW 1.1)
  - DevAddr

The Application Session consists of the following state:

- AppSKey
- FCntUp
- FCntDown (LW 1.0) or AFCntDwn (LW 1.1)

Network Session state is maintained by the NS and the end-device. Application Session state is maintained by the AS and the end-device.

 Upon completion of either the OTAA or ABP procedure, a new security session context has been established between the NS/AS and the end-device. Keys and the end-device address are fixed for the duration of a session (FNwkSIntKey, SNwkSIntKey, AppSKey, DevAddr). Frame counters increment as frame traffic is exchanged during the session (FCntUp,

1472 FCntDwn, NFCntDwn, AFCntDwn).



For OTAA devices, Frame counters MUST NOT be re-used for a given key, therefore new Session Context MUST be established well before saturation of a frame counter.

1476 1477

1478

1479

It is RECOMMENDED that session state be maintained across power cycling of an enddevice. Failure to do so for OTAA devices means the activation procedure will need to be executed on each power cycling of a device.

1480

1481

1485

1486

1487

1488

1489

1490

1491

1492 1493

1494

### 6.2 Over-the-Air Activation

For over-the-air activation, end-devices must follow a join procedure prior to participating in data exchanges with the Network Server. An end-device has to go through a new join procedure every time it has lost the session context information.

As discussed above, the join procedure requires the end-device to be personalized with the following information before it starts the join procedure: a DevEUI, JoinEUI, NwkKey and AppKey.

**Note:** For over-the-air-activation, end-devices are not personalized with a pair of network session keys. Instead, whenever an end-device joins a network, network session keys specific for that end-device are derived to encrypt and verify transmissions at the network level. This way, roaming of end-devices between networks of different providers is facilitated. Using different network session keys and application session key further allows federated Network Servers in which application data cannot be read by the network provider.

14951496

1497

#### 6.2.1 Join procedure

From an end-device's point of view, the join procedure consists of either a **join or rejoin-**request and a **Join-accept** exchange.

### 6.2.2 Join-request message

The join procedure is always initiated from the end-device by sending a join-request message.

1502 1503

1501

1500

Size (bytes)	8	8	2
Join-request	JoinEUI	DevEUI	DevNonce

1504

1507

1508

1509

1510 1511 Figure 44: Join-request message fields

The join-request message contains the **JoinEUI** and **DevEUI** of the end-device followed by a **nonce** of 2 octets (**DevNonce**).

**DevNonce** is a counter starting at 0 when the device is initially powered up and incremented with every Join-request. A DevNonce value SHALL NEVER be reused for a given JoinEUI value. If the end-device can be power-cycled then DevNonce SHALL be persistent (stored in a non-volatile memory). Resetting DevNonce without changing JoinEUI will cause the Network Server to discard the Join-requests of the device. For each end-device, the



Network Server keeps track of the last **DevNonce** value used by the end-device, and ignores Join-requests if DevNonce is not incremented.

1513 1514 1515

1516 1517

1518 1519

1520

1521

1522 1523

1524

1525 1526

1527

1528

1529 1530

1531

1532 1533

1534

1512

**Note:** This mechanism prevents replay attacks by sending previously recorded join-request messages with the intention of disconnecting the respective end-device from the network. Any time the Network Server processes a Join-Request and generates a Join-accept frame, it shall maintain both the old security context (keys and counters, if any) and the new one until it receives the first successful uplink frame containing the **RekeyInd** command using the new context, after which the old context can be safely removed.

The message integrity code (**MIC**) value (see Chapter 4 for MAC message description) for a join-request message is calculated as follows:<sup>1</sup>

```
cmac = aes128_cmac(NwkKey, MHDR | JoinEUI | DevEUI | DevNonce)
MIC = cmac[0..3]
```

The join-request message is not encrypted. The join-request message can be transmitted using any data rate and following a random frequency hopping sequence across the specified join channels. It is RECOMMENDED to use a plurality of data rates. The intervals between transmissions of **Join-Requests** SHALL respect the condition described in chapter 7. For each transmission of a Join-request, the end-device SHALL increment the DevNonce value.

#### 6.2.3 Join-accept message

1535 The Network Server will respond to the join or rejoin-request message with a join-accept 1536 message if the end-device is permitted to join a network. The join-accept message is sent 1537 JOIN\_ACCEPT DELAY1 normal downlink but uses delavs 1538 JOIN ACCEPT DELAY2 (instead of RECEIVE DELAY1 and RECEIVE DELAY2, 1539 respectively). The channel frequency and data rate used for these two receive windows are 1540 identical to the one used for the RX1 and RX2 receive windows described in the "receive 1541 windows" section of [PHY]

No response is given to the end-device if the Join-request is not accepted.

The join-accept message contains a server nonce (**JoinNonce**) of 3 octets, a network identifier (**NetID**), an end-device address (**DevAddr**), a (**DLSettings**) field providing some of the downlink parameters, the delay between TX and RX (**RxDelay**) and an optional list of network parameters (**CFList**) for the network the end-device is joining. The optional CFList field is region specific and is defined in [PHY].

1547 1548

1543

1544

1545 1546

Size (bytes)	3	3	4	1	1	(16) Optional
Join-accept	JoinNonce	Home_NetID	DevAddr	DLSettings	RxDelay	CFList

Figure 45 : Join-accept message fields

1550 1551

1549

The **JoinNonce** is a device specific counter value (that never repeats itself) provided by the Join Server and used by the end-device to derive the session keys **FNwkSIntKey**,

<sup>1</sup> [RFC4493]



SNwkSIntKey, NwkSEncKey and AppSKey. JoinNonce is incremented with every Joinaccept message.

The device keeps track of the JoinNonce value used in the last successfully processed Join-accept (corresponding to the last successful key derivation). The device SHALL accept the Join-accept only if the MIC field is correct and the JoinNonce is strictly greater than the recorded one. In that case the new JoinNonce value replaces the previously stored one.

1558 If the device is susceptible of being power cycled the JoinNonce SHALL be persistent (stored in a non-volatile memory).

The LoRa Alliance allocates a 24bits unique network identifier (**NetID**) to all networks with the exception of the following **NetID** values reserved for experimental/private networks that are left unmanaged.

There are 2^15 Private /Experimental network reserved NetID values built as follow:

Nb bits	3	14	7
	3'b000	xxxxxxxxxxxx	7'b0000000
		Arbitrary 14bit value	Or 7'b0000001

1564 1565

1566

1563

The **home\_NetID** field of the Join-accept frame corresponds to the **NetId** of the device's home network.

The network that assigns the devAddr and the home network may be different in a roaming scenario. For more precision please refer to [BACKEND].

The **DLsettings** field contains the downlink configuration:

1570

1569

Bits	7	6:4	3:0
DLsettings	OptNeg	RX1DRoffset	RX2 Data rate

1571

1572

1573

1574

1575

1576

1577

The OptNeg bit indicates whether the Network Server implements the LoRaWAN1.0 protocol version (unset) or 1.1 and later (set). When the OptNeg bit is set

- The protocol version is further (1.1 or later) negotiated between the end-device and the Network Server through the RekeyInd/RekeyConf MAC command exchange.
- The device derives FNwkSIntKey & SNwkSIntKey & NwkSEncKey from the NwkKey
- The device derives **AppSKey** from the **AppKey**

1578 1579 1580

1581

1582

1583

When the OptNeg bit is not set

- The device reverts to LoRaWAN1.0, no options can be negotiated
- The *RekeyInd* command is not sent by the device
- The device derives FNwkSIntKey & AppSKey from the NwkKey
- The device sets SNwkSIntKey & NwkSEncKey equal to FNwkSIntKey

1584 1585 1586

The 4 session keys FNwkSIntKey, SNwkSIntKey, NwkSEncKey and AppSKey are derived as follows:



- 1589 If the OptNeg is unset, the session keys are derived from the NwkKey as follow: 1590 AppSKey = aes128 encrypt(NwkKey, 0x02 | JoinNonce | NetID | DevNonce | pad<sub>16</sub><sup>1</sup>) 1591 FNwkSIntKey = aes128 encrypt(NwkKey, 0x01 | JoinNonce | NetID | DevNonce | pad<sub>16</sub>) 1592 SNwkSIntKey = NwkSEncKey = FNwkSIntKey. 1593 1594 The MIC value of the join-accept message is calculated as follows:<sup>2</sup> 1595 cmac = aes128\_cmac(NwkKey, MHDR | JoinNonce | NetID | DevAddr | DLSettings | 1596 RxDelay | CFList ) 1597 MIC = cmac[0..3]1598 1599 1600 Else if the OptNeg is set, the AppSKey is derived from AppKey as follow: 1601 AppSKey = aes128\_encrypt(AppKey, 0x02 | JoinNonce | JoinEUI | DevNonce | pad<sub>16</sub>) 1602 1603 And the network session keys are derived from the NwkKey: 1604 FNwkSIntKey = aes128\_encrypt(NwkKey, 0x01 | JoinNonce | JoinEUI | DevNonce | pad<sub>16</sub>) 1605 SNwkSIntKey = aes128 encrypt(NwkKey, 0x03 | JoinNonce | JoinEUI | DevNonce | pad<sub>16</sub>) NwkSEncKey = aes128\_encrypt(NwkKey, 0x04 | JoinNonce | JoinEUI | DevNonce | pad<sub>16</sub>) 1606 1607 1608 In this case the MIC value is calculated as follows:3 1609 cmac = aes128\_cmac(JSIntKey, 1610 JoinReqType | JoinEUI | DevNonce | MHDR | JoinNonce | NetID | DevAddr | 1611 DLSettings | RxDelay | CFList ) 1612 MIC = cmac[0..3]1613
- 1614 JoinRegType is a single byte field encoding the type of Join-request or Rejoin-request that 1615 triggered the Join-accept response.

Join-request or Rejoin-request type	JoinReqType
	value
Join-request	0xFF
Rejoin-request type 0	0x00
Rejoin-request type 1	0x01
Rejoin-request type 2	0x02

Table 13 : JoinRegType values

The key used to encrypt the Join-Accept message is a function of the Join or ReJoin-Request message that triggered it.

Triggering Join-request or Rejoin-request type	Join-accept Encryption Key
Join-request	NwkKey
Rejoin-request type 0 or 1 or 2	JSEncKey

Table 14: Join-Accept encryption key

1621 The Join-Accept message is encrypted as follows: 1622 aes128\_decrypt(NwkKey or JSEncKey, JoinNonce | NetID | DevAddr | DLSettings | 1623 RxDelay | CFList | MIC). 1624

<sup>1</sup> The pad<sub>16</sub> function appends zero octets so that the length of the data is a multiple of 16

1616

1617

1618

1619

<sup>&</sup>lt;sup>2</sup> [RFC4493]

<sup>&</sup>lt;sup>3</sup> [RFC4493]



1625 The message is either 16 or 32 bytes long.

**Note:** AES decrypt operation in ECB mode is used to encrypt the join-accept message so that the end-device can use an AES encrypt operation to decrypt the message. This way an end-device only has to implement AES encrypt but not AES decrypt.

**Note:** Establishing these four session keys allows for a federated Network Server infrastructure in which network operators are not able to eavesdrop on application data. The application provider commits to the network operator that it will take the charges for any traffic incurred by the end-device and retains full control over the AppSKey used for protecting its application data.

**Note**: The device's protocol version (1.0 or 1.1) is registered on the backend side out-of-band at the same time than the DevEUI and the device's NwkKey and possibly AppKey

The RX1DRoffset field sets the offset between the uplink data rate and the downlink data rate used to communicate with the end-device on the first reception slot (RX1). By default this offset is 0. The offset is used to take into account maximum power density constraints for base stations in some regions and to balance the uplink and downlink radio link margins.

The actual relationship between the uplink and downlink data rate is region specific and detailed in [PHY]

The delay **RxDelay** follows the same convention as the **Delay** field in the **RXTimingSetupReq** command.

If the Join-accept message is received following the transmission of:

- A Join-Request or a Rejoin-request Type 0 or 1 and if the CFlist field is absent, the
  device SHALL revert to its default channel definition. If the CFlist is present, it
  overrides all currently defined channels. The MAC layer parameters (except
  RXdelay1, RX2 data rate, and RX1 DR Offset that are transported by the join-accept
  message) SHALL all be reset to their default values.
- A Rejoin-request Type 2 and if the CFlist field is absent, the device SHALL keep its current channels definition unchanged. If the CFlist is present, it overrides all currently defined channels. All other MAC parameters (except frame counters which are reset) are kept unchanged.

In all cases following the successful processing of a Join-accept message the device SHALL transmit the *RekeyInd* MAC command until it receives the *RekeyConf* command (see 5.9). The reception of the *RekeyInd* uplink command is used by the Network Server as a signal to switch to the new security context.



1673

1674

1675

1676

1677

1678

1679

1680

1681

1682

1683

1684

1685

1686 1687

1688 1689

1690

1691

1692

1693

### 6.2.4 ReJoin-request message

Once activated a device MAY periodically transmit a Rejoin-request message on top of its normal applicative traffic. This Rejoin-request message periodically gives the backend the opportunity to initialize a new session context for the end-device. For this purpose the network replies with a Join-Accept message. This may be used to hand-over a device between two networks or to rekey and/or change devAddr of a device on a given network.

The Network Server may also use the Rejoin-request RX1/RX2 windows to transmit a normal confirmed or unconfirmed downlink frame optionally carrying MAC commands. This possibility is useful to reset the device's reception parameters in case there is a MAC layer state de-synchronization between the device and the Network Server.

Example: This mechanism might be used to change the RX2 window data rate and the RX1 window data rate offset for a device that isn't reachable any more in downlink using the current downlink configuration.

The Rejoin procedure is always initiated from the end-device by sending a Rejoin-request message.

Note: Any time the network backend processes a ReJoin-Request (type 0,1 or 2) and generates a Join-accept message, it shall maintain both the old security context (keys and counters, if any) and the new one until it receives the first successful uplink frame using the new context, after which the old context may be safely discarded. In all cases, the processing of the ReJoin-request message by the network backend is similar to the processing of a standard Join-request message, in that the Network Server initially processing the message determines if it should be forwarded to a Join Server to create a Join-accept message in response.

There are three types of Rejoin-request messages that can be transmitted by an end device and corresponds to three different purposes. The first byte of the Rejoin-request message is called Rejoin Type and is used to encode the type of Rejoin-request. The following table describes the purpose of each Rejoin-Request message type.



RejoinReq type	Content & Purpose
0	Contains NetID+DevEUI. Used to reset a device context including all radio parameters (devAddr, session keys, frame counters, radio parameters,). This message can only be routed to the device's home Network Server by the receiving Network Server, not to the device's JoinServer The MIC of this message can only be verified by the serving or home Network Server.
1	Contains JoinEUI+DevEUI. Exactly equivalent to the initial Join-Request message but may be transmitted on top of normal applicative traffic without disconnecting the device. Can only be routed to the device's JoinServer by the receiving Network Server. Used to restore a lost session context (Example, Network Server has lost the session keys and cannot associate the device to a JoinServer). Only the JoinServer is able to check the MIC of this message.
2	Contains NetID+DevEUI. Used to rekey a device or change its DevAddr (DevAddr, session keys, frame counters). Radio parameters are kept unchanged. This message can only be routed to the device's home Network Server by visited networks, not to the device's Join Server. The MIC of this message can only be verified by the serving or home Network Server.

Table 15: summary of RejoinReg messages

#### 6.2.4.1 ReJoin-request Type 0 or 2 message

1697

1696

1695

Size (bytes)	1	3	8	2
Rejoin-request	Rejoin Type = 0 or 2	NetID	DevEUI	RJcount0

Figure 46: Rejoin-request type 0&2 message fields

1699 1700

1701

1702

1703 1704

1705

1706

1698

The Rejoin-request type 0 or 2 message contains the **NetID** (identifier of the device's home network) and **DevEUI** of the end-device followed by a 16 bits counter (**RJcount0**).

RJcount0 is a counter incremented with every Type 0 or 2 Rejoin frame transmitted. RJcount0 is initialized to 0 each time a Join-Accept is successfully processed by the enddevice. For each end-device, the Network Server MUST keep track of the last RJcount0 value (called RJcount0 last) used by the end-device. It ignores Rejoin-requests if (Rjcount0 <= RJcount0\_last)

RJcount0 SHALL never wrap around. If RJcount0 reaches 2^16-1 the device SHALL stop transmitting ReJoin-request type 0 or 2 frames. The device MAY go back to Join state.

1707 1708 1709

Note: This mechanism prevents replay attacks by sending previously recorded Reioin-request messages

1711 1712

1710

The message integrity code (MIC) value (see Chapter 4 for MAC message description) for a Rejoin-request message is calculated as follows:1

1713 1714

cmac = aes128\_cmac(SNwkSIntKey, MHDR | Rejoin Type | NetID | DevEUI | RJcount0)

1715 1716

MIC = cmac[0..3]

<sup>&</sup>lt;sup>1</sup> [RFC4493]



1717 The Rejoin-request message is not encrypted.

The device's **Rejoin-Req** type 0 or 2 transmissions duty-cycle SHALL always be <0.1%

Note: The Rejoin-Request type 0 message is meant to be transmitted from once per hour to once every few days depending on the device's use case. This message can also be transmitted following a ForceRejoinReq MAC command. This message may be used to reconnect mobile device to a visited network in roaming situations. It can also be used to rekey or change the devAddr of a static device. Mobile devices expected to roam between networks should transmit this message more frequently than static devices.

1726 1727 1728

1729

1730

1731

1732

1733

1734

1735 1736

1718

1719 1720

1721 1722

1723 1724

1725

Note: The Rejoin-Request type 2 message is only meant to enable rekeying of an end-device. This message can only be transmitted following a ForceRejoinReq MAC command.

## 6.2.4.2 ReJoin-request Type 1 message

Similarly to the Join-Request, the Rejoin-Request type 1 message contains the JoinEUI and the DevEUI of the end-device. The Rejoin-Request type 1 message can therefore be routed to the Join Server of the end-device by any Network Server receiving it. The Rejoin-request Type 1 may be used to restore connectivity with an end-device in case of complete state loss of the Network Server. It is recommended to transmit a Rejoin-Request type 1 message a least once per month.

1738 1739

1740

1744

1745

1746

1737

Size (bytes)	1	8	8	2
Rejoin-request	ReJoin Type = 1	JoinEUI	DevEUI	RJcount1

Figure 47: Rejoin-request type 1 message fields

1741 The RJcount1 for Rejoin-request Type 1 is a different counter from the RJCount0 used for 1742 Rejoin-request type 0.

1743 **RJcount1** is a counter incremented with every Rejoin-request Type 1 frame transmitted. For each end-device, the Join Server keeps track of the last RJcount1 value (called RJcount1 last) used by the end-device. It ignores Rejoin-requests if (Rjcount1 <= RJcount1\_last).

1747 RJcount1 SHALL never wrap around for a given JoinEUI. The transmission periodicity of 1748 Rejoin-Request type 1 shall be such that this wrap around cannot happen for the lifetime of 1749 the device for a given JoinEUI value.

1750

1751

1752

1753

**Note:** This mechanism prevents replay attacks by sending previously recorded Rejoin-request messages

The message integrity code (MIC) value (see Chapter 4 for MAC message description) for a Rejoin-request-Type1 message is calculated as follows:1

cmac = aes128\_cmac(JSIntKey, MHDR | RejoinType | JoinEUI| DevEUI | RJcount1)

<sup>&</sup>lt;sup>1</sup> [RFC4493]



1757 MIC = cmac[0..3]

1759 1760

1761

1762

1763 1764

1765

1766

1767 1768

1769 1770

1771

1781

1782

1783

1784

1758 The Rejoin-request-type 1 message is not encrypted.

The device's **Rejoin-Req** type 1 transmissions duty-cycle shall always be **<0.01%** 

Note: The Rejoin-Request type 1 message is meant to be transmitted from once a day to once a week. This message is only used in the case of a complete loss of context of the server side. This event being very unlikely a latency of 1 day to 1 week to reconnect the device is considered as appropriate

#### 6.2.4.3 Rejoin-Request transmissions

The following table summarizes the possible conditions for transmission of each Rejoin-request type message.

RejoinReq	Transmitted autonomously &	Transmitted following a
type	periodically by the end-device	ForceRejoinReq MAC command
0	X	X
1	x	
2		X

Table 16: transmission conditions for RejoinReg messages

- 1772 Rejoin-Request type 0&1 messages SHALL be transmitted on any of the defined Join channels (see [PHY]) following a random frequency hopping sequence.
- 1774 Rejoin-Request type 2 SHALL be transmitted on any of the currently enabled channels following a random frequency hopping sequence.
- 1776 Rejoin-Request type 0 or type 2 transmitted following a **ForceRejoinReq** command SHALL use the data rate specified in the MAC command.
- 1778 Rejoin-Request type 0 transmitted periodically and autonomously by the end-device (with a maximum periodicity set by the RejoinParamSetupReq command) and Rejoin-Request type 1780 1 SHALL use:
  - The data rate & TX power currently used to transmit application payloads if ADR is enabled
    - Any data rate allowed on the Join Channels and default TX power if ADR is disabled.
       In that case it is RECOMMENDED to use a plurality of data rates.



1788

1789

1790

1791

1792 1793

1794 1795

1796

### 1785 6.2.4.4 Rejoin-Request message processing

1786 For all 3 Rejoin-Request types the Network Server may respond with:

- A join-accept message (as defined in 6.2.3) if it wants to modify the device's network identity (roaming or re-keying). In that case RJcount (0 or 1) replaces DevNonce in the key derivation process
  - A normal downlink frame optionally containing MAC commands. This downlink SHALL be sent on the same channel, with the same data rate and the same delay that the Join-accept message it replaces.

In most cases following a ReJoin-Request type 0 or 1 the network will not respond.

## 6.2.5 Key derivation diagram

The following diagrams summarize the key derivation schemes for the cases where a device connects to a LoRaWAN1.0 or 1.1 Network Server.

1801

1802

#### LoRaWAN1.0 network backend:

When a LoRaWAN1.1 device is provisioned with a LoRaWAN1.0.X network backend, all keys are derived from the **NwkKey** root key. The device's **AppKey** is not used.




Figure 48: LoRaWAN1.0 key derivation scheme

#### LoRaWAN1.1 network backend:




Figure 49 : LoRaWAN1.1 key derivation scheme



1828

1829

1830 1831

1832

1833

1834

1835 1836

## 6.3 Activation by Personalization

- Activation by personalization directly ties an end-device to a specific network by-passing the
- 1812 **Join-request Join-accept** procedure.
- 1813 Activating an end-device by personalization means that the **DevAddr** and the four session
- 1814 keys FNwkSIntKey, SNwkSIntKey, NwkSEncKey and AppSKey are directly stored into
- the end-device instead of being derived from the **DevEUI**, **JoinEUI**, **AppKey** and **NwkKey**
- 1816 during the join procedure. The end-device is equipped with the required information for
- participating in a specific LoRa network as soon as it is started.
- 1818 Each device SHALL have a unique set of F/SNwkSIntKey, NwkSEncKey and AppSKey.
- 1819 Compromising the keys of one device SHALL NOT compromise the security of the
- 1820 communications of other devices. The process to build those keys SHALL be such that the
- 1821 keys cannot be derived in any way from publicly available information (like the node address
- or the end-device's devEUI for example).
- 1823 When a personalized end-device accesses the network for the first time or after a re-
- initialization, it SHALL transmit the ResetInd MAC command in the FOpt field of all uplink
- messages until it receives a ResetConf command from the network. After a re-initialization
- the end-device MUST use its default configuration (id the configuration that was used when
- the device was first connected to the network).

**Note:** Frame counter values SHALL only be used once in all invocations of a same key with the CCM\* mode of operation. Therefore, re-initialization of an ABP end-device frame counters is forbidden. ABP devices MUST use a non-volatile memory to store the frame counters.

ABP devices use the same session keys throughout their lifetime (i.e., no rekeying is possible. Therefore, it is recommended that OTAA devices are used for higher security applications.



### 7 Retransmissions back-off

1839 Uplink frames that:

1837 1838

1840

1841

1842 1843

1844 1845

1846

1847 1848

1849

1850 1851

1852 1853

1854 1855

1856

1857

1858

1859 1860

- Require an acknowledgement or an answer by the network or an application server, and are retransmitted by the device if the acknowledgement or answer is not received.
- And can be triggered by an external event causing synchronization across a large (>100) number of devices (power outage, radio jamming, network outage, earthquake...)

can trigger a catastrophic, self-persisting, radio network overload situation.

Note: An example of such uplink frame is typically the Join-request if the implementation of a group of end-devices decides to reset the MAC layer in the case of a network outage.

The whole group of end-device will start broadcasting Join-request uplinks and will only stops when receiving a JoinResponse from the network.

For those frame retransmissions, the interval between the end of the RX2 slot and the next uplink retransmission SHALL be random and follow a different sequence for every device (For example using a pseudo-random generator seeded with the device's address) .The transmission duty-cycle of such message SHALL respect the local regulation and the following limits, whichever is more constraining:

Aggregated during the first hour following power-up or reset	T0 <t<t0+1h< th=""><th>Transmit time 36Sec</th><th>&lt;</th></t<t0+1h<>	Transmit time 36Sec	<
Aggregated during the next 10 hours	T0+1 <t<t0+11h< td=""><td>Transmit time 36Sec</td><td>&lt;</td></t<t0+11h<>	Transmit time 36Sec	<
After the first 11 hours , aggregated over 24h	T0+11+N <t<t0+35+n N&gt;=0</t<t0+35+n 	Transmit time 8.7Sec per 24h	٧

Table 17: Join-request dutycycle limitations



# CLASS B - BEACON



1872

1873

1874

1875

1876

1877

1878 1879

1880

1881

1882 1883

1884 1885

1886

#### 8 Introduction to Class B

- This section describes the LoRaWAN Class B layer which is optimized for battery-powered end-devices that may be either mobile or mounted at a fixed location.
- End-devices should implement Class B operation when there is a requirement to open receive windows at fixed time intervals for the purpose of enabling server initiated downlink messages.
- 1871 LoRaWAN Class B option adds a synchronized reception window on the end-device.
  - One of the limitations of LoRaWAN Class A is the Aloha method of sending data from the end-device; it does not allow for a known reaction time when the customer application or the server wants to address the end-device. The purpose of Class B is to have an end-device available for reception at a predictable time, in addition to the reception windows that follows the random uplink transmission from the end-device of Class A. Class B is achieved by having the gateway sending a beacon on a regular basis to synchronize all end-devices in the network so that the end-device can open a short additional reception window (called "ping slot") at a predictable time during a periodic time slot.

**Note:** The decision to switch from Class A to Class B comes from the application layer of the end-device. If this class A to Class B switch needs to be controlled from the network side, the customer application must use one of the end-device's Class A uplinks to send back a downlink to the application layer, and it needs the application layer on the end-device to recognize this request – this process is not managed at the LoRaWAN level.



# 9 Principle of synchronous network initiated downlink (Class-B option)

For a network to support end-devices of Class B, all gateways must synchronously broadcast a beacon providing a timing reference to the end-devices. Based on this timing reference the end-devices can periodically open receive windows, hereafter called "ping slots", which can be used by the network infrastructure to initiate a downlink communication. A network initiated downlink using one of these ping slots is called a "ping". The gateway chosen to initiate this downlink communication is selected by the Network Server based on the signal quality indicators of the last uplink of the end-device. For this reason, if an end-device moves and detects a change in the identity advertised in the received beacon, it must send an uplink to the Network Server so that the server can update the downlink routing path database.

Before a device can operate in Class B mode, the following informations must be made available to the Network Server out-of-band.

- The device's default ping-slot periodicity
- Default Ping-slot data rate
- Default Ping-slot channel



All end-devices start and join the network as end-devices of Class A. The end-device application can then decide to switch to Class B. This is done through the following process:

- The end-device application requests the LoRaWAN layer to switch to Class B mode.
  The LoRaWAN layer in the end-device searches for a beacon and returns either a
  BEACON\_LOCKED service primitive to the application if a network beacon was
  found and locked or a BEACON\_NOT\_FOUND service primitive. To accelerate the
  beacon discovery the LoRaWAN layer may use the "DeviceTimeReq" MAC
  command.
  - Once in Class B mode, the MAC layer sets to 1 the Class B bit of the FCTRL field of every uplink frame transmitted. This bit signals to the server that the device has switched to Class B. The MAC layer will autonomously schedule a reception slot for each beacon and each ping slot. When the beacon reception is successful the end-device LoRaWAN layer forwards the beacon content to the application together with the measured radio signal strength. The end-device LoRaWAN layer takes into account the maximum possible clock drift in the scheduling of the beacon reception slot and ping slots. When a downlink is successfully demodulated during a ping slot, it is processed similarly to a downlink as described in the LoRaWAN Class A specification.
- A mobile end-device must periodically inform the Network Server of its location to update the downlink route. This is done by transmitting a normal (possibly empty) "unconfirmed" or "confirmed" uplink. The end-device LoRaWAN layer will appropriately set the Class B bit to 1 in the frame's FCtrl field. Optimally this can be done more efficiently if the application detects that the node is moving by analyzing the beacon content. In that case the end-device must apply a random delay (as defined in Section 15.5 between the beacon reception and the uplink transmission to avoid systematic uplink collisions.
- At any time the Network Server may change the device's ping-slot downlink frequency or data rate by sending a PingSlotChannelReg MAC command.
- The device may change the periodicity of its ping-slots at any time. To do so, it MUST temporarily stop class B operation (unset classB bit in its uplink frames) and send a PingSlotInfoReq to the Network Server. Once this command is acknowledged the device may restart classB operation with the new ping-slot periodicity
- If no beacon has been received for a given period (as defined in Section 12.2), the synchronization with the network is lost. The MAC layer must inform the application layer that it has switched back to Class A. As a consequence the end-device LoRaWAN layer stops setting the *Class B* bit in all uplinks and this informs the Network Server that the end-device is no longer in Class B mode. The end-device application can try to switch back to Class B periodically. This will restart this process starting with a beacon search.

The following diagram illustrates the concept of beacon reception slots and ping slots.






Figure 50: Beacon reception slot and ping slots

1946 1947

In this example, given the beacon period is 128 s, the end-device also opens a ping reception slot every 32 s. Most of the time this ping slot is not used by the server and therefore the end-device reception window is closed as soon as the radio transceiver has assessed that no preamble is present on the radio channel. If a preamble is detected the radio transceiver will stay on until the downlink frame is demodulated. The MAC layer will then process the frame, check that its address field matches the end-device address and that the Message Integrity Check is valid before forwarding it to the application layer.



1956

1957

1958 1959

1960

1961

1962 1963 1964

1965 1966

1967

## 10 Uplink frame in Class B mode

The uplink frames in Class B mode are same as the Class A uplinks with the exception of the RFU bit in the FCtrl field in the Frame header. In the Class A uplink this bit is unused (RFU). This bit is used for Class B uplinks.

Bit#	7	6	5	4	30
FCtrl	ADR	ADRACKReq	ACK	Class B	FOptsLen

Figure 51: classB FCtrl fields

The *Class B* bit set to 1 in an uplink signals the Network Server that the device as switched to Class B mode and is now ready to receive scheduled downlink pings.

The signification of the FPending bit for downlink is unaltered and still signals that one or more downlink frames are queued for this device in the server and that the device should keep is receiver on as described in the Class A specification.



1979

1984

1989

1990

1991

1992

1993

1994 1995

## 11 Downlink Ping frame format (Class B option)

### 1969 11.1 Physical frame format

1970 A downlink Ping uses the same format as a Class A downlink frame but might follow a 1971 different channel frequency plan.

## 1972 11.2 Unicast & Multicast MAC messages

- 1973 Messages can be "unicast" or "multicast". Unicast messages are sent to a single end-device
- and multicast messages are sent to multiple end-devices. All devices of a multicast group
- 1975 must share the same multicast address and associated encryption keys. The LoRaWAN
- 1976 Class B specification does not specify means to remotely setup such a multicast group or
- 1977 securely distribute the required multicast key material. This must either be performed during
- the node personalization or through the application layer.

## 11.2.1 Unicast MAC message format

- 1980 The MAC payload of a unicast downlink Ping uses the format defined in the Class A
- 1981 specification. It is processed by the end-device in exactly the same way. The same frame
- 1982 counter is used and incremented whether the downlink uses a Class B ping slot or a Class A
- 1983 "piggy-back" slot.

### 11.2.2 Multicast MAC message format

- 1985 The Multicast frames share most of the unicast frame format with a few exceptions:
- They are not allowed to carry MAC commands, neither in the **FOpt** field, nor in the payload on port 0 because a multicast downlink does not have the same authentication robustness as a unicast frame.
  - The **ACK** and **ADRACKReq** bits must be zero. The **MType** field must carry the value for Unconfirmed Data Down.
  - The FPending bit indicates there is more multicast data to be sent. If it is set the
    next multicast receive slot will carry a data frame. If it is not set the next slot may or
    may not carry data. This bit can be used by end-devices to evaluate priorities for
    conflicting reception slots.

©2017 LoRa Alliance™



2001

2002 2003

20042005

2006

2007

2008

2009

2010 2011

2012

2013

2014

2015

2017

2018

2019

2020

2021

2022

2023

2024

2025

### 12 Beacon acquisition and tracking

Before switching from Class A to Class B, the end-device must first receive one of the network beacons to align his internal timing reference with the network.

Once in Class B, the end-device must periodically search and receive a network beacon to cancel any drift of its internal clock time base, relative to the network timing.

A Class B device may be temporarily unable to receive beacons (out of range from the network gateways, presence of interference, ..). In this event, the end-device has to gradually widen its beacon and ping slots reception windows to take into account a possible drift of its internal clock.

**Note:** For example, a device which internal clock is defined with a +/-10ppm precision may drift by +/-1.3mSec every beacon period.

### 12.1 Minimal beacon-less operation time

In the event of beacon loss, a device shall be capable of maintaining Class B operation for 2 hours (120 minutes) after it received the last beacon. This temporary Class B operation without beacon is called "beacon-less" operation. It relies on the end-device's own clock to keep timing.

During beacon-less operation, unicast, multicast and beacon reception slots must all be progressively expanded to accommodate the end-device's possible clock drift.




Figure 52: beacon-less temporary operation

### 12.2 Extension of beacon-less operation upon reception

During this 120 minutes time interval the reception of any beacon directed to the end-device, should extend the Class B beacon-less operation further by another 120 minutes as it allows to correct any timing drift and reset the receive slots duration.

### 12.3 Minimizing timing drift

The end-devices may use the beacon's (when available) precise periodicity to calibrate their internal clock and therefore reduce the initial clock frequency imprecision. As the timing oscillator's exhibit a predictable temperature frequency shift, the use of a temperature sensor could enable further minimization of the timing drift.




### 13 Class B Downlink slot timing

### 13.1 Definitions

To operate successfully in Class B the end-device must open reception slots at precise instants relative to the infrastructure beacon. This section defines the required timing.

The interval between the start of two successive beacons is called the beacon period. The beacon frame transmission is aligned with the beginning of the BEACON\_RESERVED interval. Each beacon is preceded by a guard time interval where no ping slot can be placed. The length of the guard interval corresponds to the time on air of the longest allowed frame. This is to insure that a downlink initiated during a ping slot just before the guard time will always have time to complete without colliding with the beacon transmission. The usable time interval for ping slot therefore spans from the end of the beacon reserved time interval to the beginning of the next beacon guard interval.



2038 2039

2026

2027

2028

2029

2030

2031

2032 2033

2034

2035 2036

2037

Figure 53: Beacon timing

Beacon_period	128 s
Beacon_reserved	2.120 s
Beacon_guard	3.000 s
Beacon-window	122.880 s

2040

2043 2044

2045

2046

2047

**Table 18: Beacon timing** 

The beacon frame time on air is actually much shorter than the beacon reserved time interval to allow appending network management broadcast frames in the future.

The beacon window interval is divided into  $2^{12} = 4096$  ping slots of 30 ms each numbered from 0 to 4095.

An end-device using the slot number N must turn on its receiver exactly *Ton* seconds after the start of the beacon where:

Ton = beacon reserved + N \* 30 ms



- 2048 N is called the slot index.
- The latest ping slot starts at *beacon\_reserved* + 4095 \* 30 ms = 124 970 ms after the beacon start or 3030 ms before the beginning of the next beacon.

### 2051 13.2 Slot randomization

To avoid systematic collisions or over-hearing problems the slot index is randomized and changed at every beacon period.

2054 The following parameters are used:

2055

DevAddr	Device 32 bit network unicast or multicast address
pingNb	Number of ping slots per beacon period. This must be a power of 2 integer: $pingNb = 2^k$ where $0 \le k \le 7$
pingPeriod	Period of the device receiver wake-up expressed in number of slots: pingPeriod = 2 <sup>12</sup> / pingNb
pingOffset	Randomized offset computed at each beacon period start. Values can range from 0 to (pingPeriod-1)
beaconTime	The time carried in the field <b>BCNPayload</b> . Time of the immediately preceding beacon frame
slotLen	Length of a unit ping slot = 30 ms

Table 19: classB slot randomization algorithm parameters

20562057

2058

2059 2060

2061 2062

2064

2069

2070

2071

2072

At each beacon period the end-device and the server compute a new pseudo-random offset to align the reception slots. An AES encryption with a fixed key of all zeros is used to randomize:

 $Key = 16 \times 0 \times 000$ 

Rand = aes128\_encrypt(Key, beaconTime | DevAddr | pad16)

pingOffset = (Rand[0] + Rand[1]x 256) modulo pingPeriod

2063 The slots used for this beacon period will be:

pingOffset +  $N \times pingPeriod$  with N=[0:pingNb-1]

2065 The node therefore opens receive slots starting at :

First slot	Beacon_reserved + pingOffset x slotLen
Slot 2	Beacon_reserved + (pingOffset + pingPeriod) x slotLen
Slot 3	Beacon_reserved + (pingOffset + 2 x pingPeriod) x slotLen

2066 If the end-device serves simultaneously a unicast and one or more multicast slots this computation is performed multiple times at the beginning of a new beacon period. Once for the unicast address (the node network address) and once for each multicast group address.

In the case where a multicast ping slot and a unicast ping slot collide and cannot be served by the end-device receiver then the end-device should preferentially listen to the multicast slot. If there is a collision between multicast reception slots the FPending bit of the previous multicast frame can be used to set a preference.

The randomization scheme prevents a systematic collision between unicast and multicast slots. If collisions happen during a beacon period then it is unlikely to occur again during the next beacon period.



### 14 Class B MAC commands

All commands described in the Class A specification shall be implemented in Class B devices. The Class B specification adds the following MAC commands.

20782079

2076

2077

CID	Command	Transmitted by		Short Description
		End- device	Gateway	·
0x10	PingSlotInfoReq	х		Used by the end-device to communicate the ping unicast slot periodicity to the Network Server
0x10	PingSlotInfoAns		x	Used by the network to acknowledge a PingInfoSlotReq command
0x11	PingSlotChannelReq		x	Used by the Network Server to set the unicast ping channel of an end-device
0x11	PingSlotChannelAns	Х		Used by the end-device to acknowledge a <b>PingSlotChannelReq</b> command
0x12	BeaconTimingReq	Х		deprecated
0x12	BeaconTimingAns		х	deprecated
0x13	BeaconFreqReq		х	Command used by the Network Server to modify the frequency at which the end-device expects to receive beacon broadcast
0x13	BeaconFreqAns	х		Used by the end-device to acknowledge a BeaconFreqReq command

Table 20: classB MAC command table

# 2080

2081

### 14.1 PingSlotInfoReq

With the *PingSlotInfoReq* command an end-device informs the server of its unicast ping slot periodicity. This command must only be used to inform the server of the periodicity of a UNICAST ping slot. A multicast slot is entirely defined by the application and should not use this command.

2086

Size (bytes)	1	
PingSlotInfoReq Payload	PingSlotParam	
Figure 54 : PingSlotInfoReq payload format		

2087

Bit#	7:3	[2:0]
PingSlotParam	RFU	Periodicity

2088 2089 The **Periodicity** subfield is an unsigned 3 bits integer encoding the ping slot period currently used by the end-device using the following equation.

2090

$$pingNb = 2^{7-Periodicity}$$
 and  $pingPeriod = 2^{5+Periodicity}$ 

2091

The actual ping slot periodicity will be equal to  $0.96 \times 2^{Periodicity}$  in seconds



2095

2101

2104

2105

2120

2122

- **Periodicity** = 0 means that the end-device opens a ping slot approximately every second during the beacon\_window interval
  - **Periodicity** = 7, every 128 seconds which is the maximum ping period supported by the LoRaWAN Class B specification.

To change its ping slot periodicity a device SHALL first revert to Class A, send the new periodicity through a *PingSlotInfoReq* command and get an acknowledge from the server through a *PingSlotInfoAns*. It MAY then switch back to Class B with the new periodicity.

This command MAY be concatenated with any other MAC command in the **FHDRFOpt** field as described in the Class A specification frame format.

### 14.2 BeaconFreqReq

This command is sent by the server to the end-device to modify the frequency on which this end-device expects the beacon.

Octets	3	
BeaconFreqReq payload	Frequency	
Figure FF : Bassan Frag Bas movided format		

Figure 55: BeaconFreqReq payload format

The Frequency coding is identical to the **NewChannelReq** MAC command defined in the Class A.

Frequency is a 24bits unsigned integer. The actual beacon channel frequency in Hz is 100 x frequ. This allows defining the beacon channel anywhere between 100 MHz to 1.67 GHz by 100 Hz step. The end-device has to check that the frequency is actually allowed by its radio hardware and return an error otherwise.

A valid non-zero Frequency will force the device to listen to the beacon on a fixed frequency channel even if the default behavior specifies a frequency hopping beacon (i.e US ISM band).

A value of 0 instructs the end-device to use the default beacon frequency plan as defined in the "Beacon physical layer" section. Where applicable the device resumes frequency hopping beacon search.

Upon reception of this command the end-device answers with a **BeaconFreqAns** message.

The MAC payload of this message contains the following information:

Size (bytes)	1			
BeaconFreqAns payload	Status			
Figure 56 : BeaconFreqAns payload format				

rigaro oo . Boasom roqrano payioaa n

2121 The **Status** bits have the following meaning:

Bi	ts	7:1	0
Statu	ıs	RFU	Beacon frequency ok

Bit = 0

Beacon
frequency ok

Bit = 1

The device cannot use this frequency, the previous beacon frequency is kept

Bit = 1

The beacon frequency has been changed



2124

### 14.3 PingSlotChannelReq

This command is sent by the server to the end-device to modify the frequency and/or the data rate on which the end-device expects the downlink pings.

This command **can only be sent in a class A receive window** (following an uplink). The command SHALL NOT be sent in a class B ping-slot. If the device receives it inside a class B ping-slot, the MAC command SHALL NOT be processed.

2130

2131

Octets	3	1	
PingSlotChannelReq Payload	Frequency	DR	
Figure 57 - DingSlotChannelDag payload format			

Figure 57 : PingSlotChannelReq payload format

The Frequency coding is identical to the **NewChannelReq** MAC command defined in the Class A.

Frequency is a 24bits unsigned integer. The actual ping channel frequency in Hz is 100 x frequ. This allows defining the ping channel anywhere between 100MHz to 1.67GHz by 100Hz step. The end-device has to check that the frequency is actually allowed by its radio hardware and return an error otherwise.

2138 A value of 0 instructs the end-device to use the default frequency plan.

2139 The DR byte contains the following fields:

2140

Bits	7:4	3:0
DR	RFU	data rate

21412142

2143 2144

2145

The "data rate" subfield is the index of the Data Rate used for the ping-slot downlinks. The relationship between the index and the physical data rate is defined in [PHY] for each region.

Upon reception of this command the end-device answers with a *PingSlotFreqAns* message. The MAC payload of this message contains the following information:

2146

Size (bytes)	1	
pingSlotFreqAns Payload	Status	
Figure 58 : PingSlotFregAns payload format		

21472148

The **Status** bits have the following meaning:

Bits	<b>Bits</b> 7:2 1		0	
Status	RFU	Data rate ok	Channel frequency ok	

2149

	Bit = 0	Bit = 1
Data rate ok	The designated data rate is not defined for this end device, the previous data rate is kept	The data rate is compatible with the possibilities of the end device
Channel frequency ok	The device cannot receive on this frequency	This frequency can be used by the end-device



2151 2152 2153 2154	If either of those 2 bits equals 0, the command did not succeed and the ping-slot parameters have not been modified.
2155	14.4 BeaconTimingReq & BeaconTimingAns
2156 2157 2158	These MAC commands are deprecated in the LoRaWAN1.1 version. The device may use DeviceTimeReq&Ans commands as a substitute.



### 15 Beaconing (Class B option)

### 15.1 Beacon physical layer

Besides relaying messages between end-devices and Network Servers, gateways may participate in providing a time-synchronization mechanisms by sending beacons at regular fixed intervals. All beacons are transmitted in radio packet implicit mode, that is, without a LoRa physical header and with no CRC being appended by the radio.

2164 2165

2166

2159

2160

2161

2162

2163

PHY	Preamble	BCNPayload
Et account	FO - because a breakent	£ = = 1

Figure 59 : beacon physical format

The beacon Preamble shall begin with (a longer than default) 10 unmodulated symbols. This allows end-devices to implement a low power duty-cycled beacon search.

The beacon frame length is tightly coupled to the operation of the radio Physical layer.

Therefore the actual frame length and content might change from one region implementation to another. The beacon content, modulation parameters and frequencies to use are specified in [PHY] for each region.

### 15.2 Beacon frame content

The beacon payload **BCNPayload** consists of a network common part and a gateway-specific part.

21752176

2178

2179

2180

2181 2182

21832184

2185

2186

2187

2173

2174

Size (bytes)	2/3	4	2	7	0/1	2
BCNPayload	RFU	Time	CRC	GwSpecific	RFU	CRC

2177 Figure 60 : beacon frame content

The common part contains an RFU field equal to 0, a timestamp **Time** in seconds since 00:00:00, Sunday 6<sup>th</sup> of January 1980 (start of the GPS epoch) modulo 2^32. The integrity of the beacon's network common part is protected by a 16 bits CRC . The CRC-16 is computed on the RFU+Time fields as defined in the IEEE 802.15.4-2003 section 7.2.1.8. This CRC uses the following polynomial  $P(x) = x^{16} + x^{12} + x^5 + x^0$ . The CRC is calculated on the bytes in the order they are sent over-the-air

For example: This is a valid EU868 beacon frame:

00 00 | 00 00 02 CC | A2 7E | 00 | 01 20 00 | 00 81 03 | DE 55

Bytes are transmitted left to right. The first CRC is calculated on [00 00 00 00 00 02 CC]. The corresponding field values are:

2188

2189

Field	RFU	Time	CRC	InfoDesc	lat	long	CRC
Value Hex	0000	CC020000	7EA2	0	002001	038100	55DE

Figure 61: example of beacon CRC calculation (1)



2192

2193 2194

2196

2197

2198

2199

2200

2201

2202

2203 2204

2205

2206

2207

2208

2209 2210

2211

2212

2213

2214

The gateway specific part provides additional information regarding the gateway sending a beacon and therefore may differ for each gateway. The RFU field when applicable (region specific) should be equal to 0. The optional part is protected by a CRC-16 computed on the GwSpecific+RFU fields. The CRC-16 definition is the same as for the mandatory part.

2195

For example: This is a valid US900 beacon:

Field	RFU	Time	CRC	InfoDesc	lat	long	RFU	CRC
Value Hex	000000	CC020000	7E A2	00	002001	038100	00	D450

Figure 62: example of beacon CRC calculation (2)

Over the air the bytes are sent in the following order:

00 00 00 | 00 00 02 CC | A2 7E | 00 | 01 20 00 | 00 81 03 | 00 | 50 D4

Listening and synchronizing to the network common part is sufficient to operate a stationary end-device in Class B mode. A mobile end-device may also demodulate the gateway specific part of the beacon to be able to signal to the Network Server whenever he is moving from one cell to another.

> **Note:** As mentioned before, all gateways participating in the beaconing process send their beacon simultaneously so that for network common part there are no visible on-air collisions for a listening end-device even if the end-device simultaneously receives beacons from several gateways. Not all gateways are required to participate in the beaconing process. The participation of a gateway to a given beacon may be randomized. With respect to the gateway specific part, collision occurs but an end-device within the proximity of more than one gateway will still be able to decode the strongest beacon with high probability.

### 15.3 Beacon GwSpecific field format

The content of the **GwSpecific** field is as follow:

Size (bytes)	1	6
GwSpecific	InfoDesc	Info

Figure 63: beacon GwSpecific field format

2215 The information descriptor InfoDesc describes how the information field Info shall be 2216 interpreted.

2217

InfoDesc	Meaning
0	GPS coordinate of the gateway first
	antenna
1	GPS coordinate of the gateway second
	antenna
2	GPS coordinate of the gateway third
	antenna
3:127	RFU
128:255	Reserved for custom network specific
	broadcasts

2218

2219

2220

Table 21: beacon infoDesc index mapping

For a single omnidirectional antenna gateway the InfoDesc value is 0 when broadcasting GPS coordinates. For a site featuring 3 sectored antennas for example, the first antenna



2226

2229

2230

22312232

2233

2234

2235

2238

2240

2241

2243

2244

2245

2246

2253

2254

broadcasts the beacon with **InfoDesc** equals 0, the second antenna with **InfoDesc** field equals 1, etc.

### 15.3.1 Gateway GPS coordinate:InfoDesc = 0, 1 or 2

For **InfoDesc** = 0 ,1 or 2, the content of the **Info** field encodes the GPS coordinates of the antenna broadcasting the beacon

Size (bytes)	3	3	
Info	Lat	Lng	

Figure 64 : beacon Info field format

The latitude and longitude fields (**Lat** and **Lng**, respectively) encode the geographical location of the gateway as follows:

- The north-south latitude is encoded using a two's complement 24 bit word where -2<sup>23</sup> corresponds to 90° south (the South Pole) and 2<sup>23</sup>-1 corresponds to ~90° north (the North Pole). The Equator corresponds to 0.
- The east-west longitude is encoded using a two's complement 24 bit word where 2<sup>23</sup> corresponds to 180° West and 2<sup>23</sup>-1 corresponds to ~180° East. The Greenwich meridian corresponds to 0.

### 15.4 Beaconing precise timing

The beacon is sent every 128 seconds starting at 00:00:00, Sunday 5<sup>th</sup> – Monday 6<sup>th</sup> of January 1980 (start of the GPS epoch) plus TBeaconDelay. Therefore the beacon is sent at

 $B_T = k * 128 + TBeaconDelay$ 

2239 seconds after the GPS epoch.

wherebyk is the smallest integer for which

k \* 128 > T

2242 whereby

T = seconds since 00:00:00, Sunday 5<sup>th</sup> of January 1980 (start of the GPS time).

**Note:** T is GPS time and unlike Unix time, T is strictly monotonically increasing and is not influenced by leap seconds.

2247 Whereby TBeaconDelay is 1.5 mSec +/- 1uSec delay.

TBeaconDelay is meant to allow a slight transmission delay of the gateways required by the radio system to switch from receive to transmit mode.

All end-devices ping slots use the beacon transmission start time as a timing reference, therefore the Network Server as to take TBeaconDelay into account when scheduling the class B downlinks.

### 15.5 Network downlink route update requirements

When the network attempts to communicate with an end-device using a Class B downlink slot, it transmits the downlink from the gateway which was closest to the end-device when



the last uplink was received. Therefore the Network Server needs to keep track of the rough position of every Class B device.

Whenever a Class B device moves and changes cell, it needs to communicate with the Network Server in order to update its downlink route. This update can be performed simply by sending a "confirmed" or "unconfirmed" uplink, possibly without applicative payload.

The end-device has the choice between 2 basic strategies:

- <u>Systematic periodic uplink</u>: simplest method that doesn't require demodulation of the "gateway specific" field of the beacon. Only applicable to slowly moving or stationery end-devices. There are no requirements on those periodic uplinks.
- Uplink on cell change: The end-device demodulates the "gateway specific" field of
  the beacon, detects that the ID of the gateway broadcasting the beacon it
  demodulates has changed, and sends an uplink. In that case the device SHALL
  respect a pseudo random delay in the [0:120] seconds range between the beacon
  demodulation and the uplink transmission. This is required to insure that the uplinks
  of multiple Class B devices entering or leaving a cell during the same beacon period
  will not systematically occur at the same time immediately after the beacon
  broadcast.

Failure to report cell change will result in Class B downlink being temporary not operational. The Network Server may have to wait for the next end-device uplink to transmit downlink traffic.



2309

### 2279 16 Class B unicast & multicast downlink channel frequencies

- The class B downlink channel selection mechanism depends on the way the class B beacon is being broadcasted.
- 2282 16.1 Single channel beacon transmission
- In certain regions (ex EU868) the beacon is transmitted on a single channel. In that case, all unicast&multicastClass B downlinks use a single frequency channel defined by the
- 2285 "PingSlotChannelReq" MAC command. The default frequency is defined in [PHY].
  - 16.2 Frequency-hopping beacon transmission
- In certain regions (ex US902-928 or CN470-510) the class B beacon is transmitted following a frequency hopping pattern.
- In that case, by default Class B downlinks use a channel which is a function of the Time field of the last beacon (see Beacon Frame content) and the DevAddr.
- 2291 Class B downlink channel =  $\left[ \text{DevAddr} + \text{floor} \left( \frac{\text{Beacon\_Time}}{\text{Beacon period}} \right) \right]$  modulo NbChannel
- Whereby Beacon\_Time is the 32 bit Time field of the current beacon period
- Beacon\_period is the length of the beacon period (defined as 128sec in the specification)
- Floor designates rounding to the immediately lower integer value
- DevAddr is the 32 bits network address of the device
- NbChannel is the number of channel over which the beacon is frequency hopping
- Class B downlinks therefore hop across NbChannel channels (identical to the beacon transmission channels) in the ISM band and all Class B end-devices are equally spread amongst the NbChannel downlink channels.
- If the "*PingSlotChannelReq*" command with a valid non-zero argument is used to set the Class B downlink frequency then all subsequent ping slots should be opened on this single frequency independently of the last beacon frequency.
- 2304 If the "*PingSlotChannelReq*" command with a zero argument is sent, the end-device should resume the default frequency plan, id Class B ping slots hoping across 8 channels.
- The underlying idea is to allow network operators to configure end-devices to use a single proprietary dedicated frequency band for the Class B downlinks if available, and to keep as much frequency diversity as possible when the ISM band is used.



CLASS C - CONTINUOUSLY LISTENING



2322 2323

2324

2325

2326

2327

2328

2329

2330

2331

2332

2336

2337

2338

23392340

2341

2342

23432344

### 17 Class C: Continuously listening end-device

- The end-devices implanting the Class C option are used for applications that have sufficient power available and thus do not need to minimize reception time.
- 2314 Class C end-devices SHALL NOT implement Class B option.
- The Class C end-device will listen with RX2 windows parameters as often as possible. The end-device SHALL listen on RX2 when it is not either (a) sending or (b) receiving on RX1, according to Class A definition. To do so, it MUST open a short window using RX2 parameters between the end of the uplink transmission and the beginning of the RX1 reception window and MUST switch to RX2 reception parameters as soon as the RX1 reception window is closed; the RX2 reception window MUST remain open until the end-device has to send another message.

**Note:** If the device is in the process of demodulating a downlink using the RX2 parameters when the RX1 window should be opened, it shall drop the demodulation and switch to the RX1 receive window

**Note:** There is not specific message for a node to tell the server that it is a Class C node. It is up to the application on server side to know that it manages Class C nodes based on the contract passed during the join procedure.


In case a message is received by a device in Class C mode requiring an uplink transmission (DL MAC command request or DL message in confirmed mode), the device SHALL answer within a time period known by both the end-device and the Network Server (out-of-band provisioning information).

Before this timeout expires, the network SHALL not send any new confirmed message or MAC command to the device. Once this timeout expires or after reception of any uplink message, the network is allowed to send a new DL message.

### 17.1 Second receive window duration for Class C

Class C devices implement the same two receive windows as Class A devices, but they do not close RX2 window until they need to send again. Therefore they may receive a downlink in the RX2 window at nearly any time, including downlinks sent for the purpose of MAC command or ACK transmission. A short listening window on RX2 frequency and data rate is also opened between the end of the transmission and the beginning of the RX1 receive window.





2347

2348

2349

2350

2351

2352

2353

2354

2355

2356

2357 2358

Figure 65: Class C end-device reception slot timing.

### 17.2 Class C Multicast downlinks

Similarly to Class B, Class C devices may receive multicast downlink frames. The multicast address and associated network session key and application session key must come from the application layer. The same limitations apply for Class C multicast downlink frames:

- They SHALL NOT carry MAC commands, neither in the FOpt field, nor in the payload on port 0 because a multicast downlink does not have the same authentication robustness as a unicast frame.
- The **ACK** and **ADRACKReq** bits MUST be zero. The **MType** field MUST carry the value for Unconfirmed Data Down.
- The FPending bit indicates there is more multicast data to be sent. Given that a
  Class C device keeps its receiver active most of the time, the FPending bit does not
  trigger any specific behavior of the end-device.



### 18 Class C MAC command

All commands described in the Class A specification SHALL be implemented in Class C devices. The Class C specification adds the following MAC commands.

2362

23592360

2361

CID	Command	Transmitted by		Short Description
		End-	Gateway	-
		device		
0x20	DeviceModeInd	Х		Used by the end-device to indicate its current
				operating mode (Class A or C)
0x20	DeviceModeConf		Х	Used by the network to acknowledge a
				DeviceModeInd command

2363 Table 22 : Class C MAC command table

### 18.1 Device Mode (DeviceModeInd, DeviceModeConf)

With the **DeviceModeInd** command, an end-device indicates to the network that it wants to operate either in class A or C. The command has a one byte payload defined as follows:

23662367

2364

2365

Size (bytes)	
DeviceModeInd Payload	Class
Figure 66: DeviceModeInd paylo	ad format

2368

With the classes defined for the above commands as:

2370

2369

Class	Value
Class A	0x00
RFU	0x01
Class C	0x02

2371

2375

2376

2377

2378

2379

Table 23: DeviceModInd class mapping

When a **DeviceModeInd** command is received by the Network Server, it responds with a **DeviceModeConf** command. The device SHALL include the **DeviceModeInd** command in all uplinks until the **DeviceModeConf** command is received.

The device SHALL switch mode as soon as the first **DeviceModeInd** command is transmitted.

**Note**: When transitioning from class A to class C, It is recommended for battery powered devices to implement a time-out mechanism in the application layer to guarantee that it does not stay indefinitely in class C mode if no connection is possible with the network.

2380 2381

The **DeviceModeConf** command has a 1 byte payload.

Size (bytes)	1
DeviceModeConf Payload	Class

23822383

With the class parameter defined as for the *DeviceModeInd* command

2384

2385



## **SUPPORT INFORMATION**

This sub-section is only a recommendation.

23882389



### 19 Examples and Application Information

Examples are illustrations of the LoRaWAN spec for information, but they are not part of the formal specification.

### 19.1 Uplink Timing Diagram for Confirmed Data Messages

The following diagram illustrates the steps followed by an end-device trying to transmit two confirmed data frames (Data0 and Data1). This device's NbTrans parameter must be greater or equal to 2 for this example to be valid (because the first confirmed frame is transmitted twice)




Figure 67: Uplink timing diagram for confirmed data messages

The end-device first transmits a confirmed data frame containing the Data0 payload at an arbitrary instant and on an arbitrary channel. The frame counter Cu is simply derived by adding 1 to the previous uplink frame counter. The network receives the frame and generates a downlink frame with the ACK bit set exactly RECEIVE\_DELAY1 seconds later, using the first receive window of the end-device. This downlink frame uses the same data rate and the same channel as the Data0 uplink. The downlink frame counter Cd is also derived by adding 1 to the last downlink towards that specific end-device. If there is no downlink payload pending the network shall generate a frame without a payload. In this example the frame carrying the ACK bit is not received.

If an end-device does not receive a frame with the ACK bit set in one of the two receive windows immediately following the uplink transmission it may resend the same frame with the same payload and frame counter again at least ACK\_TIMEOUT seconds after the second reception window. This resend must be done on another channel and must obey the duty cycle limitation as any other normal transmission. If this time the end-device receives the ACK downlink during its first receive window, as soon as the ACK frame is demodulated, the end-device is free to transmit a new frame on a new channel.

The third ACK frame in this example also carries an application payload. A downlink frame can carry any combination of ACK, MAC control commands and payload.

### 19.2 Downlink Diagram for Confirmed Data Messages

The following diagram illustrates the basic sequence of a "confirmed" downlink.






Figure 68: Downlink timing diagram for confirmed data messages

The frame exchange is initiated by the end-device transmitting an "unconfirmed" application payload or any other frame on channel A. The network uses the downlink receive window to transmit a "confirmed" data frame towards the end-device on the same channel A. Upon reception of this data frame requiring an acknowledgement, the end-device transmits a frame with the ACK bit set at its own discretion. This frame might also contain piggybacked data or MAC commands as its payload. This ACK uplink is treated like any standard uplink, and as such is transmitted on a random channel that might be different from channel A.

**Note:** To allow the end-devices to be as simple as possible and have keep as few states as possible it may transmit an explicit (possibly empty) acknowledgement data message immediately after the reception of a data message requiring an acknowledgment. Alternatively the end-device may defer the transmission of an acknowledgement to piggyback it with its next data message.

### 19.3 Downlink Timing for Frame-Pending Messages

The next diagram illustrates the use of the **frame pending** (FPending) bit on a downlink. The FPending bit can only be set on a downlink frame and informs the end-device that the network has several frames pending for him; the bit is ignored for all uplink frames.

If a frame with the FPending bit set requires an acknowledgement, the end-device shall do so as described before. If no acknowledgment is required, the end-device may send an empty data message to open additional receive windows at its own discretion, or wait until it has some data to transmit itself and open receive windows as usual.

 **Note:** The FPending bit is independent to the acknowledgment scheme.

(\*) F\_P means 'frame pending' bit set




Figure 69: Downlink timing diagram for frame-pending messages, example 1



In this example the network has two confirmed data frames to transmit to the end-device. The frame exchange is initiated by the end-device via a normal "unconfirmed" uplink message on channel A. The network uses the first receive window to transmit the Data0 with the bit FPending set as a confirmed data message. The device acknowledges the reception of the frame by transmitting back an empty frame with the ACK bit set on a new channel B. RECEIVE\_DELAY1 seconds later, the network transmits the second frame Data1 on channel B, again using a confirmed data message but with the FPending bit cleared. The end-device acknowledges on channel C.




Figure 70: Downlink timing diagram for frame-pending messages, example 2

In this example, the downlink frames are "unconfirmed" frames, the end-device does not need to send back and acknowledge. Receiving the Data0 unconfirmed frame with the FPending bit set the end-device sends an empty data frame. This first uplink is not received by the network. If no downlink is received during the two receive windows, the network has to wait for the next spontaneous uplink of the end-device to retry the transfer. The end-device can speed up the procedure by sending a new empty data frame.

**Note:** An acknowledgement is never sent twice.

The FPending bit, the ACK bit, and payload data can all be present in the same downlink. For example, the following frame exchange is perfectly valid.




Figure 71: Downlink timing diagram for frame-pending messages, example 3

The end-device sends a "confirmed data" uplink. The network can answer with a confirmed downlink containing Data + ACK + "Frame pending" then the exchange continues as previously described.



2487

2488

2489

# Server by the end-device provider at the time of provisioning Configuration data related to the end-device and its characteristics must be known by the Network Server at the time of provisioning. –This provisioned data is called the "contract". This contract cannot be provided by the end-device and must be supplied by the end-device provider using another channel (out-of-band communication). This end-device contract is stored in the Network Server. It can be used by the Application Server and the network controller to adapt the algorithms.

20 Recommendation on contract to be provided to the Network

### 2486 This data will include:

- End-device specific radio parameters (device frequency range, device maximal output power, device communication settings - RECEIVE\_DELAY1, RECEIVE\_DELAY2)
- Application type (Alarm, Metering, Asset Tracking, Supervision, Network Control)



2497

2498

2499

25002501

2502

### 2491 21 Recommendation on finding the locally used channels

End-devices that can be activated in territories that are using different frequencies for LoRaWAN will have to identify what frequencies are supported for join message at their current location before they send any message. The following methods are proposed:

- A GPS enabled end-device can use its GPS location to identify which frequency band to use.
  - End-device can search for a class B beacon and use its frequency to identify its region
  - End-device can search for a class B beacon and if this one is sending the antenna GPS coordinate, it can use this to identify its region
- End-device can search for a beacon and if this one is sending a list of join frequencies, it can use this to send its join message



### 22 Revisions

### 2504 **22.1 Revision 1.0**

2503

2508

2510

2511 2512

2513

2514

2515

2516

2517

2518

2519 2520 2521

2522

2523

2524

2525 2526

2527

2528

2529

2533

2534

2535 2536

2537

2538

25392540

2541 2542

2543

2505 • Approved version of LoRaWAN1.0

### 2506 **22.2 Revision 1.0.1**

- Clarified the RX window start time definition
  - Corrected the maximum payload size for DR2 in the NA section
- Corrected the typo on the downlink data rate range in 7.2.2
  - Introduced a requirement for using coding rate 4/5 in 7.2.2 to guarantee a maximum time on air < 400mSec
  - Corrected the Join-accept MIC calculation in 6.2.5
  - Clarified the NbRep field and renamed it to NbTrans in 5.2
  - Removed the possibility to not encrypt the Applicative payload in the MAC layer, removed the paragraph 4.3.3.2. If further security is required by the application, the payload will be encrypted, using any method, at the application layer then reencrypted at the MAC layer using the specified default LoRaWAN encryption
  - Corrected FHDR field size typo
  - Corrected the channels impacted by ChMask when chMaskCntl equals 6 or 7 in 7.2.5
  - Clarified 6.2.5 sentence describing the RX1 slot data rate offset in the JoinResp message
  - Removed the second half of the DRoffset table in 7.2.7, as DR>4 will never be used for uplinks by definition
  - Removed explicit duty cycle limitation implementation in the EU868Mhz ISM band (chapter7.1)
  - Made the RXtimingSetupAns and RXParamSetupAns sticky MAC commands to avoid end-device's hidden state problem. (in 5.4 and 5.7)
  - Added a frequency plan for the Chinese 470-510MHz metering band
- Added a frequency plan for the Australian 915-928MHz ISM band 2531

### 2532 **22.3 Revision 1.0.2**

- Extracted section 7 "Physical layer" that will now be a separated document "LoRaWAN regional physical layers definition"
- corrected the ADR\_backoff sequence description (ADR\_ACK\_LIMT was written instead of ADR\_ACK\_DELAY) paragraph 4.3.1.1
  - Corrected a formatting issue in the title of section 18.2 (previously section 19.2 in the 1.0.1 version)
  - Added the DIChannelRec MAC command, this command is used to modify the frequency at which an end-device expects a downlink.
  - Added the Tx ParamSetupRec MAC command. This command enables to remotely modify the maximum TX dwell time and the maximum radio transmit power of a device in certain regions



- 2544 Added the ability for the end-device to process several ADRreg commands in a 2545 single block in 5.2 2546 Clarified AppKey definitionIntroduced the ResetInd / ResetConf MAC commands 2547 Split Data rate and txpower table in 7.1.3 for clarity 2548 Added DeviceTimeReg/Ans MAC command to class A Changed Class B time origin to GPS epoch, added BeaconTimingAns description 2549 Aligned all beacons of class B to the same time slot. Class B beacon is now common 2550 2551 to all networks. 2552 Separated AppKey and NwkKey to independently derive AppSKeys and NetSKeys. 2553 Separated NetSKeyUp and NetSKeyDnw for roaming 2554 22.4 Revision 1.1 2555 2556 This section provides an overview of the main changes happening between LoRaWAN1.1 2557 and LoRaWAN1.0.2. 22.4.1 Clarifications 2558 2559 Grammatical 2560 Normative text used consistently 2561 ADR behavior, 2562 Introduced the concept of ADR command block processing 2563 **TXPower handling** 2564 Default channel re-enabling 2565 ADR Backoff behavior 2566 **Default TXPower definition** 2567 FCnt shall never be reused with the same session keys 2568 MAC Commands are discarded if present in both FOpts and Payload 2569 Retransmission backoff clarification 2570 22.4.2 Functional modifications 2571 FCnt changes 2572 All counters are 32bits wide, 16bits not supported any more 2573 Separation of FCntDown into AFCntDown and NFCntDown 2574 Remove state synchronization requirement from NS/AS 2575 Remove requirement to discard frames if FCnt gap is greater than MAX FCNT GAP 2576 Unnecessary with 32bit counters 2577 End-device Frame counters are reset upon the successful processing of a Join-Accept ABP device must never reset frame counters
- 2578 2579

2581

2582

- Retransmission (transmission without incrementing the FCnt)
  - Downlink frames are never retransmitted
  - Subsequent receptions of a frame with the same FCnt are ignored
  - Uplink retransmissions are controlled by NbTrans (this includes both confirmed and unconfirmed frames)



2584	<ul> <li>A retransmission may not occur until both RX1 and RX2 receive windows have</li> </ul>
2585	expired
2586	<ul> <li>Class B/C devices cease retransmitting a frame upon the reception of a frame in the</li> </ul>
2587	RX1 window
2588	<ul> <li>Class A device cease retransmitting a frame upon the reception of a frame in either</li> </ul>
2589	the RX1 or RX2 window
2590	Key changes
2591	<ul> <li>Added one new root key (separation of cipher function)</li> </ul>
2592	NwkKey and AppKey
2593	Added new session keys
2594	·
2595	<ul> <li>NwkSEncKey encrypts payloads where Fport = 0 (MAC command payload)</li> </ul>
2596	<ul> <li>AppSKey encrypts payloads where Fport != 0 (Application payloads)</li> </ul>
2597	NwkSIntKey is used to MIC downlink frames  For downlinks with the ACK bit set, the 215Bs of the ACCettle of the
2598	For downlinks with the ACK bit set, the 2 LSBs of the AFCntUp of the     ACK are added to the ACK
2599	confirmed uplink which generated the ACK are added to the MIC
2600	calculation
2601	SNwkSIntKey and FNwkSIntKey are used to MIC uplink frames
2602	Each is used to calculate 2 separate 16 bit MICs which are combined to
2603	single 32 bit MIC
2604	The SNwkSIntKey portion is considered "private" and not shared with a
2605	roaming fNs
2606	The FNwkSIntKey portion is considered "public" and may be shared with
2607	a roaming fNs
2608	The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  Type MIC portion now uses the TxDr, TxCh  Type MIC portion now uses the TxDr, TxCh  The private MIC portion now uses the TxDr, TxCh  Type MIC portion now use the TxDr, TxCh  Type MIC portion now use the TxDr, TxCh
2609	For uplinks with the ACK bit set, the 2 LSBs of the FCntDown of the
2610	confirmed downlink which generated the ACK are added to the private
2611	MIC calculation
2612	• Keys fully defined later (section 6)
2613	Associated MIC and Encrypt changes using new keys
2614	MAC Commands introduced  Type years Catalan Page (Angelete)
2615	TxParamSetupReq/Ans  PlSh and ParamSetupReq/Ans  Reserved Res
2616	DIChannelReq/Ans
2617	ResetInd/Conf
2618	ADRParamSetupReq/Ans
2619	DeviceTimeReq/Ans
2620	ForceRejoinReq     Printin Branch a Branch
2621	RejoinParamSetupReq/Ans
2622	For the linkADRReq command
2623	<ul> <li>Value of 0xF is to be ignored for DR or TXPower</li> </ul>
2624	<ul> <li>Value of 0 is to be ignored for NbTrans</li> </ul>
2625	Activation
2626	JoinEUI replaces AppEUI (clarification)
2627	EUI's fully defined
2628	Root keys defined     North Control of the Con
2629	■ NwkKey
2630	<ul> <li>AppKey</li> </ul>
2630 2631	Additional session keys added (split MIC/Encrypt keys)
2632	<ul> <li>SNwkSIntKeyUp and FNwkSIntKeyUp (split-MIC uplink)</li> </ul>
2632 2633	NwkSIntKeyDown (MIC downlink)
_000	<ul><li>NwkSEncKey (Encrypt up/down)</li></ul>



2634	<ul> <li>JSIntKey (Rejoin-Request and related Join-Accept)</li> </ul>
2635	JSencKey (Join-Accepts in response to Rejoin-Request)
2636	Session context defined
2637	OTAA
2638	JoinAccept MIC modified to prevent replay attack
2639	Session key derivation defined
2640	ReJoin-Request messages defined (one new LoRaWAN Message type [MType]
2641	• 0 - Handover roaming assist
2642	<ul> <li>1 - Backend state recovery assist</li> </ul>
2643	<ul><li>2 - Rekey session keys</li></ul>
2644	All Nonces are now counters (not random any more)
2645	NetId clarified (association with Home Network)
2646	<ul> <li>OptNeg bit defined in Join-Accept to identify 1.0 or 1.1+ operational version of</li> </ul>
2647	network backend
2648	<ul> <li>1.0 operation reversion by a 1.1 device defined</li> </ul>
2649	○ ABP
2650	<ul> <li>Additional Session key requirement described</li> </ul>
2651	○ Class B
2652	<ul> <li>Network now controls the device's DR</li> </ul>
2653	<ul> <li>Beacon definition moved to Regional document</li> </ul>
2654	<ul> <li>Clarifications</li> </ul>
2655	<ul> <li>Deprecated the BeaconTimingReq/Ans (replaced by the standard MAC command</li> </ul>
2656	DeviceTimeReq/Ans)
2657	○ Class C
2658	<ul> <li>Clarify requirement for a DL timeout</li> </ul>
2659	<ul> <li>Add Class C MAC Commands</li> </ul>
2660	<ul><li>DeviceModeInd/Conf</li></ul>
2661	22.4.3 Examples
200 I	22.τ.υ Ελαιτιρίου
2662	
	<ul> <li>Removed aggressive data-rate backoff example during retransmission</li> </ul>
2663	



2664	23 Glossary	
2665		
2666	ADR	Adaptive Data Rate
2667	AES	Advanced Encryption Standard
2668	AFA	Adaptive Frequency Agility
2669	AR	Acknowledgement Request
2670	CBC	Cipher Block Chaining
2671	CMAC	Cipher-based Message Authentication Code
2672	CR	Coding Rate
2673	CRC	Cyclic Redundancy Check
2674	DR	Data Rate
2675	ECB	Electronic Code Book
2676	ETSI	European Telecommunications Standards Institute
2677	EIRP	Equivalent Isotropically Radiated Power
2678	FSK	Frequency Shift Keying modulation technique
2679	GPRS	General Packet Radio Service
2680	HAL	Hardware Abstraction Layer
2681	IP	Internet Protocol
2682	LBT	Listen Before Talk
2683	LoRa™	Long Range modulation technique
2684	LoRaWAN™	Long Range Network protocol
2685	MAC	Medium Access Control
2686	MIC	Message Integrity Code
2687	RF	Radio Frequency
2688	RFU	Reserved for Future Usage
2689	Rx	Receiver
2690	RSSI	Received Signal Strength Indicator
2691	SF	Spreading Factor
2692	SNR	Signal Noise Ratio
2693	SPI	Serial Peripheral Interface
2694	SSL	Secure Socket Layer
2695	Tx	Transmitter

Universal Serial Bus

2696

USB



### 24 Bibliography

2697

# 24.1 References [IEEE802154]: IEEE Standard for Local and Metropolitan Area Networks—Part 15.4: Low-Rate Wireless Personal Area Networks (LR-WPANs), IEEE Std 802.15.4TM-2011 (Revision of IEEE Std 802.15.4-2006), September 2011. [RFC4493]: The AES-CMAC Algorithm, June 2006. [PHY]: LoRaWAN Regional parameters v1.1, LoRa Alliance [BACKEND]: LoRaWAN backend Interfaces specification v1.0, LoRa Alliance



### 2705 **25 NOTICE OF USE AND DISCLOSURE**

- 2706 Copyright © LoRa Alliance, Inc. (2017). All Rights Reserved.
- 2707 The information within this document is the property of the LoRa Alliance ("The Alliance")
- 2708 and its use and disclosure are subject to LoRa Alliance Corporate Bylaws, Intellectual
- 2709 Property Rights (IPR) Policy and Membership Agreements.
- 2710 Elements of LoRa Alliance specifications may be subject to third party intellectual property
- 2711 rights, including without limitation, patent, copyright or trademark rights (such a third party
- 2712 may or may not be a member of LoRa Alliance). The Alliance is not responsible and shall
- 2713 not be held responsible in any manner for identifying or failing to identify any or all such third
- 2714 party intellectual property rights.
- 2715 This document and the information contained herein are provided on an "AS IS" basis and
- 2716 THE ALLIANCE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING
- 2717 BUT NOT LIMITED TO (A) ANY WARRANTY THAT THE USE OF THE INFORMATION
- 2718 HEREIN WILL NOT INFRINGE ANY RIGHTS OF THIRD PARTIES (INCLUDING WITHOUT
- 2719 LIMITATION ANY INTELLECTUAL PROPERTY RIGHTS INCLUDING PATENT
- 2720 COPYRIGHT OR TRADEMARK RIGHTS) OR (B) ANY IMPLIED WARRANTIES OF
- 2721 MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE OR
- 2722 NONINFRINGEMENT.
- 2723 IN NO EVENT WILL THE ALLIANCE BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF
- 2724 BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OFBUSINESS, OR FOR ANY
- 2725 OTHER DIRECT, INDIRECT, SPECIAL OR EXEMPLARY, INCIDENTIAL, PUNITIVE OR
- 2726 CONSEQUENTIAL DAMAGES OF ANY KIND, IN CONTRACT OR IN TORT, IN
- 2727 CONNECTION WITH THIS DOCUMENT OR THE INFORMATION CONTAINED HEREIN,
- 2728 EVEN IF ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE.
- 2729 The above notice and this paragraph must be included on all copies of this document that
- 2730 are made.
- 2731 LoRa Alliance, Inc.
- 2732 3855 SW 153rd Drive
- 2733 Beaverton, OR 97007
- Note: All Company, brand and product names may be trademarks that are the sole property
- 2735 of their respective owners.