

#### Binairy format:

<SOF-SID10...SID0-RTR-IDE-r0-DLC3...0-DATABYTE1...DATABYTEn-CRC15...CRC1-CRCDEL-ACK-ACKDEL-EOF7...EOF1-IFS3...IFS1>

bits	Description
SOF	Start Of Frame (always 0)
SID10 & SID9	Priority (00: highest 11: lowest priority)
SID8SID1	Address
SID0	Always 0
RTR	Remote Transmit Request
IDE	Identifier Extension (always 0)
r0	reserved (always 0)
DLC3DLC0	Data Length Code (08)
Databyte1	Command
Databyte2	Parameter
Databyte3	Parameter
Databyte4	Parameter
Databyte5	Parameter
Databyte6	Parameter
Databyte7	Parameter
Databyte8	Parameter
CRC15CRC1	Cyclic Redundancy Checksum
CRCDEL	CRC Delimiter (always 1)
ACK	Acknowledge slot (transmit 1 readback 0 if received correctly)
ACKDEL	Acknowledge Delimiter (always 1)
EOF7EOF1	End Of Frame (always 1111111)
IFS3IFS1	InterFrame Space (always 111)

### The module can transmit the following messages:

- Power up message
- Channel status
- Thermostat channel status
- Module status
- Temperature sensor status
- Thermostat settings
- Current temperature
- Module type and subtype
- Bus error counter status
- First, second and third part of the channel names
- Memory data
- Memory data block (4 bytes)
- Program step info
- Real-time clock status
- Date status
- Daylight savings status
- Real-time clock status request
- Clear linked push button led
- Set linked push button led
- Slow blink linked push button led
- Fast blink linked push button led

### The module can receive the following messages:

• Power up

#### The module can receive the following commands:

- Linked push button status
- Module type request
- Module status request
- Channel name request
- Clear channel led
- Set channel led

- Slow blink channel led
- Fast blink channel led
- Very fast channel led
- Update channel leds
- Read memory data
- Read memory data block (4 bytes)
- Memory dump request
- Write memory data
- Write memory data block (4 bytes)
- Read program step info
- Write program step
- Bus error counter status request
- Real-time clock status request
- Set real-time clock
- Set date
- Set daylight savings
- Enable/disable global sunrise/sunset related actions
- Enable/disable local sunrise/sunset related actions
- Set local alarm clock
- Set global alarm clock
- Lock channel
- Unlock channel
- Disable channel program
- Enable channel program
- Select program
- Temperature request
- Thermostat settings request
- Set thermostat heating mode
- Set thermostat cooling mode
- Set temperature sensor zone
- Set thermostat default sleep time
- Set thermostat target, safe, night, day, comfort and alarm1 to alarm 4 temperature set
- Set thermostat hysteresis
- Set thermostat temperature difference for boost output
- Set temperature sensor calibration offset and gain
- Enable/disable valve and pump unjamming
- Reset minimum and maximum temperature
- Set thermostat temperature range
- Set thermostat minimum switching time
- Switch thermostat to safe, night, day or comfort mode
- Switch the open collector output off or on
- Start a timer on the open collector output

#### Transmits power up message:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 2 data byte to send

 $DATABYTE1 = COMMAND_POWER_UP(0xAB)$ 

DATABYTE2 = module address

### Transmits real time clock status request:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 1 data byte to send

DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS\_REQUEST (0xD7)

#### Transmits the real time clock status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 data bytes to send

DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS (0xD8)

DATABYTE2 = Day

Contents	Day
0	Monday
1	Tuesday
2	Wednesday
3	Thursday
4	Friday
5	Saturday
6	Sunday

 $DATABYTE3 = \overline{Hour(0...23)}$ 

DATABYTE4 = Minute (0...59)

#### Transmits the date status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 data bytes to send

DATABYTE1 = COMMAND\_DATE\_STATUS (0xB7)

DATABYTE2 = Day (1...31)

DATABYTE3 = Month (1...12)

DATABYTE4 = High byte of Year

DATABYTE5 = Low byte of Year

#### Transmits the daylight savings status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes to send

DATABYTE1 = COMMAND\_DAYLIGHT\_SAVING\_STATUS (0xAF)

DATABYTE2 = 0 =disabled / 1 = enabled

#### Transmits the channel switch status:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 data bytes to send

DATABYTE1 = COMMAND\_PUSH\_BUTTON\_STATUS (0x00)

DATABYTE2 = Channel just pressed DATABYTE3 = Channel just released DATABYTE4 = Channel long pressed

Contents	Channel number
B'00000001'	Button 1
B'00000010'	Button 2
B'00000100'	Button 3
B'00001000'	Button 4
B'00010000'	Dark / Light output
B'00100000'	Motion output
B'01000000'	Light depending motion output
B'10000000'	Absence output

### Transmits the sensor output switch status:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Sub-address

RTR = 0

DLC3...DLC0 = 4 data bytes to send

DATABYTE1 = COMMAND\_OUTPUT\_STATUS (0x00)

DATABYTE2 = Output channel just activated (1 = just activated)

Contents	Output channel
xxxxxxx1	Heater just activated
xxxxxx1x	Boost heater/cooler just activated
xxxxx1xx	Pump just activated
xxxx1xxx	Cooler just activated
xxx1xxxx	Temperature alarm 1 just activated
xx1xxxxx	Temperature alarm 2 alarm activated
x1xxxxxx	Temperature alarm 3 just activated
1xxxxxxx	Temperature alarm 4 alarm activated

DATABYTE3 = Outputs just deactivated (1 = just deactivated)

Surpuis just deden vated (1 just deden vated)	
Contents	Output channel
xxxxxxx1	Heater just deactivated
xxxxxx1x	Boost heater/cooler just deactivated
xxxxx1xx	Pump just deactivated
xxxx1xxx	Cooler just deactivated
xxx1xxxx	Temperature alarm 1 just deactivated
xx1xxxxx	Temperature alarm 2 alarm deactivated
x1xxxxxx	Temperature alarm 3 just deactivated
1xxxxxxx	Temperature alarm 4 alarm deactivated

DATABYTE4 = always zero

#### Transmits the module type:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_MODULE\_TYPE (0xFF)

DATABYTE2 = type (0x5F = VMBGP4PIR-20)

DATABYTE3 = High byte of serial number

DATABYTE4 = Low byte of serial number

DATABYTE5 = Memory map version

DATABYTE6 = Build year

DATABYTE7 = Build week

DATABYTE8 = Properties

•	Toperties	
	Contents	Output channel
	B'xxxxxxx0'	Terminator open
	B'xxxxxxx1'	Terminator closed
	B'xxxx000x'	Hardware version number
	B'xxx0xxxx'	Velbus connection type
	B'xx0xxxxx'	Only standard CAN allowed
	B'xx1xxxxx'	CAN FD support

#### Transmits the module subtype:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

 $DATABYTE1 = COMMAND_SUBTYPE (0xB0)$ 

DATABYTE2 = type (0x5F = VMBGP4PIR-20)

DATABYTE3 = High byte of serial number

DATABYTE4 = Low byte of serial number

DATABYTE5 = Subaddress1 (H'FF' sub-address disabled)

DATABYTE6 = Subaddress2 (H'FF' sub-address disabled)

DATABYTE7 = Subaddress3 (H'FF' sub-address disabled)

DATABYTE8 = Subaddress4 (H'FF' sub-address disabled)

### Transmit: Bus error counter status

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 data bytes to send

DATABYTE1 = COMMAND\_BUSERROR\_COUNTER\_STATUS (0xDA)

DATABYTE2 = Transmit error counter

DATABYTE3 = Receive error counter

DATABYTE4 = Bus off counter

### Transmits the memory data:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 data bytes to send

DATABYTE1 = COMMAND\_MEMORY\_DATA (0xFE)

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

DATABYTE4 = memory data

Remark: address range: 0x0000 to 0x06BB

#### Transmits memory data block (4 bytes):

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 data bytes to send

DATABYTE1 = COMMAND\_MEMORY\_DATA\_BLOCK (0xCC)

DATABYTE2 = High start address of memory block

DATABYTE3 = LOW start address of memory block

DATABYTE4 = memory data1

DATABYTE5 = memory data2

DATABYTE6 = memory data3

DATABYTE7 = memory data4

Remark: address range: 0x0000 to 0x06B8

### Transmits memory data block (5...60 bytes)(only allowed for CAN FD frames):

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = number of data bytes to send

Contents	Number of data bytes
0x09	12 data bytes
0x0A	16 data bytes
0x0B	20 data bytes
0x0C	24 data bytes
0x0D	32 data bytes
0x0E	48 data bytes
0x0F	64 data bytes

DATABYTE1 = COMMAND\_MEMORY\_DATA\_BLOCK (0xCC)

DATABYTE2 = High start address of memory block

DATABYTE3 = LOW start address of memory block

DATABYTE4 = memory block length (5...60)

DATABYTE5 = memory data 1

. . .

DATABYTE12 = memory data 8 (end of data for DLC3...DLC0 = 0x09)

. . .

DATABYTE16 = memory data 12 (end of data for DLC3...DLC0 = 0x0A)

DATABYTE20 = memory data 16 (end of data for DLC3...DLC0 = 0x0B)

DATABYTE24 = memory data 20 (end of data for DLC3...DLC0 = 0x0C)

... DATABYTE32 = memory data 28 (end of data for DLC3...DLC0 = 0x0D)

---

DATABYTE48 = memory data 44 (end of data for DLC3...DLC0 = 0x0E)

. . .

DATABYTE64 = memory data 60 (end of data for DLC3...DLC0 = 0x0F)

#### Remark:

Contents of unused data bytes = 0x55

Address range: 0x0000 to (0x06BC - memory block length)

#### Transmits the first part of channel name:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_CHANNEL\_NAME\_PART1 (0xF0)

DATABYTE2 = channel number 1...4, 9 or 18 (channel 9 = temperature sensor, channel 18 = output)

DATABYTE3 = Character 1 of the channel name

DATABYTE4 = Character 2 of the channel name

DATABYTE5 = Character 3 of the channel name

DATABYTE6 = Character 4 of the channel name

DATABYTE7 = Character 5 of the channel name

DATABYTE8 = Character 6 of the channel name

#### Transmits the second part of the channel name:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_CHANNEL\_NAME\_PART2 (0xF1)

DATABYTE2 = Channel number 1...4, 9 or 18 (channel 9 = temperature sensor, channel 18 = output)

DATABYTE3 = Character 7 of the channel name

DATABYTE4 = Character 8 of the channel name

DATABYTE5 = Character 9 of the channel name

DATABYTE6 = Character 10 of the channel name

DATABYTE7 = Character 11 of the channel name

DATABYTE8 = Character 12 of the channel name

#### Transmits the third part of the channel name:

 $SID10-SID9 = \overline{11}$  (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 6 data bytes to send

DATABYTE1 = COMMAND CHANNEL NAME PART3 (0xF2)

DATABYTE2 = channel number 1...4, 9 or 18 (channel 9 = temperature sensor, channel 18 = output)

DATABYTE3 = Character 13 of the channel name

DATABYTE4 = Character 14 of the channel name

DATABYTE5 = Character 15 of the channel name

DATABYTE6 = Character 16 of the channel name

#### Remarks:

Unused characters contain H'FF'.

#### Transmits the module status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_MODULE\_STATUS (0xED)

DATABYTE2 = channel 1 to 8 status (1 = pressed / 0 = released)

Contents	Channel number
B'00000001'	Button 1
B'00000010'	Button 2
B'00000100'	Button 3
B'00001000'	Button 4
B'00010000'	Twilight(light/dark) output
B'00100000'	Motion output
B'01000000'	Light depending motion output
B'10000000'	Absence output

DATABYTE3 = test modus, button enabled/disable

Contents	
B'xxxxxxx0'	Button 1 disabled
B'xxxxxxx1'	Button 1 enabled
B'xxxxxx0x'	Button 2 disabled
B'xxxxxx1x'	Button 2 enabled
B'xxxxx0xx'	Button 3 disabled
B'xxxxx1xx'	Button 3 enabled
B'xxxx0xxx'	Button 4 disabled
B'xxxx1xxx'	Button 4 enabled
B'0xxxxxxx'	Motion test modus disabled
B'1xxxxxxx'	Motion test modus enabled

DATABYTE4 = open collector locked & temperature sensor

Contents	open collector & temperature sensor
B'xxxx0xxx'	Edge color not inhibited
B'xxxx1xxx'	Edge color inhibited
B'xxx0xxxx'	Temperature sensor program enabled
B'xxx1xxxx'	Temperature sensor program disabled
B'xx0xxxxx'	Open collector output program enabled
B'xx1xxxxx'	Open collector output program disabled
B'x0xxxxxx'	Open collector output unlocked
B'x1xxxxxx'	Open collector output locked
B'0xxxxxxx'	Open collector output off
B'1xxxxxxx'	Open collector output on

 $DATABYTE\overline{5} = locked channel status (0 = unlocked / 1 = locked)$ 

DATABYTE6 = disabled channel program status (0 = program enabled / 1 = program disabled)

DATABYTE7 = alarm & program selection

Contents	Selected program
B'xxxxxx00'	None
B'xxxxxx01'	Program group 1 (Summer)
B'xxxxxx10'	Program group 2 (Winter)
B'xxxxxx11'	Program group 3 (Holiday)
B'xxxxx0xx'	Clock alarm 1 off
B'xxxxx1xx'	Clock alarm 1 on
B'xxxx0xxx'	Local clock alarm 1
B'xxxx1xxx'	Global clock alarm 1
B'xxx0xxxx'	Clock alarm 2 off
B'xxx1xxxx'	Clock alarm 2 on
B'xx0xxxxx'	Local clock alarm 2
B'xx1xxxxx'	Global clock alarm 2
B'x0xxxxxx'	Sunrise disabled
B'x1xxxxxx'	Sunrise enabled
B'0xxxxxxx'	Sunset disabled
B'1xxxxxxx'	Sunset enabled

DATABYTE8 = light value auto send interval time

(Valid range: 10...255s)

(5...9 = auto send on light value change with min interval <math>5...9s) (<5 = auto send disabled)

#### Transmit the sensor status:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_STATUS (0xEA)

DATABYTE2 = Operating mode

Contents	Operating mode
xxxxxxx1	Mode push button locked (not used)
xxxxxxx0	Mode push button unlocked (not used)
xxxxx11x	Forced to safe mode (locked)
xxxxx01x	Manual mode
xxxxx10x	Sleep timer mode
xxxxx00x	Run mode
xxxx1xxx	Auto send sensor temperature enabled
xxxx0xxx	Auto send sensor temperature disabled
x100xxxx	Comfort mode
x010xxxx	Day mode
x001xxxx	Night mode
x000xxxx	Safe temp mode (anti frost)
1xxxxxxx	Cooler mode
0xxxxxxx	Heater mode

DATABYTE3 = Program step mode

Contents	Program step mode	
xxxxx0xx	No sensor program group 1	
xxxxx1xx	Sensor program group 1 available	
xxxx0xxx	No sensor program group 2	
xxxx1xxx	Sensor program group 2 available	
0xxxxxxx	No sensor program group 3	
1xxxxxxx	Sensor program group 3 available	
x100xxxx	Comfort program step received	
x010xxxx	Day program step received	
x001xxxx	Night program step received	
x000xxxx	Safe temperature program step received	
xxxxxx1x	Enable unjamming heater valve	
xxxxxx0x	Disable unjamming heater valve	
xxxxxxx1	Enable unjamming pump	
xxxxxxx0	Disable unjamming pump	

DATABYTE4 = Output status (1 = activated)

sulput status (1 detivated)		
Contents	Output channel	
xxxxxxx0	Heater off	
xxxxxxx1	Heater on	
xxxxxx0x	Boost heater/cooler off	
xxxxxx1x	Boost heater/cooler on	
xxxxx0xx	Pump off	
xxxxx1xx	Pump on	
xxxx0xxx	Cooler off	
xxxx1xxx	Cooler on	
xxx0xxxx	Temperature alarm 1 off	
xxx1xxxx	Temperature alarm 1 on	
xx0xxxxx	Temperature alarm 2 off	
xx1xxxxxx	Temperature alarm 2 on	
x0xxxxxx	Temperature alarm 3 off	
x1xxxxxx	Temperature alarm 3 on	
0xxxxxxx	Temperature alarm 4 off	
1xxxxxxx	Temperature alarm 4 on	
_		

DATABYTE5 = Current sensor temperature into two's complement format (resolution 0.5°)

Contents	Current sensor temperature	
01111111	63.5°C	

00000001	0.5°C
00000000	0°C
11111111	-0.5°C
10010010	-55°C

DATABYTE6 = Current temperature set (resolution  $0.5^{\circ}$ )

Contents	Current temperature set
01101100	54°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
11000000	-32°C

DATABYTE7 = High byte of the sleep timer

DATABYTE8 = Low byte of the sleep timer into minutes

#### Remark:

[DATABYTE7][DATABYTE8] contains a 16-bit sleep timer into minutes (1 to 65.279min).

If the sleep timer contains H'0000', the sleep timer is deactivated.

If the sleep timer contains a value between H'0001' and H'FEFF' (1 to 65.279min), the sleep timer is running for that time.

If the sleep timer contains 0xFFFF, manual mode is selected.

#### Transmit the sensor temperature:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 data bytes to send

DATABYTE1 = COMMAND\_SENSOR\_TEMPERATURE (0xE6)

DATABYTE2 = High byte current sensor temperature

DATABYTE3 = Low byte current sensor temperature into two's complement format (resolution 0.0625°)

DATABYTE4 = High byte minimum sensor temperature

DATABYTE5 = Low byte minimum sensor temperature into two's complement format (resolution 0.0625°)

DATABYTE6 = High byte maximum sensor temperature

DATABYTE7 = Low byte maximum sensor temperature into two's complement format (resolution 0.0625°)

High byte	Low byte	Current sensor temperature
01111111	111xxxxx	63.5°C
00000001	000xxxxx	0.5°C
00000000	100xxxxx	0.25°C
00000000	010xxxxx	0.125°C
00000000	001xxxxx	0.0625°C
00000000	000xxxxx	0°C
11111111	111xxxxx	-0.0625°C
11111111	110xxxxx	-0.125°C
11111111	100xxxxx	-0.25°C
11111110	000xxxxx	-0.5°C
10010010	000xxxxx	-55°C

#### Remark:

The 5 least significant bits of the low byte are don't care.

#### Transmit the first part of the sensor settings:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART1 (0xE8)

DATABYTE2 = Current temperature set (resolution  $0.5^{\circ}$ )

DATABYTE3 = Comfort temperature set for heating mode (resolution 0.5°)

DATABYTE4 = Day temperature set for heating mode (resolution  $0.5^{\circ}$ )

DATABYTE5 = Night temperature set for heating mode (resolution  $0.5^{\circ}$ )

 $DATABYTE6 = Anti \ frost \ temperature \ set \ for \ heating \ mode \ (resolution \ 0.5^{\circ})$ 

DATABYTE7 = Boost temperature difference set (resolution  $0.5^{\circ}$ )

DATABYTE8 = Hysteresis temperature set

Contents	Hysteresis
xxx11111	15.5°C
Xxx00001	0.5°C
Xxx00000	0°C

#### Transmit the second part of the sensor settings:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART2 (0xE9)

DATABYTE2 = Comfort temperature set for cooling mode (resolution  $0.5^{\circ}$ )

DATABYTE3 = Day temperature set for cooling mode (resolution  $0.5^{\circ}$ )

DATABYTE4 = Night temperature set for cooling mode (resolution 0.5°)

DATABYTE5 = Safe temperature set for cooling mode (resolution  $0.5^{\circ}$ )

DATABYTE6 = High byte of the default sleep timer

DATABYTE7 = Low byte of the default sleep timer into minutes (1 to 65.279min)

DATABYTE8 = Default auto send temperature time interval into seconds

(Valid range: 10...255s)

(5...9 = auto send on temperature change with min interval 5...9s)

(<4 = auto send disabled)

#### Transmit the third part of the sensor settings:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART3 (0xC6)

DATABYTE2 = Temperature alarm 1 setting (resolution  $0.5^{\circ}$ )

DATABYTE3 = Temperature alarm 4 setting (resolution  $0.5^{\circ}$ )

DATABYTE4 = Lower temperature range cool mode (resolution  $0.5^{\circ}$ )

DATABYTE5 = Upper temperature range heat mode (resolution  $0.5^{\circ}$ )

DATABYTE6 = Calibration offset factor (resolution 0.5°)

earieration offset factor (resolution o.s.)		
Contents	Calibration factor	
00001111	Calibration factor +7.5°C	
00000001	Calibration factor +0.5°C	
00000000	Calibration factor +0°C	
11111111	Calibration factor -0.5°C	
11110000	Calibration factor -8°C	

DATABYTE7 = Zone number

DATABYTE8 = Calibration gain factor

```
Transmit the fourth part of the sensor settings:
```

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART4 (0xB9)

DATABYTE2 = Minimum switching time (0...255s)

DATABYTE3 = Pump delayed on time (0...255s)

DATABYTE4 = Pump delayed off time (0...255s)

DATABYTE5 = Temperature alarm 2 setting (resolution 0.5°)

DATABYTE6 = Temperature alarm 3 setting (resolution 0.5°)

DATABYTE7 = Lower temperature range heat mode (resolution  $0.5^{\circ}$ )

DATABYTE8 = Upper temperature range cool mode (resolution  $0.5^{\circ}$ )

#### Transmit: Clears LEDs on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for clearing LEDs

RTR = 0

DLC3...DLC0 = 2 data bytes to send

DATABYTE1 = COMMAND CLEAR LED (0xF5)

DATABYTE2 = LED bit numbers (1 = clear LED)

#### Transmit: Sets LEDs on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for setting LEDs on

RTR = 0

DLC3...DLC0 = 2 data bytes to send

 $DATABYTE1 = COMMAND\_SET\_LED (0xF6)$ 

DATABYTE2 = LED bit numbers (1 = set LED)

#### Transmit: Blinks LEDs slowly on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for slowly blinking LEDs

RTR = 0

DLC3...DLC0 = 2 data bytes to send

DATABYTE1 = COMMAND SLOW BLINKING LED (0xF7)

DATABYTE2 = LED bit numbers (1 = slow blink LED)

#### Transmit: Blinks LEDs fast on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for fast blinking LEDs

RTR = 0

DLC3...DLC0 = 2 data bytes to send

DATABYTE1 = COMMAND\_FAST\_BLINKING\_LED (0xF8)

DATABYTE2 = LED bit numbers (1 = fast blink LED)

#### Transmit the light raw value:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes to send

DATABYTE1 = COMMAND\_SENSOR\_RAW\_DATA (0xA9)

DATABYTE4 = High byte current light value

DATABYTE5 = Low byte current light value

#### Transmits program step info:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes to send

DATABYTE1 = COMMAND\_PROGRAM\_STEP\_INFO (0xC1)

DATABYTE2 = Program step number (1...66 / 255 step not found)

DATABYTE3 = Program reference

Contents	Description	
000xxxxx	Disable program step	

001xxxxx	Absolute time	
010xxxxx	Wake up time 1 + relative time	
011xxxxx	Go to bed time 1 + relative time	
100xxxxx	Wake up time 2 + relative time	
101xxxxx	Go to bed time 2 + relative time	
110xxxxx	Sunrise + relative time	
111xxxxx	Sunset + relative time	
xxx01111	Rel. time = 3h45min	
•••		
xxx00001	Rel. time = 15min	
xxx00000	Rel. time = 0	
xxx11111	Rel. time = -15min	
xxx10000	Rel. time = -4h	

DATABYTE4 = Program step month & four least significant bits of day

Contents	Description	
xxxx0000	Weekly program	
xxxx0001	January	
xxxx0010	February	
xxxx0011	March	
xxxx0100	April	
xxxx0101	May	
xxxx0110	June	
xxxx0111	July	
xxxx1000	August	
xxxx1001	September	
xxxx1010	October	
xxxx1011	November	
xxxx1100	December	
xxxx1101	Monthly program	
xxxx1110	Monthly program	
xxxx1111	Monthly program	

Contents byte6	Contents byte4	Description
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1 of the month
00xxxxxx	0010xxxx	Day 2of the month
•••		
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mofr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
11xxxxxx	1111xxxx	Never

DATABYTE5 = Program step hour & group number

Contents	Description
xxx00000	Oh
xxx00001	1h
xxx10111	23h
xx1xxxxx	Program group 1 (Summer program)
x1xxxxxx	Program group 2 (Winter program)

1xxxxxxx	Program group 3 (Holiday program)
----------	-----------------------------------

DATABYTE6 = Program step minute & every flag & msb of day

Contents	Description
xx000000	0min
xx000001	1min
xx111011	59min

Contents byte6	Contents byte4	Description
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1of the month
00xxxxxx	0010xxxx	Day 2of the month
•••		
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
•••	•••	
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mofr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
11xxxxxx	1111xxxx	Never

DATABYTE7 = Program step action

Contents	Action
0	0s25 Pulse (only allowed for button channels)
1	1s Pulse (only allowed for button channels)
2	2s Pulse (only allowed for button channels)
119	1min59s Pulse (only allowed for button channels)
120	2min Pulse (only allowed for button channels)
121	2min15s Pulse (only allowed for button channels)
131	4min45s Pulse (only allowed for button channels)
132	5min Pulse (only allowed for button channels)
133	5min30s Pulse (only allowed for button channels)
•••	
181	29min30s Pulse (only allowed for button channels)
182	30min Pulse (only allowed for button channels)
183	31min Pulse (only allowed for button channels)
211	59min Pulse (only allowed for button channels)
212	1h Pulse (only allowed for button channels)
213	1h15min Pulse (only allowed for button channels)
227	4h45min Pulse (only allowed for button channels)
228	5h Pulse (only allowed for button channels)
229	5h30min Pulse (only allowed for button channels)
•••	
237	9h30min Pulse (only allowed for button channels)
238	10h Pulse (only allowed for button channels)
239	11h Pulse (only allowed for button channels)
246	18h Pulse (only allowed for button channels)
247	Press (only allowed for button channels)
248	Long Press (only allowed for button channels)
249	Release (only allowed for button channels)

250	Lock
251	Unlock
252	Thermostat safe mode (only allowed for temperature sensor channel)
253	Thermostat night mode (only allowed for temperature sensor channel)
254	Thermostat day mode (only allowed for temperature sensor channel)
255	Thermostat comfort mode (only allowed for temperature sensor channel)

### DATABYTE8 = Channel

Contents	Channel
1	Button 1
2	Button 2
3	Button 3
4	Button 4
5	Twilight (light/dark) channel (only lock/unlock action)
6	Motion channel (only lock/unlock action)
7	Light depending motion channel (only lock/unlock action)
8	Absence channel (only lock/unlock action)
9	Temperature sensor (only lock/unlock & thermostat actions)
18	Open collector output (only lock/unlock action)

#### 'Linked push button status' received:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Address of the linked push button module

RTR = 0

DLC3...DLC0 = 4 data bytes received

DATABYTE1 = COMMAND\_PUSH\_BUTTON\_STATUS (0x00)

DATABYTE2 = Linked push buttons just pressed (1 = just pressed)

DATABYTE3 = Linked push buttons just released (1 = just released)

DATABYTE4 = linked push buttons long pressed (1 = longer than 0.85s pressed)

#### Power up message' received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 2 data byte received

DATABYTE1 = COMMAND\_POWER\_UP (0xAB)

DATABYTE2 = module address

#### 'CAN FD enable command' received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 2 data byte received

DATABYTE1 = COMMAND\_SET\_CLR\_LEARN\_RF\_CODE (0xB5)

DATABYTE2 = enable/disable (0 = disable CAN FD / 1 = enable CAN FD)

#### 'Real time clock status request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 1 data byte to send

DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS\_REQUEST (0xD7)

#### 'Set real time clock' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 4 data bytes received

DATABYTE1 = COMMAND\_SET\_REALTIME\_CLOCK (0xD8)

DATABYTE2 = Day of week

Contents day of week'	Description
H'00'	Monday
H'01'	Tuesday
H'02'	Wednesday
H'03'	Thursday
H'04'	Friday
H'05'	Saterday
H'06'	Sunday

DATABYTE3 = Hours (0...23)

DATABYTE4 = Minutes (0...59)

#### 'Set date' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 5 data bytes received

DATABYTE1 = COMMAND\_SET\_REALTIME\_DATE (0xB7)

DATABYTE2 = Day (1...31)

DATABYTE3 = Month (1...12)

DATABYTE4 = High byte of Year

DATABYTE5 = Low byte of Year

#### 'Set daylight savings' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SET\_DAYLIGHT\_SAVING (0xAF)

DATABYTE2 = 0 = disabled / 1 = enabled

### 'Enable/disable global sunrise/sunset related actions' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND\_ENA\_DIS\_SUNRISE\_SUNSET (0xAE)

DATABYTE2 = Channel (0xFF)

DATABYTE3 = enable/disable flags

Contents	Description
B'xxxxxxx0'	Disable sunrise related actions
B'xxxxxxx1'	Enable sunrise related actions
B'xxxxxx0x'	Disable sunset related actions
B'xxxxxx1x'	Enable sunset related actions

#### 'Enable/disable local sunrise/sunset related actions' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND\_ENA\_DIS\_SUNRISE\_SUNSET (0xAE)

DATABYTE2 = Channel (0xFF)

DATABYTE3 = enable/disable flags

Contents	Description
B'xxxxxxx0'	Disable sunrise related actions
B'xxxxxxx1'	Enable sunrise related actions
B'xxxxxx0x'	Disable sunset related actions
B'xxxxxx1x'	Enable sunset related actions

### 'Set global clock alarm' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = 0x00

RTR = 0

DLC3...DLC0 = 7 data bytes received

DATABYTE1 = COMMAND SET ALARM CLOCK (0xC3)

DATABYTE2 = Alarm number (1 or 2)

DATABYTE3 = Wake up hour (0...23)

DATABYTE4 = Wake up minute (0...59)

DATABYTE5 = Go to bed hour (0...23)

DATABYTE6 = Go to bed minute (0...59)

DATABYTE7 = Clock alarm enable flag (0 = disabled / 1 = enabled)

#### 'Set local clock alarm' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 data bytes received

DATABYTE1 = COMMAND\_SET\_ALARM\_CLOCK (0xC3)

DATABYTE2 = Alarm number (1 or 2)

DATABYTE3 = Wake up hour (0...23)

DATABYTE4 = Wake up minute (0...59)

DATABYTE5 = Go to bed hour (0...23)

DATABYTE6 = Go to bed minute (0...59)

DATABYTE7 = Clock alarm enable flag (0 = disabled / 1 = enabled)

#### 'Module type request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 1

DLC3...DLC0 = 0 data bytes received

#### 'Module status request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND MODULE STATUS REQUEST (0xFA)

DATABYTE2 = don't care

#### 'Channel name request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_CHANNEL\_NAME\_REQUEST (0xEF)

DATABYTE2 = channel number 1...4, 9 or 18 (9 for temperature sensor name, 18 for output name)

Remark: channel = 0xFF for all 4 channel names, temperature sensor name & output channel name

#### 'Light value request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes to send

DATABYTE1 = COMMAND\_LIGHT\_VALUE\_REQUEST (H'AA')

DATABYTE2 = Auto send interval time into seconds

(valid range: 10...255s)

(5...9 = auto send on change)

(1...4 = auto send disabled)

(0 = no change on auto send interval time)

#### 'Set or Clear test mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND SET CLR LEARN MODE (H'B5')

DATABYTE2 = Operating mode

Contents	Operating mode	
0x00	Normal	
0x01	Touch test mode	
0x02	PIR sensor test mode	

#### Remark:

After changing the operating mode, the module sends his status.

There is a timeout of 30 minutes for the test mode.

#### 'Clear channel LED' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Linked module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_CLEAR\_LED (0xF5)

DATABYTE2 = LEDs to clear (a one clears the corresponding LED of channel 1 to 8)

```
'Clear channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
   DATABYTE1 = COMMAND\_CLEAR\_LED (0xF5)
   DATABYTE2 = LEDs to clear (a one clears the corresponding LED of channel 1 to 8)
'Set channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
   DATABYTE1 = COMMAND SET LED (0xF6)
   DATABYTE2 = LEDs to set (a one sets the corresponding LED of channel 1 to 8)
'Slow blink channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
   DATABYTE1 = COMMAND_SLOW_BLINK_LED (0xF7)
   DATABYTE2 = LEDs to blink slow (a one blinks slow the corresponding LED of channel 1 to 8)
'Fast blink channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
   DATABYTE1 = COMMAND_FAST_BLINK_LED (0xF8)
   DATABYTE2 = LEDs to blink fast (a one blinks fast the corresponding LED of channel 1 to 8)
'Very fast blink channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
   DATABYTE1 = COMMAND_VERY_FAST_BLINK_LED (0xF9)
   DATABYTE2 = LEDs to blink very fast (a one blinks very fast the corresponding LED of channel 1 to 8)
'Update channel LEDs' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 4 data bytes received
   DATABYTE1 = COMMAND_UPDATE_LED_STATUS (0xF4)
   DATABYTE2 = LEDs to set (a one sets the corresponding LED of channel 1 to 8)
   DATABYTE3 = LEDs to blink slow (a one blinks slow the corresponding LED of channel 1 to 8)
   DATABYTE4 = LEDs to blink fast (a one blinks very fast the corresponding LED of channel 1 to 8)
   Remark:
   The 'LEDs to set' status overrides the blinking modes.
   Very fast blinking if slow & fast blinking are set.
'Read data from memory' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 3 data bytes received
   DATABYTE1 = COMMAND_READ_DATA_FROM_MEMORY (0xFD)
   DATABYTE2 = High memory address
   DATABYTE3 = LOW memory address
   Remark: address range: 0x0000 to 0x06BB
```

#### 'Read data block from memory' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received / 4 data bytes for CAN FD response

 $DATABYTE1 = COMMAND\_READ\_MEMORY\_BLOCK (0xC9)$ 

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

DATABYTE4 = memory block length (5...60)

#### Remark:

address range: 0x0000 to 0x06B8

address range: 0x0000 to (0x06BC - memory block length) for CAN FD response

#### 'Memory dump request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 1 data bytes received

DATABYTE1 = COMMAND\_MEMORY\_DUMP\_REQUEST (0xCB)

#### 'Write data to memory' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 data bytes received

DATABYTE1 = COMMAND\_WRITE\_DATA\_TO\_MEMORY (0xFC)

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

DATABYTE4 = memory data to write

#### Remark:

Wait at least 10ms for sending a next command on the velbus.

Address range: 0x0000 to 0x06BB

Terminate always with a write command at the last memory location.

#### 'Write memory block' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 data bytes received

DATABYTE1 = COMMAND\_WRITE\_MEMORY\_BLOCK (0xCA)

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

DATABYTE4 = memory databyte1 to write

DATABYTE5 = memory databyte2 to write

DATABYTE6 = memory databyte3 to write

DATABYTE7 = memory databyte4 to write

Or

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the module

RTR = 0

DLC3...DLC0 = number of data bytes to send

Contents	Number of data bytes
0x09	12 data bytes
0x0A	16 data bytes
0x0B	20 data bytes
0x0C	24 data bytes
0x0D	32 data bytes
0x0E	48 data bytes
0x0F	64 data bytes

DATABYTE1 = COMMAND\_WRITE\_MEMORY\_BLOCK (0xCA)

DATABYTE2 = High memory address

```
DATABYTE3 = LOW memory address
   DATABYTE4 = memory block length (5...60)
   DATABYTE5 = memory data 1 to write
   DATABYTE12 = memory data 8 to write (end of data for DLC3...DLC0 = 0x09)
   DATABYTE16 = memory data 12 to write (end of data for DLC3...DLC0 = 0x0A)
   DATABYTE20 = memory data 16 to write (end of data for DLC3...DLC0 = 0x0B)
   DATABYTE24 = memory data 20 to write (end of data for DLC3...DLC0 = 0x0C)
   DATABYTE32 = memory data 28 to write (end of data for DLC3...DLC0 = 0x0D)
   DATABYTE48 = memory data 44 to write (end of data for DLC3...DLC0 = 0x0E)
   DATABYTE64 = memory data 60 to write (end of data for DLC3...DLC0 = 0x0F)
    Remark:
    Wait for 'memory data block' feedback before sending a next command on the velbus.
    address range: 0x0000 to 0x06B8 for standard CAN response
    address range: 0x0000 to (0x06BC – memory block length) for CAN FD response
   Contents of unused data bytes = 0x55
   Terminate always with a write command at the last memory location.
'Bus error counter status request' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 1 data byte received
   DATABYTE1 = COMMAND_BUS_ERROR_COUNTER STATUS REQUEST (H'D9')
'Unlock channel' command received:
   SID10-SID9 = 00 (highest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
   DATABYTE1 = COMMAND_CANCEL_FORCED_OFF (0x13)
   DATABYTE2 = Channel number 1...8, 9 or 18 (9 for temperature sensor, 18 for open collector output)
   Remark: channel number = 0xFF for all channels
'Lock channel' command received:
   SID10-SID9 = 00 (highest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 5 data bytes received
   DATABYTE1 = COMMAND\_FORCED\_OFF (0x12)
   DATABYTE2 = Channel number 1...8, 9 or 18 (9 for temperature sensor, 18 for open collector output)
   DATABYTE3 = high byte of delay time
   DATABYTE4 = mid byte of delay time
   DATABYTE5 = low byte of delay time
    Channel number = 0xFF for all channels
   [DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds
   The command will be skipped when the time parameter contains zero.
    When the time parameter contains 0xFFFFFF then the channel will be permanently locked.
'Enable Channel Program' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 data bytes received
```

DATABYTE1 = COMMAND\_ENABLE\_PROGRAM (0xB2)

Remark: channel number = 0xFF for all channels

### 'Disable Channel Program' command received:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 data bytes received

DATABYTE1 = COMMAND\_DISABLE\_PROGRAM (0xB1)

DATABYTE2 = Channel number1...8, 9 or 18 (9 for temperature sensor name, 18 for open collector output)

DATABYTE3 = high byte of delay time DATABYTE4 = mid byte of delay time DATABYTE5 = low byte of delay time

#### Remark:

Channel number = 0xFF for all channels

[DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds

The command will be skipped when the time parameter contains zero.

When the time parameter contains 0xFFFFFF then the channel program will be permanently disabled.

#### 'Select Program' command received:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SELECT\_PROGRAM (0xB3)

DATABYTE2 = Program mode

Contents	Selected program
0	None
1	Program group 1 (Summer)
2	Program group 2 (Winter)
3	Program group 3 (Holiday)

#### 'Sensor temperature request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SENSOR\_TEMP\_REQUEST (0xE5)

DATABYTE2 = Auto send time interval into seconds

(Valid range: 10...255s)

 $(5...9 = auto send on temperature change >= 0.5^{\circ})$ 

(1...4 = auto send disabled)

(0 = no change on auto send interval)

#### 'Sensor settings request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_REQUEST (0xE7)

DATABYTE2 = don't care

### 'Set heating mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SET\_HEATING\_MODE (0xE0)

DATABYTE2 = don't care

#### 'Set cooling mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SET\_COOLING\_MODE (0xDF)

DATABYTE2 = don't care

#### 'Set sensor zone number' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SET\_SENSOR\_ZONE\_NUMBER (0xC5)

DATABYTE2 = Zone number (0= no zone / 1...7 = valid zone)

### 'Set default sleep time' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND\_SET\_DEFAULT\_SLEEP\_TIME (0xE3)

DATABYTE2 = High byte of the default sleep time

DATABYTE3 = Low byte of the default sleep time into minutes

(Valid range 0x0001 to 0xFEFF or 1min to 65.279min)

Remark: Wait at least 20ms for sending a next command on the velbus

'Set temperature' command received: SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

 $DATABYTE1 = COMMAND\_SET\_TEMP (0xE4)$ 

DATABYTE2 = Pointer to temperature variable (0...20)

Contents	Temperature variable
0	Current target temperature set
1	Comfort temperature set for heating
2	Day temperature set for heating
3	Night temperature set for heating
4	Safe temperature set for heating
5	Temperature difference for turbo output
6	Hysteresis (0°15.5°C)
7	Comfort temperature set for cooling
8	Day temperature set for cooling
9	Night temperature set for cooling
10	Safe temperature set for cooling
11	Calibration offset factor (-8°+7.5°C)
12	Reset minimum/maximum temperature
14	enable/disable anti-block valve/pump
15	Temperature alarm 1 set
16	Temperature alarm 4 set
17	Lower temperature range cool mode
18	Upper temperature range heat mode
21	Minimum switching time
22	Pump delayed on time (0255 s)
23	Pump delayed off time (0255 s)
24	Temperature alarm 2 set
25	Temperature alarm 3 set
26	Lower temperature range heat mode
27	Upper temperature range cool mode
28	Calibration gain factor

### DATABYTE3 = Temperature set (resolution $0.5^{\circ}$ )

Contents	Temperature set
01111111	63.5°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
10010010	-55°C

### DATABYTE3 = Reset minimum/maximum temperature

Contents	Reset temperature
xxxxxxx1	Reset minimum temperature
xxxxxx1x	Reset maximum temperature

### DATABYTE3 = Enable/disable unjamming heater valve & pump

Contents	Enable/disable unjamming valve and pump
xxxxxx00	Disable unjamming heater valve & pump
xxxxxx01	Disable unjamming heater valve & enable unjamming pump
xxxxxx10	Enable unjamming heater valve & disable unjamming pump
xxxxxx11	Enable unjamming heater valve & pump

### DATABYTE3 = Minimum switching or pump delayed on/off time:

Contents	Operating mode	
00000000	No switching time protection	
00000001	1 seconds switching time protection	
00000010	2 seconds switching time protection	

11111110	254 seconds switching time protection
11111111	255 seconds switching time protection

#### Remark:

Valid hysteresis range =  $0 \dots 15.5$ °C

Valid calibration factor range = -8 ... 7.5°C

Wait at least 10ms for sending a next command on the velbus.

#### 'Switch to comfort mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND SWITCH TO COMFORT MODE (0xDB)

DATABYTE2 = High byte of the sleep time

DATABYTE3 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains 0xFF00, the command is a program step.

A sleep time between 0x0001 and 0xFEFF (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of 0xFFFF puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

#### 'Switch to day mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND\_SWITCH\_TO\_DAY\_MODE (0xDC)

DATABYTE2 = High byte of the sleep time

DATABYTE3 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains 0xFF00, the command is a program step.

A sleep time between 0x0001 and 0xFEFF (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of 0xFFFF puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

#### 'Switch to night mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND SWITCH TO NIGHT MODE (0xDD)

DATABYTE2 = High byte of the sleep time

DATABYTE3 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains 0xFF00, the command is a program step.

A sleep time between 0x0001 and 0xFEFF (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of 0xFFFF puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

#### 'Switch to safe temperature mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 data bytes received

DATABYTE1 = COMMAND\_SWITCH\_TO\_SAFE\_MODE (0xDE)

DATABYTE7 = High byte of the sleep time

DATABYTE8 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains 0xFF00, the command is a program step.

A sleep time between 0x0001 and 0xFEFF (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of 0xFFFF puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

### 'Switch open collector output off' command received:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

DATABYTE1 = COMMAND\_SWITCH\_RELAY\_OFF (0x01)

DATABYTE2 = channel bit = don't care

#### 'Switch open collector output on' command received:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 data bytes received

 $DATABYTE1 = COMMAND_SWITCH_RELAY_ON (0x02)$ 

DATABYTE2 = channel bit = don't care

#### 'Start open collector timer' command received:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 data bytes received

 $DATABYTE1 = COMMAND_START_RELAY_TIMER (0x03)$ 

DATABYTE2 = channel bit = don't care

DATABYTE3 = high byte of delay time

DATABYTE4 = mid byte of delay time

DATABYTE5 = low byte of delay time

#### Remark:

[DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds

The command will be skipped when the time parameter contains zero.

When the time parameter contains 0xFFFFFF then the open collector output are permanently switched on.

#### 'Read program step' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 data bytes received

DATABYTE1 = COMMAND READ PROGRAM STEP (0xC0)

DATABYTE2 = Start program step number (1...66)

DATABYTE3 = Program group number (1...3)

DATABYTE4 = Channel number1...8, 9 or 18 (9 for temperature sensor name, 18 for open collector output)

DATABYTE5 = Search direction (1 = search for next matched step / 0 = search for previous matched program step)

#### 'Write program step' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 data bytes received

DATABYTE1 = COMMAND\_WRITE\_PROGRAM\_STEP (0xC2)
DATABYTE2 = Program step number (1...66)

DATABYTE3 = Program reference

Contents	Description
000xxxxx	Disable program step
001xxxxx	Absolute time
010xxxxx	Wake up time 1 + relative time
011xxxxx	Go to bed time 1 + relative time
100xxxxx	Wake up time 2 + relative time
101xxxxx	Go to bed time 2 + relative time
110xxxxx	Sunrise + relative time
111xxxxx	Sunset + relative time
xxx01111	Rel. time = 3h45min
xxx00001	Rel. time = 15min
xxx00000	Rel. time = $0$
xxx11111	Rel. time = -15min
xxx10000	Rel. time = -4h

DATABYTE4 = Program step month & four least significant bits of day

Contents	Description
xxxx0000	Weekly program
xxxx0001	January
xxxx0010	February
xxxx0011	March
xxxx0100	April
xxxx0101	May
xxxx0110	June
xxxx0111	July
xxxx1000	August
xxxx1001	September
xxxx1010	October
xxxx1011	November
xxxx1100	December
xxxx1101	Monthly program
xxxx1110	Monthly program
xxxx1111	Monthly program

Contents byte6	Contents byte4	Description
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1 of the month
00xxxxxx	0010xxxx	Day 2of the month
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
	•••	
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mofr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
	•••	
11xxxxxx	1111xxxx	Never

DATABYTE5 = Program step hour & group number

Contents	Description
Comens	Description

xxx00000	Oh
xxx00001	1h
xxx10111	23h
xx1xxxxx	Program group 1 (Summer program)
x1xxxxxx	Program group 2 (Winter program)
1xxxxxxx	Program group 3 (Holiday program)

DATABYTE6 = Program step minute & msb of day & every flag

Contents	Description
xx000000	0min
xx000001	1min
xx111011	59min

Contents byte6	Contents byte4	Description
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1of the month
00xxxxxx	0010xxxx	Day 2of the month
•••		
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
	•••	
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mofr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
•••	•••	
11xxxxxx	1111xxxx	Never

DATABYTE7 = Program step action

Contents	Action	
0	0s25 Pulse (only allowed for button channels)	
1	1s Pulse (only allowed for button channels)	
2	2s Pulse (only allowed for button channels)	
•••		
119	1min59s Pulse (only allowed for button channels)	
120	2min Pulse (only allowed for button channels)	
121	2min15s Pulse (only allowed for button channels)	
131	4min45s Pulse (only allowed for button channels)	
132	5min Pulse (only allowed for button channels)	
133	5min30s Pulse (only allowed for button channels)	
181	29min30s Pulse (only allowed for button channels)	
182	30min Pulse (only allowed for button channels)	
183	31min Pulse (only allowed for button channels)	
211	59min Pulse (only allowed for button channels)	
212	1h Pulse (only allowed for button channels)	
213	1h15min Pulse (only allowed for button channels)	
•••		
227	4h45min Pulse (only allowed for button channels)	
228	5h Pulse (only allowed for button channels)	
229	5h30min Pulse (only allowed for button channels)	
237	9h30min Pulse (only allowed for button channels)	
238	10h Pulse (only allowed for button channels)	

239	11h Pulse (only allowed for button channels)
•••	
246	18h Pulse (only allowed for button channels)
247	Press (only allowed for button channels)
248	Long Press (only allowed for button channels)
249	Release (only allowed for button channels)
250	Lock
251	Unlock
252	Thermostat safe mode (only allowed for temperature sensor channel)
253	Thermostat night mode (only allowed for temperature sensor channel)
254	Thermostat day mode (only allowed for temperature sensor channel)
255	Thermostat comfort mode (only allowed for temperature sensor channel)

# DATABYTE8 = Channel

Contents	Channel
1	Button 1
2	Button 2
3	Button 3
4	Button 4
5	Twilight (light/dark) channel (only lock/unlock action)
6	Motion channel (only lock/unlock action)
7	Light depending motion channel (only lock/unlock action)
8	Absence channel (only lock/unlock action)
9	Temperature sensor (only lock/unlock & thermostat actions)
18	Open collector output (only lock/unlock action)

### Remark:

Erase program step if channel parameter is equal with zero.

# **Memory map version 4:**

4 7 7		4 1 7	
Address	Contents	Address	Contents
0x0000	Touch init: main control	0x0001	Touch init: sensistivity
0x0002	Touch init: config 1	0x0003	Touch init: sensor enable
0x0004	Touch init: sensor config 1	0x0005	Touch init: sensor config 2
0x0006	Touch init: average sampling	0x0007	Touch init: interrupt enable
0x0008	Touch init: repeat enable	0x0009	Touch init: mtp config
0x000A	Touch init: mtp pattern config	0x000B	Touch init: mtp pattern
0x000C	Touch init: recal config	0x000D	Touch init: sensor 1 threshold
0x000E	Touch init: sensor 2 threshold	0x000F	Touch init: sensor 3 threshold
0x0010	Touch init: sensor 4 threshold	0x0011	Touch init: sensor 5 threshold
0x0012	Touch init: sensor 6 threshold	0x0013	Touch init: sensor 7 threshold
0x0014	Touch init: sensor 8 threshold	0x0015	Touch init: noise threshold
0x0016	Touch init: standby channel	0x0017	Touch init: standby config
0x0018	Touch init: standby sensitivity	0x0019	Touch init: standby threshold
0x001A	Touch init: config 2	0x001B	Touch init: not used
0x001C	Channel 1 name character 1	0x001D	Channel 1 name character 2
0x002A	Channel 1 name character 15	0x002B	Channel 1 name character 16
0x002C	Channel 1 reaction time	0x002D	Channel 1 start function
0x002E	Channel 1 end function	0x002F	Channel 1 mode
ONOGEE	Chamer I tha function	0.10021	
0x0058	Channel 4 name character 1	0x0059	Channel 4 name character 2
0.00000	Chamier 4 hanc character 1	080037	Chamici 4 hanc character 2
0x0066	Channel 4 name character 15	0x0067	Channel 4 name character 16
0x0068	Channel 4 reaction time	0x0069	Channel 4 start function
0x0068	Channel 4 end function	0x0069 0x006B	Channel 4 start function  Channel 4 mode
0x006C	Long pressed delay	0x006D	Dual function long pressed time
0x006E	Key beep & One button mode	0x006F	Feedback led brightness for GPx series
0x0070	Dark value low byte	0x0071	Dark value high byte
0x0072	Light value low byte	0x0073	Light value high byte
0x0074	Light to dark reaction time (default 1 min)	0x0075	Dark timer mode = non restartable timer (fixed)
0x0076	Dark timeout (default momentary)	0x0077	Dark flags:
			Bit 0: cycling protect non-restartable timer (default on)
			Bit 1: external overwrite non-restartable timer (default off)
0x0078	Dark to light reaction time (default 1 min)	0x0079	Light timer mode = non restartable timer (fixed)
0x007A	Light timeout (default momentary)	0x007B	Light flags:
			Bit 0: cycling protect non-restartable timer = off (fixed)
			Bit 1: external overwrite non-restartable timer (default off)
0x007C	Motion reaction time = 0 sec (fixed)	0x007D	Motion timer mode = restartable timer (fixed)
0x007E	Motion timeout (default 2 min)	0x007F	Motion flags:
			Bit 0: cycling protect
			Bit 1: external overwrite restartable timer (default off)
0x0080	Dark value low byte for light depending motion 1	0x0081	Dark value high byte for light depending motion 1
0x0082	Light value low byte for light depending motion 1	0x0083	light value high byte for light depending motion 1
	(0.98*motion 1 dark value)		
0x0084	Dark reaction time for light depending motion $1 = 0$ sec	0x0085	Dark timer mode for light depending motion $1 = non$
	(fixed)		restartable timer (fixed)
0x0086	Dark timeout for light depending motion 1 = momentary	0x0087	Dark flags for light depending motion 1:
	(fixed)		Bit 0: cycling protect = off (fixed)
			Bit 1: external overwrite off (fixed)
0x0088	Light depending motion 1 reaction time = 0 sec (fixed)	0x0089	Light depending motion 1 timer mode = restartable timer
			(fixed)
0x008A	Light depending motion 1 timeout (default 2 min)	0x008B	Light depending motion 1 flags:
			Bit 0: cycling protect
			Bit 1: external overwrite (default off)
0x008C	Absence timeout	0x008D	Absence output mode
0x008E	Twilight output selection	0x008F	Not used
0x0090	reserved	0x0091	reserved
•••			
0x0326	reserved	0x0327	reserved
0x0328	Not used	0x0329	Not used
0x032A	Not used	0x032B	Alarm clock configuration
0x032C	Wake up 1 hour (023)	0x032D	Wake up 1 minutes (059)
0x032E	Go to bed 1 hour (023)	0x032F	Go to bed 1 minutes (059)
0x0330	Wake up 2 hour (023)	0x0331	Wake up 2 minutes (059)
		50001	

0x0332	Go to had 2 hour (0 22)	0v0222	Go to had 2 minutes (0 50)
	Go to bed 2 hour (023)	0x0333	Go to bed 2 minutes (059)
0x0334	Sunrise hour at 21 December (023)	0x0335	Sunrise minutes at 21 December (059)
0x0336	Sunrise 21 January – sunrise 5 January (-128'127')	0x0337	Sunrise 5 February – sunrise 21 January (-128'127')
0x0338	Sunrise 21 February – sunrise 5 February (-128'127')	0x0339	Sunrise 5 March – sunrise 21 February (-128'127')
0x033A	Sunrise 21 March – sunrise 5 March (-128'127')	0x033B	Sunrise 5 April – sunrise 21 March (-128'127')
0x033C	Sunrise 21 April – sunrise 5 April (-128'127')	0x033D	Sunrise 5 May – sunrise 21 April (-128'127')
0x033E	Sunrise 21 May – sunrise 5 May (-128'127')	0x033F	Sunrise 5 June – sunrise 21 May (-128'127')
0x0340	Sunrise 21 June – sunrise 5 June (-128'127')	0x0341	Sunrise 5 July – sunrise 21 June (-128'127')
0x0342	Sunrise 21 July – sunrise 5 July (-128'127')	0x0343	Sunrise 5 August – sunrise 21 July (-128'127')
0x0344	Sunrise 21 August – sunrise 5 August (-128'127')	0x0345	Sunrise 5 September – sunrise 21 August (-128'127')
0x0346	Sunrise 21 September – sunrise 5 September (-128127')	0x0347	Sunrise 5 October – sunrise 21 Sept. (-128'127')
0x0348	Sunrise 21 October – sunrise 5 October (-128'127')	0x0349	Sunrise 5 November – sunrise 21 Oct. (-128'127')
0x034A	Sunrise 21 November – sunrise 5 November (-128'127')	0x034B	Sunrise 5 December – sunrise 21 Nov. (-128'127')
0x034C	Sunrise 21 December – sunrise 5 December (-128'127')	0x034D	Sunrise 5 January – sunrise 21 December (-128'127')
0x034E	Not used	0x034F	Not used
0x0350	Sunset hour at 21 December (023)	0x0351	Sunset minutes at 21 December (059)
0x0352	Sunset 21 January – sunset 5 January (-128'127')	0x0353	Sunset 5 February – sunset 21 January (-128'127')
0x0354	Sunset 21 February – sunset 5 February (-128'127')	0x0355	Sunset 5 March – sunset 21 February (-128'127')
0x0356	Sunset 21 March – sunset 5 March (-128'127')	0x0357	Sunset 5 April – sunset 21 March (-128'127')
0x0358	Sunset 21 April – sunset 5 April (-128'127')	0x0359	Sunset 5 May – sunset 21 April (-128'127')
0x035A	Sunset 21 May – sunset 5 May (-128'127')	0x035B	Sunset 5 June – sunset 21 May (-128'127')
0x035C	Sunset 21 June – sunset 5 June (-128'127')	0x035D	Sunset 5 July – sunset 21 June (-128'127')
0x035E	Sunset 21 July – sunset 5 July (-128'127')	0x035F	Sunset 5 August – sunset 21 July (-128'127')
0x0360	Sunset 21 August – sunset 5 August (-128'127')	0x0361	Sunset 5 September – sunset 21 August (-128'127')
0x0362	Sunset 21 September – sunset 5 September (-128'127')	0x0363	Sunset 5 October – sunset 21 September (-128'127')
0x0364	Sunset 21 October – sunset 5 October (-128'127')	0x0365	Sunset 5 November - sunset 21 October (-128'127')
0x0366	Sunset 21 October – sunset 5 October (-128127)  Sunset 21 November – sunset 5 November (-128'127')	0x0367	Sunset 5 November - sunset 21 October (-128127)  Sunset 5 December - sunset 21 Nov. (-128'127')
0x0368			
	Sunset 21 December – sunset 5 December (-128'127')  Not used	0x0369	Sunset 5 January – sunset 21 December (-128'127')  Not used
0x036A		0x036B	
0x036C	Sensor name character 1	0x036D	Sensor name character 2
0x037A	Sensor name character 15	0x037B	Sensor name character 16
0x037C	Temp. sensor: zone	0x037D	Temp. sensor: calibration offset
0x037E	Temp. sensor: calibration gain	0x037F	Temp. sensor: hysteresis
0x037E	Temp. sensor: boost difference	0x0371	Temp. sensor: Pump delayed on
0x0380	Temp. sensor: pump delayed off	0x0381	Temp. sensor: min switching time
0x0384	Temp. sensor: default sleep time byte 0 (low)	0x0385	
			Temp. sensor: default sleep time byte 1 (high)
0x0386	Temp. sensor: default sleep time byte 2	0x0387	Temp. sensor: default sleep time byte 3 (msb)
0x0388	Temp. sensor: heater lower temperature range low byte	0x0389	Temp. sensor: heater lower temperature range high byte
0x038A	Temp. sensor: heater upper temperature range low byte	0x038B	Temp. sensor: heater lower temperature range high byte
0x038C	Temp. sensor: heater safe temperature set	0x038D	Temp. sensor: heater night temperature set
0x038E	Temp. sensor: heater day temperature set	0x038F	Temp. sensor: heater comfort temperature set
0x0390	Temp. sensor: cooler lower temperature range low byte	0x0391	Temp. sensor: cooler upper temp. range high byte
0x0392	Temp. sensor: cooler upper temperature range low byte	0x0393	Temp. sensor: cooler upper temp. range high byte
0x0394	Temp. sensor: cooler safe temperature set	0x0395	Temp. sensor: cooler night temperature set
0x0396	Temp. sensor: cooler day temperature set	0x0397	Temp. sensor: cooler comfort temperature set
0x0398	Temp. sensor: alarm 1 temperature set	0x0399	Temp. sensor: alarm 2 temperature set
0x039A	Temp. sensor: alarm 3 temperature set	0x039B	Temp. sensor: alarm 4 temperature set
0x039C	Temp. sensor settings	0x039D	Temp. sensor alarm 1 & 2 settings
0x039E	Temp. sensor alarm 3 & 4 settings	0x039F	Not used
0x03A0	Open collector output name character 1	0x03A1	Open collector output name character 2
0x03AE	Open collector output name character 15	0x03AF	Open collector output name character 16
	• •		· ·

### Remark:

Unused locations contain H'FF'

### Valid reaction times

Contents	Reaction time
0x01	immediately (default)
0x1C	1s
0x38	2s
0x54	3s
0xFF	Channel disabled

Channel x start/end function

Contents	Function
1	Channel 1 (default)
2	Channel 2 (default)
3	Channel 3 (default)
4	Channel 4 (default)

#### Remark:

For a normal one button function, the start and end function channel are the same.

For a multi-function button, the start function channel must be less than the end function. At every press the next channel will be send. When the end function channel is reached, the start channel will be send again at the next press.

For a dual function button, the start function channel will be send at a short press or the end function will be send at a long press.

#### Channels mode

Contents	Description
B'xxxxxxx0'	Dual function disabled (default)
B'xxxxxxx1'	Dual function enabled
B'xxxxxx0x'	Multi-function auto reset disabled (default)
B'xxxxxx1x'	Multi-function auto reset enabled
B'xxxxx0xx'	Led backlight off
B'xxxxx1xx'	Led backlight on
B'xxxx0xxx'	Led monitor mode
B'xxxx1xxx'	Led feedback mode (default)
B'xxx0xxxx'	Slow blinking led feedback disabled
B'xxx1xxxx'	Slow blinking led feedback enabled (default)
B'xx0xxxxx'	Fast blinking led feedback disabled
B'xx1xxxxx'	Fast blinking led feedback enabled (default)
B'x0xxxxxx'	Very fast blinking led feedback disabled
B'x1xxxxxx'	Very fast blinking led feedback enabled (default)

#### Remark:

When auto reset is enabled, the start function will be loaded again after 3 seconds inactivity of the channel. For a dual function button, the start function channel will be send at a short press or the end function will be send at a long press.

The dual function overwrites the multi-function mode.

Valid long pressed delay

Contents	Reaction time
0x17	0.8s (default)
0x2E	1.6s

Valid dual function long pressed times

Contents	Long pressed time
0x1C	1s
0x38	2s (default)
0x54	3s

Key beep & One button mode

Contents	Mode
B'xxxxxxx0'	Key beep disabled
B'xxxxxxx1'	Key beep enabled
B'xxxxxx0x'	4 independent buttons (default)
B'xxxxxx1x'	One button mode (the 4 buttons functions as one button)

Feedback led brightness for GPx series

Contents	Brightness
B'xxxx0000'	0% Minimum brightness
B'xxxx0001'	7% Minimum brightness
B'xxxx0010'	9% Minimum brightness
B'xxxx0011'	11% Minimum brightness
B'xxxx0100'	14% Minimum brightness
B'xxxx0101'	17% Minimum brightness
B'xxxx0110'	20% Minimum brightness

B'xxxx0111'	23% Minimum brightness
B'xxxx1000'	26% Minimum brightness
B'xxxx1001'	30% Minimum brightness
B'xxxx1010'	35% Minimum brightness
B'xxxx1011'	40% Minimum brightness
B'xxxx1100'	46% Minimum brightness
B'xxxx1101'	53% Minimum brightness
B'xxxx1110'	63% Minimum brightness
B'xxxx1111'	77% Minimum brightness
B'0000xxxx'	7% Maximum brightness
B'0001xxxx'	9% Maximum brightness
B'0010xxxx'	11% Maximum brightness
B'0011xxxx'	14% Maximum brightness
B'0100xxxx'	17% Maximum brightness
B'0101xxxx'	20% Maximum brightness
B'0110xxxx'	23% Maximum brightness
B'0111xxxx'	26% Maximum brightness
B'1000xxxx'	30% Maximum brightness
B'1001xxxx'	35% Maximum brightness
B'1010xxxx'	40% Maximum brightness
B'1011xxxx'	46% Maximum brightness
B'1100xxxx'	53% Maximum brightness
B'1101xxxx'	63% Maximum brightness
B'1110xxxx'	77% Maximum brightness
B'1111xxxx'	100% Maximum brightness

Alarm clock configuration

Contents	Channel locked/unlocked
B'xxxxxx0'	Alarm 1 disabled (default)
B'xxxxxxx1'	Alarm 1 enabled
B'0xxxxx0x'	Local alarm 1 (default)
B'1xxxxx1x'	Global alarm 1
B'xxxxx0xx'	Alarm 2 disabled (default)
B'xxxxx1xx'	Alarm 2 enabled
B'xxxx0xxx'	Local alarm 2 (default)
B'xxxx1xxx'	Global alarm 2
B'xxx0xxxx'	Sunrise disabled
B'xxx1xxxx'	Sunrise enabled (default)
B'xx0xxxxx'	Sunset disabled
B'xx1xxxxx'	Sunset enabled (default)
B'x0xxxxxx'	Day light savings disabled
B'x1xxxxxx'	Day light savings enabled (default)

Temp. sensor zone

Contents	Zone
0'	No zone
1.	Zone 1
7	Zone 7

Temperature sensor flags

in per acar e sensor juags	
Contents	Description
B'xxxxxxx0'	Pump unjamming disabled (default)
B'xxxxxxx1'	Pump unjamming enabled
B'xxxxxx0x'	Heater valve unjamming disabled (default)
B'xxxxxx1x'	Heater valve unjamming enabled
B'xxxxx0xx'	Independent temperature alarms (default)
B'xxxxx1xx'	Dependent temperature alarms

Temperature sensor calibration offset (resolution  $0.5^{\circ}$ ):

Contents	Calibration offset	

00001111	Calibration offset +7.5°C
00000001	Calibration offset +0.5°C
00000000	Calibration offset +0°C (default)
11111111	Calibration offset -0.5°C
11110000	Calibration offset -8°C

Temperature sensor calibration gain:

Contents	Calibration gain
0	Calibration gain
128	Calibration gain (default)
255	Calibration gain

Calibrated Temperature = (gain/128) \* sensortemperature + offset

Temperature sensor hysteresis (resolution 0.5°):

- '	temperature sensor mysteresis (resortation one ).		
	Contents	Hysteresis	
	00011111	15.5°C	
	00000001	0.5°C	
	00000000	0°C	

Temperature sensor boost difference (resolution  $0.5^{\circ}$ ):

Contents	Temperature difference
00010100	+10°C
00000001	+0.5°C
00000000	0°C
11111111	-0.5°C
11101100	-10°C

Temperature sensor pump delayed on, pump delayed off & valve minimum switching time:

Contents	Time
00000000	0
00000001	1 sec
00000010	2 sec
11111110	254 sec
11111111	255 sec

### Temperature sensor default sleep time into minutes

valid range 0x0001 to 0xFEFF or 1min to 65.279min

Temperature sensor lower range, upper range, safe, night, day, comfort or alarm set (resolution 0.5°):

Contents	Temperature set
01111000	60°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
11000000	-32°C

Temperature sensor Alarm1 & 2 modes

Contents	Description
B'xxxxx000'	Low temperature alarm 1

B'xxxxx001'	High temperature alarm 1 (default)
B'xxxxx010'	Anti-frost mode alarm 1
B'xxxxx011'	Night mode alarm 1
B'xxxxx100'	Day mode alarm 1
B'xxxxx101'	Comfort mode alarm 1
B'xxxxx110'	Night, Day or Comfort mode alarm 1
B'xxxxx111'	Day or Comfort mode alarm 1
B'xxxx0xxx'	Temperature alarms 1 absolute (default)
B'xxxx1xxx'	Temperature alarms 1 relative
B'x000xxxx'	Low temperature alarm 2
B'x001xxxx'	High temperature alarm 2 (default)
B'x010xxxx'	Anti-frost mode alarm 2
B'x011xxxx'	Night mode alarm 2
B'x100xxxx'	Day mode alarm 2
B'x101xxxx'	Comfort mode alarm 2
B'x110xxxx'	Night, Day or Comfort mode alarm 2
B'x111xxxx'	Day or Comfort mode alarm 2
B'0xxxxxxx'	Temperature alarms 2 absolute (default)
B'1xxxxxxx'	Temperature alarms 2 relative

Temperature sensor Alarm3 & 4 modes

Contents	Description
B'xxxxx000'	Low temperature alarm 3
B'xxxxx001'	High temperature alarm 3 (default)
B'xxxxx010'	Anti-frost mode alarm 3
B'xxxxx011'	Night mode alarm 3
B'xxxxx100'	Day mode alarm 3
B'xxxxx101'	Comfort mode alarm 3
B'xxxxx110'	Night, Day or Comfort mode alarm 3
B'xxxxx111'	Day or Comfort mode alarm 3
B'xxxx0xxx'	Temperature alarms 3 absolute (default)
B'xxxx1xxx'	Temperature alarms 3 relative
B'x000xxxx'	Low temperature alarm 4
B'x001xxxx'	High temperature alarm 4 (default)
B'x010xxxx'	Anti-frost mode alarm 4
B'x011xxxx'	Night mode alarm 4
B'x100xxxx'	Day mode alarm 4
B'x101xxxx'	Comfort mode alarm 4
B'x110xxxx'	Night, Day or Comfort mode alarm 4
B'x111xxxx'	Day or Comfort mode alarm 4
B'0xxxxxxx'	Temperature alarms 4 absolute (default)
B'1xxxxxxx'	Temperature alarms 4 relative

Reaction time (light to dark, dark to light, motion & light depending motion)

Contents	Reaction time
0	Os (factory default for motion & light depending motion)
1	1s
2	2s
59	59s
60	1min (factory default for light to dark & dark to light)
61	1min1s
•••	
119	1min59s
120	2min
121	2min15s
131	4min45s

132	5min
133	5min30s
181	29min30s
182	30min
183	31min
211	59min
212	1h

Timer mode (dark, light, motion & light depending motion)

Contents	Timer mode
0x00	non restartable timer (for dark & light)
0xFF	restartable timer (for motion & light depending motion)

Timeout (light to dark, dark to light, motion & light depending motion)

Contents	Timeout
0	0 = momentary (factory default for dark, light & motion)
1	1s
2	2s
119	1min59s
120	2min (factory default for light depending motion)
121	2min15s
131	4min45s
132	5min
133	5min30s
181	29min30s
182	30min
183	31min
•••	
211	59min
212	1h
213	1h15min
•••	
227	4h45min
228	5h
229	5h30min
•••	
237	9h30min
238	10h

#### Absence timeout

Time parameter	Timeout
60	1min
61	1min1s
62	1min2s
119	1min59s
120	2min
121	2min15s
131	4min45s
132	5min
133	5min30s
152	15min (default)
181	29min30s
182	30min

183	31min
211	59min
212	1h
213	1h15min
227	4h45min
228	5h
229	5h30min
237	9h30min
238	10h
239	11h
251	23h
252	1d

Absence output mode

Contents	Absence output mode
0x00	Momentary (default)
0xFF	1 second pulse

Dark flags

-	ark jugs	
	Contents	Timer mode
	B'xxxxxxx0'	Cycling protection non-restartable timer disabled
	B'xxxxxxx1'	Cycling protection non-restartable timer enabled (default)
	B'xxxxxx0x'	External overwrite disabled (default)
	B'xxxxxx1x'	External overwrite enabled

Light flags

Contents	Timer mode	
B'xxxxxxx0'	Cycling protection non-restartable timer disabled (fixed)	
B'xxxxxxx1'	Cycling protection non-restartable timer enabled	
B'xxxxxx0x'	External overwrite disabled (default)	
B'xxxxxx1x'	External overwrite enabled	

Motion flags

one just		
Contents Timer mode		
B'xxxxxxx0' Cycling protection disabled -> time-out interruptable		
B'xxxxxxx1'	B'xxxxxxx1' Cycling protection enabled -> time-out not interruptable	
B'xxxxxx0x'	B'xxxxxx0x' External overwrite disabled (default)	
B'xxxxxx1x'	External overwrite enabled	

Light depending motion flags

shi depending monon jugs		
Contents	ents Timer mode	
B'xxxxxxx0' Cycling protection disabled -> time-out interruptable		
B'xxxxxxx1'	Cycling protection enabled -> time-out not interruptable	
B'xxxxxx0x'	xxxx0x' External overwrite disabled (default)	
B'xxxxxx1x'	xxxx1x' External overwrite enabled	

Twilight output selection

Contents	output selection	
0x00	Dark output (default)	
0x01	Light output	

Address	Contents	Address	Contents
0x03B0 Links in use byte 0 (LSB)		0x03B1	Links in use high byte1
0x03B2 Links in use low byte 2		0x03B3	Links in use low byte 3 (MSB)
0x03B4	Linked Push button 1 module address	0x03B5	Linked Push button 1 bit number
0x03B6 Linked Push button 1 action		0x03B7	Linked Push button 1 parameter 1
0x03B8 Linked Push button 1 parameter 2			
		0x0503	Linked Push button 68 address
0x0504	Linked Push button 68 bit number	0x0505	Linked Push button 68 action
0x0506	Linked Push button 68 parameter 1	0x0507	Linked Push button 68 parameter 2

**Remark:** Unused locations contain 0xFF

### Action

number	
0 Switch status led indication - Channel	
	18, 9 or 18
2 Lock channel at opened switch - Channel	18, 9 or 18
3 Lock channel Timeout Channel	18, 9 or 18
	18, 9 or 18
5 Unlock channel - Channel	18, 9 or 18
6 Disable channel program at closed switch - Channel	18, 9 or 18
7 Disable channel program at opened switch - Channel	18, 9 or 18
8 Disable channel program channel Timeout Channel	18, 9 or 18
9 Disable/enable channel program Timeout Channel	18, 9 or 18
10 Enable channel program - Channel	18, 9 or 18
11 Select no programs	
12 Select program group 1	
13 Toggle program group 1	
14 Select program group 2	
15 Toggle program group 2	
16 Select program group 3	
17 Toggle program group 3	
18 Enable Alarm 1 at closed switch	
19 Enable Alarm 1 at open switch	
20 Disable Alarm 1 at closed switch	
21 Disable Alarm 1 at open switch	
22 Enable Alarm 1	
23 Enable/Disable Alarm 1	
24 Disable Alarm 1	
25 Enable Alarm 2 at closed switch	
26 Enable Alarm 2 at open switch	
27 Disable Alarm 2 at closed switch	
28 Disable Alarm 2 at open switch	
29 Enable Alarm 2	
30 Enable/Disable Alarm 2	
31 Disable Alarm 2	
32 Enable Sunrise at closed switch	
33 Enable Sunrise at open switch	
34 Disable Sunrise at closed switch	
35 Disable Sunrise at open switch	
36 Enable Sunrise	
37 Enable/Disable Sunrise	
38 Disable Sunrise	
39 Enable Sunset at closed switch	
40 Enable Sunset at open switch	
41 Disable Sunset at closed switch	
42 Disable Sunset at open switch	
43 Enable Sunset	
44 Enable/Disable Sunset	
45 Disable Sunset	
46 Output momentary	
47 Output off	
48 Output on	
49 Output toggle	
50 Output start/stop timer timeout -	

<i>5</i> 1	Output mastantable timen	timaqut	
51	Output restartable timer	timeout	-
52	Output non retriggerable timer	timeout	-
53	Output trigger on release timer	timeout	-
54	Sensor: Comfort mode	Short press sleep time	Long press sleep time
55	Sensor: Day mode	Short press sleep time	Long press sleep time
56	Sensor: Night mode	Short press sleep time	Long press sleep time
57	Sensor: Safe mode	Short press sleep time	Long press sleep time
58	Sensor: Heating mode	-	-
59	Sensor: Cooling mode	-	-
90	Sensor: Forced Safe mode at closed switch	-	-
91	Sensor: Forced Safe mode at open switch	-	-
92	Sensor: Forced Safe mode	Timeout	-
93	Sensor: Forced or Cancel Forced Safe mode	Timeout	-
94	Sensor: Cancel Forced Safe mode	-	-
101	Reset Absence timer at closed switch	-	-
102	Output pulse	Timeout (multiple of 10ms)	-
103	Output logical OR		
104	Output logical NOR		
105	Output logical AND		
106	Output logical NAND		
107	Output logical XOR		
108	Output logical XNOR		
109	Output pulse interval at closed switch	Pulse time (multiple of 10ms)	Pause time (multiple of 10ms)

Time parameter

ime parameter		
Time	Timeout	
parameter		
0	0s (no timer)	
1	1s	
2	2s	
3	3s	
119	1min59s	
120	2min	
121	2min15s	
131	4min45s	
132	5min	
133	5min30s	
181	29min30s	
182	30min	
183	31min	
	0 1 1 1 1 1 1	
211	59min	
212	1h	
213	1h15min	
	1111011111	
227	4h45min	
228	5h	
229	5h30min	
237	9h30min	
238	10h	
239	11h	
	1111	
251	23h	
251		
	1d	
253	2d	
254	3d	
255	Infinite	

Sleep time	Action	
parameter		
0	No action	
1	Select until next program step execution	
2	Select for default sleep time (see sensor config.)	
3	Select for 15 min (auto return to program)	
4	Select for 30 min (auto return to program)	
•••		
17	Select for 3h45 min (auto return to program)	
18	Select for 4h min (auto return to program)	
19 Select for 4h30 min (auto return to program)		
33	Select for 11h30 min (auto return to program)	
34 Select for 12h (auto return to program) 35 Select for 13h (auto return to program)		
45 Select for 23h (auto return to program)		
46	Select for 1 day (auto return to program)	
47	Select for 1 day 12h (auto return to program)	
57	Select for 6 days 12h (auto return to program)	
58 Select for 7 days (auto return to program)		
59	Select for 8 days (auto return to program)	
96	Select for 45 days (auto return to program)	
97	Select and ignore all program steps	

## Channel

1			
	Contents	Channel	
	1	Button 1	

2	Button 2
3	Button 3
4	Button 4
5	Twilight (light/dark) channel
6	Motion channel
7	Light depending motion channel
8	Absence channel
18	Open collector output (only lock/unlock action)

Address	Contents	Address	Contents
0x0508	Program steps used byte 0 (LSB)	0x0509	Program steps used byte 1
0x050A	Program steps used byte 2	0x050B	Program steps used byte 3 (MSB)
0x050C	Program step 1 byte1	0x050D	Program step 1 byte2
0x050E	Program step 1 byte3	0x050F	Program step 1 byte4
0x0510 Program step 1 byte5		0x0511	Program step 1 byte6
•••			
0x069E	Program step 68 byte1	0x069F	Program step 68 byte2
0x06A0	Program step 68 byte3	0x06A1	Program step 68 byte4
0x06A2	Program step 68 byte5	0x06A3	Program step 68 byte6

Contents program byte1	Description	
B'000xxxxx'	Disable program step	
B'001xxxxx'	Absolute time	
B'010xxxxx'	Wake up time 1 + relative time	
B'011xxxxx'	Go to bed time 1 + relative time	
B'100xxxxx'	Wake up time 2 + relative time	
B'101xxxxx'	Go to bed time 2 + relative time	
B'110xxxxx'	Sunrise + relative time	
B'111xxxxx'	Sunset + relative time	
B'xxx01111'	Rel. time = 3h45min	
B'xxx00001'	Rel. time = 15min	
B'xxx00000'	Rel. time = $0$	
B'xxx11111'	Rel. time = -15min	
•••		
B'xxx10000'	Rel. time = -4h	

Remark: Wake up, Go to bed, sunrise & sunset time are only allowed for weekly programs

Contents program byte2	Description
B'xxxx0000'	Weekly program
B'xxxx0001'	January
B'xxxx0010'	February
B'xxxx0011'	March
B'xxxx0100'	April
B'xxxx0101'	May
B'xxxx0110'	June
B'xxxx0111'	July
B'xxxx1000'	August
B'xxxx1001'	September
B'xxxx1010'	October
B'xxxx1011'	November
B'xxxx1100'	December
B'xxxx1101'	Monthly program
B'xxxx1110'	Monthly program
B'xxxx1111'	Monthly program

Contents program byte3	Description
B'xxx00000'	Oh
B'xxx00001'	1h
B'xxx10111'	23h
B'xx1xxxxx'	Program group 1 (Summer program)
B'x1xxxxxx'	Program group 2 (Winter program)
B'1xxxxxxx'	Program group 3 (Holiday program)

Description
Omin
1min
59min

Contents program byte4	Contents program byte2	Description
B'00xxxxxx'	B'0000xxxx'	Never
B'00xxxxxx'	B'0001xxxx'	Day 1 of the month
B'00xxxxxx'	B'0010xxxx'	Day 2of the month
•••	•••	
B'01xxxxxx'	B'1111xxxx'	Day 31of the month
B'10xxxxxx'	B'0000xxxx'	Never
B'10xxxxxx'	B'0001xxxx'	Every Monday
B'10xxxxxx'	B'0010xxxx'	Every Tuesday
B'10xxxxxx'	B'0111xxxx'	Every Sunday
B'10xxxxxx'	B'1000xxxx'	Every weekend (sa & su)
B'10xxxxxx'	B'1001xxxx'	Every working day (mofr)
B'10xxxxxx'	B'1010xxxx'	Every day except Sunday
B'10xxxxxx'	B'1011xxxx'	Every day
B'10xxxxxx'	B'1100xxxx'	Never
B'11xxxxxx'	B'1111xxxx'	Never

Contents program byte5	Action	
0	0s25 Pulse (only allowed for button channels)	
1	1s Pulse (only allowed for button channels)	
2	2s Pulse (only allowed for button channels)	
119	1min59s Pulse (only allowed for button channels)	
120	2min Pulse (only allowed for button channels)	
121	2min15s Pulse (only allowed for button channels)	
131	4min45s Pulse (only allowed for button channels)	
132	5min Pulse (only allowed for button channels)	
133	5min30s Pulse (only allowed for button channels)	
181	29min30s Pulse (only allowed for button channels)	
182	30min Pulse (only allowed for button channels)	
183	31min Pulse (only allowed for button channels)	
211	59min Pulse (only allowed for button channels)	
212	1h Pulse (only allowed for button channels)	
213	1h15min Pulse (only allowed for button channels)	
227	4h45min Pulse (only allowed for button channels)	
228	5h Pulse (only allowed for button channels)	
229	5h30min Pulse (only allowed for button channels)	
237	9h30min Pulse (only allowed for button channels)	
238	10h Pulse (only allowed for button channels)	
239	11h Pulse (only allowed for button channels)	
246	18h Pulse (only allowed for button channels)	
247	Press (only allowed for button channels)	
248	Long Press (only allowed for button channels)	
249	Release (only allowed for button channels)	
250	Lock	
251	Unlock	
252	Thermostat safe mode (only allowed for temperature sensor channel)	
253	Thermostat night mode (only allowed for temperature sensor channel)	
254	Thermostat day mode (only allowed for temperature sensor channel)	
255	Thermostat comfort mode (only allowed for temperature sensor channel)	

Contents program byte6	Channel
1	Button 1
2	Button 2
3	Button 3
4	Button 4
5	Twilight (light/dark) channel (only action 250 & 251 allowed)
6	Motion channel (only action 250 & 251 allowed)
7	Light depending motion channel (only action 250 & 251 allowed)
8	Absence channel (only action 250 & 251 allowed)
9	Temperature sensor (only action 252255 allowed)
18	Open collector output (only action 250 & 251 allowed)

Address	Contents	Address	Contents
0x06A4	Location id low byte	0x06A5	Location id high byte
0x06A6	Group id low byte	0x06A7	Group id high byte
0x06A8	Module name character 1	0x06A9	Module name character 2
		••	
0x06E6	Module name character 63	0x06E7	Module name character 64
0x06E8	Not used	0x06E9	Not used
0x06EA	Not used	0x06EB	Used for flash writing