Homework 4

Steinarr Hrafn Höskuldsson

February 6, 2023

1 Homemade Delay Library

Source and header files were created for the library which is designed for code compiled with Heavy Optimization.

To delay 1 microsecond, 16 clock cycles must be burned off. It is rather convenient that the call instruction and ret instruction both take 4 clock cycles to execute so a function that takes no parameters and returns immediately takes 8 clock cycles to run, exactly half a microsecond.

So a half microsecond delay could be implemented as

```
void delay_half_us()
{
    // nothing
}
```

To test if this actually burns half a microsecond a test was devised writing a simple main program:

```
int main()
{
   DDRB \mid = 0x20;
   while (1)
      delay_half_us(); // 8 cycles
      PORTB = 0x20;
                         // 1 cycle
      delay_half_us();
                        // 8 cycles
      PORTB = 0;
                         // 1 cycle
               // loop -> 2 cycles
   }
                         == 20 cycles
}
                //
```

Which, as the comments suggest should result in a square wave on pin D13 with period $20/16MHz = 1.25\mu s$

And this was confirmed by oscilloscope as can be seen on Figure 1

Now let's look at creating a variable microsecond delay. Some research yields that clock cycles can be burned off by using asm volatile("nop\n\t"::); and the volatile flag keeps the compiler from optimizing it out.

A function was devised with the overall structure of a loop counting down the us variable where each loop takes exactly 16 cycles. The function would of course also have to deal with the cycles lost in the overhead of being called.

Such a function was written, the resulting assembly instructions were then analysed and the function edited until the overhead was accounted for and the loop took exactly 16 cycles. Here is the function, the comments speak for themselves.



Figure 1: Caption

```
void delay_us(unsigned int us)
  // overhead from calling function,
  // (2*ldi + call) costs 6 cycles
  // special case for us=1, (covers us=0 as well)
  // comparison costs 2 cycles (cpc and cpi)
  if (us < 2) // branches with brcs
  {
     // branch: 2 cycles to go here
     // at this point we are aiming for 1 microseconds
     // that is 16 cycles. We spent 6 on (2*ldi+call),
     // 2 on comparison, 2 on the branching and 4 for the return
     // leaving 16-6-4-2-2 = 2 cycles left to spend
     asm volatile("nop\n\t"
                "nop\n\t"::);
     return; // 4 cycles for ret
  }
  // branch: one cycle to go here
  // burn 2 cycles to make the overhead from
  // calling to be exactly 1 microsecond
  // see calculation for why 2 cycles at the bottom
  // of the function
  asm volatile("nop\n\t"
                "nop\n\t"::);
  // subtract the one microseconds that burns up
  // in the overhead
  us--; // takes 2 cycles (sbwi)
  // each loop should then be exactly 1 microsecond
```

```
while(1)
   ₹
      // this loop should take 16 cycles,
      // so here we burn 16 -2 -2 = 12 cycles
      asm volatile("nop\n\t"
                "nop\n\t"
                "nop\n\t"::);
      us--; // sbwi: 2 cycles, saves overflow to Zero Flag
      if (!us) // branches with brne
         // 1 cycle to go here
         return; // 4 cycles
      // 2 cycles to go here (aka to loop)
  }
   // Why 2 cycles:
   // Overhead from calling is:
   // 2*ldi+call 6 cycles
   // cpi + cpc 2 cycles
   // if (brcs)
                  1 cycle (didn't branch)
   // sbwi
                  2 cycles
   // return
                  4
   // and finally the last loop will take be one cycle
   // short of 1 microsecond because the brne instruction
   // takes 2 cycles if it branches as expected in the loop
   // but the last loop doesn't branch so brne only takes 1 cycle
   // leaving the last loop as only 15 cycles.
   // so the overhead should aim for 17 cycles to make
   // up that one cycle that gets forgotten in the last loop
   // so we have 17 = 6 + 4 + 2 + 2 + 1 + X
               ==> X = 2
   //
}
```

Listing 1: A function that burns exactly 'us' microseconds when called

The variable microsecond delay was tested with the same method as before using oscilloscope for different values of **us** confirming that it works as designed.

The microsecond delay function was used as a template to write a millisecond delay function

However when trying to use the microsecond delay function inside the millisecond delay function it became clear that the compiler didn't use the call instruction as expected. Instead it added instructions that logically behaved the same but used other registers, and in turn other instructions that took a different amount of cycles. The compiler even optimized out the less than 2 check since it new it was irrelevant but in doing so messed up the cycle accounting.

At this stage it became clear that it would not be accurate to rely on the compiler and its enigmatic optimization priorities.

Therefore after many hours of testing out different methods and reading about asm and macros syntax, a new strategy was devised.

Two macros were written, DELAY_9P4(i) which delays for 9+4*i cycles and DELAY_9P262153(i) which delays for 9+262,153*i cycles.

Since they are macros they will just insert the assembly code into the function at the specified location, thus giving complete predictability of the behaviour.

The macros use registers 24 and 25 to count the loops and thus start by pushing them to the stack before looping and finally pop them back from the stack after the looping. The macros do affect the status registers, but that was found to be acceptable.

```
// Macro that delays for 9+4*us cycles
// push+push+ldi+ldi+pop+pop = 2+2+1+1+2+2 = 10 cycles
// loop is sbiw+brne = 2+2 = 4 cycles except the last one
// which is only 3, bringing the total to 9+4*us
#define DELAY_9P4(i) \
do { \
  asm volatile ("push r24"::);\
  asm volatile ("push r25"::);\
   asm volatile("ldi r25, %0"::"M"(i>>8));\
  asm volatile("ldi r24, %0"::"M"(i&0xff));\
  asm volatile("sbiw r24, 0x01");\
  asm volatile("brne .-4");\
  asm volatile ("pop r25"::);\
   asm volatile ("pop r24"::);\
} while (0)
// push+push+ldi+ldi+pop+pop = 2+2+1+1+2+2 = 10 cycles
// loop is sbiw+brne+(9+0xffff*4) = 2+2+9+4*65535 = 262.153 cycles
// except the last one which is one shorter,
// bringing the total to 9+262.153*us
#define DELAY_9P262153(i) \
do { \
   asm volatile ("push r24"::);\
   asm volatile ("push r25"::);\
   asm volatile("ldi r25, %0"::"M"(i>>8));\
  asm volatile("ldi r24, %0"::"M"(i&0xff));\
  DELAY_9P4(0xffff);\
  asm volatile("sbiw r24, 0x01");\
  asm volatile("brne .-20");\
   asm volatile ("pop r25"::);\
   asm volatile ("pop r24"::);\
} while (0)
```

Now a millisecond delay function and a second delay function could be written with the same structure as the microsecond delay function.

```
void delay_ms(unsigned int ms)
{    // 6 cycles for call overhead

    // accounting for overhead:
    // goal here is total of 16.000 cycles or exactly 1 ms
    // so far we spent 6, comparison(<2) will take 2 cycles
    // the single nop will take 1 and jump to return will take 2
    // or the skip will take 1 and the decrement will take 2
    // the return will cost 4
    // for a total of 6 + 2 + 2 + 4 = 15
    // so now we should spend 16.000 - 15 = 15.985

DELAY_9P4(3994); // takes 4*3.994 + 9 = 15.985

// 2 cycles for comparison
if (ms < 2)
{// 2 cycles to get here</pre>
```

```
// one nop here to equal the overhead branches
     asm volatile("nop\n\t");
     return;
  }
  // 1 cycle to get here
  ms--; // 2 cycles (sbiw)
  // this loop shall take 1 ms (16.000 cycles) per loop
  while(1)
  {
     // accounting for this loop
     // sbiw and brne each cost 2 cycles
     // we need to burn an additional 15.996 cycles
     DELAY_9P4(3996); // burns 3.996*4 +9 = 15.993
     // additional 3 cycles needed:
     asm volatile("nop\n\t"
            "nop\n\t"
            "nop\n\t"::);
     ms--; // sbiw: 2 cycles
     if (!ms) // comparison is free with sbiw
        // 1 cycle to get here
         // loop accounting expects the branching
         // to cost 2 cycles so add 1 nop here
         asm volatile("nop\n\t"::);
         return;
      // 2 cycles to get here and loop
  }
void delay_s(unsigned int s)
{ // 6 cycles for call overhead
  // accounting for overhead:
  // goal here is total of 16.000.000 cycles or exactly 1s
  // so far we spent 6, comparison(if s<2) will take 2 cycles</pre>
  // the single nop will take 1 and jump to return will take 2
  // or the skip will take 1 and the decrement will take 2
  // the return will cost 4
  // for a total of 6 + 2 + 2 + 1 + 4 = 15
  // so now we should spend 16,000,000 - 15 = 15,999,985
  DELAY_9P262153(61); // takes 262.153*61 + 9 = 15,991,342
  // we still need 15,999,985 - 15,991,342 = 8,643
  DELAY_9P4(2158); // takes 9 + 4*2,158 = 8,641
  // we still need 8,643 - 8,641 = 2 cycles
  asm volatile("nop\n\t"
         "nop\n\t"::);
  // 2 cycles for comparison
  if (s < 2)
  {// 2 cycles to get here
     // one nop here to equal the overhead branches
     asm volatile("nop\n\t");
     return;
```

```
}
   // 1 cycle to get here
   s--; // 2 cycles (sbiw)
   // this loop shall take 1 s (16.000.000 cycles) per loop
   while(1)
   {
     // accounting for this loop
     // sbiw and brne each cost 2 cycles for total of 4
     // so now we should spend 16,000,000 - 4 = 15,999,996
     DELAY_9P262153(61); // takes 262.153*61 + 9 = 15,991,342
      // we still need 15,999,996 - 15,991,342 = 8,654
     DELAY_9P4(2161); // takes 9 + 4*2,161 = 8,653
      // we still need 8,654 - 8,653 = 1 cycles
     asm volatile("nop\n\t");
     s--; // sbiw: 2 cycles
     if (!s) // comparison is free with sbiw
         // 1 cycle to get here
         // loop accounting expects the branching
         // to cost 2 cycles so add 1 nop here
         asm volatile("nop\n\t"::);
         return;
      // 2 cycles to get here and loop
  }
}
```

Here the assembly instructions can be seen for the different delay functions.

```
00000094 <delay_us>:
 94: 82 30
                  cpi r24, 0x02 ; 2
 96: 91 05
                  cpc r25, r1
 98: 90 f0
                  brcs .+36
                               ; 0xbe <delay_us+0x2a>
 9a: 00 00
                  nop
 9c: 00 00
                  nop
 9e: 01 97
                  sbiw r24, 0x01; 1
 b8: 01 97
                  sbiw r24, 0x01; 1
 ba: 91 f7
                  brne .-28 ; 0xa0 <delay_us+0xc>
 bc: 08 95
                  ret
 be: 00 00
                 nop
 c0: 00 00
                 nop
 c2: 08 95
                  ret
000000c4 <delay_ms>:
 c4: 8f 93
            push r24
 c6: 9f 93
                  push r25
 c8: 9f e0
                  ldi r25, 0x0F; 15
 ca: 8a e9
                 ldi r24, 0x9A ; 154
 cc: 01 97
                 sbiw r24, 0x01 ; 1
 ce: f1 f7
                 brne .-4
                             ; 0xcc <delay_ms+0x8>
 d0: 9f 91
                 pop r25
 d2: 8f 91
                  pop r24
 d4: 82 30
                  cpi r24, 0x02 ; 2
 d6: 91 05
                  cpc r25, r1
                               ; 0xfa <delay_ms+0x36>
  d8: 80 f0
                  brcs .+32
  da: 01 97
                  sbiw r24, 0x01 ; 1
```

```
dc: 8f 93
                  push r24
 de: 9f 93
                  push r25
 e0: 9f e0
                  ldi r25, 0x0F; 15
 e2: 8c e9
                  ldi r24, 0x9C; 156
 e4: 01 97
                  sbiw r24, 0x01; 1
  e6: f1 f7
                  brne .-4
                              ; 0xe4 <delay_ms+0x20>
  e8: 9f 91
                  pop r25
 ea: 8f 91
                  pop r24
 ec: 00 00
                  nop
 ee: 00 00
                  nop
 f0: 00 00
                  nop
 f2: 01 97
                  sbiw r24, 0x01; 1
 f4: 99 f7
                  brne .-26
                              ; 0xdc <delay_ms+0x18>
 f6: 00 00
                  nop
 f8: 08 95
                  ret
 fa: 00 00
                  nop
 fc: 08 95
                  ret
000000fe <delay_s>:
 fe: 8f 93
                  push r24
 100: 9f 93
                  push r25
 102: 90 e0
                  ldi r25, 0x00 ; 0
104: 8d e3
                  ldi r24, 0x3D ; 61
106: 8f 93
                  push r24
108: 9f 93
                  push r25
10a: 9f ef
                  ldi r25, 0xFF; 255
10c: 8f ef
                  ldi r24, 0xFF; 255
10e: 01 97
                  sbiw r24, 0x01; 1
110: f1 f7
                  brne .-4
                                ; 0x10e <delay_s+0x10>
112: 9f 91
                  pop r25
114: 8f 91
                  pop r24
116: 01 97
                  sbiw r24, 0x01; 1
118: b1 f7
                  brne .-20
                              ; 0x106 <delay_s+0x8>
11a: 9f 91
                  pop r25
11c: 8f 91
                  pop r24
11e: 8f 93
                  push r24
120: 9f 93
                  push r25
122: 98 e0
                  ldi r25, 0x08; 8
124: 8e e6
                  ldi r24, 0x6E; 110
126: 01 97
                  sbiw r24, 0x01; 1
128: f1 f7
                  brne .-4
                                ; 0x126 <delay_s+0x28>
12a: 9f 91
                  pop r25
12c: 8f 91
                  pop r24
12e: 00 00
                  nop
130: 00 00
                  nop
132: 82 30
                  cpi r24, 0x02 ; 2
134: 91 05
                   cpc r25, r1
136: f0 f0
                  brcs .+60
                                 ; 0x174 <delay_s+0x76>
138: 01 97
                  sbiw r24, 0x01; 1
13a: 8f 93
                  push r24
13c: 9f 93
                  push r25
13e: 90 e0
                  ldi r25, 0x00 ; 0
140: 8d e3
                  ldi r24, 0x3D ; 61
142: 8f 93
                  push r24
144: 9f 93
                  push r25
146: 9f ef
                  ldi r25, 0xFF; 255
148: 8f ef
                  ldi r24, 0xFF; 255
                  sbiw r24, 0x01 ; 1
14a: 01 97
14c: f1 f7
                  brne .-4
                                ; 0x14a <delay_s+0x4c>
14e: 9f 91
                  pop r25
150: 8f 91
                  pop r24
```

```
152: 01 97
                 sbiw r24, 0x01; 1
154: b1 f7
                 brne .-20 ; 0x142 <delay_s+0x44>
156: 9f 91
                 pop r25
158: 8f 91
                 pop r24
15a: 8f 93
                 push r24
15c: 9f 93
                 push r25
15e: 98 e0
                 ldi r25, 0x08 ; 8
160: 81 e7
                 ldi r24, 0x71 ; 113
162: 01 97
                 sbiw r24, 0x01; 1
164: f1 f7
                 brne .-4
                               ; 0x162 <delay_s+0x64>
166: 9f 91
                 pop r25
168: 8f 91
                 pop r24
16a: 00 00
                 nop
16c: 01 97
                 sbiw r24, 0x01 ; 1
16e: 29 f7
                 brne .-54
                            ; 0x13a <delay_s+0x3c>
170: 00 00
                 nop
172: 08 95
                 ret
174: 00 00
                 nop
176: 08 95
                 ret
```

2 Fading an LED

The main.c program was edited to emulate a changing PMW signal using the delay_us to delay a variable amount between turning led on and off.

The main program looked like this:

```
#include <avr/io.h>
#include "delay_lib/steinarr_delay.h"
#define LEDON PORTB=OxFF;
#define LEDOFF PORTB=0;
int main()
{
   DDRB \mid = 0x20;
   unsigned char N = 255;
   while (1)
   {
      for(unsigned char i = 0; i<N; i++)</pre>
         for(int j=0; j<50; j++)</pre>
         {
             LEDON;
            delay_us(i);
            LEDOFF;
             delay_us(255-i);
         }
      for(unsigned char i = 0; i<N; i++)</pre>
      {
         for(int j=0; j<50; j++)</pre>
         {
             LEDON;
             delay_us(255-i);
             LEDOFF;
             delay_us(i);
         }
      }
```

```
}
}
```

The fading can be seen in action at: https://youtube.com/shorts/U72zUJ9GwMs?feature=share

3 Sensors for the Final projects

I have three contenders for the thigh slap sensors, Accelerometer, Piezo microphone and A sponge with 2 sheets of aluminum foil that act as a variable capacitor.

In price they are, respectively \$10, \$3 and \$1, however they all involve some arts- and craftstyle work I consider them all equal in regards to cost.

How they perform is another matter and an active research project.

I also need to detect what the feet are doing. The right foot is probably easier since an accelerometer can probably very easily pick up the taps of the right foot on the imaginary base drum. However the left foot is harder. The system has to be able to both detect a tap, resulting in a closed hi-hat sound, and the orientation, that is, the tilt, of the left foot indicating if the user is holding the hi-hats closed or not.

For the left foot sensor I am hoping an accelerometer will be able to detect both the taps and the tilt, but I have yet to test it.

Final Project

This week I ordered components on Mouser, a sound board and 3 types of piezo microphones.

I also looked into creating a variable capacitor using a sponge and 2 sheets of aluminium foil. I do not see it working out as a sensor, testing out some sponges I noticed that to compress them any appreciable amount quite some force was needed and that would prevent the user from doing double taps.

I haven't completely ruled out the sponge and aluminium foil, though. If the other sensors also prove uncapable of detecting double taps then the sponge will be back in the running.

Next week I will receive the piezo microphones and I intend to try out sensing taps with them.

A Code