

Geodynamic Principles and Computational Frameworks for Rayleigh Wave Velocity and Critical Velocity Assessment in High-Speed Rail Formation Design

The engineering of high-speed rail infrastructure necessitates a sophisticated departure from traditional quasi-static geotechnical design paradigms, transitioning into the realm of advanced geodynamics. As the operational velocities of modern rolling stock continue to escalate, reaching and exceeding 300 kilometers per hour, the interaction between the track-ground system and the moving load becomes increasingly dominated by wave propagation phenomena. The most significant of these is the generation and propagation of Rayleigh waves—surface waves that travel along the interface between the earth and the atmosphere. When the speed of a train approaches the inherent phase velocity of these waves within the supporting formation, a resonance-like state is achieved, commonly referred to as the critical velocity. The consequences of operating at or near this threshold include extreme dynamic amplification of track displacements, accelerated structural degradation, and severe risks to operational safety. Consequently, the accurate calculation of Rayleigh wave velocity and the strategic assessment of critical velocity during the design phase are non-negotiable requirements for contemporary rail developments.

The Physical Mechanism of Critical Velocity and Rayleigh Wave Interaction

The phenomenon of critical velocity in a railway context occurs when the velocity of the moving axle load coincides with the speed of surface waves in the underlying ground. This geodynamic threshold is fundamentally defined by the Rayleigh wave velocity (V_R) of the site. At low train speeds, the ground response is primarily quasi-static, and the energy generated by the wheels dissipates quickly through the formation. However, as the speed increases toward the V_R of the soil, the vertical displacements of the track begin to increase above those for static loading, first slowly and then with rapid acceleration, reaching a maximum at the critical velocity.¹ This effect is analogous to the sonic boom created by supersonic aircraft, where the source of the vibration moves as fast as or faster than the waves it generates, leading to a constructive superposition of wave fronts known as a "ground vibration boom".²

The most well-documented instance of this phenomenon occurred at Ledsgård in Sweden.

Following the opening of a new high-speed line, large track displacements were recorded when the X2000 train reached speeds of approximately 200 km/h.¹ In this specific location, the ground consisted of very soft organic clays with a Rayleigh wave velocity as low as 45 meters per second (162 km/h).² As the train speed increased from 140 km/h to 180 km/h, the ground vibration levels increased by a factor of ten, and vertical track deflections of up to 15-20 mm were measured.² These observations emphasize that softer, less dense ground is uniquely susceptible to critical velocity effects, both because the displacements per unit load are greater and because the intrinsic wave speeds are lower.¹

Wave Regimes in High-Speed Rail Operations

The relationship between the train velocity (V_{train}) and the Rayleigh wave velocity (V_R) categorizes the dynamic state of the track-ground system into three distinct regimes:

1. **Sub-Rayleigh Regime ($V_{\text{train}} < V_R$):** The train travels slower than the surface waves. In this state, the wave crests on the embankment surface do not intersect, and no wave superposition occurs. Vibration magnitudes remain manageable and predictable through quasi-static models.⁵
2. **Trans-Rayleigh Regime ($V_{\text{train}} \approx V_R$):** The train velocity approaches the phase velocity of the ground waves. This is the region where dynamic amplification factors (DAF) increase dramatically. It is often recommended that operational speeds be limited to a factor of 0.6 to 0.7 of the site critical velocity to avoid this regime.¹
3. **Super-Rayleigh Regime ($V_{\text{train}} > V_R$):** The train travels faster than the surface waves. This results in the formation of a Mach cone of shock waves propagating into the soil. While theoretically possible, HSR infrastructure is rarely designed to operate in this regime due to the extreme maintenance and safety implications.²

Mathematical Foundations for Rayleigh Wave Velocity Calculation

The calculation of Rayleigh wave velocity begins with the fundamental equations of elastodynamics in an isotropic, linear elastic medium. These waves are a hybrid of longitudinal (P-waves) and vertical transverse (S-waves) motions, with energy concentrated near the surface and decaying exponentially with depth.⁸

The Governing Elastic Wave Equations

The displacement vector \mathbf{u} in a solid medium is governed by the following partial differential equations, which can be decomposed into two auxiliary potentials: a scalar potential ϕ (associated with dilatation or P-waves) and a vector potential Ψ (associated with rotation or S-waves)¹⁰:

$$\$ \$ \mathbf{u} = \nabla \phi + \nabla \times \mathbf{\Psi} \$ \$$$

11

In the context of a 2D half-space with horizontal propagation (x) and depth (z), the displacements u and w are expressed as:

$$\$ \$ u = \frac{\partial \phi}{\partial x} + \frac{\partial \psi}{\partial z} \$ \$$$

11

$$\$ \$ w = \frac{\partial \phi}{\partial z} - \frac{\partial \psi}{\partial x} \$ \$$$

11

The wave velocities for the constituent body waves are determined by the Lamé parameters λ and μ (rigidity) and the density ρ of the soil ¹⁰:

$$\$ \$ V_P = \sqrt{\frac{\lambda + 2\mu}{\rho}} \$ \$$$

11

$$\$ \$ V_S = \sqrt{\frac{\mu}{\rho}} \$ \$$$

13

The ratio of these velocities is fundamentally linked to the Poisson's ratio (ν), which describes the material's lateral deformation under axial load.¹⁰

The Rayleigh Cubic Equation and Velocity Ratios

The phase velocity of the Rayleigh wave (V_R) is the real root of the Rayleigh cubic equation, which relates the surface wave speed to the shear wave velocity ⁸:

$$\$ \$ \zeta^3 - 8\zeta^2 + 8\zeta(3 - 2\eta) - 16(1 - \eta) = 0 \$ \$$$

8

Where $\zeta = (V_R / V_S)^2$ and $\eta = (V_S / V_P)^2$. Solving this equation reveals that V_R is always slightly less than V_S . For a "Poisson solid" where $\nu = 0.25$ and $\lambda = \mu$, the root with physical meaning is 0.9194, indicating that $V_R \approx 0.92 V_S$.¹⁰

For practical design applications, analytical approximations avoid the need to solve the polynomial directly. A widely utilized formula, particularly for soils where $\nu > 0.3$, is the

Viktorov approximation ⁸:

$$V_R \approx V_S \frac{0.862 + 1.14\nu}{1 + \nu}$$

⁸

The following table illustrates the relationship between Poisson's ratio and the resulting velocity ratio, which is critical for early-stage design estimates.

Material Classification	Poisson's Ratio (ν)	Velocity Ratio (VR/VS)	Characteristic Particle Motion
Ideal Poisson Solid	0.25	0.9194	Retrograde Elliptical
Typical Engineering Soils	0.30	0.9274	Retrograde Elliptical
Saturated Clays/Sands	0.45	0.9476	Transition at Depth to Prograde
Nearly Incompressible	0.49	0.9538	Strongly Surface-Confining

Sources: ⁸

Calculation Procedures during the Design Phase

The design of a high-speed rail formation involves calculating the wave propagation characteristics of both the engineered embankment and the natural foundation ground. This process begins with the determination of the small-strain shear modulus and density of the constituent materials.

Small-Strain Stiffness and Shear Modulus (G_{max})

The shear wave velocity is the primary indicator for critical velocity effects. It is directly related to the small-strain shear modulus (G_{max} or G_0), which represents the soil stiffness at strains of $10^{-3}\%$ or less.¹⁵ During design, G_{max} is calculated from the shear wave velocity as:

$$G_{max} = \rho V_S^2$$

Where ρ is the bulk density. In the absence of direct seismic measurements, designers use effective stress-based algorithms to model how V_S and V_R vary with depth.¹⁸ The shear wave velocity typically follows a power law relationship with the vertical effective stress (σ'):

$$V_S = A(\sigma')^B + C$$

15

The coefficients A , B , and C are influenced by the lithology, porosity, and over-consolidation ratio of the soil. For multi-layered foundations, the bulk density (ρ_b) is a composite function of the soil porosity (n), water saturation (S_w), and the densities of solid particles and pore fluid.¹⁸

Depth of Influence and Layering Effects

In a perfectly homogeneous half-space, Rayleigh waves are non-dispersive. However, high-speed rail formations are inherently layered, which introduces dispersion: the phase velocity becomes frequency-dependent.⁸ Low-frequency waves have long wavelengths that penetrate deeper into the ground, while high-frequency waves are confined to the shallow embankment layers.⁸

Research indicates that for most practical HSR designs, the top 8 meters of soil are the most influential in determining the critical velocity.²² This depth-of-influence is critical for scoping site investigations. If the stiffness increases with depth (normally dispersive), the low-frequency waves will travel faster. If a stiff engineered embankment is placed over soft clay (inversely dispersive), higher modes of propagation may dominate the response.²¹

Critical Velocity Factor (X_{VC}) and Safety Margins

To ensure safety and minimize maintenance, design standards impose a restriction on the maximum train speed relative to the calculated critical velocity. This safety factor, X_{VC} , is typically set at 0.7.¹ The reasoning behind this limit is that dynamic amplification remains minimal until approximately 70% of the critical speed is reached, after which displacements increase exponentially.¹

The design critical velocity (V_{crit}) is calculated using either the direct Rayleigh wave velocity of the subgrade or more sophisticated models that include track stiffness.³ While V_{crit} is often approximated as V_R , the presence of the track structure can shift this value. The track critical velocity is frequently in the region of 1.1 to 1.3 times the ground Rayleigh wave velocity.³

Calculation of Formation Wave Velocities via Field Testing

Validation of design assumptions requires the direct measurement of Rayleigh wave velocities in situ. The preferred method for construction compliance in high-speed rail is the Multichannel Analysis of Surface Waves (MASW).⁹

Multichannel Analysis of Surface Waves (MASW) Procedure

MASW is a non-invasive geophysical technique that measures the dispersive character of a site to provide a V_R profile against depth. The calculation sequence is as follows:

1. **Field Data Acquisition:** An array of geophones (usually 24 to 48) is spaced at 1 to 2-meter intervals. A seismic source, such as a hammer or weight drop, is used to trigger a wavefield.⁹
2. **Wavefield Transformation:** The recorded time-distance ($x-t$) data is transformed into the frequency-phase velocity domain (dispersion image) using techniques like the $f-k$ (frequency-wavenumber) transform or the phase-shift method.²⁴
3. **Dispersion Curve Picking:** The phase velocity of the Rayleigh wave is identified as the peak energy trend in the dispersion image. Analysts must distinguish between the fundamental mode and higher modes, especially in layered soils with high velocity contrasts.⁹
4. **Inversion to V_S :** An iterative solution technique (such as the Levenberg-Marquardt method) is used to resolve the inverse problem, matching the experimental dispersion curve to a theoretical model to estimate the V_S profile with depth.¹⁶

The Direct V_R Rule of Thumb for Construction Compliance

Because the inversion process is mathematically complex and can lead to non-unique solutions, modern high-speed projects often employ a simplified "rule of thumb" for routine construction compliance. This allows engineers to assess the V_R directly from the dispersion data without full inversion.⁹ A common standard relates wavelength (λ) to depth (z):

$$z \approx \frac{\lambda}{3}$$

⁹

By calculating the wavelength from the frequency (f) and the picked phase velocity (V_R) as $\lambda = V_R / f$, the Rayleigh wave velocity can be plotted against a representative depth. This ensures that the embankment and subgrade have achieved the minimum target stiffness during the compaction process.⁹

Parameter	Recommended Specification	Objective
Geophone Spacing	1m - 2m	High resolution at shallow depths
Source Offset	Multiple (short and long)	Capture fundamental and higher modes
Target V_R	$> 1.4 \times V_{train}$	Maintain sub-Rayleigh regime
Compliance Depth	$\geq 5m - 8m$	Cover primary zone of influence

Sources: ⁹

Design Standards: UIC 719-R and HS2 Technical Standards

Formalized guidelines for managing critical velocity risks are embedded in international railway codes and project-specific technical standards.

UIC 719-R: Earthworks and Track Bed Construction

The UIC 719-R code (International Union of Railways) provides a comprehensive framework for soil classification and the dimensioning of trackbed layers.³⁰ It classifies subgrade soils into four quality classes (QS0 to QS3) based on particle size distribution, Atterberg limits, and organic content.³¹

- **QS0:** Unsuitable materials (clays with high plasticity or organic soils).
- **QS1:** Poor materials (weathered slate or highly compressible soils).
- **QS2:** Average materials.
- **QS3:** Good granular materials (granite, crushed stone).³¹

The bearing capacity of the substructure is similarly divided into P1 (bad), P2 (average), and P3 (good) classes. For high-speed lines, it is a standard requirement to achieve a P3 classification, typically necessitating a QS3 soil in the formation layer.³¹ The code provides empirical formulas for the total thickness of the track bed (ballast plus blanket layers) as a function of train speed, axle load, and traffic tonnage.³⁴ However, these empirical methods have limited capabilities in capturing the multi-dimensional dynamic stresses inherent in

ultra-high-speed operations.³⁴

HS2 Phase 1: Case Study of Technical Standard Earthworks (TS-E)

The UK's High Speed 2 (HS2) project defines some of the most rigorous geodynamic requirements in the industry. The Technical Standard – Earthworks (TS-E) and Specification for Civil Engineering Works (SCEW) emphasize that mainline earthworks must meet stringent dynamic stiffness criteria reflective of the 360 km/h (100 m/s) design speed.⁹

The dynamic performance is defined as a limiting Rayleigh wave velocity measured at formation level, using the following criterion:

$$V_R \geq 1.4 \times DS$$

²³

Where DS is the design speed. For the Phase 1 Contract C23, this translates to a minimum V_R of 140 m/s.²³ Initially, a screening factor of 1.6 was used, alongside a partial safety factor of 1.25, resulting in the following risk categories for design planning:

Risk Category	VR Threshold	Equivalent VS	Required Mitigation
Low Risk	> 200 m/s	> 210 m/s	Standard compaction
Medium Risk	$160 - 200$ m/s	$170 - 210$ m/s	Localized assessment
High Risk	< 160 m/s	< 170 m/s	Foundation treatment (Lime/Cement)

Sources: ²³

Computational Modeling of Formation Dynamics

Calculating critical velocity in the design phase often requires numerical models that represent the interaction between the rolling stock, the track structure, and the multi-layered half-space.

Analytical Beam on Elastic Foundation (BEF) Models

Under low-frequency ranges (below 100 Hz), it is common to obtain the critical velocity using a beam on a Winkler foundation.⁵ The dynamic governing equations for an infinite beam on an elastic half-space allow for the determination of the system's equivalent stiffness in the Fourier domain.⁵ These models identify two critical velocity values: one slightly less than the Rayleigh wave speed and one equal to it.⁵

Advanced Multi-Layered and 3D Models

For practical applications where ground layering is complex, more sophisticated models are required. The Thompson–Haskell method or the stiffness matrix method is used to determine the radial and vertical surface stresses and displacements in the wavenumber-frequency domain.⁵ The "dispersion approach" defines the critical speed as the velocity where the dispersion curves of the ground's P-SV modes intersect with the track's bending wave propagation curves.²²

Numerical approaches often utilize 2.5D models, which assume the track-ground system is invariant in the direction of travel, allowing for high-accuracy simulations with reduced computational expense compared to full 3D models.¹ These models incorporate shear forces via Timoshenko beam elements to accurately transmit high-frequency forces into the track structure.³⁷

Formation Design and Mitigation Strategies

When the calculated V_R of a site is insufficient to support the intended train speeds, engineering interventions are necessary to enhance the geodynamic response of the earthwork structure.

Foundation Treatment and Soil Stabilization

The most common method for increasing the Rayleigh wave velocity of a formation is soil stabilization using binders such as cement or lime.³¹ For HS2, a minimum V_S of 250 m/s was initially assumed for engineered fill, but this was revised to 300 m/s based on field trials to ensure compliance with the dynamic criteria.²⁹ Stabilizing the top layers of the natural ground increases the "effective" V_R sensed by the track and shifts the critical velocity to a higher range.

Track Structure and Stiffness Interaction

While the critical velocity is primarily governed by the ground properties, the track structure plays a significant role in mitigating displacements. Stiffer trackbed elements, such as concrete slab tracks instead of traditional ballasted lines, distribute axle loads over a wider area, reducing the magnitude of vertical deflections even if the train operates near the critical

speed.³ Research confirms that while the track's bending stiffness does not significantly alter the fundamental ground V_R , it does reduce the absolute dynamic amplification factor.²¹

Bridge Transitions and Discontinuity Management

Critical velocity effects are often exacerbated at transition zones, such as the interface between an embankment and a bridge. UIC 719-R summarizes various European methods (SNCF, MAV, DB) for bridge transition design, emphasizing the need for a gradual transition of support stiffness to minimize differential settlement and dynamic issues.³⁹

Calculation Nuances: Poisson's Ratio and Particle Motion

The calculation of V_R is sensitive to the assumed or measured Poisson's ratio, particularly in saturated fine-grained soils. As the Poisson's ratio varies from 0 to 0.5, the eccentricity of the Rayleigh wave's elliptical motion changes.¹⁰

The Transition Depth and Rotation Direction

In a homogeneous half-space, the particle motion at the surface is retrograde. However, as depth increases, the horizontal displacement ($U(z)$) decreases faster than the vertical displacement ($W(z)$). At a critical depth, the horizontal displacement reaches zero and then reverses, changing the motion from retrograde to prograde.¹⁰ This depth is a function of the Poisson's ratio and is vital for understanding the volume of soil involved in the dynamic interaction.

Impact of Saturation and Water Content

Fully saturated soils often exhibit Poisson's ratios approaching 0.5. In such cases, the Rayleigh wave velocity is nearly equal to the shear wave velocity ($V_R \approx 0.95 V_S$).¹⁸ Designers must account for seasonal variations in the water table, as changes in saturation can alter the density and Poisson's ratio, thereby shifting the site's critical velocity.¹⁸

Synthesis of Geodynamic Design Workflow

A robust engineering approach for high-speed rail formations integrates these calculations into a unified design and verification workflow.

1. **Site Classification:** Determine soil quality using UIC 719-R standards (QS0-QS3) and estimate initial V_S from index properties.¹⁵
2. **Critical Velocity Estimation:** Use the V_R cubic equation or Viktorov approximation to establish the baseline critical speed.⁸
3. **Numerical Simulation:** Conduct 2.5D or 3D dynamic analysis to include track stiffness

and layering effects.¹

4. **Target Specification:** Set V_R targets for construction, typically ≥ 1.4 times the design speed.²³
5. **Construction Verification:** Employ MASW or CSW testing with the $\lambda/3$ rule of thumb to confirm that as-built stiffness meets the dynamic requirements.⁹
6. **Operational Monitoring:** Establish speed limits based on $0.7 V_{crit}$ and implement vibration monitoring in known soft-soil risk zones.¹

The evolution of high-speed rail necessitates a rigorous adherence to these geodynamic principles. By treating the formation as a dynamic system rather than a static support, engineers can ensure that the infrastructure remains stable, safe, and efficient throughout its intended design life. The accurate calculation of Rayleigh wave velocities serves as the foundation for this modern engineering discipline, bridging the gap between theoretical elastodynamics and practical geotechnical construction.

Summary of Key Geodynamic Indicators

The following table summarizes the critical parameters and formulas used in the assessment of formation geodynamics for high-speed rail.

Design Parameter	Fundamental Relationship	Primary Application
Shear Wave Velocity (V_S)	$\sqrt{\mu / \rho}$	Basic indicator of site stiffness
Rayleigh Wave Velocity (V_R)	Root of $\zeta^3 - 8\zeta^2 + 8\zeta(3-2\eta) - 16(1-\eta) = 0$	Determination of critical speed
Small-Strain Modulus (G_{max})	ρV_S^2	Structural modeling input
Critical Velocity (V_{crit})	$V_R \times (1.1 \text{ to } 1.3)$	Operational limit definition
Compliance Target (V_{target})	$1.4 \times V_{train}$	Earthwork construction quality check
Depth Rule of Thumb	$\lambda / 3$	Rapid MASW data

(\$z\$)		interpretation
---------	--	----------------

Sources:³

By systematically applying these frameworks, designers can mitigate the "Rayleigh effect"—the risk of unstable track motions and excessive vibrations—ensuring that the rapid development of high-speed rail continues to be a safe and reliable mode of transportation. The interplay between site-specific geology and precision engineering remains the cornerstone of this geotechnical challenge.

Works cited

1. Assessing the risk of critical velocity effects at railway sites using site investigation and advanced laboratory testing - ePrints Soton - University of Southampton, accessed January 20, 2026,
https://eprints.soton.ac.uk/451818/1/4th_ICTG_401_original_v3.pdf
2. High Speed Rail - Parliament UK, accessed January 20, 2026,
<https://publications.parliament.uk/pa/cm201012/cmselect/cmtran/writev/rail/m53.htm>
3. Use of Conventional Site Investigation Parameters to Calculate Critical Velocity of Trains from Rayleigh Waves | Request PDF - ResearchGate, accessed January 20, 2026,
https://www.researchgate.net/publication/283520550_Use_of_Conventional_Site_Investigation_Parameters_to_Calculate_Critical_Velocity_of_Trains_from_Rayleigh_Waves
4. rayleigh waves and high-speed railways - SvF UNIZA, accessed January 20, 2026,
https://svf.uniza.sk/strahos/images/Paper_07_Petyrek.pdf
5. Critical embankment velocity - Wikipedia, accessed January 20, 2026,
https://en.wikipedia.org/wiki/Critical_embankment_velocity
6. (PDF) Effect of track properties on ground vibrations generated by high-speed trains, accessed January 20, 2026,
https://www.researchgate.net/publication/233598832_Effect_of_track_properties_on_ground_vibrations_generated_by_high-speed_trains
7. Scoping exercise to estimate critical velocity of trains from Rayleigh waves using conventional site investigation data | Request PDF - ResearchGate, accessed January 20, 2026,
https://www.researchgate.net/publication/268576481_Scoping_exercise_to_estimate_critical_velocity_of_trains_from_Rayleigh_waves_using_conventional_site_investigation_data
8. Rayleigh wave - Wikipedia, accessed January 20, 2026,
https://en.wikipedia.org/wiki/Rayleigh_wave
9. Blind field tests to determine Rayleigh wave velocity on a high-speed.pdf, accessed January 20, 2026,
<https://eprints.whiterose.ac.uk/id/eprint/226490/2/Blind%20field%20tests%20to%20determine%20Rayleigh%20wave%20velocity%20on%20a%20high-speed.pdf>
10. Rayleigh Waves: Velocity, Attenuation with Depth and Elliptical Polarization - SciELO, accessed January 20, 2026,
<https://www.scielo.br/j/rbef/a/rFK5SnkMKTWZn8cSyWNWDsd/>
11. Rayleigh Waves: Velocity, Attenuation with Depth and Elliptical Polarization - SciELO, accessed January 20, 2026,
<http://www.scielo.br/pdf/rbef/v46/1806-9126-rbef-46-e20240277.pdf>
12. The mathematics behind the Rayleigh waves, accessed January 20, 2026,
https://www.auctoresonline.org/images/manuscript/1609324370Revised_.pdf

13. Benchmarking railway vibrations - Track, vehicle, ground and building effects - Account, accessed January 20, 2026,
https://www.pure.ed.ac.uk/ws/files/56997567/Benchmarking_Railway_Vibrations_Track_Vehicle_Ground.pdf
14. Theoretical and experimental revision of surface acoustic waves on the (100) plane of silicon - NIH, accessed January 20, 2026,
<https://pmc.ncbi.nlm.nih.gov/articles/PMC7854651/>
15. Correlations between shear wave velocity and geotechnical parameters in Norwegian clays, accessed January 20, 2026,
https://www.ngm2016.com/uploads/2/1/7/9/21790806/034-059-ngm_2016_-_correlations_between_shear_wave_velocity_and_geotechnical_parameters_in_norwegian_clays_lheureux_long.pdf
16. Estimation of near-surface shear-wave velocity by inversion of Rayleigh waves - Kansas Geological Survey, accessed January 20, 2026,
<https://www.kgs.ku.edu/software/surfseis/Publications/XiaEtAl1999.pdf>
17. An improved approximation for the Rayleigh wave equation | Request PDF - ResearchGate, accessed January 20, 2026,
https://www.researchgate.net/publication/6699733_An_improved_approximation_for_the_Rayleigh_wave_equation
18. (PDF) Rayleigh wave propagation assessment for transport corridors, accessed January 20, 2026,
https://www.researchgate.net/publication/288665747_Rayleigh_wave_propagation_assessment_for_transport_corridors
19. Relationship between Shear-Wave Velocity and Geotechnical Parameters for Norwegian Clays - ISSMGE: Heritage Time Capsule (HTC) Project, accessed January 20, 2026,
[https://xyzhtc.issmge.org/uploads/contributions/Lheureux%20and%20Long\(2017\).pdf](https://xyzhtc.issmge.org/uploads/contributions/Lheureux%20and%20Long(2017).pdf)
20. (PDF) Effective phase velocity of surface waves in layered soil media - ResearchGate, accessed January 20, 2026,
https://www.researchgate.net/publication/288775034_Effective_phase_velocity_of_surface_waves_in_layered_soil_media
21. Management of the dynamic performance of earthworks for High-Speed Rail, accessed January 20, 2026,
https://www.researchgate.net/publication/384854713_Management_of_the_dynamic_performance_of_earthworks_for_High-Speed_Rail
22. Railway critical speed assessment: A simple experimental-analytical approach - CORE, accessed January 20, 2026,
<https://files01.core.ac.uk/download/pdf/323059548.pdf>
23. Management of the dynamic performance of earthworks ... - ISSMGE, accessed January 20, 2026,
https://www.issmge.org/uploads/publications/51/126/746_D_management_of_the_dynamic_performance_of_earthwork.pdf
24. ACTIVE AND PASSIVE SURFACE WAVE TECHNIQUES - Geometrics, accessed January 20, 2026,

https://www.geometrics.com/wp-content/uploads/2018/10/GeoVision_SurfaceWaveMethods.pdf

25. Multi-channel analysis of surface waves (MASW) of models with high shear-wave velocity contrast - Kansas Geological Survey, accessed January 20, 2026, <https://www.kgs.ku.edu/software/surfseis/Publications/IvanovEtAl2011.pdf>
26. Determination of Rayleigh wave dispersion curves for near surface applications in unconsolidated sediments - ResearchGate, accessed January 20, 2026, https://www.researchgate.net/publication/249858159_Determination_of_Rayleigh_wave_dispersion_curves_for_near_surface_applications_in_unconsolidated_sediments
27. Estimation of near-surface shear-wave velocity by inversion of Rayleigh waves - USGS.gov, accessed January 20, 2026, <https://www.usgs.gov/publications/estimation-near-surface-shear-wave-velocity-inversion-rayleigh-waves>
28. Blind field tests to determine Rayleigh wave velocity on a high-speed railway environment: The reliability of seismic surface waves methods - Loughborough University, accessed January 20, 2026, https://repository.lboro.ac.uk/articles/journal_contribution/Blind_field_tests_to_determine_Rayleigh_wave_velocity_on_a_high-speed_railway_environment_The_reliability_of_seismic_surface_waves_methods/21252099
29. SciELO Brazil - A strategic and novel field trial to investigate the ..., accessed January 20, 2026, <https://www.scielo.br/j/soiroc/a/mYBng8rc6ZVysrKvYZ7rhkv/?lang=en>
30. UIC 719: Earthworks for Railways | PDF | Density | Geotechnical Engineering - Scribd, accessed January 20, 2026, <https://www.scribd.com/document/512972539/uic-719-rpdf>
31. EVALUATION OF DESIGN OF RAILWAY'S SUB-STRUCTURE IN ..., accessed January 20, 2026, <https://fenix.tecnico.ulisboa.pt/downloadFile/395142131542/Resumo.pdf>
32. (PDF) Modification of UIC Code 719 "Earthworks and track bed construction for railway lines" according to the principles developed in EN 16907 "Earthworks" and other European EN Standards - ResearchGate, accessed January 20, 2026, https://www.researchgate.net/publication/324703736_Modification_of_UIC_Code_719_Earthworks_and_track_bed_construction_for_railway_lines_according_to_the_principles_developed_in_EN_16907_Earthworks_and_other_European_EN_Sta_ndards
33. Modern Railways for Cargo and Passenger Traffic High Speed- Heavy Loads Track Systems - NTNU, accessed January 20, 2026, <https://www.ntnu.no/ojs/index.php/BCRRA/article/download/3251/3134/13170>
34. Geosynthetic reinforced & unreinforced rail track foundation comparison of analytical methods and numerical modelling, accessed January 20, 2026, <https://library.geosyntheticsociety.org/wp-content/uploads/resources/proceedings/122021/S03-06.pdf>
35. Analysis of Rayleigh wave dynamic response and propagation characteristics in layered site, accessed January 20, 2026, <https://pmc.ncbi.nlm.nih.gov/articles/PMC11438886/>

36. High speed railway ground dynamics: a multi-model analysis, accessed January 20, 2026, <https://eprints.whiterose.ac.uk/id/eprint/156260/1/Accepted.pdf>
37. Numerical modelling of ground borne vibrations from high speed rail lines on embankments - White Rose Research Online, accessed January 20, 2026, <https://eprints.whiterose.ac.uk/id/eprint/125158/1/7458259.pdf>
38. Hs2-Hs2-Cv-Spe-000-010600 (P05) - Scribd, accessed January 20, 2026, <https://www.scribd.com/document/638008040/HS2-HS2-CV-SPE-000-010600-P05>
39. Layer thickness variations with Chinese codes 3.2 UIC 719R Guideline... - ResearchGate, accessed January 20, 2026, https://www.researchgate.net/figure/Layer-thickness-variations-with-Chinese-codes-32-UIC-719R-Guideline-International-union_fig5_277258181
40. Modelling Traffic Action in High Speed Railway Bridges - Spiral, accessed January 20, 2026, <https://spiral.imperial.ac.uk/server/api/core/bitstreams/b7ded70f-5b49-44e8-9144-b08cdf09d8a7/content>