```
Q 1.
# To Determine the bearing capacity of soil with water table
BulkDensity =float(input("Enter the value of Bulk Density of soil:"))
SatDensity = float(input("Enter the value of Saturated Density of soil:"))
WaterDensity = float(input("Enter the unit Weight of Water:"))
Df= float(input("Enter the value of depth of footing:"))
Dw = float(input("Enter the value of water table above footing level:"))
Dw1= float(input("Enter the value of Water table below the level of footing:"))
B = float(input("Enter the value of width of footing:"))
Nq= float(input("Enter the vaiue of Nq:"))
N = float(input("Enter the value of N ganna (N):"))
SubDensity = SatDensity - WaterDensity
print("Submerged Weight of soil is:", SubDensity)
# The bearing capacity of soil when water table is at ground
print("CASE A")
qu= (SubDensity* Df*Nq) + (0.5*0.8*B*SubDensity*N)
print("The value of ultimate bearing capacity of soil is:", qu)
#Approximate calculation of Bearing capacity of soil is.
Rw = 0.5 + 0.5*(Dw/B)
print("The value of Rw is:", Rw)
Rw1 = 0.5 + 0.5*(Dw1/B)
print("The value of Rw1 is:", Rw1)
qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity *N*Rw1)
print("The value ultimate bearing capacity of soil is:", qu)
# Case B
print ("CASE B")
qu= (BulkDensity*Df*Nq) + (0.5*0.8*B*SubDensity*N)
print("The value of ultimate bearing capacity is:", qu)
Dw = float(input("Enter the value of water table above footing level:"))
Dwl = float(input(" Enter the value of Water table below the level of footing: "))
print("The approximate value of ultimate bearing capacity is: ", qu)
RW = 0.5 + 0.5*(DW/B)
print("The value of Rw is:", Rw)
Rw1 = 0.5 + 0.5* (Dw1/B)
print ("The value of Rw1 is:", Rw1)
qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity*N*Rw1)
print("The approximate value of ultimate bearing capacity is: ", qu)
# Case C
print("CASE C")
x = float(input("Enter the value of depth of water below footing:"))
qu = (BulkDensity*Df*Nq) + (0.5*0.8* ((BulkDensity*x)+(SubDensity* (B-x))) *N)
print("The value of ultimate bearing capacity is:", qu)
Dw = float(input("Enter the value of water table above footing level:"))
Dw1= float(input("Enter the value of Water table below the level of footing:'"))
print("The approximate value of ultimate bearing capacity is:" , qu)
Rw = 0.5 + 0.5 * (Dw/B)
print("The value of Rw is:", Rw)
Rw1 = 0.5+0.5*(Dw1/B)
print("The value of Rwl is: ", Rw1)
qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity*N*Rw1)
print("the value of ultimate bearing capacity is:", qu)
   Enter the value of Bulk Density of soil:18
   Enter the value of Saturated Density of soil:20
   Enter the unit Weight of Water:10
   Enter the value of depth of footing:2
   Enter the value of water table above footing level:0
   Enter the value of Water table below the level of footing:0
   Enter the value of width of footing:3
   Enter the vaiue of Nq:33
```

```
Enter the value of N ganna (N):34
    Submerged Weight of soil is: 10.0
    The value of ultimate bearing capacity of soil is: 1068.0
    The value of Rw is: 0.5
    The value of Rw1 is: 0.5
    The value ultimate bearing capacity of soil is: 961.2
    CASE B
    The value of ultimate bearing capacity is: 1596.0
    Enter the value of water table above footing level:3
    Enter the value of Water table below the level of footing: 0
    The approximate value of ultimate bearing capacity is: 1596.0
    The value of Rw is: 1.0
    The value of Rw1 is: 0.5
    The approximate value of ultimate bearing capacity is: 1555.2
    CASE C
    Enter the value of depth of water below footing:1
    The value of ultimate bearing capacity is: 1704.8000000000002
    Enter the value of water table above footing level:3
    Enter the value of Water table below the level of footing:'1
    The approximate value of ultimate bearing capacity is: 1704.80000000000000
    The value of Rw is: 1.0
    The value of Rwl is: 0.666666666666666
    the value of ultimate bearing capaciy is: 1677.6
Q 2.
# To find the ultimate load carring capacity of pile
UCS = float(input("Enter the value of UCS of soil:"))
Cu = UCS/2
B = float(input("Enter the value of dimension of pile:"))
1 =float(input("Enter the length of pile:"))
Alpha = float(input("Enter the value of adhesion factor:"))
Nc= float(input("The value of Nc: "))
Ab = B*B
print("the Base area of footing is:", Ab)
As = 4*B*1
print("The value of chohesion of soil is:", Cu)
Qpu = Cu*Nc*Ab
print("'Qpu:", Qpu)
Qf = Alpha*Cu*As
print("Qf:", Qf)
Qu = Qpu + Qf
print("the value of load carring capacity of pile is (Qu):", Qu)
    Enter the value of UCS of soil:75
    Enter the value of dimension of pile:0.45
    Enter the length of pile:15
    Enter the value of adhesion factor:0.8
    The value of Nc: 9
    the Base area of footing is: 0.2025
    The value of chohesion of soil is: 37.5
    'Opu: 68.34375
    Of: 810.0
    the value of load carring capacity of pile is (Qu): 878.34375
Q 3.
# To Determine the bearing capacity of soil with water table
BulkDensity = float (input ("Enter the value of Bulk Density of soil:"))
SatDensity = float (input ("Enter the value of Saturated Density of soil:"))
WaterDensity = float (input ("Enter the unit Weight of Water:"))
Df = float (input ("Enter the value of depth of footing:"))
B = float (input ("Enter the value of width of footing:"))
Ng = float (input ("Enter the value of Ng:"))
N_Gamma = float (input ("Enter the value of N gamma (N):"))
SubDensity = SatDensity - WaterDensity
print("Submerged Weight of soil is:", SubDensity)
M = int(input("Number of data values of Water table above footing level: "))
N = int(input("Number of data values of Water table below footing level: "))
Dw = []
```

```
Dw1 = []
for i in range (1, M+1):
  print("Enter the value of water table above footing level measured w.r.t.ground (Dw) : ")
  Depth Dw = float (input ())
  Dw. append (Depth Dw)
  Rw = 0.5 + 0.5* (Depth_Dw/B)
  print("The value of Rw is:", Rw)
for j in range (1, N+1):
  print("Enter the value of water table above footing level measured w.r.t.ground (Dw1): ")
  Depth_Dw1 = float (input())
  Dw.append (Depth Dw1)
  Rw1 = 0.5 + 0.5*(Depth Dw1/B)
  print("The value of Rw1 is:", Rw1)
  qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity*N_Gamma*Rw1)
  print("'qu: ", qu, "kN/m^2")
    Enter the value of Bulk Density of soil:18
    Enter the value of Saturated Density of soil:20
    Enter the unit Weight of Water:10
    Enter the value of depth of footing:2
    Enter the value of width of footing:3
    Enter the value of Ng:33
    Enter the value of N gamma (N):34
    Submerged Weight of soil is: 10.0
    Number of data values of Water table above footing level: 3
    Number of data values of Water table below footing level: 3
    Enter the value of water table above footing level measured w.r.t.ground (Dw) :
    The value of Rw is: 0.5
    Enter the value of water table above footing level measured w.r.t.ground (Dw) :
    The value of Rw is: 0.666666666666666
    Enter the value of water table above footing level measured w.r.t.ground (Dw) :
    The value of Rw is: 0.8333333333333333
    Enter the value of water table above footing level measured w.r.t.ground (Dw1):
    The value of Rw1 is: 0.5
     'qu: 1357.19999999998 kN/m^2
    Enter the value of water table above footing level measured w.r.t.ground (Dw1):
    The value of Rw1 is: 0.5
    'qu: 1357.19999999998 kN/m^2
    Enter the value of water table above footing level measured w.r.t.ground (Dw1):
    The value of Rw1 is: 0.666666666666666
     'qu: 1479.6 kN/m^2
```