

# SimpleLink™ Wi-Fi® AT Command User's Guide

The SimpleLink™ Wi-Fi® Internet-on-a chip™ family of devices from Texas Instruments™ provides a suite of integrated protocols for Wi-Fi and internet connectivity to dramatically simplify the implementation of internet-enabled devices and applications.

This document describes the AT command protocol for SimpleLink, which is a widely used method to configure and control embedded networking systems due to its simplicity, textual parameter representation, and inherent flexibility.

#### Contents

1	Supported Platforms	. 4
2	Architecture Overview	
3	Getting Started	
4	Commands Summary	
5	Protocol Syntax	
6	Command Description	. 8
	List of Tables	
1	Device Commands	. 5
2	Socket Commands	. 5
3	WLAN Commands	. 5
4	File System Commands	. 6
5	Network Application Commands	. 6
6	Network Configuration Commands	. 6
7	Network Utility Commands	. 7
8	Asynchronous Events	. 7
9	AT+Start Starts the NWP	. 8
10	AT+Stop Stops the NWP	. 8
11	AT+Get Getting Device Configurations	. 9
12	AT+Set Setting Device Configurations	10
13	AT+Test Test Command	10
14	AT+Socket Create an End-Point for Communication	10
15	AT+Close Close Socket	11
16	AT+Accept Accept a Connection on a Socket	11
17	AT+Bind Assign a Name to a Socket	11
18	AT+Listen Listen for Connections on a Socket	11
19	AT+Connect Initiate a Connection on a Socket	12
20	AT+Select Monitor Socket Activity	12
21	AT+SetSockOpt Set Socket Options	13
22	AT+GetSockOpt Get Socket Options	15
23	AT+Recv Read Data From TCP Socket	15
24	AT+RecvFrom Read Data From Socket	16
25	AT+Send Write Data to TCP Socket	16
26	AT+SendTo Write Data to Socket	16





27	AT+WlanConnect Connect to WLAN Network as a Station	17
28	AT+WlanDisconnect Disconnect the Connection	17
29	AT+WlanProfileAdd Add Profile	18
30	AT+WlanProfileGet Get Profile	18
31	AT+WlanProfileDel Delete Profile	18
32	AT+WlanPolicySet Set Policy Values	19
33	AT+WlanPolicyGet Get Policy Values	
34	AT+WlanScan Gets the WLAN Scan Operation Results	
35	AT+WlanSetMode WLAN Set Mode	
36	AT+WlanSet Setting WLAN Configurations	
37	AT+ WlanGet Getting WLAN Configurations	
38	AT+FileOpen Open File in Storage Device	
39	AT+FileClose Close File in Storage Device	
40	AT+FileCtl Controls Various File System Operations	
41	AT+FileDel Delete File From Storage Device	
42	AT+FileGetFilelist Get a List of Files	
43	AT+FileGetInfo Get Information About a File	
44	AT+FileRead Read a Block of Data From a File in Storage Device	
45	AT+FileWrite Write Block of Data to a File in Storage Device	
46	AT+NetAPPStart Starts a Network Application	
47	AT+NetAPPStop Stops a Network Application	
48	AT+NetAPPGetHostByName Get Host IP by Name	
49	AT+NetAPPGetHostByService Get Host IP by Service	
50	AT+NetAPPSet Setting Network Application Configurations	
51	AT+NetAPPGet Getting Network Applications Configurations	
52	AT+NetAPPSend Sends Network Application Response or Data Following a Network Application Request Event	
53	AT+NetAPPRecv Receives Data From the Network Processor Following a Network Application Response Event	33
54	AT+NetAPPPing Send Ping to Network Hosts	33
55	AT+NetAPPGetServiceList Get Service List	34
56	AT+NetAPPRegisterService Register a New mDNS Service	34
57	AT+NetAPPUnRegisterService Unregister mDNS Service	35
58	AT+NetCfgSet Setting Network Configurations	36
59	AT+NetCfgGet Getting Network Configurations	37
60	AT+NetUtilGet Getting Utilities Configurations	39
61	AT+NetUtilCmd Performing Utilities-Related Commands	40
62	+EventFatalError Fatal Error Event for Inspecting Fatal Error	41
63	+EventGeneral General Asynchronous Event for Inspecting General Events	41
64	+EventWlan WLAN Asynchronous Event	42
65	+EventNetApp Network Application Asynchronous Event	43
66	+EventSock Socket Asynchronous Event	43
67	+EventMqtt MQTT Asynchronous Event	44
68	AT+MqttCreate MQTT Client Create	45
69	AT+MqttDelete MQTT Client Delete	
70	AT+MqttConnect MQTT Client Connect to Broker	46
71	AT+MqttDisconnect MQTT Client Disconnect From Broker	46
72	AT+MqttPublish MQTT Client Send Message to Broker	47
73	AT+MqttSubscribe MQTT Client Subscribe for Topic	47



#### www.ti.com

AT+MqttUnsubscribe MQTT Client Unsubscribe for Topic	47
AT+MqttSet MQTT Client Set Option	48
AT+HttpCreate Http Client Create	49
AT+HttpDestroy Http Client Delete	49
AT+HttpConnect Http Client Connect to Host	49
AT+HttpDisconnect Http Client Disconnect From Host	49
AT+HttpSendReg Http Client Send Request to Host	50
AT+HttpReadResBody Http Client Read Response Body From Host	50
AT+HttpSetHeader Http Client Set Header	51
AT+HttpGetHeader Http Client Get Header	52
AT+HttpSetOptHttp Client Set Option	53
AT+HttpSetProxy Http Client Set Proxy Address	53
	AT+MqttSet MQTT Client Set Option.  AT+HttpCreate Http Client Create  AT+HttpDestroy Http Client Delete  AT+HttpConnect Http Client Connect to Host.  AT+HttpDisconnect Http Client Disconnect From Host  AT+HttpSendReq Http Client Send Request to Host.  AT+HttpSendResBody Http Client Read Response Body From Host  AT+HttpSetHeader Http Client Set Header.  AT+HttpGetHeader Http Client Get Header  AT+HttpSetOptHttp Client Set Option

#### **Trademarks**

SimpleLink, Internet-on-a chip, Texas Instruments are trademarks of Texas Instruments. Wi-Fi, Wi-Fi Direct are registered trademarks of Wi-Fi Alliance. All other trademarks are the property of their respective owners.



Supported Platforms www.ti.com

#### 1 Supported Platforms

Hardware platforms that support the AT command library are:

- CC3220R
- CC3220S
- CC3220SF

#### 2 Architecture Overview

SimpleLink Wi-Fi AT Command consists of two main modules:

AT Commands Application

The application is one of the following application demos:

- The AT\_Commands application provides control by the AT Commands on the local device.
- The Serial\_wifi application provides control by the AT Commands on the local and the remote device.
- The user-customized application is based on the two previous applications.
- AT Command Core
  - The core includes the command parser, execution, and return status.
  - The AT Command Core should already be compiled into the library.

The following API communicate between the two modules:


- ATCmd\_create creates the AT Command core task and initializes the RX event queue.
- ATCmd\_send transmits string from the AT Command application to the AT Command Core.
   The function takes one parameter, Buffer, which stores the sent string.
- ATCmd\_recv transmits a string from the AT Command Core to the AT Command application.

The function takes two parameters:

- Buffer stores the received string.
- Nonblock variant set to 0 for waits forever on the RX queue, otherwise set to 1.

All send and receive buffers should be allocated by the AT Commands application.

Figure 1 shows the basic architecture.



Copyright © 2017, Texas Instruments Incorporated

Figure 1. Basic Architecture Scheme



www.ti.com Getting Started

#### 3 Getting Started

The following describes the procedure to build the AT Command Core. For building and executing the application binary file, refer to the *README.html* file that is located in each AT Command application. Ensure that the AT Command library includes in the application linking list.

The AT Command Core is prebuilt into the library "atcmd.a" per two OS (TI-RTOS and FreeRTOS) and per three compilers (CCS, GCC, and IAR). In the case where changes must be made to the core and you need to recompile it, there are two ways to build it:

For CCS (TI-RTOS or FreeRTOS), import the CCS project located under {SDK ROOT}\source\ti\net\atcmd\ccs and build the library.

**NOTE:** Pay attention to choose the appropriate product number.

 For all other favorites (including CCS), open the command prompt line under the directory {SDK ROOT}\source\ti\net\atcmd, and execute gmake from the XDC tool root directory. To clean all outputs, execute gmake clean.

#### 4 Commands Summary

**Table 1. Device Commands** 

Command	Definition
AT+Start	Starts the network processor (NWP)
AT+Stop	Stops the NWP
AT+Get	Gets device configurations
AT+Set	Sets device configurations
AT+Test	Test command

**Table 2. Socket Commands** 

Command	Definition
AT+Socket	Create an endpoint for communication
AT+Close	Close socket
AT+Accept	Accept a connection on a socket
AT+Bind	Assign a name to a socket
AT+Listen	Listen for connections on a socket
AT+Connect	Initiate a connection on a socket
AT+Select	Monitor socket activity
AT+SetSockOpt	Set socket options
AT+GetSockOpt	Get socket options
AT+Recv	Read data from TCP socket
AT+RecvFrom	Read data from socket
AT+Send	Write data to TCP socket
AT+SendTo	Write data to socket

**Table 3. WLAN Commands** 

Command	Definition
AT+WlanConnect	Connect to WLAN network as a station
AT+WlanDisconnect	Disconnect connection
AT+WlanProfileAdd	Add profile
AT+WlanProfileGet	Get profile



Commands Summary www.ti.com

### **Table 3. WLAN Commands (continued)**

Command	Definition
AT+WlanProfileDel	Delete profile
AT+WlanPolicySet	Set policy values
AT+WlanPolicyGet	Get policy values
AT+WlanScan	Gets the WLAN scan operation results
AT+WlanSetMode	WLAN set mode
AT+WlanSet	Setting WLAN configurations
AT+ WlanGet	Getting WLAN configurations

### **Table 4. File System Commands**

Command	Definition
AT+FileOpen	Open file in storage device
AT+FileClose	Close file in storage device
AT+FileCtl	Controls various file system operations
AT+FileDel	Delete file from storage device
AT+FileGetFilelist	Get list of a files
AT+FileGetInfo	Get information of a file
AT+FileRead	Read block of data from a file in storage device
AT+FileWrite	Write block of data to a file in storage device

### **Table 5. Network Application Commands**

Command	Definition
AT+NetAPPStart	Starts a network application
AT+NetAPPStop	Stops a network application
AT+NetAPPGetHostByName	Get host IP by name
AT+NetAPPGetHostByService	Host IP by service
AT+NetAPPSet	Setting network applications configurations
AT+NetAPPGet	Getting network applications configurations
AT+NetAPPSend	Sends Network Application response or data following a Network Application request event
AT+NetAPPRecv	Receives data from the network processor following a Network Application response event
AT+NetAPPPing	Send ping to network hosts
AT+NetAPPGetServiceList	Get service list
AT+NetAPPRegisterService	Register a new mDNS service
AT+NetAPPUnRegisterService	Unregister mDNS service

## **Table 6. Network Configuration Commands**

Command	Definition
AT+NetCfgSet	Setting network configurations
AT+NetCfgGet	Getting network configurations



www.ti.com Protocol Syntax

#### **Table 7. Network Utility Commands**

Command	Definition
AT+NetUtilGet	Getting utilities configurations
AT+NetUtilCmd	Performing utilities-related commands

#### **Table 8. Asynchronous Events**

Command	Definition
+EventFatalError	Fatal Error event for inspecting fatal error
+EventGeneral	General asynchronous event for inspecting general events
+EventWlan	WLAN asynchronous event
+EventNetApp	Network Application asynchronous event
+EventSock	Socket asynchronous event

#### 5 Protocol Syntax

#### 5.1 Commands

#### Syntax:

AT<command name>=<param1>, <param2>, ...,<paramX>

- Commands that contain parameters should include an equal sign (=) between the command name and the first parameter.
- Commands that contain parameters should include a comma mark (,) as a delimiter between them—comma delimiters are mandatory.
- In case the parameter is defined as "ignore" or "optional", it could be left empty but the comma delimiter should be mentioned—it looks like two conjunction delimiters (,,).
- Parameters that are left empty must be treated as 0 or NULL (according to the parameter type), and in case it was not defined as "ignore" or "optional", an error should be raised.
- String parameters containing spaces must be enclosed with quotes (" ").
- String parameters containing a comma delimiter (,) must be enclosed with quotes (" ").
- Numeric value parameters could be one of the following:
  - Decimal
  - Hexadecimal—must have a prefix of zero x notation (0x)
- Numeric array parameters could be enclosed with square brackets ([]).
- Numeric array parameters could be one of the following:
  - IPv4 address—contains four numeric values (8 bits each) with a point mark (.) as a delimiter between them enclosed with or without square brackets—x.x.x.x or [x.x.x.x]
  - IPv6 address—contains four numeric values (32 bit each) with a colon mark (:) as a delimiter between them enclosed with or without square brackets—x:x:x:x or [x:x:x:x]
  - MAC address—contains six numeric values (8 bit each) with a colon mark (:) as a delimiter between them enclosed with or without square brackets—x:x:x:x:x:x or [x:x:x:x:x:x]
- Bitmask parameters should contain values with a vertical bar ( | ) as delimiter between them enclosed with or without square brackets—x|x|x or [x|x|x]
- The AT command handler allows for the AT commands to be entered in uppercase or lowercase with spaces between the arguments.
- Data parameter should be one of the following formats:
  - Binary format
  - Base64 format—binary to text encoding



Protocol Syntax www.ti.com

#### 5.2 Command Return Status

Command return status could be one of the following cases:

· Command that returns values:

<command name>: <value1>, ...,<valueX>

Command that returns success:

OK

· Command that returns failure:

ERROR: <error description>, <error code>

Command return status should include a colon mark (:) between the command name and the first value.

Command return status that contains list values should include a semicolon mark (;) as a delimiter between the list members.

#### 5.3 Asynchronous Event

The events may arrive at any time. Asynchronous events are always built in the following format:

<event name>: <event ID>,<value1>,...,<valueX>

The event should include a colon mark (:) between the event name and the event ID.

#### 6 Command Description


#### 6.1 Device Commands

Table 9. AT+Start Starts the NWP

Request:	Response:
AT+Start	OK
Arguments: none	Arguments: none

#### Table 10. AT+Stop Stops the NWP

Request:	Response:
AT+Stop =[Timeout]	ОК
Arguments: Timeout: Stop timeout in milliseconds should be used to give the device time to finish any transmission or reception that is not completed when the function was called.  • 0: Enter to hibernate immediately  • 0xFFFF: Host waits for the response from the device before hibernating, without timeout protection  • 0 <timeout[msec] <0xffff:="" a="" be="" before="" can="" defined="" defines="" device="" earlier="" for="" from="" hibernating,="" host="" maximum="" nwp="" protection="" response="" sent="" td="" than="" the="" this="" time="" timeout="" timeout.<="" to="" wait.="" waits="" with=""><td>Arguments: none</td></timeout[msec]>	Arguments: none







## Table 11. AT+Get Getting Device Configurations

Request:		Response:
AT+Get= [ID],[Option]		+Get:[Value1],,[ValueX] OK
Arguments:		Arguments:
ID	Option	Return Values
Device  WLAN  Status  BSD  NETAPP	Device	Value1: bitmask: General error
	WLAN	Value1: bitmask:  • WLANASYNCONNECTEDRESPONSE  • WLANASYNCDISCONNECTEDRESPONSE  • STA_CONNECTED  • STA_DISCONNECTED  • P2P_DEV_FOUND  • CONNECTION_FAILED  • P2P_NEG_REQ_RECEIVED  • RX_FILTERS  • WLAN_STA_CONNECTED
	Value1: bitmask:  • TX_FAILED	
	NETAPP	Value1: bitmask:  • IPACQUIRED  • IPACQUIRED_V6  • IP_LEASED  • IP_RELEASED  • IPV4_LOST  • DHCP_ACQUIRE_TIMEOUT  • IP_COLLISION  • IPV6_LOST
	Version	<ul> <li>Value1: Chip ID</li> <li>Value2: FW Version (x.x.x.x)</li> <li>Value3: PHY Version (x.x.x.x)</li> <li>Value4: NWP Version (x.x.x.x)</li> <li>Value5: ROM Version</li> </ul>
General	Time	<ul> <li>Value1: Hour = Current hours</li> <li>Value2: Minute = Current minutes</li> <li>Value3: Second = Current seconds</li> <li>Value4: Day = Current Date, 1-31</li> <li>Value5: Month = Current Month, 1-12</li> <li>Value6: Year = Current year</li> </ul>
	Persistent	Value1:     1: Enable     0: Disable
IOT	UDID	16 bytes



### **Table 12.** AT+Set **Setting Device Configurations**

Request:			Response:
AT+Set= [ID],	[Option],[Value1],,[ValueX]		OK
Arguments:			
ID	Option	Value	
	Persistent sets the default system-wide configuration persistence mode. In case true, all APIs that follow system configured persistence (see persistence attribute noted per API) shall maintain the configured settings. In case false, all calls to APIs that follow system configured persistence shall be volatile. Configuration should revert to default after reset or power recycle.	Value1: • 1: Enable • 0: Disable	
General	Time sets the device time and date	<ul> <li>Value1: Hour = Current hours</li> <li>Value2: Minute = Current minutes</li> <li>Value3: Second = Current seconds</li> <li>Value4: Day = Current Date, 1–31</li> <li>Value5: Month = Current Month, 1–12</li> <li>Value6: Year = Current year</li> </ul>	


#### Table 13. AT+Test Test Command

Request:	Response:
AT+Test	OK
Arguments: none	Arguments: none

### 6.2 Socket Commands

#### Table 14. AT+Socket Create an End-Point for Communication

Request:	Response:
AT+Socket= [Domain],[Type],[Protocol]	+Socket: [socket] OK
Arguments:	
Domain: Specifies the protocol family of the created socket:	
<ul> <li>INET: For network protocol IPv4</li> </ul>	
<ul> <li>INET6: For network protocol IPv6</li> </ul>	
<ul> <li>RF: For starting transceiver mode</li> </ul>	
Type: Specifies the communication semantic:	Arguments:
<ul> <li>STREAM: Reliable stream-oriented service or Stream Sockets</li> </ul>	socket: Socket descriptor that will be
<ul> <li>DGRAM: Datagram service or Datagram Sockets</li> </ul>	used in the socket commands described in Table 15 through
<ul> <li>RAW: Raw protocols atop the network layer</li> </ul>	Table 26.
Protocol: Specifies a particular transport to be used with the socket:	
- TCP	
- UDP	
- RAW	
- SEC	







#### Table 15. AT+Close Close Socket

Request:	Response:
AT+Close= [socket]	+Close: [socket] OK
Arguments: socket: Socket descriptor received from AT+Socket command	

### Table 16. AT+Accept Accept a Connection on a Socket

Request:	Response:
AT+Accept = [socket],[family]	OK +Accept: [New Socket],[Family],[Port],[Address]
Arguments:  • socket: Socket descriptor received from AT+Socket command  • family: Specifies the protocol family of the created socket:  - INET: For network protocol IPv4  - INET6: For network protocol IPv6	<ul> <li>NewSocket: New connected socket</li> <li>Family: internet protocol (AF_INET)</li> <li>Port: Address port</li> <li>Address: Peer socket address</li> </ul>

#### Table 17. AT+Bind Assign a Name to a Socket

Request:	Response:
AT+Bind = [Socket],[Family],[Port],[Address]	OK
Arguments:	
Socket: Socket descriptor received from AT+Socket command	
Family: Specifies the protocol family of the created socket:	
<ul> <li>INET: For network protocol IPv4</li> </ul>	
<ul> <li>INET6: For network protocol IPv6</li> </ul>	
Port: Address port	
Address: Local socket address	

#### Table 18. AT+Listen Listen for Connections on a Socket

Request:	Response:
AT+Listen = [socket],[backlog]	OK
Arguments:	
<ul> <li>socket: Received from AT+Socket command</li> </ul>	
backlog: Listen	




### Table 19. AT+Connect Initiate a Connection on a Socket

Request:	Response:
AT+Connect = [Socket],[Family],[Port],[Address]	OK +Connect : [Port], [Address]
Arguments:	
Socket: Received from AT+Socket command	
Family: internet protocol:	
<ul> <li>INET: For network protocol IPv4</li> </ul>	
<ul> <li>INET6: For network protocol IPv6</li> </ul>	
Port: Address port	
Address: Peer socket address ("x.x.x.x")	

### Table 20. AT+Select Monitor Socket Activity

Request:	Response:
AT+Select = [nfds],[readsds],[timeout sec],[timeout usec]	OK +Select: [readsds]
Arguments:     nfds: The highest-numbered file descriptor in any of the three sets (read, write, and except)     readsds: Socket descriptors as bit list (for example, 0 2 for monitoring socket 0 and socket 2)     timeout sec: Time in seconds is an upper bound on the amount of time elapsed before select() returns. 0 means return immediately.     timeout usec: Time in microseconds	Arguments: readsds: Socket descriptors list for read monitoring and accept monitoring





www.ti.com

# Table 21. AT+SetSockOpt Set Socket Options

Request:		· ·	Response:
AT+SetSockOpt	AT+SetSockOpt = [sd],[Level],[Option],[Value1],,[ValueX]		ОК
Arguments: sd: Socket descr	riptor		
Level: Defines the protocol level for this option	Option	Value	
	KEEPALIVE Enable or disable periodic keep alive. Keeps TCP connections active by enabling the periodic transmission of messages	Value1:     1: Enable     0: Disable	
	KEEPALIVETIME Set keep alive timeout	Value1: Timeout in seconds	
	RX_NO_IP_BOUNDARY Enable or disable RX IP boundary	Value1:  • 1: Enable  • 0: Disable	
	RCVTIMEO Sets the timeout value that specifies the maximum amount of time an input function waits until it completes	Value1: Seconds     Value2: Microseconds. 10000 microseconds resolution	
	RCVBUF Sets TCP maximum receive window size	Value1: Size in bytes	
	NONBLOCKING Sets socket to nonblocking	Value1:     • 1: Enable     • 0: Disable	
	SECMETHOD Sets method to TCP secured socket	Value1 security method:  • SSLV3: Security method SSL v3  • TLSV1: Security method TLS v1  • TLSV1_1: Security method TLS v1_1  • TLSV1_2: Security method TLS v1_2  • SSLV3_TLSV1_2: Use highest possible version from SSLv3_TLS 1.2	
SOCKET	SECURE_MASK Sets specific ciphers as OR bitmask to TCP secured socket (default value: all ciphers)	Value1: Cipher type: SSL_RSA_WITH_RC4_128_SHA SSL_RSA_WITH_RC4_128_MD5 TLS_RSA_WITH_AES_256_CBC_SHA TLS_DHE_RSA_WITH_AES_256_CBC_SHA TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA TLS_ECDHE_RSA_WITH_RC4_128_SHA TLS_RSA_WITH_AES_128_CBC_SHA256 TLS_RSA_WITH_AES_128_CBC_SHA256 TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA256 TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA256 TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA TLS_ECDHE_ECDSA_WITH_AES_256_CBC_SHA TLS_RSA_WITH_AES_128_GCM_SHA256 TLS_RSA_WITH_AES_128_GCM_SHA384 TLS_DHE_RSA_WITH_AES_128_GCM_SHA384 TLS_DHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_CHACHA20_POLY1305_SHA256 TLS_DHE_RSA_WITH_CHACHA20_POLY1305_SHA256 TLS_DHE_RSA_WITH_CHACHA20_POLY1305_SHA256 TLS_DHE_RSA_WITH_CHACHA20_POLY1305_SHA256	



## Table 21. AT+SetSockOpt Set Socket Options (continued)

Request:			Response:	
	SECURE_FILES_CA_FILE_NAME Map secured socket to CA file by name	Value1: File name		
	SECURE_FILES_PRIVATE_KEY_FILE_NAME Map secured socket to private key by name	Value1: File name		
	SECURE_FILES_CERTIFICATE_FILE_NAME Map secured socket to certificate file by name	Value1: File name		
	SECURE_FILES_DH_KEY_FILE_NAME Map secured socket to Diffie Hellman file by name	Value1: File name		
	CHANGE_CHANNEL Sets channel in transceiver mode	Value1: Channel number (range is 1–13)		
SOCKET	SECURE_ALPN Sets the ALPN list	Value1: The parameter is a bit map consist of or of the following values: H1   H2   H2C   H2_14   H2_16   FULL_LIST		
(continued)	LINGER Socket lingers on close pending remaining send and receive packets	Value1:  - 1: Enable  - 0: Disable  Value2: Linger time in seconds		
	SECURE_EXT_CLIENT_CHLNG_RESP Set with no parameter to indicate that the client uses external signature using Network Application request	Value1: Ignore		
	SECURE_DOMAIN_NAME_VERIFICATION Set a domain name, to check in SSL client connection	Value1: Domain name		
	MULTICAST_TTL Set the time-to-live value of outgoing multicast packets for this socket	Value1: Number of hops		
	ADD_MEMBERSHIP UDP socket, join a multicast group	<ul><li>Value1: IPv4 multicast address to join</li><li>Value2: Multicast interface address</li></ul>		
IP	DROP_MEMBERSHIP UDP socket, leave a multicast group	<ul><li>Value1: IPv4 multicast address to join</li><li>Value2: Multicast interface address</li></ul>		
	RAW_RX_NO_HEADER Raw socket remove IP header from received data	Value1:     1: Remove header     0: Keep header		
	HDRINCL RAW socket only, the IPv4 layer generates an IP header when sending a packet unless this option is enabled on the socket	Value1: • 1: Enable • 0: Disable		
	RAW_IPV6_HDRINCL RAW socket only, the IPv6 layer generates an IP header when sending a packet unless this option is enabled on the socket	Value1:     1: Enable     0: Disable		



### Table 21. AT+SetSockOpt Set Socket Options (continued)

Request:			Response:
	PHY_RATE Set WLAN PHY transmit rate on RAW socket	Value1: Rate	
	PHY_TX_POWER RAW socket, set WLAN PHY TX power	Value1: Power rage is 1–15	
	PHY_NUM_FRAMES_TO_TX RAW socket, set number of frames to transmit in transceiver mode	Value1: Number of frames	
	PHY_PREAMBLE RAW socket, set WLAN PHY preamble for long or short	Value1: Preamble value	
		Value1: Threshold value:	
PHY		• MIN	
1111	PHY_TX_INHIBIT_THRESHOLD RAW socket, set WLAN TX inhibit threshold (CCA).	• LOW	
		DEFAULT	
		• MED	
		• HIGH	
		• MAX	
	PHY_TX_TIMEOUT RAW socket, changes the TX timeout (lifetime) of transceiver frames	Value1: Time in milliseconds, maximum value is 10 ms	
	PHY ALLOW ACKS	Value1:	
	RAW socket, enable sending ACKs in transceiver	1: Enable	
	mode	0: Disable	

### Table 22. AT+GetSockOpt Get Socket Options

Request:	Response:
AT+GetSockOpt = [sd],[level],[option]	+GetSockOpt: [value1],,[valueX] OK
Arguments:         • sd: Socket handle         • level: Defines the protocol level for this option (see Table 21)         • option: Defines the option name to interrogate (see Table 21)	Arguments: value1,,valueX (see the AT+SetSockOpt command in Table 21)

## Table 23. AT+Recv Read Data From TCP Socket

Request:	Response:
AT+Recv = [sd],[format],[length]	OK +Recv: [sd],[format],[length],[data]
Arguments:	
sd: Socket handle	
format: Data format:	
<ul> <li>0: Binary data format</li> </ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
length: Maximum number of bytes to receive	



#### Table 24. AT+RecvFrom Read Data From Socket


Request:	Response:
AT+RecvFrom = [sd],[family],[port],[addr],[format],[length]	OK +RecvFrom: [sd],[format],[length],[data]
Arguments:	
sd: Socket handle	
family: internet protocol	
<ul> <li>INET: For network protocol IPv4</li> </ul>	
<ul> <li>INET6: For network protocol IPv6</li> </ul>	
port: Address port (16 bits)	
addr: internet address (32 bits)	
format: Data format:	
<ul><li>0: Binary data format</li></ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
length: Maximum number of bytes to receive	

#### Table 25. AT+Send Write Data to TCP Socket

Request:	Response:
AT+Send = [sd],[format],[length],[data]	OK
Arguments:  • sd: Socket handle  • format: Data format:  - 0: Binary data format  - 1: Base64 data format (binary to text encoding)  • length: Number of bytes to send  • data: Data to send	

#### Table 26. AT+SendTo Write Data to Socket

Request:	Response:
AT+SendTo = [sd],[family],[port],[addr],[format],[length],[data]	ОК
Arguments:	
sd: Socket handle	
family: internet protocol:	
<ul> <li>INET: For network protocol IPv4</li> </ul>	
<ul> <li>INET6: For network protocol IPv6</li> </ul>	
port: Address port (16 bits)	
addr: internet address (32 bits)	
format: Data format:	
<ul> <li>0: Binary data format</li> </ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
length: Maximum number of bytes to receive	
data: Data to send	







#### 6.3 **WLAN Commands**

#### Table 27. AT+WlanConnect Connect to WLAN Network as a Station

Request:	Response:
AT+WlanConnect = [SSID],[BSSID],[SecurityType],[SecurityKey],[SecurityExtUser],	ОК
[SecurityExtAnonUser],[SecurityExtEapMethod]	
Arguments:	
SSID: Name of the Access Point	
BSSID: Access Point MAC address (Optional)	
SecurityType: Security type:	
- OPEN	
– WEP	
- WEP_SHARED	
- WPA_WPA2	
- WPA_ENT	
- WPS_PBC	
- WPS_PIN	
SecurityKey: Password (Optional in case it is not needed)	
<ul> <li>SecurityExtUser: Enterprise user name parameters (Ignored in case WPA_ENT was not selected)</li> </ul>	
<ul> <li>SecurityExtAnonUser: Enterprise anonymous user name parameters (Ignored in case WPA_ENT was not selected)</li> </ul>	
<ul> <li>SecurityExtEapMethod: Extensible Authentication Protocol (Ignored in case WPA_ENT was not selected):</li> </ul>	
- TLS	
- TTLS_TLS	
- TTLS_MSCHAPv2	
- TTLS_PSK	
- PEAPO_TLS	
- PEAP0_MSCHAPv2	
- PEAPO_PSK	
- PEAP1_TLS	
- PEAP1_PSK	

#### Table 28. AT+WlanDisconnect Disconnect the Connection

Request:	Response:
AT+WlanDisconnect	OK
Arguments: none	



#### Table 29. AT+WlanProfileAdd Add Profile


AT+WlanProfileAdd = [SSID],[BSSID],[SecurityType],[SecurityKey],[SecurityExtUser],  [SecurityExtAnonUser],[SecurityExtEapMethod],[Priority]  Arguments:  SSID: Name of the Access Point  BSSID: Access Point MAC address (Optional)  SecurityType: Security type:  OPEN  WEP	ProfileAdd: [index]
<ul> <li>SSID: Name of the Access Point</li> <li>BSSID: Access Point MAC address (Optional)</li> <li>SecurityType: Security type: <ul> <li>OPEN</li> </ul> </li> </ul>	
- WEP_SHARED - WPA_WPA2 - WPA_ENT - WPS_PBC - WPS_PIN  • SecurityKey: Password (Optional in case it is not needed) • SecurityExtUser: Enterprise user name parameters (Ignored in case WPA_ENT was not selected) • SecurityExtAnonUser: Enterprise anonymous user name parameters (Ignored in case WPA_ENT was not selected) • SecurityExtEapMethod: Extensible Authentication Protocol (Ignored in case WPA_ENT was not selected): - TLS - TTLS_TLS - TTLS_TLS - TTLS_MSCHAPv2 - TTLS_PSK - PEAP0_TLS - PEAP0_TLS - PEAP0_PSK - PEAP1_TLS - PEAP1_TLS - PEAP1_TLS - PEAP1_PSK - Piority: Profile priority: - Lowest priority: 0 - Highest priority: 15	ents: Profile stored index

#### Table 30. AT+WlanProfileGet Get Profile

Request:	Response:
AT+WlanProfileGet = [index]	+WlanProfileGet: [SSID],[BSSID],[SecurityType],[SecurityExtUser], [SecurityExtAnonUser],[SecurityExtEapMethod],[priority] OK
Arguments: index: Profile stored index received from +WlanProfileAdd	Arguments: See the AT+WlanProfileAdd command in Table 29.

#### Table 31. AT+WlanProfileDel Delete Profile

Request:	Response:
AT+ WlanProfileDel = [index]	OK
Arguments: index: Number of profile to delete received from +WlanProfileAdd To delete all profiles, use index = 0xFF	





## Table 32. AT+WlanPolicySet Set Policy Values

Request:			Response:
AT+WlanPolicySet = [Type],[Option],[	Value]		OK
Туре	Option	Value	
	Auto Reconnect to one of the stored profiles each time the connection fails or the device is rebooted	Ignore	
CONNECTION Defines options available to connect	Fast Establish a fast connection to AP	Ignore	
to the AP (Options could be set as bit masked). No option selected = disable all	P2P Automatically connect to the first P2P device available	Ignore	
	Auto_Provisioning Start the provisioning process after a long period of disconnection when profiles exist	Ignore	
SCAN	Hidden_SSID	Scan interval in seconds	
Defines system scan time interval. An interval is 10 minutes. After	No_Hidden_SSID	Scan interval in seconds	
settings scan interval, an immediate scan is activated	Disable_Scan	Ignore	
	Normal	Ignore	
5.4	Low_Latency	Ignore	
PM Defines a power management policy	Low_Power	Ignore	
for Station mode	Always_On	Ignore	
	Long_Sleep	Maximum sleep time in milliseconds	
P2P Defines P2P negotiation policy parameters for P2P role	CLIENT Indicates that the device is forced to be CLIENT GROUP_OWNER Indicates that the device is forced to be P2P GO NEGOTIATE Indicates that the device can be either CLIENT or GO, depending on the Wi-Fi Direct® negotiation tiebreaker	ACTIVE     When the remote peer is found after the discovery process, the device immediately sends the negotiation request to the peer device.      PASSIVE     When the remote peer is found after the discovery process, the device passively waits for the peer to start the negotiation, and only responds after.      RAND_BACKOFF     When the remote peer is found after the discovery process, the device triggers a random timer (from 1 to 6 seconds). During this period, the device passively waits for the peer to start the negotiation. If the timer expires without negotiation, the device immediately sends the negotiation request to the peer device.	



## Table 33. AT+WlanPolicyGet Get Policy Values

Request:	Response:
AT+WlanPolicyGet = [Type]	+WlanPolicyGet: [Option],[Value] OK
Arguments:	
Type: Type of policy. The options are:	
<ul> <li>CONNECTION     Get connection policy</li> </ul>	Arguments:
<ul><li>SCAN</li><li>Get scan policy</li></ul>	<ul> <li>Option: See the AT+WlanPolicySet command in Table 32</li> <li>Value: See the AT+WlanPolicySet</li> </ul>
<ul> <li>PM</li> <li>Get power management policy</li> </ul>	command in Table 32
<ul><li>– P2P</li><li>Get P2P policy</li></ul>	

## Table 34. AT+WlanScan Gets the WLAN Scan Operation Results

Request:	Response:		
AT+WlanScan = [Index],[Count]	+WlanScan: [SSID],[BSSID],[RSSI],[Channel],[Security_Type],[Hidden_SSII [Cipher],[Key_Mgmt]; OK		
Arguments:  • Index: Starting index identifier (range 0–29) for getting scan results.  • Count: How many entries to fetch; maximum is 30	Arguments:  SSID: Wireless LAN identifier  BSSID: MAC address of the wireless access point  Channel  RSSI: Relative received signal strength in a wireless environment  Security_Type:  OPEN  WEP  WPA  WPA2  WPA2  WPA_WPA2  Hidden_SSID:  1: Hidden  0: Not hidden  Cipher:  None  WEP40  WEP104  TKIP  CCMP  Key_Mgmt:  None  802_1_X  PSK		



### Table 35. AT+WlanSetMode WLAN Set Mode

Request:	Response:
AT+WlanSetMode = [Mode] OK	
Arguments:	
Mode: WLAN mode to start the device:  OTA For MI AN existing years.	
<ul> <li>STA: For WLAN station mode</li> <li>AP: For WLAN Access Point mode</li> </ul>	
- P2P: For WLAN Access Form mode - P2P: For WLAN P2P mode	


## Table 36. AT+WlanSet Setting WLAN Configurations

Request:			Response:	
AT+WlanS	et = [ID],[Option],[Value1],,[ValueX]		OK	
ID	Option	Value		
	SSID Set SSID for AP mode	String up to 32 characters		
	CHANNEL Set channel for AP mode	Channel in the range of [1–11]		
	HIDDEN_SSID Set Hidden SSID Mode for AP mode	<ul> <li>0: Disabled</li> <li>1: Send empty (length = 0) SSID in beacon and ignore probe request for broadcast SSID</li> <li>2: Clear SSID (ASCII 0), but keep the original length (this may be required with some clients that do not support empty SSID) and ignore probe requests for broadcast SSID</li> </ul>		
AP P. Se	SECURITY Set Security type for AP mode  • OPEN: Open security • WEP: WEP security • WPA_WPA2: WPA security			
	PASSWORD Set Password for AP mode (for WEP or for WPA)	Password for WPA: 8–63 characters Password for WEP: 5 or 13 characters (ASCII)		
	MAX_STATIONS Set Max AP stations	14 Note: can be less than the number of currently connected stations		
	MAX_STA_AGING Set Max station aging time	Number of seconds		
	ACCESS_LIST_MODE Set AP access list mode	DISABLE     DENY_LIST: Set Black List Mode		
Add MAC addr	ACCESS_LIST_ADD_MAC Add MAC address to the AP access list	MAC address: 6 characters		
	ACCESS_LIST_DEL_MAC Delete MAC address from the AP access list	MAC address: 6 characters		
	ACCESS_LIST_DEL_IDX Delete MAC address from index in the AP access list	Index		



## Table 36. AT+WlanSet Setting WLAN Configurations (continued)

Request:			Response:
GENERAL	COUNTRY_CODE Set Country Code for AP mode	Two characters country code	
	STA_TX_POWER Set STA mode TX power level	Number between 0–15, as dB offset from maximum power (0 sets maximum power)	
	AP_TX_POWER Set AP mode TX power level	Number between 0–15, as dB offset from maximum power (0 sets maximum power)	
	INFO_ELEMENT Set Info Element for AP mode	Value1: Index of the info element Value2: Role:  AP  P2P Value3: Info element ID Value4: Organization unique ID first Byte Value5: Organization unique ID second Byte Value6: Organization unique ID third Byte Value7: Info element (maximum 252 chars)	
	SCAN_PARAMS Set scan parameters	<ul><li> Value1: Channel mask</li><li> Value2: RSSI threshold</li></ul>	
	SUSPEND_PROFILES Set suspended profiles mask	Suspended bitmask	-
	DISABLE_ENT_SERVER_AUTH This option enables to skip server authentication and is valid for one use, when manually connection to an enterprise network	1: Disable the server authentication     0: Enable	
	DEV_TYPE Set P2P Device type	Device type is published under P2P I.E (maximum length of 17 characters)	
P2P	CHANNEL_N_REGS Set P2P Channels	<ul> <li>Value1: Listen channel (either 1/6/11 for 2.4 GHz)</li> <li>Value2: Listen regulatory class (81 for 2.4 GHz)</li> <li>Value3: Operating channel (channel 1, 6, or 11 for 2.4 GHz)</li> <li>Value4: Operating regulatory class (81 for 2.4 GHz)</li> </ul>	
	STATE Enable or disable filters	Filter Bitmap array (16 bytes in format xx:xx)	
DV EII TED	SYS_STATE Enable or disable system filters	Filter Bitmap array (4 bytes in format xx:xx)	
RX_FILTER	REMOVE Remove filters	Filter Bitmap array (16 bytes in format xx:xx)	
	STORE Save the filters as persistent	null	







## Table 37. AT+ WlanGet Getting WLAN Configurations

Request:	Response:	
AT+WlanGet = [ID],[Option]	+WlanGet: [Value1],,[ValueX] OK	
Arguments:		Arguments: See the AT+WlanSet command in Table 36.
ID	Option	
	SSID Get SSID for AP mode	
	CHANNEL Get channel for AP mode	
	HIDDEN_SSID Get Hidden SSID Mode for AP mode	
AP	SECURITY Get Security type for AP mode	
Ar	PASSWORD Get Password for AP mode (for WEP or for WPA)	
	MAX_STATIONS Get Max AP allowed stations	
	MAX_STA_AGING Get AP aging time in seconds	
	ACCESS_LIST_NUM_ENTRIES Get AP access list number of entries	_
ACCESS_LIST Get the AP access list from start index	The start index in the access list	
	COUNTRY_CODE Get Country Code for AP mode	
OFNEDAL	STA_TX_POWER Get STA mode TX power level	
GENERAL	AP_TX_POWER Get AP mode TX power level	
	SCAN_PARAMS Get scan parameters	
P2P	CHANNEL_N_REGS Get P2P Channels	
DV FILTED	STATE Retrieves the filters enable/disable status	
RX_FILTER	SYS_STATE Retrieves the system filters enable or disable status	



## Table 37. AT+ WlanGet Getting WLAN Configurations (continued)

Request:	Response:
Connection Ignore	Response:  Value1: Role:  sta  ap  p2p  Value2: Status:  disconnected  station_connected  p2pcl_connected  p2pgo_connected  ap_connected  say_connected  ap_connected  wap_connected  wap_act  wap_sploc  wap



#### File System Commands 6.4

Table 38. AT+FileOpen Open File in Storage Device

Request:		Response:
AT+FileOpen= [Filename], [Options],[File size]		+FileOpen:[FileID],[Secure Token] OK
Arguments	:	
• Filena	ame: Full path File Name	
Option	ns: Bitmask depend in option:	
_	READ: Read a file (no bitmask)	
_	WRITE: Open for write for an existing file (optionally bitmask with CREATE)	
-	CREATE: Open for creating a new file (optionally bitmask with WRITE or OVERWRITE)	
_	OVERWRITE: Opens an existing file (optionally bitmask with CREATE) /* Creation flags bitmask with CREATE */	
_	CREATE_FAILSAFE: Fail safe	
_	CREATE_SECURE: Secure file	
<ul> <li>CREATE_NOSIGNATURE : Relevant to secure file only</li> </ul>		
<ul> <li>CREATE_STATIC_TOKEN: Relevant to secure file only</li> </ul>		
_	CREATE_VENDOR_TOKEN: Relevant to secure file only	
_	CREATE_PUBLIC_WRITE: Relevant to secure file only, the file can be opened for write without Token	
_	CREATE_PUBLIC_READ: Relevant to secure file only, the file can be opened for read without Token	
	ize: Maximum file size is defined in bytes (mandatory only for the CREATE option signored for other options)	

## Table 39. AT+FileClose Close File in Storage Device

Request:	Response:
AT+FileClose= [FileID],[CeritificateFileName],[Signature]	OK
Arguments:	
FileID: Assigned from AT+FileOpen	
CeritificateFileName: Certificate file with full path (Optional)	
Signature: The signature is SHA-1, the certificate chain may include SHA-256 (Optional)	



## Table 40. AT+FileCtl Controls Various File System Operations

Request:				Response:	
AT+FileCtl= [Command]	T+FileCtl= [Command],[Secure_Token],[Filename],[Data] +FileCtl:[NewSecureToOK		cureToken],[OutputData]		
Arguments:			Arguments:		
Command	Token	Filename	Data	Token	Output Data
RESTORE Return to factory default	Ignore	Ignore	FACTORY_IMAGE The system will be back to the production image. FACTORY_DEFAULT Return to factory default	Ignore	Ignore
ROLLBACK Roll-back file	Token assigned from AT+FileOpen	Filename to roll back	Ignore	New secure token	Ignore
COMMIT Commit file	Token assigned from AT+FileOpen	Filename to commit	Ignore	New secure token	Ignore
RENAME Rename file	Token assigned from AT+FileOpen	Filename to rename	New file name	Ignore	Ignore
GET_STORAGE_INFO Get storage information	Ignore	Ignore	Ignore	Ignore	DeviceBlockSize     DeviceBlocks     Capacity     NumOfAllocated     Blocks     NumOfReserved     Blocks     NumOfReserved     BlocksFor     Systemfiles     LargestAllocated     GapInBlocks     NumOfAvailable     Blocks     ForUserFiles     MaxFsFiles     IsDevlopment     FormatType     Bundlestate     MaxFsFilesRese     rvedForSysFiles     ActualNumOf     UserFiles     ActualNumOf     SysFiles     NumOfAlerts     NumOfAlerts     Threshold     FATWrite     Counter
BUNDLE_ROLLBACK Roll back a bundle	Ignore	Ignore	Ignore	Ignore	Ignore
BUNDLE_COMMIT Commit a bundle	Ignore	Ignore	Ignore	Ignore	Ignore



### Table 41. AT+FileDel Delete File From Storage Device

Request:	Response:
AT+FileDel= [FileName],[SecureToken]	OK
Arguments:	
FileName: Full path File Name	
SecureToken: Token assigned from AT+FileOpen (optional)	

### Table 42. AT+FileGetFilelist Get a List of Files

Request:	Response:	
AT+FileGetFileList	+FileGetFileList: [FileName],[FileMaxSize],[Properties],[FileAllocatedBlocks] OK	
Arguments:	Arguments:     FileName: File name     FileMaxSize: Maximum file size     Properties: Info flag bitmask     FileAllocatedBlocks: Allocated blocks	

#### Table 43. AT+FileGetInfo Get Information About a File

Request:	Response:
AT+FileGetInfo= [FileName],[SecureToken]	+FileGetInfo: [Flags],[File Size],[Allocated Size], [Tokens],[Storage Size],[Write Counter] OK
Arguments:	
FileName: Full path file name	
SecureToken: token assigned from AT+FileOpen (optional)	

### Table 44. AT+FileRead Read a Block of Data From a File in Storage Device

Request:	Response:
AT+FileRead= [FileID], [Offset],[Format],[Length]	+FileRead:[format],[NumberOfReadBytes],[ReceivedData] OK
Arguments:	
FileID: Assigned from AT+FileOpen	
Offset: Offset to specific read block	
Format: Data format:	
<ul> <li>0: Binary data format</li> </ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
Length: Number of bytes to read	



## Table 45. AT+FileWrite Write Block of Data to a File in Storage Device

Request:	Response:
AT+FileWrite= [FileID], [Offset],[Format],[Length],[Data]	+FileWrite:[NumberOfWrittenBytes] OK
Arguments:	
FileID: Assigned from AT+FileOpen	
Offset: Offset to specific block to be written	
Format: Data format:	
<ul> <li>0: Binary data format</li> </ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
Length: Number of bytes to write	
Data: Transmitted data to the storage device	



#### 6.5 **Network Application Commands**

Activate networking applications, such as:

- HTTP Server
- **DHCP Server**
- Ping
- DNS
- mDNS

#### Table 46. AT+NetAPPStart Starts a Network Application

Request:	Response:
AT+NetAPPStart = [APP Bitmap]	ОК
Arguments:	
<ul> <li>APP Bitmap: Application bitmap, could be one or a combination of the following with OR (" " between them:</li> </ul>	
- HTTP_SERVER	
- DHCP_SERVER	
- MDNS	
- DNS_SERVER	

## Table 47. AT+NetAPPStop Stops a Network Application

Request:	Response:
AT+NetAPPStop = [APP Bitmap]	OK
Arguments:	
<ul> <li>APP Bitmap: Application bitmap, could be one or a combination of the following with OR (" ") between them:</li> </ul>	
- HTTP_SERVER	
- DHCP_SERVER	
- MDNS	
- DNS_SERVER	

### Table 48. AT+NetAPPGetHostByName Get Host IP by Name

Request:	Response:
AT+NetAPPGetHostByName = [HostName],[Family]	OK +NetAPPGetHostByName: [HostName],[Host IP address]
Arguments:  • HostName  • Family: Protocol Family:  - INET: For network protocol IPv4  - INET6: For network protocol IPv6	Arguments:



### Table 49. AT+NetAPPGetHostByService Get Host IP by Service

Request:	Response:
AT+NetAPPGetHostByService = [ServiceName],[Family]	OK +NetAPPGetHostByService: [ServiceName],[Port],[HostIPAddress],[Text]
Arguments:	Arguments:
ServiceName: Service name can be full or partial	ServiceName
Family: Protocol Family:	Port: Service port
<ul> <li>INET: For network protocol IPv4</li> </ul>	HostIPAddress: Host IP address (IPv4 or IPv6)
<ul> <li>INET6: For network protocol IPv6</li> </ul>	Text: Text of the service full or partial

### **Table 50.** AT+NetAPPSet **Setting Network Application Configurations**

Request:			Response:
AT+NetAPPSet = [App ID],[Option],[Value1],,[ValueX]			OK
Arguments:			
App ID	Option	Values	
DHCP_SERVER	BASIC	<ul> <li>Value1: Lease time (in seconds) of the IP Address</li> <li>Value2: First IP Address for allocation</li> <li>Value3: Last IP Address for allocation</li> </ul>	
	PRIM_PORT_NUM	Value1: port number	
	AUTH_CHECK	Value1:     1: Authentication enable     0: Authentication disable	
	AUTH_NAME	Value1: Authentication name (maximum length is 20 bytes)	
	AUTH_PASSWORD	Value1: Authentication password (maximum length is 20 bytes)	
	AUTH_REALM	Value1: Authorization realm (maximum length is 20 bytes)	
	ROM_PAGES_ACCESS	Value1: • 1: Access enable • 0: Access disable	
	SECOND_PORT_NUM	Value1: port number	
HTTP_SERVER SE	SECOND_PORT_EN	Value1:  • 1: Enable  • 0: Disable	
	PRIM_PORT_SEC_EN	Value1:     1: Enable     0: Disable	
	PRIV_KEY_FILE	Value1: File name (maximum length is 96 bytes)	
	DEV_CERT_FILE	Value1: File name (maximum length is 96 bytes)	
	CA_CERT_FILE	Value1: File name (maximum length is 96 bytes)	
	TMP_REGISTER_SERVICE	Value1: Service name for MDNS (maximum length is 80 bytes)	
	TMP_UNREGISTER_SERVICE	Value1: Service name for MDNS (maximum length is 80 bytes)	



## Table 50. AT+NetAPPSet Setting Network Application Configurations (continued)

Request:			Response:
	CONT_QUERY	Value1: Service name (maximum length is 80 bytes)	
MDNS	QEVETN_MASK	Value1: Event mask:  ipp deviceinfo http https workstation guid h323 ntp objective rdp remote rtsp sip smb soap ssh telnet tftp xmpp raop	
	TIMING_PARAMS	<ul> <li>Value1: Period in ticks (100 ticks = 1 second)</li> <li>Value2: Repetitions</li> <li>Value3: Telescopic factor</li> <li>Value4: Retransmission interval</li> <li>Value5: Maximum period interval</li> <li>Value6: Maximum time</li> </ul>	
DEVICE	URN	Value1: device name (maximum length is 33 bytes)	
	DOMAIN	Value1: domain name (maximum length is 63 bytes)	
DNS_CLIENT	TIME	<ul><li>Value1: Maximum response time in milliseconds</li><li>Value2: Number of retries</li></ul>	



### **Table 51.** AT+NetAPPGet **Getting Network Applications Configurations**

Request:  AT+NetAPPGet = [App ID],[Option]  Arguments:		Response: +NetAPPGet: [return values] OK	
		App ID	Option
DHCP_SERVER	BASIC		
	PRIM_PORT_NUM		
	AUTH_CHECK		
	AUTH_NAME		
	AUTH_PASSWORD		
HTTP_SERVER	AUTH_REALM		
	ROM_PAGES_ACCESS		
	SECOND_PORT_NUM		
	SECOND_PORT_EN		
	PRIM_PORT_SEC_EN		
MDNS	CONT_QUERY		
	QEVETN_MASK		
	TIMING_PARAMS		
DEVICE	URN		
DEVICE	DOMAIN		
DNS_CLIENT	TIME		

**Table 52.** AT+NetAPPSend Sends Network Application Response or Data Following a Network Application Request Event

Request:	Response:
AT+NetAPPSend = [Handle],[Flags],[Format],[Length],[Data]	OK
Arguments:	
Handle: Handle to send the data to. Should match the handle received in the Network     Application request event	
Flags: Bitmask:	
<ul> <li>CONTINUATION: More data will arrive in subsequent calls to AT+NetAPPSend</li> </ul>	
<ul> <li>METADATA: Define data as metadata, otherwise data is payload</li> </ul>	
<ul> <li>ACCUMULATION: The network processor should accumulate the data chunks and will process it when it is completely received</li> </ul>	
Format: Data format:	
<ul><li>0: Binary data format</li></ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
Length: Number of bytes to send	
Data: Data to send. Can be just data payload or metadata (depends on flags)	



# Table 53. AT+NetAPPRecv Receives Data From the Network Processor Following a Network Application Response Event

Request:	Response:
AT+NetAPPRecv = [Handle],[Format],[Length]	OK +NetAPPRecv:[Handle],[Flags],[Format],[Length],[Data]
Arguments:     Handle: Handle to receive data from. Should match the handle receive in the Network Application request event     Format: Data format:	Arguments:
O: Binary data format     I: Base64 data format (binary to text encoding)      Length: Number of bytes to receive	Format: Data format:  - 0: Binary data format  - 1: Base64 data format  Length: Number of bytes received  Data: Data received

#### Table 54. AT+NetAPPPing Send Ping to Network Hosts

Request:	Response:	
AT+NetAPPPing = [Family],[Destination],[Size],[Delay],[Timeout],[Max],[Flags]	OK +NetAPPPing: [PacketsSent],[PacketsReceived],[RoundTime]	
Arguments:		
Family:		
<ul> <li>INET: For network protocol IPv4</li> </ul>		
<ul> <li>INET6: For network protocol IPv6</li> </ul>		
<ul> <li>Destination: Destination IP address. For stopping an ongoing ping activity, set destination to 0</li> </ul>		
Size: Size of ping, in bytes		
<ul> <li>Delay: Delay between pings, in milliseconds</li> </ul>		
<ul> <li>Timeout: Timeout for every ping in milliseconds</li> </ul>		
<ul> <li>Max: Maximum number of ping requests</li> </ul>		
<ul><li>0: Forever</li></ul>		
Flags:		
<ul> <li>Set to 0: Ping reports back once all requested pings are done</li> </ul>		
<ul> <li>Set to 1: Ping reports back after every ping</li> </ul>		
<ul> <li>Set to 2: Ping stops after the first successful ping and reports back for the successful ping, as well as any preceding failed pings</li> </ul>		



#### Table 55. AT+NetAPPGetServiceList Get Service List

Request:	Response:
AT+NetAPPGetServiceList = [IndexOffset],[MaxServiceCount],[Flags]	+NetAPPGetServiceList:[ServiceInfo1];;[ServiceInfoX] OK
Arguments:  • IndexOffset: The start index in the peer cache that from it the first service is returned  • MaxServiceCount: The maximum services that can be returned if existed or if not exceed the maximum index in the peer cache  • Flags: Which service to use (means which types of service to fill):  - FULL_IPV4_WITH_TEXT  - FULL_IPV4  - SHORT_IPV4  - FULL_IPV6_WITH_TEXT  - FULL_IPV6_WITH_TEXT  - SHORT_IPV6	Arguments: ServiceInfo: Depends on flag type:  SHORT_IPV4 SHORT_IPV6  ip port FULL_IPV4 FULL_IPV6  ip port service name service host name FULL_IPV4_WITH_TEXT FULL_IPV6_WITH_TEXT  ip port service name service name service host name

### Table 56. AT+NetAPPRegisterService Register a New mDNS Service

Request:		
AT+NetAPPRegisterService= [ServiceName],[Text],[Port],[TTL],[Options]	OK	
Arguments:		
ServiceName: The service name		
Text: The description of the service		
Port: The port on this target host port		
TTL: The TTL of the service		
Options: Bitwise parameters:		
<ul> <li>IS_UNIQUE_BIT: Service is unique per interface (means that the service needs to be unique)</li> </ul>		
<ul> <li>IPV6_IPV4_SERVICE: Add this service to IPv6 interface, if exist (default is IPv4 service only)</li> </ul>		
<ul> <li>IPV6_ONLY_SERVICE: Add this service to IPv6 interface, but remove it from IPv4 (only IPv6 is available)</li> </ul>		
<ul> <li>UPDATE_TEXT: For update text fields (without reregistering the service)</li> </ul>		
<ul> <li>IS_NOT_PERSISTENT: For setting a nonpersistent service</li> </ul>		



www.ti.com Command Description

## Table 57. AT+NetAPPUnRegisterService Unregister mDNS Service

Request:		Response:
AT+NetAF	PPUnRegisterService= [ServiceName],[Options]	OK
Arguments	5:	
<ul> <li>Servi</li> </ul>	ceName: Full service name	
<ul> <li>Option</li> </ul>	ns: Bitwise parameters:	
-	IS_UNIQUE_BIT: Service is unique per interface (means that the service needs to be unique)	
_	IPV6_IPV4_SERVICE: Add this service to IPv6 interface, if exist (default is IPv4 service only)	
-	IPV6_ONLY_SERVICE: Add this service to IPv6 interface, but remove it from IPv4 (only IPv6 is available)	
-	UPDATE_TEXT: For update text fields (without reregistering the service)	
, –	IS_NOT_PERSISTENT: For setting a nonpersistent service	




### 6.6 Network Configuration Commands

The Network Configuration Commands control the configuration of the device addresses (that is, IP and MAC addresses).

Table 58. AT+NetCfgSet Setting Network Configurations

Request:			Response:
AT+NetCfgSet = [ConfigId],[ConfigOpt],[Value1],,[ValueX]		OK	
Arguments:			
Configld	ConfigOpt	Value	
IF	STATE Enable or disable modes (bitmask)	IPV6_STA_LOCAL:     Enable ipv6 local     IPV6_STA_GLOBAL:     Enable ipv6 global     DISABLE_IPV4_DHCP:     Disable ipv4 DHCP     IPV6_LOCAL_STATIC:     Enable ipv6 local static     IPV6_LOCAL_STATELESS:     Enable ipv6 local stateless     IPV6_LOCAL_STATEFUL:     Enable ipv6 local stateful     IPV6_GLOBAL_STATIC:     Enable ipv6 global static     IPV6_GLOBAL_STATEFUL:     Enable ipv6 global static     IPV6_GLOBAL_STATEFUL:     Enable ipv6 global stateful     DISABLE_IPV4_LLA:     Disable LLA feature     ENABLE_DHCP_RELEASE:     Enables DHCP release     IPV6_GLOBAL_STATELESS:     Enable ipv6 global stateless     DISABLE_FAST_RENEW:     Fast renew disabled	
SET_MAC_ADDR Setting MAC address to the Device	Ignore value	New MAC address	
IPV4_STA_ADDR Setting IP address	STATIC Setting a static IP address	<ul><li>Value1: IP address</li><li>Value2: Subnet mask</li><li>Value3: Default gateway address</li><li>Value4: DNS server address</li></ul>	
	DHCP Setting IP address by DHCP	Ignore value	
	DHCP_LLA Setting DHCP LLA	Ignore value	
	RELEASE_IP_SET Setting release IP before disconnect enables sending a DHCP release frame to the server	Ignore value	
	RELEASE_IP_OFF Setting release IP before disconnect disables sending a DHCP release frame to the server	Ignore value	
IPV4_AP_ADDR Setting a static IP address to the device working in AP mode	STATIC Setting a static IP address	<ul><li>Value1: IP address</li><li>Value2: Subnet mask</li><li>Value3: Default gateway address</li><li>Value4: DNS server address</li></ul>	







## Table 58. AT+NetCfgSet Setting Network Configurations (continued)

Request:			Response:
	STATIC Setting a IPv6 Local static address	IP address	
IPV6_ADDR_LOCAL	STATELESS Setting a IPv6 Local stateless address	Ignore value	
	STATEFUL Setting a IPv6 Local stateful address	Ignore value	
IPV6_ADDR_GLOBAL	STATIC Setting a IPv6 Global static address Value1 : IP address Value2: DNS Server IP STATEFUL	<ul><li>Value1: IP address</li><li>Value2: DNS Server IP</li></ul>	
	STATEFUL Setting a IPv6 Global stateful address	Ignore value	
AP_STATION_DISCONNECT Disconnect AP station by MAC address	Ignore value	AP MAC address	
IPV4_DNS_CLIENT Set secondary DNS address	Ignore value	Secondary DNS Server address	


## Table 59. AT+NetCfgGet Getting Network Configurations

Request:	Response:	
AT+NetCfgGet = [ConfigId]	+NetCfgGet:[Value1],,[ValueX] OK	
Arguments: Configld: Configuration ID:	Arguments:	
GET_MAC_ADDR Get the device MAC address	Value1: MAC address	
IPV4_STA_ADDR Get IP address from WLAN station or P2P client	Value1: Address option:     DHCP	
IPV4_AP_ADDR Get static IP address for AP or P2P go	<ul> <li>DHCP_LLA</li> <li>STATIC</li> <li>Value2: Address</li> <li>Value3: Subnet mask</li> <li>Value4: Gateway</li> <li>Value5: DNS</li> </ul>	
IF Get interface bitmap	Value1: State (bitmask):  ipv6_sta_local  ipv6_sta_global  disable_ipv4_dhcp  ipv6_local_static  ipv6_local_stateless  ipv6_local_stateful  ipv6_global_static  ipv6_global_stateful  disable_ipv4_lla  enable_dhcp_release  ipv6_global_stateless  disable_fast_renew	



## Table 59. AT+NetCfgGet Getting Network Configurations (continued)

Request:	Response:
IPV6_ADDR_LOCAL Get IPV6 Local address	Vaule1: Address option:
IPV6_ADDR_GLOBAL Get IPV6 Global address	<ul><li>stateful</li><li>STATIC</li><li>Value2: Address</li></ul>
AP_STATIONS_CONNECTED Get AP number of connected stations	Value1: Number of connected stations
AP_STATIONS_INFO Get AP full list of connected stations	[address1],[MAC address1],[name1];; [addressX],[MAC addressX],[nameX]
IPV4_DNS_CLIENT Set secondary DNS address	Value1: DNS second server address
IPV4_DHCP_CLIENT Get DHCP Client info	<ul> <li>Value1: Address</li> <li>Value2: Subnet mask</li> <li>Value3: Gateway</li> <li>Value4: DNS 1</li> <li>Value5: DNS 2</li> <li>Value6: DHCP server</li> <li>Value7: Lease time</li> <li>Value8: Time to renew</li> <li>Value9: DHCP State:  – unknown – disabled – enabled – bound – renew – rebind</li> </ul>







#### **Network Utility Commands** 6.7

Networking related commands and configuration.

### Table 60. AT+NetUtilGet Getting Utilities Configurations

Request:		Response:
AT+NetUtilGet =[ID],[Option]		+NetUtilGet: [Value1],,[ValueX] OK
Arguments:		Arguments:
ID Identifier of the specific "get" operation to perform	Option	Value
public_key	O: Binary data format  1: Base64 data format (binary to text encoding)	Value1: Public key format:  - 0: Binary data format  - 1: Base64 data format  Value2: Public key length (maximum length is 255 bytes or 370 bytes in base64 format)  Value3: Public key
true_random	Number of random numbers (maximum is 172 numbers)	List of random numbers



## Table 61. AT+NetUtilCmd Performing Utilities-Related Commands

Request:		Response:
AT+NetUtilCmd = [Cmd],[Value1],,[Va	lueX]	+NetUtilCmd:[Value1],,[ValueX] OK
Arguments:		Arguments:
Cmd Identifier of the specific command to perform	Option	Value
sign_msg Create a digital signature using the ECDSA algorithm	Value1: Key index: Value2: Data format:  O: Binary data format  1: Base64 data format (binary to text encoding) Value3: Data length (maximum length is 1500 bytes) Value4: Data	<ul> <li>Value1: Signature format:         <ul> <li>0: Binary data format</li> <li>1: Base64 data format (binary to text encoding)</li> </ul> </li> <li>Value2: Signature length (maximum length is 255 bytes)</li> <li>Value3: Signature</li> </ul>
verify_msg verify a digital signature using the ECDSA algorithm	Value1: Key index Value2: Data and signature format:  O: Binary data format  1: Base64 data format (binary to text encoding) Value3: Data length (maximum length is 1500 bytes) Value4: Signature length Value5: Data and signature (signature concatenate to end of data)	Value1: Success or failure
temp_keys Create or remove a temporary ECC key pair with the SECP256R1 curve	<ul><li>Value1: Key index</li><li>Value2: Action:</li><li>create</li><li>remove</li></ul>	
install_op Install or uninstall a key pair in one of the crypto utilities key pair management mechanism	Value1: Key index Value2: Action:  - install - uninstall  Value3: Key Algorithm (ignored for uninstall action):  - none - ec Value4: EC Named Curve identifier (optional for Key Algorithm none) (ignored for uninstall action):  - none - secp256r1 Value5: Certification file name (ignored for uninstall action) Value6: Key file name (ignored for uninstall action)	



#### 6.8 Asynchronous Events

Table 62. +EventFatalError Fatal Error Event for Inspecting Fatal Error

Response:	
+EventFatalError:[EventID],[Value1],,[ValueX]	
Arguments:	
EventID	Value
DEVICE_ABORT Indicates a severe error occurred and the device stopped	<ul><li>Value1: An indication of the abort type</li><li>Value2: The abort data</li></ul>
NO_CMD_ACK Indicates that the command sent to the device had no ACK	Value1: An indication of the CMD opcode
CMD_TIMEOUT Indicates that the command got a timeout while waiting for its asynchronous response	Value1: An indication of the asynchronous event opcode
DRIVER_ABORT Indicates a severe error occurred in the driver	null
SYNC_LOSS Indicates a sync loss with the device	null

Table 63. +EventGeneral General Asynchronous Event for Inspecting General Events

Response:	
+EventGeneral:[EventID],[Value1],,[ValueX]	
Arguments:	
EventID Value	
RESET_REQUEST	<ul> <li>Value1: An error code indication from the device</li> <li>Value2: The sender originator:         <ul> <li>WLAN</li> <li>NETCFG</li> <li>NETAPP</li> <li>SECURITY</li> <li>OTHER</li> </ul> </li> </ul>
ERROR	<ul><li>Value1: An error code indication from the device</li><li>Value2: The sender originator</li></ul>



## Table 64. +EventWlan WLAN Asynchronous Event

Response:		
+EventWlan:[EventID],[Value1],,[ValueX]		
Arguments:		
EventID	Value	
CONNECT STA connection indication event	Value1: SSID name     Value2: BSSID	
P2P_CONNECT P2P client connection indication event	<ul><li>Value1: SSID name</li><li>Value2: BSSID</li><li>Value3: Go Device Name</li></ul>	
DISCONNECT STA client disconnection event	<ul><li> Value1: SSID name</li><li> Value2: BSSID</li><li> Value3: Reason</li></ul>	
P2P_DISCONNECT P2P client disconnection event	<ul><li>Value1: SSID name</li><li>Value2: BSSID</li><li>Value3: Reason</li><li>Value4: Go Device Name</li></ul>	
STA_ADDED AP connected STA	Value1: MAC address	
STA_REMOVED AP disconnected STA	Value1: MAC address	
P2P_CLIENT_ADDED P2P(Go) connected P2P(Client)	<ul><li>Value1: MAC address</li><li>Value2: Go Device Name</li><li>Value3: Own SSID</li></ul>	
P2P_CLIENT_REMOVED P2P(Go) disconnected P2P(Client)	<ul><li>Value1: MAC address</li><li>Value2: Go Device Name</li><li>Value3: Own SSID</li></ul>	
P2P_DEVFOUND	<ul><li>Value1: Go Device Name</li><li>Value2: MAC address</li><li>Value3: WPS Method</li></ul>	
P2P_REQUEST	<ul><li>Value1: Go Device Name</li><li>Value2: MAC address</li><li>Value3: WPS Method</li></ul>	
P2P_CONNECTFAIL P2P only	Value1: Status	
PROVISIONING_STATUS	Value1: Status	
PROVISIONING_PROFILE_ADDED	Value1: Status     Value2: SSID name	



## Table 65. +EventNetApp Network Application Asynchronous Event

Response:			
+EventNetApp:[EventID],[Value1],,[ValueX]	+EventNetApp:[EventID],[Value1],,[ValueX]		
Arguments:	Arguments:		
EventID	Value		
IPV4_ACQUIRED	<ul><li>Value1: IP address</li><li>Value2: Gateway</li><li>Value3: DNS</li></ul>		
IPV6_ACQUIRED	<ul><li>Value1: IP address</li><li>Value2: DNS</li></ul>		
ip_collision	<ul><li>Value1: IP address</li><li>Value2: DHCP MAC</li><li>Value3: DNS</li></ul>		
IP_LEASED AP or P2P go DHCP lease event	<ul><li>Value1: IP address</li><li>Value2: Lease time</li><li>Value3: MAC</li></ul>		
IP_RELEASED AP or P2P go DHCP IP release event	<ul><li>Value1: IP address</li><li>Value2: MAC</li><li>Value3: Reason</li></ul>		
IPV4_LOST	Value1: Status		
dhcp_ipv4_acquire_timeout	Value1: Status		
IPV6_LOST	Value1: IP lost		


### Table 66. +EventSock Socket Asynchronous Event

Response:	
+EventSock:[EventID],[Value1],,[ValueX]	
Arguments:	
EventID	Value
TX_FAILED	<ul><li>Value1: sd</li><li>Value2: Status</li></ul>
ASYNC_EVENT	<ul> <li>Value1: sd</li> <li>Value2: Type:  <ul> <li>SSL_ACCEPT</li> <li>RX_FRAG_TOO_BIG</li> <li>OTHER_SIDE_CLOSE_SSL</li> <li>CONNECTED_SECURED</li> <li>WRONG_ROOT_CA</li> </ul> </li> <li>Value3: Error value</li> </ul>



## Table 67. +EventMqtt MQTT Asynchronous Event

Response:		
+EventMqtt:[EventID],[Valu	ue1],,[ValueX]	
Arguments:		
EventID	Value	
	Value1: operation ID:	
	<ul> <li>Connack: connection acknowledge</li> </ul>	
	Value2: 16 bits:	
	8 MSBs: Acknowledge Flags	
	8 LSBs: return code:	
	0: Connection Accepted	
	1: Connection Refused, unacceptable protocol version	
	2: Connection Refused, identifier rejected	
	3: Connection Refused, Server unavailable	
	4: Connection Refused, bad user name or password	
operation	5: Connection Refused, not authorized	
	<ul> <li>Puback: publish acknowledge</li> <li>Value2: Packet Identifier from the PUBLISH Packet that is being acknowledged</li> </ul>	
	<ul> <li>Suback: subscribe acknowledge</li> <li>Value2: Packet Identifier from the SUBSCRIBE Packet that is being acknowledged</li> <li>Value3 to ValueX: return code per topic:</li> </ul>	
	0: Success, Maximum QoS 0	
	1: Success, Maximum QoS 1	
	2: Success, Maximum QoS 2	
	128: Failure	
	<ul> <li>Unsuback: unsubscribe acknowledge</li> <li>Value2: Packet Identifier from the UNSUBSCRIBE Packet that is being acknowledged</li> </ul>	
	Topic: topic string	
	QoS: Quality of service type:	
	- QoS 0	
	- QoS 1	
	- QoS 2	
	Retain:	
	<ul> <li>0: message should not be retained</li> </ul>	
recv	1: message should be retained  Purlicate:	
	Duplicate:  On first attempted to cond the masses.	
	O: first attempted to send the message  1: might be re-delivery of an earlier attempt to cond the message.	
	<ul> <li>1: might be re-delivery of an earlier attempt to send the message</li> <li>Message Format:</li> </ul>	
	O: Binary data format	
	1: Base64 data format (binary to text encoding)	
	Message length: number of bytes to send	
	Message: message to send	
disconnect		







#### 6.9 **MQTT Client Commands**

MQTT client commands and configuration.

Table 68. AT+MqttCreate MQTT Client Create

Request:	Response:
AT+MqttCreate =[client ID], [flags], [address], [port], [method], [cipher], [private key], [Certificate], [CA], [DH key], [protocol], [blocking send], [data format]	+ MqttCreate: [index] OK
Arguments:	Arguments:
client ID	
flags: bitmask of the following:	
<ul><li>ip4: IPv4 connection</li></ul>	
- <i>ip6</i> : IPv6 connection	
<ul> <li>url: Server address is an URL and not IP address</li> </ul>	
<ul> <li>sec: Connection to server must be secure (TLS)</li> </ul>	
<ul> <li>skip_domain_verify: skip domain name verification</li> </ul>	
<ul> <li>skip_cert_verify: skip certificate catalog verification</li> </ul>	
<ul> <li>skip_date_verify: skip date verification</li> </ul>	
address: server address (ip or url)	
port: address port (16 bits)	
method: security method (mandatory only in case of secure connection):	
- SSLV3: Security method SSL v3	
- TLSV1: Security method TLS v1	
<ul> <li>TLSV1_1: Security method TLS v1_1</li> </ul>	
<ul> <li>TLSV1_2: Security method TLS v1_2</li> </ul>	
- <b>SSLV3_TLSV1_2</b> : Use highest possible version from SSLv3–TLS 1.2	
cipher: security cipher as OR bitmask (optional), (default value: all ciphers):	
- SSL_RSA_WITH_RC4_128_SHA	
- SSL_RSA_WITH_RC4_128_MD5	
- TLS_RSA_WITH_AES_256_CBC_SHA	index: client handle
- TLS_DHE_RSA_WITH_AES_256_CBC_SHA	
- TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA	
- TLS_ECDHE_RSA_WITH_RC4_128_SHA	
- TLS_RSA_WITH_AES_128_CBC_SHA256	
- TLS_RSA_WITH_AES_256_CBC_SHA256	
- TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA256	
- TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA256	
- TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA	
- TLS_ECDHE_ECDSA_WITH_AES_256_CBC_SHA	
- TLS_RSA_WITH_AES_128_GCM_SHA256	
- TLS_RSA_WITH_AES_256_GCM_SHA384	
- TLS_DHE_RSA_WITH_AES_128_GCM_SHA256	
- TLS_DHE_RSA_WITH_AES_256_GCM_SHA384	
- TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256	
- TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384	
- TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA256	
- TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384	
- TLS_ECDHE_ECDSA_WITH_CHACHA20_POLY1305_SHA256	
- TLS_ECDHE_RSA_WITH_CHACHA20_POLY1305_SHA256	
- TLS_DHE_RSA_WITH_CHACHA20_POLY1305_SHA256	



### Table 68. AT+MqttCreate MQTT Client Create (continued)

Request:	Response:
<ul> <li>private key: private key file name (Optional)</li> <li>certificate: certificate file name (Optional)</li> <li>CA: certificate authority file name (mandatory only in case of secure connection)</li> <li>DH key: Diffie Hellman file name (Optional)</li> <li>protocol: MQTT protocol:</li> </ul>	
- v3_1: protocol v3.1 - v3_1_1: protocol v3.1.1	index: client handle
<ul> <li>blocking send:</li> <li>0: do not wait for server response</li> </ul>	
<ul> <li>1: wait for response</li> <li>data format: set format globally to all MQTT commands and events:</li> </ul>	
<ul><li>0: Binary data format</li><li>1: Base64 data format (binary to text encoding)</li></ul>	

## Table 69. AT+MqttDelete MQTT Client Delete

Request:	Response:
AT+MqttDelete =[index]	OK
Arguments:	Arguments:
index: client handle received from At+MqttCreate	

#### Table 70. AT+MqttConnect MQTT Client Connect to Broker

Request:	Response:
AT+MqttConnect =[index]	OK
Arguments:	Arguments:
index: client handle received from At+MqttCreate	

### Table 71. AT+MqttDisconnect MQTT Client Disconnect From Broker

Request:	Response:
AT+MqttDisconnect =[index]	OK
Arguments:	Arguments:
index: client handle received from At+MqttCreate	



### Table 72. AT+MqttPublish MQTT Client Send Message to Broker

Request:	Response:
AT+MqttPublish =[index],[topic],[QoS],[retain],[message length][message]	OK
Arguments:	Arguments:
index: client handle received from At+MqttCreate	
topic: topic string	
QoS: Quality of service type:	
- QoS 0	
- QoS 1	
- QoS 2	
retain:	
<ul> <li>0: message should not be retained</li> </ul>	
<ul> <li>1: message should be retained</li> </ul>	
message length: number of bytes to send	
<ul> <li>message: message to send in format according to previous configuration in At+MqttCreate (Data format field)</li> </ul>	

## Table 73. AT+MqttSubscribe MQTT Client Subscribe for Topic

Request:	Response:
AT+MqttSubscribe =[index],[number of topics] ,[topic1][QoS1],[persistent1],, [topicX][QoSX],[persistentX]	ОК
Arguments:	Arguments:
<ul> <li>index: client handle received from At+MqttCreate</li> <li>number of topics: maximum 4 topics</li> <li>topic: topic string</li> <li>QoS: Quality of service type: <ul> <li>QoS 0</li> <li>QoS 1</li> <li>QoS 2</li> </ul> </li> <li>persistent (optional for future use)</li> </ul>	

### Table 74. AT+MqttUnsubscribe MQTT Client Unsubscribe for Topic

Request:	Response:
AT+MqttUnsubscribe =[index],[number of topics] ,[topic1],[persistent1],, [topicX],[persistentX]	ОК
Arguments:	Arguments:
<ul> <li>index: client handle received from At+MqttCreate</li> <li>number of topics: maximum 4 topics</li> <li>topic: topic string</li> <li>persistent (optional for future use)</li> </ul>	



## Table 75. AT+MqttSet MQTT Client Set Option

Request:		Response:
AT+MqttSet =[index],[option],[value	e1],,[valueX]	ОК
Arguments:		Arguments:
index: client handle received from	At+MqttCreate	
Option	Value	
user	Value1: User name string	
password	Value1: Password string	
will	Value1: Topic: will topic string  Value2: QoS: Quality of service type:  QoS 0  QoS 1  QoS 2  Value3: Retain:  0: will message should not be retained  1: will message should be retained  Value4: Message length: number of bytes contain in will message  Value5: Message: will message to send in format according to previous configuration in At+MqttCreate (Data format field)	
keepalive	Value1: keep alive time in seconds (16 bits)	
clean	Value1:	



#### 6.10 HTTP Client Commands

HTTP client commands and configuration.

#### Table 76. AT+HttpCreate Http Client Create

Request:	Response:
AT+HttpCreate	+HttpCreate: [index] OK
Arguments:	Arguments:
	index: client handle

## Table 77. AT+HttpDestroy Http Client Delete

Request:	Response:
AT+HttpDestroy =[index]	OK
Arguments:	Arguments:
index: client handle received from At+HttpCreate	

### Table 78. AT+HttpConnect Http Client Connect to Host

Request:	Response:
AT+HttpConnect =[index],[host],[flags],[private key],[certificate],[ca]	OK
Arguments:	Arguments:
<ul> <li>index: client handle received from At+HttpCreate</li> <li>host: host name</li> <li>flags: bitmask:         <ul> <li>ignore_proxy</li> <li>host_exist</li> </ul> </li> <li>private key: private key file name (optional)</li> <li>certificate: client certificate file name (optional)</li> <li>ca: root ca file name (optional)</li> </ul>	

## Table 79. AT+HttpDisconnect Http Client Disconnect From Host

Request:	Response:
AT+HttpDisconnect =[index]	OK
Arguments:	Arguments:
index: client handle received from At+HttpCreate	




## Table 80. AT+HttpSendReq Http Client Send Request to Host

Request:	Response:
AT+HttpSendReq =[index],[method],[uri],[flags],[format],[length],[data]	+HttpSendReq: [status] OK
Arguments:	Arguments:
index: client handle received from At+HttpCreate method:	Arguments:  Status: case of success status = 200, else
<ul><li>uri: request uri string</li><li>flags: bitmask:</li></ul>	failure
<ul> <li>chunk_start: Sets the client's request state into chunked body</li> <li>chunk_end: Sets the client's request state out of chunked body and sends last chunk</li> <li>drop_body: Flushes the response body</li> <li>format: request data format (mandatory only in case of methods post or put)</li> <li>0: Binary data format</li> <li>1: Base64 data format (binary to text encoding)</li> <li>length: length of request data (mandatory only in case of methods post or put)</li> <li>data: request data (mandatory only in case of methods post or put)</li> </ul>	

# Table 81. AT+HttpReadResBody Http Client Read Response Body From Host

Request:	Response:
AT+HttpReadResBody =[index],[format],[length]	+HttpReadResBody: [index],[flag],[format],[length],[body] OK
Arguments:	Arguments:
<ul> <li>index: client handle received from At+HttpCreate</li> <li>format: request data format         <ul> <li>0: Binary data format</li> <li>1: Base64 data format (binary to text encoding)</li> </ul> </li> <li>length: maximum length of body</li> </ul>	<ul> <li>index: client handle</li> <li>flag: more data flag</li> <li>format: request data format <ul> <li>0: Binary data format</li> <li>1: Base64 data format (binary to text encoding)</li> </ul> </li> <li>length: maximum length of body</li> <li>body: received data</li> </ul>







## Table 82. AT+HttpSetHeader Http Client Set Header

Request:	Response:
AT+HttpSetHeader =[index],[option],[flags],[format],[length],[data]	OK
Arguments:	Arguments:
<ul> <li>index: client handle received from At+HttpCreate</li> <li>option:</li> </ul>	
<pre>- res_age</pre>	
<ul><li>res_allow</li></ul>	
<ul><li>res_cache_control</li></ul>	
<ul><li>res_connection</li></ul>	
<ul><li>res_content_encoding</li></ul>	
<ul><li>res_content_language</li></ul>	
<ul><li>res_content_length</li></ul>	
<ul><li>res_content_location</li></ul>	
<ul><li>res_content_range</li></ul>	
<ul><li>res_content_type</li></ul>	
<ul><li>res_date</li></ul>	
<ul><li>res_etag</li></ul>	
<ul><li>res_expires</li></ul>	
<ul><li>res_last_modified</li></ul>	
<ul><li>res_location</li></ul>	
<ul><li>res_proxy_auth</li></ul>	
<ul><li>res_retry_after</li></ul>	
<ul><li>res_server</li></ul>	
<ul><li>res_set_cookie</li></ul>	index: client handle
<ul><li>res_trailer</li></ul>	flag: more data flag
<ul><li>res_tx_encoding</li></ul>	format: request data format
<ul><li>res_upgrade</li></ul>	<ul> <li>0: Binary data format</li> </ul>
<ul><li>res_vary</li></ul>	<ul> <li>1: Base64 data format (binary to text</li> </ul>
<ul><li>res_via</li></ul>	encoding)
<ul><li>res_www_auth</li></ul>	length: maximum length of body     hadry received data
<ul><li>res_warning</li></ul>	body: received data
<ul><li>req_accept</li></ul>	
<ul><li>req_accept_charset</li></ul>	
<ul><li>req_accept_encoding</li></ul>	
<ul><li>req_accept_language</li></ul>	
<ul><li>req_allow</li></ul>	
<ul><li>req_auth</li></ul>	
<ul><li>req_cache_control</li></ul>	
<ul><li>req_connection</li></ul>	
<ul><li>req_content_encoding</li></ul>	
<ul><li>req_content_language</li></ul>	
<ul><li>req_content_location</li></ul>	
<ul><li>req_content_type</li></ul>	
<ul><li>req_cookie</li></ul>	
<ul><li>req_date</li></ul>	
- req_expect	
<ul><li>req_forwarded</li></ul>	
- req_from	
- req_host	
- req_if_match	
<ul><li>req_if_modified_since</li></ul>	




## Table 82. AT+HttpSetHeader Http Client Set Header (continued)

Request:	Response:
• option:	
<ul><li>req_if_none_match</li></ul>	
<ul><li>req_if_range</li></ul>	
<ul><li>req_if_unmodified_since</li></ul>	
<ul><li>req_origin</li></ul>	
<ul><li>req_proxy_auth</li></ul>	
<ul><li>req_range</li></ul>	
<pre>- req_te</pre>	
<ul><li>req_tx_encoding</li></ul>	
<ul><li>req_upgrade</li></ul>	
<ul><li>req_user_agent</li></ul>	
– req_via	
<ul><li>req_warning</li></ul>	
flags: bitmask:	
<ul> <li>not_persistent: Header Field added is not persistent</li> </ul>	
<ul> <li>persistent: Header Field added is persistent</li> </ul>	
format: data format	
<ul> <li>0: Binary data format</li> </ul>	
<ul> <li>1: Base64 data format (binary to text encoding)</li> </ul>	
length: length of data (optional)	
data: (optional)	

## Table 83. AT+HttpGetHeader Http Client Get Header

Request:	Response:
AT+HttpGetHeader =[index],[option],[format],[length]	+HttpGetHeader:[index],format],[length],[data] OK
Arguments:	Arguments:
<ul> <li>index: client handle received from At+HttpCreate</li> <li>option: see option in AT+HttpSetHeader command (Table 82)</li> <li>format: data format         <ul> <li>0: Binary data format</li> <li>1: Base64 data format (binary to text encoding)</li> </ul> </li> <li>length: maximum length of data</li> </ul>	index: client handle format: data format  0: Binary data format  1: Base64 data format (binary to text encoding)  length: current length of data data: received value







### Table 84. AT+HttpSetOptHttp Client Set Option

Request:		Response:
AT+HttpSetOpt =[index],[option],[value]		OK
Arguments:		Arguments:
Index: client handle received from A	t+HttpCreate	
Option	Value	
redirect_feature	0: disable redirect feature     1: enable redirect feature	
res_filter_clear	1: clear response filter to default (all enabled)	
redirect_tls_downgrade	<ul><li>0: disable the option for tls downgrade</li><li>1: enable the option for tls downgrade</li></ul>	

## Table 85. AT+HttpSetProxy Http Client Set Proxy Address

Request:	Response:
AT+HttpSetOpt =[family],[port],[address]	OK
Arguments:	Arguments:
family: Internet Protocol	



Revision History www.ti.com

# **Revision History**

Changes from October 23, 2017 to May 18, 2018	
Table 3: Deleted AT+WlanProvisioning	5
Table 21: Deleted DLSV1 from SECMETHOD	13
Table 21: Changed description of SECURE_MASK	13
Table 23: Changed Response	15
Table 24: Changed Response	
• Section 6.3: Deleted AT+WlanProvisioning Start Provisioning table. Subsequent tables renumbered	17
Table 44: Changed Response	27
Table 53: Changed Response	33
Table 53: Added Format: Data format to Arguments	
Table 60: Changed Response	39
Table 60: Changed Value column for public_key	39
Table 61: Changed Option and Value columns for sign_msg	40
Table 67: Added table	44
Section 6.9: Added subsection	45
Section 6.10: Added subsection	49

#### IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ("TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products <a href="http://www.ti.com/sc/docs/stdterms.htm">http://www.ti.com/sc/docs/stdterms.htm</a>), evaluation modules, and samples (<a href="http://www.ti.com/sc/docs/sampterms.htm">http://www.ti.com/sc/docs/sampterms.htm</a>).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2018, Texas Instruments Incorporated