CS 61C:

Great Ideas in Computer Architecture More RISC-V Instructions and How to Implement Functions

Instructors:

Krste Asanović and Randy H. Katz http://inst.eecs.Berkeley.edu/~cs61c/fa17

Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

Levels of

Representation/Interpretation
temp = v[k];

High-Level Language Program (e.g., C)

Compiler

Assembly Language Program (e.g., RISC-V)

Assembler

Machine Language Program (RISC-V)

Machine

Interpretation
Hardware Arch

Hardware Architecture Description (e.g., block diagrams)

Architecture Implementation


Logic Circuit Description (Circuit Schematic Diagrams)

temp = v[k]; v[k] = v[k+1]; v[k+1] = temp;

Review From Last Lecture ...

- Computer "words" and "vocabulary" are called instructions and instruction set respectively
- RISC-V is example RISC instruction set used in CS61C
 - Lecture/problems use 32-bit RV32 ISA, book uses 64-bit RV64 ISA
- Rigid format: one operation, two source operands, one destination
 - add, sub, mul, div, and, or, sll, srl, sra
 - lw,sw,lb,sb to move data to/from registers from/to memory
 - beq, bne, j for decision/flow control
- Simple mappings from arithmetic expressions, array access, in C to RISC-V instructions

Recap: Registers live inside the Processor



6

CS 61c

Example *if-else* Statement

Assuming translations below, compile

```
f \rightarrow x10 g \rightarrow x11 h \rightarrow x12

i \rightarrow x13 j \rightarrow x14

if (i == j) bne x13,x14,Else

f = g + h; add x10,x11,x12

else j Exit

f = g - h; Else: sub x10,x11,x12

Exit:
```

Magnitude Compares in RISC-V

- Until now, we've only tested equalities (== and != in C);
 General programs need to test < and > as well.
- RISC-V magnitude-compare branches:

"Branch on Less Than Unsigned"

```
Syntax: bltu reg1, reg2, label

Meaning: if (reg1 < reg2) // treat registers as unsigned integers goto label;
```

C Loop Mapped to RISC-V Assembly

```
int A[20];
int sum = 0;
for (int i=0; i<20; i++)
   sum += A[i];

Loop:
   lw x12, 0(x9) # x12=A[i]
   addi x9,x9,4 # &A[i++]
   addi x11,x11,1 # i++
   addi x13,x0,20 # x13=20
   blt x11,x13,Loop</pre>
```

Peer Instruction

Which of the following is TRUE?

RED: add x10, x11, 4(x12) is valid in RV32

GREEN: can byte address 8GB of memory with an RV32 word

ORANGE: imm must be multiple of 4 for lw x10, imm (x10)

to be valid

YELLOW: None of the above

Peer Instruction

Which of the following is TRUE?

for RISCV except store and load no operations can access memory

RED: add x10, x11, 4(x12) is valid in RV32

GREEN: can byte address 8GB of memory with an RV32 word

ORANGE: imm must be multiple of 4 for lw x10, imm (x10)

to be valid

YELLOW: None of the above


both are same

Gb = pow(2,36) > pow(2,32)

Outline


- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

Assembler to Machine Code (more later in course)




13

How Program is Stored




Program Execution



- **PC** (program counter) is internal register inside processor holding byte address of next instruction to be executed
- Instruction is fetched from memory, then control unit executes instruction using datapath and memory system, and updates program counter (default is <u>add +4</u> <u>bytes to PC</u>, to move to next sequential instruction)

In the News: Why fast computers matter





European Weather supercomputer ECMWF 50 tonnes ~120,000 compute cores (Intel Broadwell)

120,000 compute cores (inter Broadweii 10 PetaBytes of storage Runs Linux on each node

Break!



Helpful RISC-V Assembler Features

- Symbolic register names
 - E.g., a0-a7 for argument registers (x10-x17)
 - E.g., **zero** for **x0**
- Pseudo-instructions
 - Shorthand syntax for common assembly idioms
 - -E.g., mv rd, rs = addi rd, rs, 0
 - -E.g.2, li rd, 13 = addi rd, x0, 13

RISC-V Symbolic Register Names

	Register	ABI Name	Description	Saver
Numbers	x 0	zero	Hard-wired zero	
hardware	x1	ra	Return address	Caller
understands	x2	sp	Stack pointer	Callee
	хЗ	gp	Global pointer	·
	x4	tp	Thread pointer	
	x 5	t0	Temporary/alternate link register	Caller
	x6-7	t1-2	Temporaries	Caller
	8x	s0/fp	Saved register/frame pointer	Callee
	x9	s1	Saved register	Callee
Human-friendly	x10-11	a0-1	Function arguments/return values	Caller
symbolic names —	x12-17	a2-7	Function arguments	Caller
in assembly	x18-27	s2-11	Saved registers	Callee
code	x28-31	t3-6	Temporaries	Caller

Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

Six Fundamental Steps in Calling a Function

- 1. Put parameters in a place where function can access them
- 2. Transfer control to function
- 3. Acquire (local) storage resources needed for function
- Perform desired task of the function
- Put result value in a place where calling code can access it and restore any registers you used
- 6. Return control to point of origin, since a function can be called from several points in a program

RISC-V Function Call Conventions

- Registers faster than memory, so use them
- a0-a7 (x10-x17): eight argument registers to pass parameters and two return values (a0-a1)
- ra: one return address register to return to the point of origin (x1)

Instruction Support for Functions (1/4)

```
sum(a,b);... /* a,b:s0,s1 */
 int sum(int x, int y) {
  return x+y;
          (shown
                  in decimal)
address
 1000
                      In RISC-V, all instructions are 4 bytes, and
 1004
 1008
                      stored in memory just like data. So here we
 1012
                      show the addresses of where the programs
 1016
                      are stored.
 2000
 2004
```

Instruction Support for Functions (2/4)

```
... sum(a,b);... /* a,b:s0,s1 */
     int sum(int x, int y) {
      return x+y;
   address (shown in decimal)
     1000 mv a0, s0 \# x = a
     1004 mv a1,s1 # y = b
1004 mv a1,s1 # y = b
1008 addi ra,zero,1016 #ra=1016
1012 j sum #jump
1016 ... # next
...
2000 sum: add a0.a0.a1
                                     #jump to sum
                                      # next instruction
     2000 sum: add a0,a0,a1
     2004 jr ra # new instr. "jump register"
```

Instruction Support for Functions (3/4)

```
... sum(a,b);... /* a,b:s0,s1 */
}
int sum(int x, int y) {
  return x+y;
}
```

- Question: Why use jr here? Why not use j?
- Answer: sum might be called by many places, so we can't return to a fixed place. The calling proc to sum must be able to say "return here" somehow.

```
2000 sum: add a0,a0,a1
2004 jr ra # new instr. "jump register"
```

Instruction Support for Functions (4/4)

- Single instruction to jump and save return address: jump and link
 (jal)
- Before:

```
1008 addi ra,zero,1016 #ra=1016
1012 j sum #goto sum
```

• After:

```
1008 jal sum # ra=1012, goto sum
```

- Why have a jal?
 - Make the common case fast: function calls very common
 - Reduce program size
 - Don't have to know where code is in memory with jal!

RISC-V Function Call Instructions

- Invoke function: jump and link instruction (jal) (really should be laj "link and jump")
 - "link" means form an address or link that points to calling site to allow function to return to proper address
 - Jumps to address and simultaneously saves the address of the <u>following</u> instruction in register ra

```
jal FunctionLabel
```

- Return from function: jump register instruction (jr)
 - Unconditional jump to address specified in register: jr ra
 - Assembler shorthand: ret = jr ra

Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

Example

```
int Leaf
  (int g, int h, int i, int j)
{
  int f;
  f = (g + h) - (i + j);
  return f;
}
```

- Parameter variables g, h, i, and j in argument registers a0, a1, a2, and a3, and f in s0
- Assume need one temporary register s1

Where Are Old Register Values Saved to Restore Them After Function Call?

- Need a place to save old values before call function, restore them when return, and delete
- Ideal is stack: last-in-first-out queue (e.g., stack of plates)
 - Push: placing data onto stack
 - Pop: removing data from stack
- Stack in memory, so need register to point to it
- sp is the stack pointer in RISC-V (x2)
- Convention is grow stack down from high to low addresses
 - Push decrements sp, Pop increments sp

RISC-V Code for Leaf()


```
Leaf: addi sp,sp,-8 # adjust stack for 2 items sw s1, 4(sp) # save s1 for use afterwards sw s0, 0(sp) # save s0 for use afterwards

add s0,a0,a1 # f = g + h
add s1,a2,a3 # s1 = i + j
sub a0,s0,s1 # return value (g + h) - (i + j)

lw s0, 0(sp) # restore register s0 for caller lw s1, 4(sp) # restore register s1 for caller addi sp,sp,8 # adjust stack to delete 2 items jr ra # jump back to calling routine
```

Stack Before, During, After Function

Need to save old values of s0 and s1




Administrivia

- HW1 is out! Get started early.
- C and Memory Management Guerrilla Session is tonight 7-9pm in 293 Cory
- Small group tutoring sessions have launched

New RISC-V book!

- "The RISC-V Reader", David Patterson, Andrew Waterman
- Available at
- https://www.createspace.com/7439283
- Early print edition \$9.99
- Kindle edition to follow at some point
- Recommended, not required



Break!



What If a Function Calls a Function? Recursive Function Calls?

- Would clobber values in a0-a7 and ra
- What is the solution?

Nested Procedures (1/2)

```
int sumSquare(int x, int y) {
  return mult(x,x)+ y;
}
```

- Something called sumSquare, now sumSquare is calling mult
- So there's a value in ra that sumSquare wants to jump back to, but this will be overwritten by the call to mult

Need to save **sumSquare** return address before call to **mult**

Nested Procedures (2/2)

- In general, may need to save some other info in addition to **ra**.
- When a C program is run, there are three important memory areas allocated:
 - Static: Variables declared once per program, cease to exist only after execution completes - e.g., C globals
 - Heap: Variables declared dynamically via malloc
 - Stack: Space to be used by procedure during execution;
 this is where we can save register values

Optimized Function Convention

To reduce expensive loads and stores from spilling and restoring registers, RISC-V function-calling convention divides registers into two categories:

- 1. Preserved across function call
 - Caller can rely on values being unchanged
 - sp, gp, tp, "saved registers" s0-s11 (s0 is also fp)
- 2. Not preserved across function call
 - Caller cannot rely on values being unchanged
 - Argument/return registers a0-a7, ra, "temporary registers" t0-t6

Peer Instruction

- Which statement is FALSE?
- RED: RISC-V uses jal to invoke a function and jr to return from a function
- GREEN: jal saves PC+1 in ra
- ORANGE: The callee can use temporary registers (ti)
 without saving and restoring them
- YELLOW: The caller can rely on save registers (si)
 without fear of callee changing them


Peer Instruction

- Which statement is FALSE?
- RED: RISC-V uses jal to invoke a function and jr to return from a function
- GREEN: **jal** saves PC+1 in **ra**
- ORANGE: The callee can use temporary registers (ti)
 without saving and restoring them
- YELLOW: The caller can rely on save registers (si)
 without fear of callee changing them

Allocating Space on Stack

- C has two storage classes: automatic and static
 - Automatic variables are local to function and discarded when function exits
 - Static variables exist across exits from and entries to procedures
- Use stack for automatic (local) variables that don't fit in registers
- Procedure frame or activation record: segment of stack with saved registers and local variables

Stack Before, During, After Function



Using the Stack (1/2)

- So we have a register **sp** which always points to the last used space in the stack
- To use stack, we decrement this pointer by the amount of space we need and then fill it with info
- So, how do we compile this?

```
int sumSquare(int x, int y) {
   return mult(x,x)+ y;
}
```


Using the Stack (2/2)

```
int sumSquare(int x, int y) {
                      return mult(x,x)+ y; }
  sumSquare:
       addi sp,sp,-8 # space on stack
"push" sw ra, 4(sp) # save ret addr
       sw a1, 0(sp) # save y
       mv a1,a0 # mult(x,x)
       jal mult # call mult
       lw a1, 0(sp) # restore y
       add a0,a0,a1 # mult()+y
       lw ra, 4(sp) # get ret addr
      addi sp,sp,8 # restore stack
       ir ra
```

Where is the Stack in Memory?

- RV32 convention (RV64 and RV128 have different memory layouts)
- Stack starts in high memory and grows down
 - Hexadecimal (base 16): bfff_fff0_{hex}
 - Stack must be aligned on 16-byte boundary (not true in examples above)
- RV32 programs (text segment) in low end
 - 0001_0000_{hex}
- static data segment (constants and other static variables) above text for static variables
 - RISC-V convention global pointer (gp) points to static
 - RV32 gp = 1000_0000_{hex}
- Heap above static for data structures that grow and shrink; grows up to high addresses

RV32 Memory Allocation



Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

And in Conclusion ...

- Functions called with jal, return with jr ra.
- The stack is your friend: Use it to save anything you need. Just leave it the way you found it!
- Instructions we know so far...

```
Arithmetic: add, addi, sub
```

Memory: lw, sw, lb, lbu, sb

Decision: beg, bne, blt, bge

Unconditional Branches (Jumps): j, jal, jr

- Registers we know so far
 - All of them!
 - a0-a7 for function arguments, a0-a1 for return values
 - sp, stack pointer, ra return address
 - s0-s11 saved registers
 - t0-t6 temporaries
 - zero