#### CS 61C:

# Great Ideas in Computer Architecture More RISC-V Instructions and How to Implement Functions

**Instructors:** 

Krste Asanović and Randy H. Katz http://inst.eecs.Berkeley.edu/~cs61c/fa17

#### Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

#### Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

## Levels of

Representation/Interpretation
temp = v[k];

High-Level Language Program (e.g., C)

Compiler

Assembly Language Program (e.g., RISC-V)

Assembler

Machine Language Program (RISC-V)

Machine

Interpretation
Hardware Arch

Hardware Architecture Description (e.g., block diagrams)

Architecture Implementation


Logic Circuit Description (Circuit Schematic Diagrams)

temp = v[k]; v[k] = v[k+1]; v[k+1] = temp;

#### Review From Last Lecture ...

- Computer "words" and "vocabulary" are called instructions and instruction set respectively
- RISC-V is example RISC instruction set used in CS61C
  - Lecture/problems use 32-bit RV32 ISA, book uses 64-bit RV64 ISA
- Rigid format: one operation, two source operands, one destination
  - add, sub, mul, div, and, or, sll, srl, sra
  - lw,sw,lb,sb to move data to/from registers from/to memory
  - beq, bne, j for decision/flow control
- Simple mappings from arithmetic expressions, array access, in C to RISC-V instructions

#### Recap: Registers live inside the Processor



6

CS 61c

# Example *if-else* Statement

Assuming translations below, compile

```
f \rightarrow x10 g \rightarrow x11 h \rightarrow x12

i \rightarrow x13 j \rightarrow x14

if (i == j) bne x13,x14,Else

f = g + h; add x10,x11,x12

else j Exit

f = g - h; Else: sub x10,x11,x12

Exit:
```

# Magnitude Compares in RISC-V

- Until now, we've only tested equalities (== and != in C);
   General programs need to test < and > as well.
- RISC-V magnitude-compare branches:

"Branch on Less Than Unsigned"

```
Syntax: bltu reg1, reg2, label

Meaning: if (reg1 < reg2) // treat registers as unsigned integers goto label;
```

### C Loop Mapped to RISC-V Assembly

```
int A[20];
int sum = 0;
for (int i=0; i<20; i++)
   sum += A[i];

Loop:
   lw x12, 0(x9) # x12=A[i]
   addi x9,x9,4 # &A[i++]
   addi x11,x11,1 # i++
   addi x13,x0,20 # x13=20
   blt x11,x13,Loop</pre>
```

#### Peer Instruction

#### Which of the following is TRUE?

RED: add x10, x11, 4(x12) is valid in RV32

GREEN: can byte address 8GB of memory with an RV32 word

ORANGE: imm must be multiple of 4 for lw x10, imm (x10)

to be valid

YELLOW: None of the above

#### Peer Instruction

Which of the following is TRUE?

for RISCV except store and load no operations can access memory

RED: add x10, x11, 4(x12) is valid in RV32

GREEN: can byte address 8GB of memory with an RV32 word

ORANGE: imm must be multiple of 4 for lw x10, imm (x10)

to be valid

YELLOW: None of the above


both are same

Gb = pow(2,36) > pow(2,32)

#### Outline


- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

# Assembler to Machine Code (more later in course)




13

# How Program is Stored




Program Execution



- **PC** (program counter) is internal register inside processor holding byte address of next instruction to be executed
- Instruction is fetched from memory, then control unit executes instruction using datapath and memory system, and updates program counter (default is <u>add +4</u> <u>bytes to PC</u>, to move to next sequential instruction)

# In the News: Why fast computers matter





European Weather supercomputer ECMWF 50 tonnes ~120,000 compute cores (Intel Broadwell)

120,000 compute cores (inter Broadweii 10 PetaBytes of storage Runs Linux on each node

# Break!



#### Helpful RISC-V Assembler Features

- Symbolic register names
  - E.g., a0-a7 for argument registers (x10-x17)
  - E.g., **zero** for **x0**
- Pseudo-instructions
  - Shorthand syntax for common assembly idioms
  - -E.g., mv rd, rs = addi rd, rs, 0
  - -E.g.2, li rd, 13 = addi rd, x0, 13

# RISC-V Symbolic Register Names

	Register	ABI Name	Description	Saver
Numbers	<b>x</b> 0	zero	Hard-wired zero	
hardware	x1	ra	Return address	Caller
understands	x2	sp	Stack pointer	Callee
	хЗ	gp	Global pointer	·
	x4	tp	Thread pointer	
	<b>x</b> 5	t0	Temporary/alternate link register	Caller
	x6-7	t1-2	Temporaries	Caller
	8x	s0/fp	Saved register/frame pointer	Callee
	x9	s1	Saved register	Callee
Human-friendly	x10-11	a0-1	Function arguments/return values	Caller
symbolic names —	x12-17	a2-7	Function arguments	Caller
in assembly	x18-27	s2-11	Saved registers	Callee
code	x28-31	t3-6	Temporaries	Caller

#### Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

# Six Fundamental Steps in Calling a Function

- 1. Put parameters in a place where function can access them
- 2. Transfer control to function
- 3. Acquire (local) storage resources needed for function
- Perform desired task of the function
- Put result value in a place where calling code can access it and restore any registers you used
- 6. Return control to point of origin, since a function can be called from several points in a program

#### RISC-V Function Call Conventions

- Registers faster than memory, so use them
- a0-a7 (x10-x17): eight argument registers to pass parameters and two return values (a0-a1)
- ra: one return address register to return to the point of origin (x1)

#### Instruction Support for Functions (1/4)

```
sum(a,b);... /* a,b:s0,s1 */
 int sum(int x, int y) {
  return x+y;
          (shown
                  in decimal)
address
 1000
                      In RISC-V, all instructions are 4 bytes, and
 1004
 1008
                      stored in memory just like data. So here we
 1012
                      show the addresses of where the programs
 1016
                      are stored.
 2000
 2004
```

## Instruction Support for Functions (2/4)

```
... sum(a,b);... /* a,b:s0,s1 */
     int sum(int x, int y) {
      return x+y;
   address (shown in decimal)
     1000 mv a0, s0 \# x = a
     1004 mv a1,s1 # y = b
1004 mv a1,s1 # y = b
1008 addi ra,zero,1016 #ra=1016
1012 j sum #jump
1016 ... # next
...
2000 sum: add a0.a0.a1
                                     #jump to sum
                                      # next instruction
     2000 sum: add a0,a0,a1
     2004 jr ra # new instr. "jump register"
```

### Instruction Support for Functions (3/4)

```
... sum(a,b);... /* a,b:s0,s1 */
}
int sum(int x, int y) {
  return x+y;
}
```

- Question: Why use jr here? Why not use j?
- Answer: sum might be called by many places, so we can't return to a fixed place. The calling proc to sum must be able to say "return here" somehow.

```
2000 sum: add a0,a0,a1
2004 jr ra # new instr. "jump register"
```

# Instruction Support for Functions (4/4)

- Single instruction to jump and save return address: jump and link
   (jal)
- Before:

```
1008 addi ra,zero,1016 #ra=1016
1012 j sum #goto sum
```

• After:

```
1008 jal sum # ra=1012, goto sum
```

- Why have a jal?
  - Make the common case fast: function calls very common
  - Reduce program size
  - Don't have to know where code is in memory with jal!

#### RISC-V Function Call Instructions

- Invoke function: jump and link instruction (jal) (really should be laj "link and jump")
  - "link" means form an address or link that points to calling site to allow function to return to proper address
  - Jumps to address and simultaneously saves the address of the <u>following</u> instruction in register ra

```
jal FunctionLabel
```

- Return from function: jump register instruction (jr)
  - Unconditional jump to address specified in register: jr ra
  - Assembler shorthand: ret = jr ra

#### Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

# Example

```
int Leaf
  (int g, int h, int i, int j)
{
  int f;
  f = (g + h) - (i + j);
  return f;
}
```

- Parameter variables g, h, i, and j in argument registers a0, a1, a2, and a3, and f in s0
- Assume need one temporary register s1

# Where Are Old Register Values Saved to Restore Them After Function Call?

- Need a place to save old values before call function, restore them when return, and delete
- Ideal is stack: last-in-first-out queue (e.g., stack of plates)
  - Push: placing data onto stack
  - Pop: removing data from stack
- Stack in memory, so need register to point to it
- sp is the stack pointer in RISC-V (x2)
- Convention is grow stack down from high to low addresses
  - Push decrements sp, Pop increments sp

# RISC-V Code for Leaf()


```
Leaf: addi sp,sp,-8 # adjust stack for 2 items sw s1, 4(sp) # save s1 for use afterwards sw s0, 0(sp) # save s0 for use afterwards

add s0,a0,a1 # f = g + h
add s1,a2,a3 # s1 = i + j
sub a0,s0,s1 # return value (g + h) - (i + j)

lw s0, 0(sp) # restore register s0 for caller lw s1, 4(sp) # restore register s1 for caller addi sp,sp,8 # adjust stack to delete 2 items jr ra # jump back to calling routine
```

## Stack Before, During, After Function

Need to save old values of s0 and s1




#### Administrivia

- HW1 is out! Get started early.
- C and Memory Management Guerrilla Session is tonight 7-9pm in 293 Cory
- Small group tutoring sessions have launched

#### New RISC-V book!

- "The RISC-V Reader", David Patterson, Andrew Waterman
- Available at
- https://www.createspace.com/7439283
- Early print edition \$9.99
- Kindle edition to follow at some point
- Recommended, not required



# Break!



# What If a Function Calls a Function? Recursive Function Calls?

- Would clobber values in a0-a7 and ra
- What is the solution?

# Nested Procedures (1/2)

```
int sumSquare(int x, int y) {
  return mult(x,x)+ y;
}
```

- Something called sumSquare, now sumSquare is calling mult
- So there's a value in ra that sumSquare wants to jump back to, but this will be overwritten by the call to mult

Need to save **sumSquare** return address before call to **mult** 

## Nested Procedures (2/2)

- In general, may need to save some other info in addition to **ra**.
- When a C program is run, there are three important memory areas allocated:
  - Static: Variables declared once per program, cease to exist only after execution completes - e.g., C globals
  - Heap: Variables declared dynamically via malloc
  - Stack: Space to be used by procedure during execution;
     this is where we can save register values

# **Optimized Function Convention**

To reduce expensive loads and stores from spilling and restoring registers, RISC-V function-calling convention divides registers into two categories:

- 1. Preserved across function call
  - Caller can rely on values being unchanged
  - sp, gp, tp, "saved registers" s0-s11 (s0 is also fp)
- 2. Not preserved across function call
  - Caller cannot rely on values being unchanged
  - Argument/return registers a0-a7, ra, "temporary registers" t0-t6

## Peer Instruction

- Which statement is FALSE?
- RED: RISC-V uses jal to invoke a function and jr to return from a function
- GREEN: jal saves PC+1 in ra
- ORANGE: The callee can use temporary registers (ti)
  without saving and restoring them
- YELLOW: The caller can rely on save registers (si)
  without fear of callee changing them


#### Peer Instruction

- Which statement is FALSE?
- RED: RISC-V uses jal to invoke a function and jr to return from a function
- GREEN: **jal** saves PC+1 in **ra**
- ORANGE: The callee can use temporary registers (ti)
  without saving and restoring them
- YELLOW: The caller can rely on save registers (si)
  without fear of callee changing them

## Allocating Space on Stack

- C has two storage classes: automatic and static
  - Automatic variables are local to function and discarded when function exits
  - Static variables exist across exits from and entries to procedures
- Use stack for automatic (local) variables that don't fit in registers
- Procedure frame or activation record: segment of stack with saved registers and local variables

#### Stack Before, During, After Function



### Using the Stack (1/2)

- So we have a register **sp** which always points to the last used space in the stack
- To use stack, we decrement this pointer by the amount of space we need and then fill it with info
- So, how do we compile this?

```
int sumSquare(int x, int y) {
   return mult(x,x)+ y;
}
```


## Using the Stack (2/2)

```
int sumSquare(int x, int y) {
                                   return mult(x,x)+ y; }
   sumSquare:
           addi sp,sp,-8 # space on stack
                                                        this is the address from where sumSquare has been
"push"
           sw ra, 4(sp) # save ret addr
                                                        called, after completing sumSquare function we have to
                                                        retrun back to this ra.
           sw a1, 0(sp) # save y
           mv a1,a0
                        # mult(x,x)
                       # call mult
                                                   if we don't store previous ra here "jal" might be overwritten to
           jal mult
                                                   comeback from mult. Then we don't know where to give this
                                                   sumSquare output i.e stored in a stack
           lw a1, 0(sp) # restore y
           add a0,a0,a1 # mult()+y
           lw ra, 4(sp) # get ret addr
           addi sp,sp,8 # restore stack
           ir ra
   9/14/17
```

## Where is the Stack in Memory?

- RV32 convention (RV64 and RV128 have different memory layouts)
- Stack starts in high memory and grows down
  - Hexadecimal (base 16): bfff\_fff0<sub>hex</sub>
  - Stack must be aligned on 16-byte boundary (not true in examples above)
- RV32 programs (text segment) in low end
  - 0001\_0000<sub>hex</sub>
- static data segment (constants and other static variables) above text for static variables
  - RISC-V convention global pointer (gp) points to static
  - RV32 gp = 1000\_0000<sub>hex</sub>
- Heap above static for data structures that grow and shrink; grows up to high addresses

## **RV32 Memory Allocation**



#### Outline

- RISC-V ISA and C-to-RISC-V Review
- Program Execution Overview
- Function Call
- Function Call Example
- And in Conclusion ...

#### And in Conclusion ...

- Functions called with jal, return with jr ra.
- The stack is your friend: Use it to save anything you need. Just leave it the way you found it!
- Instructions we know so far...

```
Arithmetic: add, addi, sub
```

Memory: lw, sw, lb, lbu, sb

Decision: beg, bne, blt, bge

Unconditional Branches (Jumps): j, jal, jr

- Registers we know so far
  - All of them!
  - a0-a7 for function arguments, a0-a1 for return values
  - sp, stack pointer, ra return address
  - s0-s11 saved registers
  - t0-t6 temporaries
  - zero