# Schedule --- 'Hardware' segment of the class

#### Homework deadline

11/16 (late in the day): part 1

• 11/23 (2pm!): part 2

#### Class schedule

• 11/4 Class material cont'd; time for questions regarding the homework

• <u>11/9 (today)</u> Quiz review; time for questions regarding the homework

• 11/11 Quiz: 2 hours, starting at the beginning of normal class time

Quiz is designed for 1 hour. 2 hours will give everybody enough time to complete the task

I will be sitting in during the first hour (60 minutes, not the whole class period) to answer questions

11/23 Quiz and homework return



wpc: our unit

# Recap 'Data Streams'

So far we have talked about data streams and how to improve bandwidth

Recap 'Data streams'

300 cycles to move data between main memory to the CPU

Average bandwidth = 1 'word' per 200 cycles (0.005 wpc)

Assume <u>no streams</u> for the example: a = b + c

- Assume <u>no screams</u> for the example, a six
  - 'a', 'b', and 'c' are 4-byte or 8-byte words
- Moving 'b' and 'c' from memory to CPU: 2 words per 300 cycles
- Moving 'a' from CPU to memory: 1 word per 300 cycles
- Average: 3 words per 600 cycles = 0.005 wpc

round-trip: 600 cycles

### Summary Part 1

Keep in mind that we have mostly discussed concepts

Many relevant details of the 3 major hardware features are still missing We have not discussed the ramifications for code design

Particularly our discussion of caches is very much incomplete!

(and we will continue with caches in the next section)

#### Main bottlenecks

Transfer the data between memory and CPU

**Actual computation** 

#### Major technologies to increase concurrency

**Streaming** of data between memory and CPU to <u>hide memory latency</u> and <u>increase memory bandwidth</u>

**Pipelining** computation (add/mult) to increase compute throughput

**Caches** to re-use data in order to decrease pressure on the Memory-to-CPU connection and to also to <u>hide memory latency</u> and to <u>increase memory bandwidth</u>

#### Concurrency

A single action (flops, memory operation, etc.) can only be so fast

Clock speed, power consumption, speed of light

Increasing the 'concurrency' is the best (maybe only) way to increase performance substantially

1. Pipelined operation

System designed to get 1 opc

#### Memory

1. Data streams

System designed to support 1 wpc (for one row)


#### Caches

- 1. Managed by run-time
- 2. Cache size (for stencil update)

System designed for 'enough' bandwidth to support 2 rows

Size: at least 3×n words

Our computer has been somewhat 'hypothetical' so far We have designed the specs so that we get 'optimal' performance for a stencil update



Requirement: Size of the cache =  $3 \times n$ 

n could be any number, any large number

Size of cache in hardware certainly not adjustable Also differences between chip generations



M

m

0

### **Cache Associativity**

Let's make up some address space notation

- Address has 6 digits
- Each digit holds alue between 1 and 4

We encor What if I it like this 1414 23 1414 24 1414 31 4433 11 1414 32 1414 33 1211 23 4433 23 Example: Cache with 4-way associativity



An element of data may be cached in 1 of 4 locations FIFO: replace the 'oldest' data element (out of the 4)

#### Advantages of Caches with Associativity

- 1. Ineffective mapping alleviated (somewhat)
- 2. Compare addresses only for few (4) locations
- 3. Eviction policy FIFO or LRU schedule
- 4. Keep 'age' for few (4) entries (In principle, 'random' eviction could work, too)



### Recap

#### Topics that we have addressed so far

Data streams

**Pipelining** 

#### Caches

- Why?
- Cache blocking (software)
- Address mapping
- Eviction policy (FIFO, LRU, etc.)
- Associativity
  - fully associative, <u>set-associative</u>, direct mapping
- Storage efficiency (for addresses)
  - Cache lines
- Cache coherency (MOSI protocol)
- Shared-memory architecture
- False sharing

#### One more hardware feature to cover (unrelated to caches)

And then we will start looking into 'writing fast code'

#### All these topics come with these questions:

- What is it?
- Why do we need it?
- How is it implemented?
- Is there a specific trick?
- How does this increase concurrency?

#### Overarching idea

Single transaction is limited in speed


Increasing concurrency is our goal

Memory transactions and (floating point) operations

### **Vector Hardware**

$$a(i) = b(i) + c(i)$$

Example for vector length = 4 words



#### Scalar Unit

Input: 2 words (single or double precision)

Output: 1 word

Operations: 1 operation → 1 result

#### Vector Unit

Input: 2 cache lines
Output: 1 cache line

Operations: 1 operation  $\rightarrow$  8/16 results (dp/sp)

# **Strided Memory Access**

Stride 1 access

Stride 2 access

Stride 8 access

Stride 'n>8' access

Which access is best?
Lower strides are better
Stride-1 is best

Which one is worse?
Higher strides are worse
Stride-8, and stride-n are worst

Lower 'effective' memory bandwidth

Lower number of results per numerical vector operation

### **Vectorizable code?**

```
for ( int i=0; i<n; i++ ) {
   a[i] = b[i] + c[i];
}</pre>
```

Yes
Loop iterations are independent

```
do i=2, n-1
  a(i) = a(i-1) + a(i+1)
end do
```


No Loop iterations are not independent

```
for ( int i=0; i<n; i++ ) {
  temp = a[i] + 2.;
  a[i] = b[i];
  b[i] = temp;
}</pre>
```


Yes
Compiler resolves dependencies for scalars
like temp, and also takes care of
unnamed constants

### **Vector Lanes**

#### All elements!



Complete cache lines are loaded Unwanted results are not stored back to register




Load b(1:8) Load c(1:8) Compute: add Store a(1:8) – full mask

Total: 4 instructions 8 results

Mask: All results copied back

# **Prefetching**

$$a(i) = b(i) + c(i)$$



The computer does not know the code and cannot infer anything from the pattern in the code.

However, it can analyze the pattern from previous memory access. For example, data is requested cache line by cache line.

This is called prefetching Prefetch instructions are added either

- during execution by the hardware (hardware prefetching)
- or to the assembly code by the compiler (software prefetching)

Typical defaults (x86 architecture):

- Software prefetching is off
- Hardware prefetching is on

Prefetching fills the data streams
Unwanted data (that is not useful) is ignored

# Recap: Vectorization & Prefetching

Vectorization: When, how, why?

Under what circumstances can loops be vectorized?

**Vector lanes** 

Strided data access

Vectorization efficiency

Data transfer efficiency

Prefetching

Multi dimensional arrays: strice-1 v. stride-n

Pointers and 'array overlap'; mostly in C

#### All these topics come with these questions:

- What is it?
- Why do we need it?
- How is it implemented?
- Is there a specific trick?
- How does this increase concurrency?

#### Overarching idea

Single transaction is limited in speed

Increasing concurrency is our goal

Memory transactions and (floating point) operations



# **Optimizations in Code**

Cost of a division: maybe 60 cycles (depends highly on precision and accuracy)

Note that the following is not exactly (bit-wise) the same

$$z1 = y / x$$
 $z2 = y * (1./x)$ 
Do no assume that z1 is exactly/bit-wise z2

If you change the code, or if you allow the compiler to change the code, you will get a slightly different result (last bits will vary)

Compiler options allow you to control (to some degree)

- Whether operations in code are replaced by cheaper operations
- Whether operations are 'executed' to the fullest accuracy (which is expensive)
  - The default is some 'reasonable' compromise between accuracy and speed

Many optimization techniques will change the rounding bits.



### Refresher

RAW

WAR

WAW

Do you get the same result when running forward and backward?

Can these loops be vectorized?

Definition of 'WAR', 'RAW', and 'WAW' at: cvw.cac.cornell.edu/vector/coding dependencies