

Imperas Peripheral Model Guide

Model Specific Information for intel.ovpworld.org / PciPM

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, U.K. docs@imperas.com.



Author	Imperas Software Limited		
Version	20210408.0		
Filename	OVP_Peripheral_Specific_Information_PciPM.pdf		
Created	05 May 2021		
Status	OVP Standard Release		

Copyright Notice

Copyright 2021 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Copyright (c) 2021 Imperas Software Limited www.imperas.com

Table Of Contents

1.0 Model Specific Information	
1.1 Licensing	
1.2 Description	
1.3 Limitations	
1.4 Reference	
1.5 Location	
2.0 Peripheral Instance Parameters	
3.0 Bus Slave Ports	
3.1 Bus Slave Port: PCIconfig	
3.2 Bus Slave Port: busPort	
4.0 Platforms that use this peripheral component	
5.0 Peripheral components in the library	6
6.0 General Information on Peripheral Models	8
6.1 Background	8
7.0 Building peripherals easily with Imperas iGen	8
8.0 Peripheral model internals	8
9.0 Parts of peripheral models	
9.1 Configuring the Peripheral Instance with Parameters	
9.2 Net Ports	
9.3 Bus master ports	
9.4 Bus slave ports	
9.5 Packetnets	
10.0 More information (documentation) on peripheral models and mode	eling

1.0 Model Specific Information

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers, other component parts, and configuration options and general information for peripheral modeling with Imperas OVP.

1.1 Licensing

Open Source Apache 2.0

1.2 Description

PCI Power Manager.

1.3 Limitations

This model has sufficient functionality to allow a Linux Kernel to Boot on the MIPS:MALTA platform.

1.4 Reference

Intel 82371EB South Bridge Chipset Datasheet

1.5 Location

The PciPM peripheral model is located in an Imperas/OVP installation at the VLNV: intel.ovpworld.org / peripheral / PciPM / 1.0.

2.0 Peripheral Instance Parameters

This model accepts the following parameters:

Table 1. Peripheral Parameters

Tuesto 1. 1 originatus i aramotoris			
Name Type Description		Description	
PCIslot	uns32	Specify which PCI slot the device occupies.	
PCIfunction	uns32 Specify which PCI function:code the device implements.		

3.0 Bus Slave Ports

This model has the following bus slave ports:

3.1 Bus Slave Port: PCIconfig

Table 2. Bus Slave Port: PCIconfig

Name	Size (bytes)	Must Be Connected	Description
PCIconfig	0x800	F (False)	

No address blocks have been defined for this slave port.

Copyright (c) 2021 Imperas Software Limited www.imperas.com

OVP License. Release 20210408.0 Page 4 of 10

3.2 Bus Slave Port: busPort

Table 3. Bus Slave Port: busPort

Name	Size (bytes)	Must Be Connected	Description
busPort	0x8	F (False)	

No address blocks have been defined for this slave port.

4.0 Platforms that use this peripheral component

Peripheral components can be used in many different platforms, including those developed by Imperas or by other users of OVP. You can use this peripheral in your own platforms.

Table 4. Publicly available platforms using peripheral 'PciPM'

Tuest :: I wester, withinter provide using perspiratur	1 411 1/1
Platform Name	Vendor
HeteroArmNucleusMIPSLinux	imperas.ovpworld.org
MipsMalta	mips.ovpworld.org
MipsMalta	mips.ovpworld.org

This peripheral is used in some internal Imperas virtual platforms. Please contact Imperas for more information.

Copyright (c) 2021 Imperas Software Limited OVP License. Release 20210408.0

5.0 Peripheral components in the library

Table 5. Publicly available Imper	ras/OVP peripheral models (224 mod	lels)
Peripheral	Peripheral	Peripheral
intel.ovpworld.org/PciUSB	intel.ovpworld.org/Ps2Control	marvell.ovpworld.org/GT6412x
maxim.ovpworld.org/max673x	microsemi.ovpworld.org/CoreUARTapb	mips.ovpworld.org/16450C
mips.ovpworld.org/MaltaFPGA	mips.ovpworld.org/SmartLoaderLinux	motorola.ovpworld.org/MC146818
national.ovpworld.org/16450	national.ovpworld.org/16550	national.ovpworld.org/16550_4bytes
nxp.ovpworld.org/iMX6_Analog	nxp.ovpworld.org/iMX6_CCM	nxp.ovpworld.org/iMX6_GPC
nxp.ovpworld.org/iMX6_GPIO	nxp.ovpworld.org/iMX6_GPT	nxp.ovpworld.org/iMX6_MMDC
nxp.ovpworld.org/iMX6_SDHC	nxp.ovpworld.org/iMX6_SRC	nxp.ovpworld.org/iMX6_UART
nxp.ovpworld.org/iMX6_WDOG	ovpworld.org/Alpha2x16Display	ovpworld.org/DynamicBridge
ovpworld.org/FlashDevice	ovpworld.org/ledRegister	ovpworld.org/SerInt
ovpworld.org/SimpleDma	ovpworld.org/switchRegister	ovpworld.org/temperatureSensor
ovpworld.org/trap	ovpworld.org/trap4K	ovpworld.org/vEthernet_Bridge
ovpworld.org/VirtioBlkMMIO	ovpworld.org/VirtioNetMMIO	philips.ovpworld.org/ISP1761
renesas.ovpworld.org/adc	renesas.ovpworld.org/bcu	renesas.ovpworld.org/brg
renesas.ovpworld.org/can	renesas.ovpworld.org/can	renesas.ovpworld.org/clkgen
renesas.ovpworld.org/crc	renesas.ovpworld.org/csib	renesas.ovpworld.org/csie
renesas.ovpworld.org/dma	renesas.ovpworld.org/intc	renesas.ovpworld.org/memc
renesas.ovpworld.org/rng	renesas.ovpworld.org/taa	renesas.ovpworld.org/tms
renesas.ovpworld.org/tmt	renesas.ovpworld.org/uartc	renesas.ovpworld.org/UPD70F3441Logic
riscv.ovpworld.org/CLINT	riscv.ovpworld.org/PLIC	riscv.ovpworld.org/SmartLoaderRV64Linux
safepower.ovpworld.org/node	safepower.ovpworld.org/NostrumNode	safepower.ovpworld.org/ring_oscillator
safepower.ovpworld.org/TTELNode	sifive.ovpworld.org/gpio	sifive.ovpworld.org/MSEL
sifive.ovpworld.org/PRCI	sifive.ovpworld.org/pwm	sifive.ovpworld.org/spi
sifive.ovpworld.org/teststatus	sifive.ovpworld.org/UART	smsc.ovpworld.org/LAN9118
smsc.ovpworld.org/LAN91C111	ti.ovpworld.org/tca6416a	ti.ovpworld.org/UartInterface
ti.ovpworld.org/ucd9012a	ti.ovpworld.org/ucd9248	vendor.com/fifo
xilinx.ovpworld.org/axi-gpio	xilinx.ovpworld.org/axi-intc	xilinx.ovpworld.org/axi-pcie
xilinx.ovpworld.org/axi-timer	xilinx.ovpworld.org/logicore-fit	xilinx.ovpworld.org/mdm
xilinx.ovpworld.org/mpmc	xilinx.ovpworld.org/xps-gpio	xilinx.ovpworld.org/xps-iic
xilinx.ovpworld.org/xps-intc	xilinx.ovpworld.org/xps-ll-temac	xilinx.ovpworld.org/xps-mch-emc
xilinx.ovpworld.org/xps-sysace	xilinx.ovpworld.org/xps-timer	xilinx.ovpworld.org/xps-uartlite
xilinx.ovpworld.org/zynq_7000-can	xilinx.ovpworld.org/zynq_7000-ddrc	xilinx.ovpworld.org/zynq_7000-devcfg
xilinx.ovpworld.org/zynq_7000-dmac	xilinx.ovpworld.org/zynq_7000-gpio	xilinx.ovpworld.org/zynq_7000-iic
xilinx.ovpworld.org/zynq_7000-ocm	xilinx.ovpworld.org/zynq_7000-qos301	xilinx.ovpworld.org/zynq_7000-qspi
xilinx.ovpworld.org/zynq_7000-sdio	xilinx.ovpworld.org/zynq_7000-slcr	xilinx.ovpworld.org/zynq_7000-spi
xilinx.ovpworld.org/zynq_7000-swdt	xilinx.ovpworld.org/zynq_7000-ttc	xilinx.ovpworld.org/zynq_7000-tz_GPVsecurity
xilinx.ovpworld.org/zynq_7000-tz_security	xilinx.ovpworld.org/zynq_7000-usb	altera.ovpworld.org/dw-apb-timer
altera.ovpworld.org/dw-apb-uart	altera.ovpworld.org/IntervalTimer32Core	altera.ovpworld.org/IntervalTimer64Core
altera.ovpworld.org/JtagUart	altera.ovpworld.org/PerformanceCounterCore	altera.ovpworld.org/RSTMGR
altera.ovpworld.org/SystemIDCore	altera.ovpworld.org/Uart	amd.ovpworld.org/79C970
andes.ovpworld.org/ATCUART100	andes.ovpworld.org/NCEPLIC100	andes.ovpworld.org/NCEPLMT100
arm.ovpworld.org/AaciPL041	arm.ovpworld.org/CompactFlashRegs	arm.ovpworld.org/CoreModule9x6
arm.ovpworld.org/DebugLedAndDipSwitch	arm.ovpworld.org/DMemCtrlPL341	arm.ovpworld.org/IcpControl

arm.ovpworld.org/IcpCounterTimer	arm.ovpworld.org/IntICP	arm.ovpworld.org/IntICP
arm.ovpworld.org/KbPL050	arm.ovpworld.org/L2CachePL310	arm.ovpworld.org/LcdPL110
arm.ovpworld.org/MmciPL181	arm.ovpworld.org/RtcPL031	arm.ovpworld.org/SerBusDviRegs
arm.ovpworld.org/SmartLoaderArm64Linux	arm.ovpworld.org/SmartLoaderArmLinux	arm.ovpworld.org/SMemCtrlPL354
arm.ovpworld.org/SysCtrlSP810	arm.ovpworld.org/TimerSP804	arm.ovpworld.org/TzpcBP147
arm.ovpworld.org/UartPL011	arm.ovpworld.org/VexpressSysRegs	arm.ovpworld.org/WdtSP805
atmel.ovpworld.org/AdvancedInterruptController	atmel.ovpworld.org/ParallelIOController	atmel.ovpworld.org/PowerSaving
atmel.ovpworld.org/SpecialFunction	atmel.ovpworld.org/TimerCounter	atmel.ovpworld.org/UsartInterface
atmel.ovpworld.org/WatchdogTimer	cadence.ovpworld.org/gem	cadence.ovpworld.org/uart
cirrus.ovpworld.org/GD5446	freescale.ovpworld.org/KinetisADC	freescale.ovpworld.org/KinetisAIPS
freescale.ovpworld.org/KinetisAXBS	freescale.ovpworld.org/KinetisCAN	freescale.ovpworld.org/KinetisCMP
freescale.ovpworld.org/KinetisCMT	freescale.ovpworld.org/KinetisCRC	freescale.ovpworld.org/KinetisDAC
freescale.ovpworld.org/KinetisDDR	freescale.ovpworld.org/KinetisDMA	freescale.ovpworld.org/KinetisDMAC
freescale.ovpworld.org/KinetisDMAMUX	freescale.ovpworld.org/KinetisENET	freescale.ovpworld.org/KinetisEWM
freescale.ovpworld.org/KinetisFB	freescale.ovpworld.org/KinetisFMC	freescale.ovpworld.org/KinetisFTFE
freescale.ovpworld.org/KinetisFTM	freescale.ovpworld.org/KinetisGPIO	freescale.ovpworld.org/KinetisI2C
freescale.ovpworld.org/KinetisI2S	freescale.ovpworld.org/KinetisLLWU	freescale.ovpworld.org/KinetisLPTMR
freescale.ovpworld.org/KinetisMCG	freescale.ovpworld.org/KinetisMPU	freescale.ovpworld.org/KinetisNFC
freescale.ovpworld.org/KinetisOSC	freescale.ovpworld.org/KinetisPDB	freescale.ovpworld.org/KinetisPIT
freescale.ovpworld.org/KinetisPMC	freescale.ovpworld.org/KinetisPORT	freescale.ovpworld.org/KinetisRCM
freescale.ovpworld.org/KinetisRFSYS	freescale.ovpworld.org/KinetisRFVBAT	freescale.ovpworld.org/KinetisRNG
freescale.ovpworld.org/KinetisRTC	freescale.ovpworld.org/KinetisSDHC	freescale.ovpworld.org/KinetisSIM
freescale.ovpworld.org/KinetisSMC	freescale.ovpworld.org/KinetisSPI	freescale.ovpworld.org/KinetisTSI
freescale.ovpworld.org/KinetisUART	freescale.ovpworld.org/KinetisUSB	freescale.ovpworld.org/KinetisUSBDCD
freescale.ovpworld.org/KinetisUSBHS	freescale.ovpworld.org/KinetisVREF	freescale.ovpworld.org/KinetisWDOG
freescale.ovpworld.org/Uart	freescale.ovpworld.org/VybridADC	freescale.ovpworld.org/VybridANADIG
freescale.ovpworld.org/VybridCCM	freescale.ovpworld.org/VybridDMA	freescale.ovpworld.org/VybridGPIO
freescale.ovpworld.org/VybridI2C	freescale.ovpworld.org/VybridLCD	freescale.ovpworld.org/VybridQUADSPI
freescale.ovpworld.org/VybridSDHC	freescale.ovpworld.org/VybridSPI	freescale.ovpworld.org/VybridUART
freescale.ovpworld.org/VybridUSB	imperas.ovpworld.org/frameBuffer	imperas.ovpworld.org/uart
imperas.ovpworld.org/usecCounter	intel.ovpworld.org/82077AA	intel.ovpworld.org/82371EB
intel.ovpworld.org/8253	intel.ovpworld.org/8259A	intel.ovpworld.org/NorFlash48F4400
intel.ovpworld.org/PciIDE	intel.ovpworld.org/PciPM	

6.0 General Information on Peripheral Models

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers etc. and configuration options and general information for peripheral modeling with Imperas OVP.

6.1 Background

Imperas OVP simulation technology enables very high performance simulation, debug and analysis of platforms containing multiple processors and peripheral models. The technology is designed to be extensible: you can create new models of processors, peripherals and other platform components using interfaces and libraries defined by OVP.

The peripheral models created using the OVP APIs run on the Peripheral Simulation Engine (PSE).

The model is typically written in C and compiled into an executable for the PSE processor architecture. The model is compiled for speed of execution and to protect IP. It is dynamically loaded by the simulator at run time.

7.0 Building peripherals easily with Imperas iGen

To aid with model creation, Imperas products include iGen, a model generation tool. iGen takes the laborious and error-prone task of constructing the various hardware model and software element files required for a typical model, and automates this process. iGen creates the needed C files. iGen also creates the C++ SystemC TLM2 interface files needed to run peripheral models in SystemC simulations.

iGen takes as input a simple script specification that includes device internals such as registers and memories, port information, component descriptors, and other elements. iGen then builds the C code model files and user editable templates. These include model frameworks with registers, function calls, memory map, and other items. It ensures that all component parts of the model are well-structured using best practices, and are consistent throughout the files, thus eliminating a common source of errors.

More information on iGen can be found: imperas.com/products.

8.0 Peripheral model internals

Each instance of a peripheral model runs on its own virtual machine with an address space large enough for the model. This processor (the PSE) and its memory are separate from any processors, memories and buses in the platform being simulated; they exist only to execute the code of the peripheral model.

Interception of functions defined in the peripheral model allows the use of features of the host system in the

implementation of the behavior of a peripheral. As an example, a real platform might contain a video display device. When simulating this system, it is generally more convenient not to simulate the complete video display device but to use a video package available on the host machine, such as SDL, and to use this to render to the host display. Also models of uarts, ethernet devices and USB components can make use of the host PC resources during simulation, to allow, for example, a simulation to browse the real internet, or the simulation to connect to a real USB device.

9.0 Parts of peripheral models

9.1 Configuring the Peripheral Instance with Parameters

A peripheral can include the behaviour of several configurations. These are controlled when the peripheral is instanced in the platform by setting parameters defined on the peripheral.

9.2 Net Ports

Peripherals may be connected to other peripherals or processors with signal wires (nets). These can be used to act as interrupt signals or used to control behavior between peripherals.

The wires are created in the platform as nets and this net is connected into the peripheral using a net port.

9.3 Bus master ports

A bus master port initiates (and controls the address of) a bus cycle. Bus cycles are generated by behavioral code within the peripheral model.

9.4 Bus slave ports

A peripheral can be defined as having several bus slave ports. The bus slave ports can be split into several address blocks. Each address block be either local memory or memory mapped registers. Both of these can have associated callback functions. A memory mapped register can also be defined as specific read/write access, whether it is volatile, and also whether it is associated with a reset pin and mask. A memory mapped register can also have specific bit fields defined.

9.5 Packetnets

A peripheral can be defined as being connected to packetnet ports. A packetnet is used to model packet based communication such as Ethernet, CAN bus or GSM. A packetnet is created in a platform, then connected to packetnet ports on model instances. A packetnet can have many connections, each able to send or receive packets. A packetnet is used as an efficient method of communication within OVP models.

For more information on modeling with packetnets, please see the peripheral modeling documentation: OVP_Peripheral_Modeling_Guide.pdf, OVPsim_and_CpuManager_User_Guide.pdf and the example: \$IMPERAS_HOME/Examples/Models/Peripherals/packetnet.

10.0 More information (documentation) on peripheral models and modeling

More information on modeling and APIs can be found at: OVPworld.org/technology_apis.

specifics on model	ing peripherals can	be found: OVE	Peripheral Mo	odeling Guide.pd	<u>f</u> .		
A full list of the currently available OVP documentation is available: OVPworld.org/documentation #							