

Imperas Peripheral Model Guide

Model Specific Information for freescale.ovpworld.org / KinetisAIPS

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, U.K. docs@imperas.com.



Author	mperas Software Limited		
Version	20210408.0		
Filename	OVP_Peripheral_Specific_Information_KinetisAIPS.pdf		
Created	05 May 2021		
Status	OVP Standard Release		

Copyright Notice

Copyright 2021 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Converight (a) 2021 Impores Software Limited www.impores.com

Table Of Contents

1.0 Model Specific Information	4
1.1 Description	4
1.2 Limitations	4
1.3 Reference	4
1.4 Licensing	4
1.5 Location	4
2.0 Net Ports	4
3.0 Bus Slave Ports	4
3.1 Bus Slave Port: bport1	4
4.0 Platforms that use this peripheral component	5
5.0 Peripheral components in the library	6
6.0 General Information on Peripheral Models	8
6.1 Background	8
7.0 Building peripherals easily with Imperas iGen	8
8.0 Peripheral model internals	8
9.0 Parts of peripheral models	9
9.1 Configuring the Peripheral Instance with Parameters	9
9.2 Net Ports	9
9.3 Bus master ports	9
9.4 Bus slave ports	9
9.5 Packetnets	9
10.0 More information (documentation) on peripheral models and modeling	9

1.0 Model Specific Information

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers, other component parts, and configuration options and general information for peripheral modeling with Imperas OVP.

1.1 Description

Model of the AIPS peripheral used on the Freescale Kinetis platform

1.2 Limitations

Provides the base behaviour for the OVP Freescale Kinetis platforms

1.3 Reference

www.freescale.com/Kinetis

1.4 Licensing

Open Source Apache 2.0

1.5 Location

The KinetisAIPS peripheral model is located in an Imperas/OVP installation at the VLNV: freescale.ovpworld.org / peripheral / KinetisAIPS / 1.0.

2.0 Net Ports

This model has the following net ports:

Table 1. Net Ports

Name	Туре	Must Be Connected	Description
Reset	input	F (False)	

3.0 Bus Slave Ports

This model has the following bus slave ports:

3.1 Bus Slave Port: bport1

Table 2. Bus Slave Port: bport1

Name	Size (bytes)	Must Be Connected	Description
bport1	0x1000	F (False)	

Table 3. Bus Slave Port: bport1 Registers:

Name	Offset	Width (bits)	Description	R/W	is Volatile
ab_MPRA	0x0		Master Privilege Register A, offset: 0x0		

Copyright (c) 2021 Imperas Software Limited

www.imperas.com

OVP License. Release 20210408.0

ab_PACRA	0x20	32	Peripheral Access Control	
			Register, offset: 0x20	
ab_PACRB	0x24	32	Peripheral Access Control Register, offset: 0x24	
ab_PACRC	0x28	32	Peripheral Access Control Register, offset: 0x28	
ab_PACRD	0x2c	32	Peripheral Access Control Register, offset: 0x2C	
ab_PACRE	0x40	32	Peripheral Access Control Register, offset: 0x40	
ab_PACRF	0x44	32	Peripheral Access Control Register, offset: 0x44	
ab_PACRG	0x48	32	Peripheral Access Control Register, offset: 0x48	
ab_PACRH	0x4c	32	Peripheral Access Control Register, offset: 0x4C	
ab_PACRI	0x50	32	Peripheral Access Control Register, offset: 0x50	
ab_PACRJ	0x54	32	Peripheral Access Control Register, offset: 0x54	
ab_PACRK	0x58	32	Peripheral Access Control Register, offset: 0x58	
ab_PACRL	0x5c	32	Peripheral Access Control Register, offset: 0x5C	
ab_PACRM	0x60	32	Peripheral Access Control Register, offset: 0x60	
ab_PACRN	0x64	32	Peripheral Access Control Register, offset: 0x64	
ab_PACRO	0x68	32	Peripheral Access Control Register, offset: 0x68	
ab_PACRP	0x6c	32	Peripheral Access Control Register, offset: 0x6C	

4.0 Platforms that use this peripheral component

Peripheral components can be used in many different platforms, including those developed by Imperas or by other users of OVP. You can use this peripheral in your own platforms.

Table 4. Publicly available platforms using peripheral 'KinetisAIPS'

Platform Name	Vendor
FreescaleKinetis60	freescale.ovpworld.org
FreescaleKinetis64	freescale.ovpworld.org

5.0 Peripheral components in the library

Table 5. Publicly available Imp	eras/OVP peripheral models (224 models)	lels)
Peripheral	Peripheral	Peripheral
freescale.ovpworld.org/KinetisAXBS	freescale.ovpworld.org/KinetisCAN	freescale.ovpworld.org/KinetisCMP
freescale.ovpworld.org/KinetisCMT	freescale.ovpworld.org/KinetisCRC	freescale.ovpworld.org/KinetisDAC
freescale.ovpworld.org/KinetisDDR	freescale.ovpworld.org/KinetisDMA	freescale.ovpworld.org/KinetisDMAC
freescale.ovpworld.org/KinetisDMAMUX	freescale.ovpworld.org/KinetisENET	freescale.ovpworld.org/KinetisEWM
freescale.ovpworld.org/KinetisFB	freescale.ovpworld.org/KinetisFMC	freescale.ovpworld.org/KinetisFTFE
freescale.ovpworld.org/KinetisFTM	freescale.ovpworld.org/KinetisGPIO	freescale.ovpworld.org/KinetisI2C
freescale.ovpworld.org/KinetisI2S	freescale.ovpworld.org/KinetisLLWU	freescale.ovpworld.org/KinetisLPTMR
freescale.ovpworld.org/KinetisMCG	freescale.ovpworld.org/KinetisMPU	freescale.ovpworld.org/KinetisNFC
freescale.ovpworld.org/KinetisOSC	freescale.ovpworld.org/KinetisPDB	freescale.ovpworld.org/KinetisPIT
freescale.ovpworld.org/KinetisPMC	freescale.ovpworld.org/KinetisPORT	freescale.ovpworld.org/KinetisRCM
freescale.ovpworld.org/KinetisRFSYS	freescale.ovpworld.org/KinetisRFVBAT	freescale.ovpworld.org/KinetisRNG
freescale.ovpworld.org/KinetisRTC	freescale.ovpworld.org/KinetisSDHC	freescale.ovpworld.org/KinetisSIM
freescale.ovpworld.org/KinetisSMC	freescale.ovpworld.org/KinetisSPI	freescale.ovpworld.org/KinetisTSI
freescale.ovpworld.org/KinetisUART	freescale.ovpworld.org/KinetisUSB	freescale.ovpworld.org/KinetisUSBDCD
freescale.ovpworld.org/KinetisUSBHS	freescale.ovpworld.org/KinetisVREF	freescale.ovpworld.org/KinetisWDOG
freescale.ovpworld.org/Uart	freescale.ovpworld.org/VybridADC	freescale.ovpworld.org/VybridANADIG
freescale.ovpworld.org/VybridCCM	freescale.ovpworld.org/VybridDMA	freescale.ovpworld.org/VybridGPIO
freescale.ovpworld.org/VybridI2C	freescale.ovpworld.org/VybridLCD	freescale.ovpworld.org/VybridQUADSPI
freescale.ovpworld.org/VybridSDHC	freescale.ovpworld.org/VybridSPI	freescale.ovpworld.org/VybridUART
freescale.ovpworld.org/VybridUSB	imperas.ovpworld.org/frameBuffer	imperas.ovpworld.org/uart
imperas.ovpworld.org/usecCounter	intel.ovpworld.org/82077AA	intel.ovpworld.org/82371EB
intel.ovpworld.org/8253	intel.ovpworld.org/8259A	intel.ovpworld.org/NorFlash48F4400
intel.ovpworld.org/PciIDE	intel.ovpworld.org/PciPM	intel.ovpworld.org/PciUSB
intel.ovpworld.org/Ps2Control	marvell.ovpworld.org/GT6412x	maxim.ovpworld.org/max673x
microsemi.ovpworld.org/CoreUARTapb	mips.ovpworld.org/16450C	mips.ovpworld.org/MaltaFPGA
mips.ovpworld.org/SmartLoaderLinux	motorola.ovpworld.org/MC146818	national.ovpworld.org/16450
national.ovpworld.org/16550	national.ovpworld.org/16550_4bytes	nxp.ovpworld.org/iMX6_Analog
nxp.ovpworld.org/iMX6_CCM	nxp.ovpworld.org/iMX6_GPC	nxp.ovpworld.org/iMX6_GPIO
nxp.ovpworld.org/iMX6_GPT	nxp.ovpworld.org/iMX6_MMDC	nxp.ovpworld.org/iMX6_SDHC
nxp.ovpworld.org/iMX6_SRC	nxp.ovpworld.org/iMX6_UART	nxp.ovpworld.org/iMX6_WDOG
ovpworld.org/Alpha2x16Display	ovpworld.org/DynamicBridge	ovpworld.org/FlashDevice
ovpworld.org/ledRegister	ovpworld.org/SerInt	ovpworld.org/SimpleDma
ovpworld.org/switchRegister	ovpworld.org/temperatureSensor	ovpworld.org/trap
ovpworld.org/trap4K	ovpworld.org/vEthernet_Bridge	ovpworld.org/VirtioBlkMMIO
ovpworld.org/VirtioNetMMIO	philips.ovpworld.org/ISP1761	renesas.ovpworld.org/adc
renesas.ovpworld.org/bcu	renesas.ovpworld.org/brg	renesas.ovpworld.org/can
renesas.ovpworld.org/can	renesas.ovpworld.org/clkgen	renesas.ovpworld.org/crc
renesas.ovpworld.org/csib	renesas.ovpworld.org/csie	renesas.ovpworld.org/dma
renesas.ovpworld.org/intc	renesas.ovpworld.org/memc	renesas.ovpworld.org/rng
renesas.ovpworld.org/taa	renesas.ovpworld.org/tms	renesas.ovpworld.org/tmt
renesas.ovpworld.org/uartc	renesas.ovpworld.org/UPD70F3441Logic	riscv.ovpworld.org/CLINT
riscv.ovpworld.org/PLIC	riscv.ovpworld.org/SmartLoaderRV64Linux	safepower.ovpworld.org/node
safepower.ovpworld.org/NostrumNode	safepower.ovpworld.org/ring_oscillator	safepower.ovpworld.org/TTELNode

sifive.ovpworld.org/gpio	sifive.ovpworld.org/MSEL	sifive.ovpworld.org/PRCI
sifive.ovpworld.org/pwm	sifive.ovpworld.org/spi	sifive.ovpworld.org/teststatus
sifive.ovpworld.org/UART	smsc.ovpworld.org/LAN9118	smsc.ovpworld.org/LAN91C111
ti.ovpworld.org/tca6416a	ti.ovpworld.org/UartInterface	ti.ovpworld.org/ucd9012a
ti.ovpworld.org/ucd9248	vendor.com/fifo	xilinx.ovpworld.org/axi-gpio
xilinx.ovpworld.org/axi-intc	xilinx.ovpworld.org/axi-pcie	xilinx.ovpworld.org/axi-timer
xilinx.ovpworld.org/logicore-fit	xilinx.ovpworld.org/mdm	xilinx.ovpworld.org/mpmc
xilinx.ovpworld.org/xps-gpio	xilinx.ovpworld.org/xps-iic	xilinx.ovpworld.org/xps-intc
xilinx.ovpworld.org/xps-ll-temac	xilinx.ovpworld.org/xps-mch-emc	xilinx.ovpworld.org/xps-sysace
xilinx.ovpworld.org/xps-timer	xilinx.ovpworld.org/xps-uartlite	xilinx.ovpworld.org/zynq_7000-can
xilinx.ovpworld.org/zynq_7000-ddrc	xilinx.ovpworld.org/zynq_7000-devcfg	xilinx.ovpworld.org/zynq_7000-dmac
xilinx.ovpworld.org/zynq_7000-gpio	xilinx.ovpworld.org/zynq_7000-iic	xilinx.ovpworld.org/zynq_7000-ocm
xilinx.ovpworld.org/zynq_7000-qos301	xilinx.ovpworld.org/zynq_7000-qspi	xilinx.ovpworld.org/zynq_7000-sdio
xilinx.ovpworld.org/zynq_7000-slcr	xilinx.ovpworld.org/zynq_7000-spi	xilinx.ovpworld.org/zynq_7000-swdt
xilinx.ovpworld.org/zynq_7000-ttc	xilinx.ovpworld.org/zynq_7000-tz_GPVsecurity	xilinx.ovpworld.org/zynq_7000-tz_security
xilinx.ovpworld.org/zynq_7000-usb	altera.ovpworld.org/dw-apb-timer	altera.ovpworld.org/dw-apb-uart
altera.ovpworld.org/IntervalTimer32Core	altera.ovpworld.org/IntervalTimer64Core	altera.ovpworld.org/JtagUart
altera.ovpworld.org/PerformanceCounterCore	altera.ovpworld.org/RSTMGR	altera.ovpworld.org/SystemIDCore
altera.ovpworld.org/Uart	amd.ovpworld.org/79C970	andes.ovpworld.org/ATCUART100
andes.ovpworld.org/NCEPLIC100	andes.ovpworld.org/NCEPLMT100	arm.ovpworld.org/AaciPL041
arm.ovpworld.org/CompactFlashRegs	arm.ovpworld.org/CoreModule9x6	arm.ovpworld.org/DebugLedAndDipSwitch
arm.ovpworld.org/DMemCtrlPL341	arm.ovpworld.org/IcpControl	arm.ovpworld.org/IcpCounterTimer
arm.ovpworld.org/IntICP	arm.ovpworld.org/IntICP	arm.ovpworld.org/KbPL050
arm.ovpworld.org/L2CachePL310	arm.ovpworld.org/LcdPL110	arm.ovpworld.org/MmciPL181
arm.ovpworld.org/RtcPL031	arm.ovpworld.org/SerBusDviRegs	arm.ovpworld.org/SmartLoaderArm64Linux
arm.ovpworld.org/SmartLoaderArmLinux	arm.ovpworld.org/SMemCtrlPL354	arm.ovpworld.org/SysCtrlSP810
arm.ovpworld.org/TimerSP804	arm.ovpworld.org/TzpcBP147	arm.ovpworld.org/UartPL011
arm.ovpworld.org/VexpressSysRegs	arm.ovpworld.org/WdtSP805	atmel. ovpworld. org/Advanced Interrupt Controller
atmel.ovpworld.org/ParallelIOController	atmel.ovpworld.org/PowerSaving	atmel.ovpworld.org/SpecialFunction
atmel.ovpworld.org/TimerCounter	atmel.ovpworld.org/UsartInterface	atmel.ovpworld.org/WatchdogTimer
cadence.ovpworld.org/gem	cadence.ovpworld.org/uart	cirrus.ovpworld.org/GD5446
freescale.ovpworld.org/KinetisADC	freescale.ovpworld.org/KinetisAIPS	

Copyright (c) 2021 Imperas Software Limited OVP License. Release 20210408.0

6.0 General Information on Peripheral Models

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers etc. and configuration options and general information for peripheral modeling with Imperas OVP.

6.1 Background

Imperas OVP simulation technology enables very high performance simulation, debug and analysis of platforms containing multiple processors and peripheral models. The technology is designed to be extensible: you can create new models of processors, peripherals and other platform components using interfaces and libraries defined by OVP.

The peripheral models created using the OVP APIs run on the Peripheral Simulation Engine (PSE).

The model is typically written in C and compiled into an executable for the PSE processor architecture. The model is compiled for speed of execution and to protect IP. It is dynamically loaded by the simulator at run time.

7.0 Building peripherals easily with Imperas iGen

To aid with model creation, Imperas products include iGen, a model generation tool. iGen takes the laborious and error-prone task of constructing the various hardware model and software element files required for a typical model, and automates this process. iGen creates the needed C files. iGen also creates the C++ SystemC TLM2 interface files needed to run peripheral models in SystemC simulations.

iGen takes as input a simple script specification that includes device internals such as registers and memories, port information, component descriptors, and other elements. iGen then builds the C code model files and user editable templates. These include model frameworks with registers, function calls, memory map, and other items. It ensures that all component parts of the model are well-structured using best practices, and are consistent throughout the files, thus eliminating a common source of errors.

More information on iGen can be found: <u>imperas.com/products</u>.

8.0 Peripheral model internals

Each instance of a peripheral model runs on its own virtual machine with an address space large enough for the model. This processor (the PSE) and its memory are separate from any processors, memories and buses in the platform being simulated; they exist only to execute the code of the peripheral model.

Interception of functions defined in the peripheral model allows the use of features of the host system in the

implementation of the behavior of a peripheral. As an example, a real platform might contain a video display device. When simulating this system, it is generally more convenient not to simulate the complete video display device but to use a video package available on the host machine, such as SDL, and to use this to render to the host display. Also models of uarts, ethernet devices and USB components can make use of the host PC resources during simulation, to allow, for example, a simulation to browse the real internet, or the simulation to connect to a real USB device.

9.0 Parts of peripheral models

9.1 Configuring the Peripheral Instance with Parameters

A peripheral can include the behaviour of several configurations. These are controlled when the peripheral is instanced in the platform by setting parameters defined on the peripheral.

9.2 Net Ports

Peripherals may be connected to other peripherals or processors with signal wires (nets). These can be used to act as interrupt signals or used to control behavior between peripherals.

The wires are created in the platform as nets and this net is connected into the peripheral using a net port.

9.3 Bus master ports

A bus master port initiates (and controls the address of) a bus cycle. Bus cycles are generated by behavioral code within the peripheral model.

9.4 Bus slave ports

A peripheral can be defined as having several bus slave ports. The bus slave ports can be split into several address blocks. Each address block be either local memory or memory mapped registers. Both of these can have associated callback functions. A memory mapped register can also be defined as specific read/write access, whether it is volatile, and also whether it is associated with a reset pin and mask. A memory mapped register can also have specific bit fields defined.

9.5 Packetnets

A peripheral can be defined as being connected to packetnet ports. A packetnet is used to model packet based communication such as Ethernet, CAN bus or GSM. A packetnet is created in a platform, then connected to packetnet ports on model instances. A packetnet can have many connections, each able to send or receive packets. A packetnet is used as an efficient method of communication within OVP models.

For more information on modeling with packetnets, please see the peripheral modeling documentation: OVP_Peripheral_Modeling_Guide.pdf, OVPsim_and_CpuManager_User_Guide.pdf and the example: \$IMPERAS_HOME/Examples/Models/Peripherals/packetnet.

10.0 More information (documentation) on peripheral models and modeling

More information on modeling and APIs can be found at: OVPworld.org/technology_apis.

Specifics on modeling peripherals can be found:						
---	--	--	--	--	--	--