# Installation of a basic environment on a Raspberry Pi

[Adapted from: PRÁCTICAS DE ENSAMBLADOR BASADAS EN RASPBERRY PI, AJ Villena Godoy - 2015, riuma.uma.es]

EC1617 Chapter 4-Lab.1

Dept. of Comp. Arch., UMA, 2016

## **Index**

- Introduction
- Setting up the system
- Example

### **Introduction**

- Aim: to manage at low level the input/output system
- Requirements: I/O cannot be managed by the Operating System
- □ Consequences: No OS, then there aren't filesystems, editors, compilers,...
- Answer: we need a host system to edit and compile, and a bootloader to load and execute programs in the device

EC1617 Chapter 4-Lab.3

Dept. of Comp. Arch., UMA, 2016


## **Setting up the system**

- We need two computers:
  - A bare Raspberry Pi (the device)
  - A PC/Notebook running Windows or Linux (the host)
- And an optional USB-Serial adapter to connect both computers



# **USB-serial adapter**

- □ Pins 2 or 4: 5V, 6: GND, 8: TX and 10: Rx
  - TX and RX are crossed to RXD and TXD in the adapter



EC1617 Chapter 4-Lab.5

Dept. of Comp. Arch., UMA, 2016


## **Setting up the device**

- We don't use a OS in the Raspberry
  - During booting (\*) a kernel.img file, containing our executable, is loaded.
- □ If we have the serial adapter we can use a special kernel.img that listens to the serial port to load our.img.

(\*) The Raspberry Pi booting process is explained in detail in the manual.

## **SD** content and booting

- 1. GPU initiates the booting from an internal ROM.
  - \* It loads bootcode.bin from SD and runs it
- 2. GPU activates SDRAM, loads start.elf and runs it
- 3. GPU loads kernel.img en 0x8000 and wakes up CPU
  - \* CPU runs the code starting in 0x8000



EC1617 Chapter 4-Lab.7

Dept. of Comp. Arch., UMA, 2016

## Setting up the device

- Download required files from the course web page.
  - bootcode.bin and start.elf (and kernel.img for USB-serial adapter)
- Use some program to format the SD card
  - Use FAT filesytem!
- In case of not using USB-serial adapter
  - Rename your .img as kernel.img and write it in the SD card
- Insert SD card in Raspberry

### Setting up the host

- Program edition and compilation is carried out in the host
  - Scite, a SCIntilla based Text Editor, available in Windows and Linux.
  - Yagarto, Yet Another Gnu ARm TOolchain, a cross development environment for the ARM architecture, running on a Windows host.
  - TeraTerm, a terminal emulator that supports serial communication.
  - Other alternatives are available, just search for them!

EC1617 Chapter 4-Lab.9

Dept. of Comp. Arch., UMA, 2016

## Setting up the host

- Install Scite and Yagarto
- Look for cpp.properties in Scite installation path and add next two lines at the end of the file:

```
command.build.*.s=yagarto-path\bin\make $(FileName)
command.go.*.s=yagarto-path\bin\send $(FileDir)\$(FileName).img
```

where *yagarto-path* is the installation path to Yagarto, for example C:\Yagarto

### Setting up the host

□ Create a file, make.bat, in the Yagarto bin path with the next content

make.bat

```
arm-none-eabi-as -o tmp.o %1.s
arm-none-eabi-ld -e 0 -Ttext=0x8000 tmp.o
arm-none-eabi-objcopy a.out -O binary %1.img
```

where we are instructing the compiler to create an executable that will start at address 0x8000.

- □ Edit your source file in Scite and compile it with F7.
  - The resulting .img file is the kernel.img we must store in our SD card (if no USB-serial adapter available).

EC1617 Chapter 4-Lab.11

Dept. of Comp. Arch., UMA, 2016

#### Setting up the adapter

- □ If we have the USB-serial adapter, we must send the kernel.img file provided into the SD card.
- After boot:
  - A beep will sound.
  - 2. Rpi will listen to the serial port.
  - 3. We will send kernel.img through the serial port (F5 function in Scite)
  - 4. The received file will be executed.

#### Setting up the adapter

□ To be able to send the file, you must install Tera Term, and create a file in Tera Term path, send.ttl, with

send.ttl


connect '/C=3'
setbaud 115200
setdtr 0
xmodemsend param2 1
closett

where \'/C=3' should be substituted by the COMM port of your USB-serial adapter in the host.

EC1617 Chapter 4-Lab.13

Dept. of Comp. Arch., UMA, 2016

## Setting up the adapter



### Setting up the adapter

Create another file, send.bat, in the Yagarto bin path with the next content

```
send.bat
```

TeraTermPath\ttpmacro.exe TeraTermPath\send.ttl %1

where TeraTermPath is the path to Tera Term where we stored send.ttl.

If path has white spaces use double quotes: "C:
\Program Files\teraterm\ttpmacro.exe"

EC1617 Chapter 4-Lab.15

Dept. of Comp. Arch., UMA, 2016

#### **Example**

□ Launch Scite and create a new file:

## **Example**

- Previous example turns on one led in the GPIO.
- □ After writing the file, press F7 to compile it
- Without USB-serial adapter:
  - Rename your .img as kernel.img, and write it to the SD card.
  - Insert the SD card back to the Rpi.
  - Plug again the device: the device boots and executes the kernel.img.
- With USB-serial adapter:
  - Press F5 to send your . img to the Raspberry Pi. It will execute automatically.
  - To execute another .img, unplug and plug back your device.

EC1617 Chapter 4-Lab.17

Dept. of Comp. Arch., UMA, 2016