Lab 4- Sem 2 2024

ECE3073 Computer Systems

Laboratory Session 4

Interrupts and Interrupt Latency

Semester 1, 2020

1. Objectives

In the previous laboratory exercise you looked at polling as a way for a computer to respond to outside events. An alternative to polling is the use of interrupts and they are the subject of this exercise. Functionally the program developed in this lab will be similar to lab 3 (8 red LEDs will count in binary fashion on the rising edge of the MSB of a 20-bit counter counting the 50MHz clock and push button KEY1 will toggle green LED LEDG1 (Note: this function for KEY1 is slightly different to the previous lab as it includes de-bouncing code). However, the counter will be serviced by an interrupt routine not by polling. This lab will give you an idea of the programming structures and hardware required to support interrupts together with interrupt latency. In this exercise you will:

- Write a C/assembler program to support interrupt servicing of external events
- Use an oscilloscope to measure interrupt latency
- Work from the assembler code to calculate the theoretical interrupt latency
- Compare the theoretical and measured values of interrupt latency.

Equipment

```
§ DE2 FPGA Development Board
§ A USB memory device provided by you to backup your design files
§ A 2 or 4 channel 1GS/s digital oscilloscope
```

§ Breakout pins to allow connection of CRO probes to DE2 board

2. Preliminary work (6 Marks)

You must complete this preliminary work before attending the lab session.

Read through the whole of this document so that you understand all of the things you will be required to do.

For each of the following initializations indicate the processor control register or PIO register map register that is involved and the bit pattern that must be written to the register to perform the required initialization:

Demonstrator initials for satisfactory completion of preliminary work



3. Design a new Nios system

For this laboratory exercise you will need a Nios system which is very similar but not identical to the one you designed for lab3. You can modify your previous design or start from the beginning:


- a) Using Qsys create a microprocessor system with:
 - a Nios II/e processor,
 - 8192 bytes of RAM
 - one 8-bit PIO output port (to drive LEDR[7:0])
 - two 1-bit PIO output ports One to the corner RED LED (PIN_H15) , this LED gets ON and OFF for every alternative rising edge of the MSB counter pulse. One to Green LED LEDG (PIN_E21)
 - two 1-bit PIO input ports (one to read KEY[1] and the other to read the most significant bit (MSB) of the 1 Hz counter . Read the parallel input/output (PIO) core section in the Nios embedded peripherals datasheet on Moodle. Use this information to setup **rising** edge triggered interrupts on the PIO counter MSB input.

To attach the interrupt request line from the counter PIO to the Nios processor click on the bubble in the Qsys IRQ column and make a note of the allocated interrupt number.

After you compile your Nios system take note of the base address of all of the Nios peripherals (these will probably be the same as for the previous exercise) and the interrupt request (IRQ) level/number allocated to the counter PIO.


(b) Lab 4 follows Lab3b - 1 Hz counter

IMPORTANT: FOLLOW THE LAB4- Supporting.doc word file to view the schematics and gysys settings



4. C normal and interrupt code

You are provided with skeleton code (use files from Moodle) for a normal code main function and interrupt code. The following figure shows flowcharts for this code. Your C code should implement the flowchart elements in the dashed boxes. You need to refer to your lecture notes and the Nios embedded peripherals datasheet on Moodle in order to learn how to set up and service an interrupt.



Lab4_main.c

Lab4_exception.c

```
#include "nios2_ctrl_reg_macros.h"
/* function prototypes */
void main(void);
void interrupt_handler(void);
void the_exception (void);
/* global variables */
extern int* example pointer;
// extern indicates to the linker that the variable has been declared
// elsewhere. This declaration does not allocate any memory.
/* The assembly language code below handles CPU reset processing */
void the_reset (void) __attribute__ ((section (".reset")));
void the reset (void) /
************************
* Reset code. By giving the code a section attribute with the name ".reset"*
* we allow the linker program to locate this code at the proper reset
* vector address. This code just calls the main program.
                                     // Magic, for the C compiler
// Magic, for the C --
asm (".set
                  noat");
                  nobreak");
                                      // Magic, for the C compiler
// Call the C language main program
asm (".set
                   r2, main");
asm ("movia
asm ("jmp
                  r2");
/* The assembly language code below handles CPU exception processing. This
* code should not be modified; instead, the C language code in the function
* interrupt_handler() can be modified as needed for a given application.
void the_exception (void) __attribute__ ((section (".exceptions")));
void the_exception (void)
* Exceptions code. By giving the code a section attribute with the name  *
* ".exceptions" we allow the linker program to locate this code at the
* proper exceptions vector address.
* This code calls the interrupt handler and later returns from the
* exception.
noat");
asm ( ".set
                                           // Magic, for the C compiler
                 nobreak");
asm ( ".set
                                           // Magic, for the C compiler
                 sp, sp, 128"); // make space on the stack et, 96(sp)"); // save exception temporary et, ctl4"); // read control register ctl4 ipending et, r0, SKIP_EA_DEC"); // Interrupt is not external
asm ( "subi
asm ( "stw
asm ( "rdctl
asm ( "beq
asm ( "subi
                                           // if external must decrement
                   ea, ea, 4");
                                            // ea by one instruction for
                                            // external interrupts, so that
                                            // the interrupted instruction
                                            // will be run
asm ( "SKIP EA DEC:" );
      "stw r1, 4(sp)");
                                          // Save all registers
asm (
asm ( "stw r2, 8(sp)");
asm ( "stw r3, 12(sp)");
asm ( "stw r4, 16(sp)");
asm ( "stw r5, 20(sp)" );
```

```
"stw
              r6, 24(sp)");
       "stw
              r7,
                    28(sp)");
asm (
                    32(sp)");
36(sp)");
asm (
       "stw
              r8,
       "stw
              r9,
asm (
              r10, 40(sp)");
       "stw
asm (
             r11, 44(sp)");
       "stw
asm (
             r12, 48(sp)");
r13, 52(sp)");
r14, 56(sp)");
       "stw
asm (
       "stw
asm (
       "stw
asm (
             r15, 60(sp)");
       "stw
asm (
             r16, 64(sp)");
asm (
       "stw
             r17, 68(sp)");
r18, 72(sp)");
asm (
       "stw
       "stw
asm (
             r19, 76(sp)");
       "stw
       "stw
             r20, 80(sp)");
asm (
              r21, 84(sp)");
r22, 88(sp)");
asm (
       "stw
       "stw
asm (
             r23, 92(sp)");
       "stw
asm (
             r25, 100(sp)");
asm ( "stw
                                           // r25 = bt (skip r24 = et, because
                                                                         // it is
saved above)
asm ( "stw
                                           // r26 = gp
              r26, 104(sp)");
// skip r27 because it is sp, and there is no point in saving this
             r28, 112(sp)");  // r28 = fp
r29, 116(sp)");  // r29 = ea
r30, 120(sp)");  // r30 = ba
       "stw
asm (
       "stw
asm ( "stw
              r31, 124(sp)");
asm ( "stw
                                           // r31 = ra
asm ( "addi fp, sp, 128" );
// handler
                    4(sp)");
8(sp)");
12(sp)");
              r1,
       "ldw
                                                   // Restore all registers
asm (
       "ldw
asm (
              r2,
       "ldw
              r3,
asm (
                    16(sp)");
       "ldw
              r4,
asm (
             r5,
                    20(sp)");
24(sp)");
28(sp)");
asm (
       "ldw
       "ldw
              r6,
asm (
       "ldw
             r7,
asm (
                    32(sp)");
       "ldw
             r8,
asm (
             r9, 36(sp)");
r10, 40(sp)");
r11, 44(sp)");
       "ldw
asm (
asm (
       "ldw
       "ldw
asm (
             r12, 48(sp)");
       "ldw
asm (
             r13, 52(sp)");
r14, 56(sp)");
r15, 60(sp)");
r16, 64(sp)");
       "ldw
asm (
asm (
       "ldw
       "ldw
asm (
       "ldw
asm (
             r17, 68(sp)");
       "ldw
asm (
             r18, 72(sp)");
r19, 76(sp)");
r20, 80(sp)");
asm (
       "ldw
       "ldw
asm (
       "ldw
asm (
             r21, 84(sp)");
       "ldw
asm (
       "ldw
             r22, 88(sp)");
asm (
              r23, 92(sp)");
r24, 96(sp)");
asm (
       "ldw
       "ldw
asm (
             r25, 100(sp)");
       "ldw
                                           // r25 = bt
asm (
asm ( "ldw
              r26, 104(sp)");
                                           // r26 = gp
// skip r27 because it is sp, and we did not save this on the stack
             r28, 112(sp)");
r29, 116(sp)");
asm (
       "ldw
                                 // r28 = fp
       "ldw
                                           // r29 = ea
asm (
              r30, 120(sp)");
      "ldw
                                          // r30 = ba
asm (
asm ( "ldw
              r31, 124(sp)");
                                           // r31 = ra
asm ( "addi sp, sp, 128" );
asm ( "eret" );
```

Note: When you compile your code you will need the header file "nios2_ctrl_reg_macros.h" in the same folder as your c code files. You will find the header file on Moodle. This header file contains macro functions that you can use to write to and read from the Nios control registers.

5. Run your interrupt code on your Nios system

Use the Altera Monitor program to load your Nios processor design into the DE2 board followed by compiling and down-loading your C-code.



Demonstrator initials to indicate that your C-code compiles without errors.



Then:

a) Using the instruction timings you measured in lab 1 and the disassembly of your C code provided by the Monitor calculate the interrupt latency that you expect for the counter service. For this exercise assume that latency is the time between the external event happening and the start of the associated service code. This question refers to theoretical value calculation.

Expected Latency .40 * 120ns = 4800ns

What is major source of latency in this system?

. The major source of latency is the pushing registers (context switching). The exception processing can only happen when the registers values have been saved on the stack.

Demonstrator initials for satisfactory latency calculation



When you have completed the lab or when time is running out then start the assessment quiz for this laboratory exercise. The demonstrator will enter the password and record your mark (out of 5, one for each check box).

Ensure that your mark for this exercise is entered before you leave the lab.