











# CS110 Computer Architecture

# Thread-Level Parallelism (TLP) and OpenMP Intro

Chundong Wang & Siting Liu SIST, ShanghaiTech















### Review

- Amdahl's Law: Serial sections limit speedup
- Flynn Taxonomy
- Intel SSE SIMD Instructions
  - Exploit data-level parallelism in loops
  - One instruction fetch that operates on multiple operands simultaneously
  - 128-bit XMM registers
- SSE Instructions in C
  - Embed the SSE machine instructions directly into C programs through use of Intrinsics
  - Achieve efficiency beyond that of optimizing compiler














# Big Idea: Amdahl's (Heartbreaking) Law

Speedup due to enhancement E is

 Suppose that enhancement E accelerates a fraction F (F < 1) of the task by a factor S (S>1) and the remainder of the task is unaffected





**New-School** 

Machine

Structures











#### Software

Parallel Requests
 Assigned to computer
 e.g., Search "Chundong"

Parallel Threads
 Assigned to core
 e.g., Lookup, Ads

- Parallel Instructions
   >1 instruction @ one time
   e.g., 5 pipelined instructions
- Parallel Data
   >1 data item @ one time
   e.g., Add of 4 pairs of words
- Hardware descriptions
   All gates @ one time
- Programming Languages

#### Hardware


Warehouse Scale Computer

Harness
Parallelism &
Achieve High
Performance



Smart Phone




















# Simple Multiprocessor














# 4 Core Processor with Graphics















# Multiprocessor Execution Model

- Each processor has its own PC and executes an independent stream of instructions (MIMD)
- Different processors can access the same memory space
  - Processors can communicate via shared memory by storing/loading to/from common locations
- Two ways to use a multiprocessor:
  - 1. Deliver high throughput for independent jobs via job-level parallelism
  - Improve the run time of a single program that has been specially crafted to run on a multiprocessor - a parallel-processing program

Use term *core* for processor ("Multicore") because "Multiprocessor Microprocessor" too redundant




























### Current Multi-Core CPUs

- Intel Core i7: 4-10 real cores
- Intel Core i9: 10-18 real cores
- Intel Xeon Platinum: 16, 24, 26, 28 real cores
- AMD Epyc 2: 8 64 real cores
- Apple A13: 2 (high performance) + 4 (low power) Apple designed ARM CPUs
- Samsung S20 (Samsung Exynos 990): 1 + 3 + 4

1 x ARM Cortex-A77	2.85GHz	512kB L2\$
3 x ARM Cortex-A77	2.4GHz	256kB L2\$
4 x ARM Cortex-A55	1.8GHz	128kB L2\$













### Parallelism the Only Path to Higher Performance

- Sequential processor performance not expected to increase much, and might go down
- If want apps with more capability, have to embrace parallel processing (SIMD and MIMD)
- In mobile systems, use multiple cores and GPUs
- In warehouse-scale computers, use multiple nodes, and all the MIMD/SIMD capability of each node













# Comparing Types of Parallelism...

- SIMD-type parallelism (Data Parallel)
  - A SIMD-favorable problem can map easily to a MIMD-type fabric
  - SIMD-type fabrics generally offer a much higher throughput per \$
    - Much simpler control logic
    - Classic example: Graphics cards are massive supercomputers compared to the CPU: TeraFLOPS rather than gigaflops
- MIMD-type parallelism (data-dependent Branches!)
  - A MIMD-favorable problem will not map easily to a SIMD-type fabric
  - E.g.: some problems work well on GPU (e.g. Deep Learning). Others NOT (e.g. compiler)













### Multiprocessors and You

- Only path to performance is parallelism
  - Clock rates flat or declining
  - CPI generally flat
  - SIMD:
    - 2011: 256b Intel & AMD
    - 2016: 512b Intel & Fujitsu A64FX
    - X: 1024b specified no CPU planned yet
    - GPUs: massive SIMD
  - MIMD: Add 2 cores every 2 years: 2, 4, 6, 8, 10, ...
- Key challenge is to craft parallel programs that have high performance on multiprocessors as the number of processors increase i.e., that scale
  - Scheduling, load balancing, time for synchronization, overhead for communication













### Threads

- Thread: a sequential flow of instructions that performs some task
- Each thread has a PC + processor registers and accesses the shared memory
- Each processor provides one (or more) hardware threads that actively execute instructions
- Operating system multiplexes multiple software threads onto the available hardware threads













# **Operating System Threads**

Give the illusion of many active threads by time-multiplexing software threads onto hardware threads

- Remove a software thread from a hardware thread by interrupting its execution and saving its registers and PC into memory
  - Also if one thread is blocked waiting for network access or user input
- Can make a different software thread active by loading its registers into a hardware thread's registers and jumping to its saved PC













# Hardware Multithreading (Hyperthreading)

- Basic idea: Processor resources are expensive and should not be left idle
  - Long memory latency to memory on cache miss?
- Hardware switches threads to bring in other useful work while waiting for cache miss
  - Cost of thread context switch must be much less than cache miss latency
- Put in redundant hardware so don't have to save context on every thread switch:
  - PC, Registers
- Attractive for apps with abundant TLP
  - Commercial multi-user workloads



threads!





























Hyper-threading (simplified)

- Duplicate all elements that hold the state (registers)
- Use the same CL blocks
- Use muxes to select which state to use every clock cycle
- => run 2 independent processes
  - No Hazards: registers different; different control flow; memory different;
     Threads: memory hazard should be solved by software (locking, mutex, ...)
- Speedup?
  - No obvious speedup; Complex pipeline: make use of CL blocks in case of unavailable resources (e.g. wait for memory)













# Multithreading vs. Multicore

- Multithreading => Better Utilization
  - ≈5% more hardware, 1.10X better performance?
  - Share integer adders, floating-point units, all caches (L1 I\$, L1 D\$, L2\$, L3\$),
     Memory Controller
- Multicore => Duplicate Processors
  - ≈50% more hardware, ≈2X better performance?
  - Share outer caches (L2\$, L3\$), Memory Controller
- Modern machines do both
  - Multiple cores with multiple threads per core













# Chundong's Workstation

```
wangc@HP:~$ lscpu
Architecture:
                  x86 64
CPU op-mode(s): 32-bit, 64-bit
                  Little Endian
Byte Order:
Address sizes:
                  36 bits physical, 48 bits virtual
                  16
CPU(s):
On-line CPU(s) list: 0-15
Thread(s) per core: 2
Core(s) per socket: 8
Socket(s):
Vendor ID:
                  GenuineIntel
CPU family:
                   6
Model:
                   158
Model name:
                  Intel(R) Core(TM) i9-9900K CPU @ 3.60GHz
Stepping:
                   13
CPU MHz:
                   3600.000
CPU max MHz:
                   3600.0000
BogoMIPS:
                  7200.00
Virtualization:
                   x-TV
```













### 100s of (Mostly Dead) Parallel Programming Languages

ActorScript	Concurrent Pascal	JoCaml	Orc
Ada	Concurrent ML	Join	Oz
Afnix	Concurrent Haskell	Java	Pict
Alef	Curry	Joule	Reia
Alice	CUDA	Joyce	SALSA
APL	E	LabVIEW	Scala
Axum	Eiffel	Limbo	SISAL
Chapel	Erlang	Linda	SR
Cilk	Fortan 90	MultiLisp	Stackless Python
Clean	Go	Modula-3	SuperPascal
Clojure	Io	Occam	VHDL
Concurrent C	Janus	occam-п	XC













# OpenMP

- OpenMP is a language extension used for multi-threaded, sharedmemory parallelism
  - Compiler Directives (inserted into source code)
  - Runtime Library Routines (called from your code)
  - Environment Variables (set in your shell)
- Portable
- Standardized
- Easy to compile: cc -fopenmp name.c













### Shared Memory Model with Explicit Thread-based Parallelism

 Multiple threads in a shared memory environment, explicit programming model with full programmer control over parallelization

#### • Pros:

- Takes advantage of shared memory, programmer need not worry (that much) about data placement
- Compiler directives are simple and easy to use
- Legacy serial code does not need to be rewritten

#### • Cons:

- Code can only be run in shared memory environments
- Compiler must support OpenMP













### OpenMP in CS110

- OpenMP is built on top of C, so you don't have to learn a whole new programming language
  - Make sure to add #include <omp.h>
  - Compile with flag: gcc -fopenmp
  - Mostly just a few lines of code to learn
- You will NOT become experts at OpenMP
  - Use slides as reference, will learn to use in lab

#### Key ideas:

- Shared vs. Private variables
- OpenMP directives for parallelization, work sharing, synchronization














**OpenMP Programming Model** 

• Fork - Join Model:



- OpenMP programs begin as single process (*master thread*) and executes sequentially until the first parallel region construct is encountered
  - FORK: Master thread then creates a team of parallel threads
  - Statements in program that are enclosed by the parallel region construct are executed in parallel among the various threads
  - JOIN: When the team threads complete the statements in the parallel region construct, they synchronize and terminate, leaving only the master thread













# OpenMP Extends C with Pragmas

- Pragmas are a preprocessor mechanism C provides for language extensions
- Commonly implemented pragmas: structure packing, symbol aliasing, floating point exception modes (not covered)
- Good mechanism for OpenMP because compilers that don't recognize a pragma are supposed to ignore them
  - Runs on sequential computer even with embedded pragmas













### parallel Pragma and Scope

• Basic OpenMP construct for parallelization:

- Each thread runs a copy of code within the block
- Thread scheduling is *non-deterministic*
- OpenMP default is shared variables
  - To make private, need to declare with pragma:

```
#pragma omp parallel private (x)
```













### **Thread Creation**

- How many threads will OpenMP create?
- Defined by OMP\_NUM\_THREADS environment variable (or code procedure call)
  - Set this variable to the maximum number of threads you want OpenMP to use
  - Usually equals the number of physical cores \* number of threads/core in the underlying hardware on which the program is run













### What Kind of Threads?

- OpenMP threads are operating system (software) threads.
- OS will multiplex requested OpenMP threads onto available hardware threads.
- Hopefully each gets a real hardware thread to run on, so no OS-level time-multiplexing.
- But other tasks on machine can also use hardware threads!
  - And you may want more threads than hardware if you have a lot of I/O so that while waiting for I/O other threads can run













### OMP NUM THREADS

OpenMP intrinsic to set number of threads:

```
omp set num threads(x);
```

OpenMP intrinsic to get number of threads:

```
num th = omp get num threads();
```

• OpenMP intrinsic to get Thread ID number:

```
th_ID = omp_get_thread_num();
```













### Parallel Hello World

```
#include <stdio.h>
#include <omp.h>
int main () {
  int nthreads, tid;
  /* Fork team of threads with private var tid */
  #pragma omp parallel private(tid)
    tid = omp get thread num(); /* get thread id */
    printf("Hello World from thread = %d\n", tid);
    if (tid == 0) {
     /* Only master thread does this */
     nthreads = omp get num threads();
     printf("Number of threads = %d\n", nthreads);
    /* All threads join master and terminate */
```













### Results

```
vangc@HP:~/TT$ gcc omp.c -03 -o p -fopenmp
wangc@HP:~/TT$ ./p
Hello World from thread = 6
Hello World from thread = 11
Hello World from thread = 12
Hello World from thread = 7
Hello World from thread = 15
Hello World from thread = 0
Number of threads = 16
Hello World from thread = 2
Hello World from thread = 10
Hello World from thread = 9
Hello World from thread = 5
Hello World from thread = 14
Hello World from thread = 4
Hello World from thread = 8
Hello World from thread = 13
Hello World from thread = 3
Hello World from thread = 1
```

```
wangc@HP:~/TT$ ./p
Hello World from thread = 13
Hello World from thread = 0
Number of threads = 16
Hello World from thread = 7
Hello World from thread = 6
Hello World from thread = 11
Hello World from thread = 1
Hello World from thread = 9
Hello World from thread = 3
Hello World from thread = 15
Hello World from thread = 8
Hello World from thread = 4
Hello World from thread = 10
Hello World from thread = 2
Hello World from thread = 14
Hello World from thread = 12
Hello World from thread = 5
```













### omp set num threads

```
#include <stdio.h>
#include <omp.h>
int main () {
 int nthreads, tid;
 omp set num threads(8); // Newly-added here.
 /* Fork team of threads with private var tid */
 #pragma omp parallel private(tid)
   tid = omp get thread num(); /* get thread id */
   printf("Hello World from thread = %d\n", tid);
   if (tid == 0) {
    /* Only master thread does this */
     nthreads = omp get num threads();
     printf("Number of threads = %d\n", nthreads);
    /* All threads join master and terminate */
```













### omp set num threads

```
vangc@HP:~/TT$ gcc omp.c -o p -03 -fopenmp
wangc@HP:~/TT$ ./p
Hello World from thread = 1
Hello World from thread = 7
Hello World from thread = 6
Hello World from thread = 5
Hello World from thread = 0
Number of threads = 8
Hello World from thread = 2
Hello World from thread = 4
Hello World from thread = 3
wangc@HP:~/TT$ ./p
Hello World from thread = 3
Hello World from thread = 0
Number of threads = 8
Hello World from thread = 1
Hello World from thread = 2
Hello World from thread = 7
Hello World from thread = 5
Hello World from thread = 6
Hello World from thread = 4
wangc@HP:~/TT$ ./p
Hello World from thread = 2
Hello World from thread = 7
Hello World from thread = 5
Hello World from thread = 3
Hello World from thread = 0
Number of threads = 8
Hello World from thread = 6
Hello World from thread = 4
Hello World from thread = 1
vangc@HP:~/TT$
```













### Data Races and Synchronization

- Two memory accesses form a data race if from different threads to same location, and at least one is a write, and they occur one after another
- If there is a data race, result of program can vary depending on chance (which thread first?)
- Avoid data races by synchronizing writing and reading to get deterministic behavior
- Synchronization done by user-level routines that rely on hardware synchronization instructions
- (more later)













### **Analogy: Buying Yogurt**

- Your fridge has no yogurt. You and your roommate will return from classes at some point and check the fridge
- Whoever gets home first will check the fridge, go and buy yogurt, and return
- What if the other person gets back while the first person is buying yogurt?
  - You've just bought twice as much yogurt as you need!
- It would've helped to have left a note...













# Lock Synchronization (1/2)

- Use a "Lock" to grant access to a region (*critical section*) so that only one thread can operate at a time
  - Need all processors to be able to access the lock, so use a location in shared memory as the lock
- Processors read lock and either wait (if locked) or set lock and go into critical section
  - 0 means lock is free / open / unlocked / lock off
  - 1 means lock is set / closed / locked / lock on













## Lock Synchronization (2/2)

Pseudocode:

```
Check lock

Can loop/idle here if locked

Set the lock

Critical section

(e.g. change shared variables)

Unset the lock
```













### Possible Lock Implementation

Lock (a.k.a. busy wait)

```
Get_lock: # s0 -> addr of lock
    addiu t1,zero,1 # t1 = Locked value
Loop: lw t0,0(s0) # load lock
    bne t0,zero,Loop # loop if locked
Lock: sw t1,0(s0) # Unlocked, so lock
```

Unlock

```
Unlock: sw zero, 0(s0)
```

Any problems with this?













#### Possible Lock Problem

Loop: lw t0,0(s0)

Thread 1

addiu t1, zero, 1

bne t0, zero, Loop

Lock: sw t1,0(s0)

Thread 2

addiu t1, zero, 1

Loop: lw t0,0(s0)

bne t0, zero, Loop

Lock: sw t1,0(s0)

Both threads think they have set the lock! Exclusive access not guaranteed!

Time













### Hardware Synchronization

- Hardware support required to prevent an interloper (another thread) from changing the value
  - Atomic read/write memory operation
  - No other access to the location allowed between the read and write
- How best to implement in software?
  - Single instr? Atomic swap of register ↔ memory
  - Pair of instr? One for read, one for write
- Needed even on uniprocessor systems
  - Interrupts can happen: can trigger thread context switches...













#### RISC-V: Two solutions!

- Option 1: Read/Write Pairs
  - Pair of instructions for "linked" read and write
  - Load reserved and Store conditional
  - No other access permitted between read and write
    - Must use shared memory (multiprocessing)

- Option 2: Atomic Memory Operations
  - Atomic swap of register 
     ← memory













## Read/Write Pairs

- Load reserved: Ir rd, rs
  - Load the word pointed to by rs into rd, and add a reservation
- Store conditional: sc rd, rs1, rs2
  - Store the value in **rs2** into the memory location pointed to by **rs1**, only if the reservation is still valid and set the status in **rd** 
    - Returns 0 (success) if location has not changed since the Ir
    - Returns nonzero (failure) if location has changed:
       Actual store will not take place













### Synchronization in RISC-V Example

- Atomic swap (to test/set lock variable)
- Exchange contents of register and memory:
   s4 ←→ Mem(s1)

#### try:

```
lr t1, s1 #load reserved
sc t0, s1, s4 #store conditional
bne t0, x0, try #loop if sc fails
add s4, x0, t1 #load value in s4
```














#### Test-and-Set

- In a single atomic operation:
  - *Test* to see if a memory location is set (contains a 1)
  - **Set** it (to 1) if it isn't (it contained a zero when tested)
    - Otherwise indicate that the Set failed, so the program can try again
  - While accessing, no other instruction can modify the memory location, including other Test-and-Set instructions
- Useful for implementing lock operations















# Test-and-Set in RSIC-V using lr/sc

• Example: RISC-V sequence for implementing a T&S at (s1)

Try:

li t2, 1

lr t1, s1

bne t1, x0, Try

sc t0, s1, t2


bne t0, x0, Try

Locked:

# critical section

Unlock:

sw x0,0(s1)















### Option 2: RISC-V Atomic Memory Operations (AMOs)

- Encoded with an R-type instruction format
  - swap, add, and, or, xor, max, min
  - AMOSWAP rd, rs2, (rs1)
  - AMOADD rd, rs2, (rs1)
- Take the value pointed to by rs1
  - Load it into rd aq(acquire) and rl(release) to insure in order execution
  - Apply the operation to that value with the contents in rs2
    - If rs2==rd, use the old value in rd
  - Store the result back to where rs1 is pointed to
- This allows atomic swap as a primitive
  - It also allows "reduction operations" that are common to be efficiently implemented













#### RISC-V Critical Section

- Assume that the lock is in memory location stored in register a0
- The lock is "set" if it is 1; it is "free" if it is 0 (it's initial value)













### Lock Synchronization

```
Fix (lock is at location (a0))
Broken Synchronization
while (lock != 0);
                                  li
                                                       t0, 1
                              Try: amoswap.w.aq t1, t0, (a0)
                                         t1, Try
                                   bnez
                              Locked:
lock = 1;
                                  # critical section
// critical section
                              Unlock:
lock = 0;
                                  amoswap.w.rl x0, x0, (a0)
```













#### How to use

Don't implement yourself!

- Use according library e.g.:
  - pthread
  - C++:

• std::thread C++11

https://en.cppreference.com/w/cpp/thread

std::jthread

- C++20
- std::mutex; std::lock\_guard; std::scoped\_lock; std::shared\_lock
- std::condition\_variable; std::counting\_semaphore; std::latch; std::barrier
- std::promise; std::future
- Qt QThread
- OpenMP













### And in Conclusion, ...

- Sequential software is slow software
  - SIMD and MIMD only path to higher performance
- Multithreading increases utilization, Multicore more processors (MIMD)
- OpenMP as simple parallel extension to C
  - Threads, Parallel for, private, critical sections, ...
  - ≈ C: small so easy to learn, but not very high level and it's easy to get into trouble