

- SEAL ALL DUPONT ™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT ™ TYVEK® TAPE.
- \bullet FASTEN DUPONT $^{\text{\tiny{TM}}}$ TYVEK $^{\circledR}$ WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.
- EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT ™ TYVEK ® LAYER.

