

## $\frac{\mathsf{METAL\ PANEL\ -\ NON\ FLANGED\ WINDOW\ SILL}}{(\mathsf{STRAIGHTFLASH\ ^{IM}\ VF})}$

- SEAL ALL DUPONT ™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT ™ TYVEK® TAPE.
- $\bullet$  FASTEN DUPONT  $^{\mathsf{TM}}$  TYVEK  $^{\mathsf{R}}$  WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.
- EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT ™TYVEK ® LAYER.

