US Patent & Trademark Office Patent Public Search | Text View

United States Patent

Kind Code

B2

Date of Patent

Inventor(s)

12395165

B2

August 19, 2025

Kwak; Taewoo et al.

Apparatus and methods to control well bias in a semiconductor device

Abstract

An example circuit includes a substrate including a first transistor of a gate driver output stage, the substrate including a first well region; a diode circuit including a first terminal and a second terminal, the first terminal coupled to a first tap of the first well region; and a second transistor including a first terminal, a second terminal, and a body, the first terminal of the second transistor coupled to a switching voltage terminal, and the second terminal and the body of the second transistor coupled to the first tap of the first well region and to the first terminal of the diode circuit.

Inventors: Kwak; Taewoo (McKinney, TX), Amey; Benjamin (Allen, TX), Otani; Daijiro

(Plano, TX)

Applicant: Texas Instruments Incorporated (Dallas, TX)

Family ID: 1000008762944

Assignee: TEXAS INSTRUMENTS INCORPORATED (Dallas, TX)

Appl. No.: 18/385852

Filed: October 31, 2023

Prior Publication Data

Document IdentifierUS 20250141443 A1

May. 01, 2025

Publication Classification

Int. Cl.: H03K17/10 (20060101); H03K17/687 (20060101); H03K19/0185 (20060101)

U.S. Cl.:

CPC **H03K17/102** (20130101); **H03K17/687** (20130101); **H03K19/018514** (20130101);

H03K2217/0063 (20130101); H03K2217/0072 (20130101)

Field of Classification Search

CPC: H03K (17/102)

USPC: 327/108

References Cited

U.S. PATENT DOCUMENTS

Patent No.	Issued Date	Patentee Name	U.S. Cl.	CPC
6825700	12/2003	Hano	327/108	H10D 84/811
2013/0278301	12/2012	Huynh	327/108	H01L 24/06
2022/0199611	12/2021	Chen	N/A	H10D 84/0109

OTHER PUBLICATIONS

Waller, "Analog Layout—Wells, Taps, and Guard Rings," Pulsic, Feb. 18, 2021, retrieved from https://pulsic.com/analog-layout-wells-taps-and-guard-rings/ on Sep. 20, 2023, 6 pages. cited by applicant

Primary Examiner: Skibinski; Tomi

Background/Summary

TECHNICAL FIELD

(1) This description relates generally to circuits and, more particularly, to apparatus and methods to control well bias in a semiconductor device.

BACKGROUND

(2) Electronic integrated circuit devices such as microchips that implement processors, logic devices, amplifiers, voltage converters, etc., are implemented using semiconductor materials. Semiconductor materials can be adapted to conduct electricity under various conditions to produce varying voltages and electrical currents according to different intended functions. An electronic integrated circuit device is a semiconductor device that includes multiple layers of semiconductor materials forming multiple electronic components such as transistors, capacitors, inductors, resistors, logic gates, etc. Predictable operation of such components facilitates implementing stable and intended functions of a semiconductor device such as numerical calculations, amplifications, filtering, etc. Different regions of a semiconductor device are designed to operate at corresponding voltage potentials and/or electrical current draws. To achieve stable and intended functionality of such a semiconductor device, its different regions are operated within their intended voltage potentials and/or electrical current draws.

Description

BRIEF DESCRIPTION OF THE DRAWINGS

(1) FIG. **1**A (represented as FIG. **1**A, FIG. **1**A-**1**, FIG. **1**A-**2**) is an example voltage converter circuit including a gate driving circuit and a well bias voltage clamp circuit to dynamically control

- well bias in a semiconductor device.
- (2) FIG. **1**B (represented as FIG. **1**B, FIG. **1**B-**1**, FIG. **1**B-**2**) is the example voltage converter circuit of FIG. **1**A including a gate voltage controller connected to the well bias voltage clamp circuit of FIG. **1**A.
- (3) FIG. **2** shows example waveforms of different node voltages associated with the voltage clamp circuit and the semiconductor of FIGS. **1**A and **1**B.
- (4) FIG. **3**A is an example P-well (PW) voltage clamp circuit to control well bias voltage in a p-type well region of a semiconductor device.
- (5) FIG. **3**B is an example waveform of voltage clamping generated by the PW voltage clamp circuit of FIG. **3**A to control a p-type well bias.
- (6) FIG. **4**A is an example N-well (NW) voltage clamp circuit to control well bias voltage in an n-type well region of a semiconductor device.
- (7) FIG. **4**B is an example waveform of voltage clamping generated by the NW voltage clamp circuit of FIG. **4**A to control an n-type well bias.
- (8) FIG. **5** is the example semiconductor device and the example PW voltage clamp circuit of FIGS. **1**A and **1**B to control well bias in a p-type well region of the semiconductor device.
- (9) FIG. **6**. is the example semiconductor device of FIGS. **1**A and **1**B and an alternative implementation of the example PW voltage clamp circuit of FIGS. **1**A and **1**B to control well bias in a p-type well region of the semiconductor device.
- (10) FIG. **7** is the example semiconductor and the example PW voltage clamp circuit of FIGS. **1**A and **1**B coupled to a gate voltage controller of FIG. **1**B to accommodate more negative output voltages and control well bias in a p-type well region of the semiconductor device.
- (11) FIG. **8** is the example semiconductor device of FIGS. **1**A and **1**B and the alternative example PW voltage clamp circuit of FIG. **6** coupled to the gate voltage controller of FIG. **7** to accommodate more negative output voltages and control well bias in a p-type well region of the semiconductor device.
- (12) FIG. **9** is the example semiconductor device of FIGS. **1**A and **1**B and the example NW voltage clamp circuit of FIG. **4**A to control well bias in an n-type well region of the semiconductor device.
- (13) FIG. **10**, is the example semiconductor device of FIGS. **1**A and **1**B and an alternative implementation of the example NW voltage clamp circuit of FIG. **4**A to control well bias in an n-type well region of the semiconductor device.
- (14) FIG. **11** is the example semiconductor device of FIGS. **1**A and **1**B and the example NW voltage clamp circuit of FIG. **9** coupled to a gate voltage controller to accommodate more positive output voltages and control well bias in an n-type well region of the semiconductor device.
- (15) FIG. **12** is the example semiconductor device of FIGS. **1**A and **1**B and the alternative example NW voltage clamp circuit of FIG. **10** coupled to the gate voltage control circuit of FIG. **11** to accommodate more positive output voltages and control well bias in an n-type well region of the semiconductor device.
- (16) FIG. **13** is a flowchart of the operation of the example PW voltage clamp circuits of FIGS. **1**A, **1**B, **3**A and **5-8** to control well bias in a p-type well region of a semiconductor device.
- (17) FIG. **14** is a flowchart of the operation of the example NW voltage clamp circuits of FIGS. **4**A and **9-12** to control well bias in an n-type well region of a semiconductor device.
- (18) In general, the same reference numbers will be used throughout the drawings and accompanying written description to refer to the same or like parts. The figures are not necessarily to scale. Instead, the thickness of the layers or regions may be enlarged in the drawings. Although the figures show layers and regions with clean lines and boundaries, some or all of these lines and/or boundaries may be idealized. In reality, the boundaries and/or lines may be unobservable, blended, and/or irregular.

DETAILED DESCRIPTION

(19) Latchup or p-n junction breakdown can be problematic for circuits that operate in a floating

voltage domain such as high-side (HS) n-channel field effect transistor (NFET) gate driver circuits in inverting buck-boost voltage converters. In such circuits, biasing an N+ buried layer (NBL) by an external power source and operating its inner P-well (PW) as a switching voltage node (Vsw) creates a risk of latchup when the external power to NBL is shorted to ground (GND). Biasing the PW to a lowest voltage (e.g., -5.25V) is not always possible because when a bootstrapped voltage (Vboot) increases to $^{\sim}10V$, the voltage differential (e.g., 15.25V) violates an N-well (NW)-PW junction breakdown voltage limit of the corresponding semiconductor device. The NW-PW junction breakdown voltage limit is dependent on the semiconductor process (e.g., a $^{\sim}12V$ process vs. a $^{\sim}20V$ process) used to fabricate the semiconductor device.

- (20) Examples described herein include well bias voltage clamping circuits that control well bias voltage in p-type well regions and n-type well regions in semiconductor devices that operate in floating voltage domains. A floating voltage domain is a circuitry environment in which a voltage swings between two values (e.g., between low and high voltage values, between a negative voltage value and a positive voltage value, between ground and a negative voltage value, or between ground and a positive voltage value). In examples described herein, a p-type well region is also referred to as a P-well (PW) region, and an n-type well region is also referred to as an N-well (NW) region. In examples described herein, an NW region is a semiconductor layer that implements a body of a metal-oxide semiconductor (MOS) transistor (e.g., a p-channel MOS (PMOS)), and a PW region is another semiconductor layer surrounding the NW region of the MOS transistor to electrically isolate the MOS transistor from other NW regions in the semiconductor device. In examples described herein, another NW region is a N-type buried layer (NBL) region which isolates the PW region from a semiconductor substrate. Such electrical isolation prevents or decreases the likelihood of electron transfers (e.g., electrical current flow) between separate NW regions.
- (21) Undesired electron transfers (e.g., undesired electrical current flow) between separate regions in a semiconductor device can occur from unwanted p-n junction forward bias. If unwanted junction forward bias occurs, it can trigger a parasitic NPN transistor or a parasitic PNP transistor, which might result in latchup. In examples described herein, a p-n junction is a boundary between a p-type semiconductor material, such as a PW region, and an n-type semiconductor material, such as an NW region. Also, in examples described herein, an unwanted p-n junction forward bias refers to unwanted electron flow or unwanted electrical current flow between a p-type semiconductor material and an n-type semiconductor material. Such unwanted p-n junction forward biases lead to latchup in circuits. As used herein, latchup refers to an unpredictable operational state or a non-operational state of a circuit. Accordingly, during latchup, a circuit does not behave as expected and/or is rendered non-operational. Some instances of latchup can be resolved by re-starting or resetting the circuit. However, other instances of latchup are non-recoverable due to a permanent change or physical damage in a circuit.
- (22) To substantially reduce or eliminate unwanted p-n junction breakdowns and/or latchups in circuits, examples described herein include PW voltage clamping circuits to control well bias voltage in p-type well regions of semiconductor devices and NW voltage clamping circuits to control well bias voltage in n-type well regions of semiconductor devices. Example voltage clamping circuits described herein may be implemented using relatively little semiconductor area with only a negligible increase or substantially no increase in power consumption of a circuit. (23) As such, example voltage clamping circuits described herein are suitable for battery-powered devices due to the small footprint requirements and low to no increase in power consumption of the voltage clamping circuits. However, example voltage clamping circuits described herein are equally suitable for high-power devices such as devices that operate using external voltage supplies from an alternating-current (AC) source or direct-current (DC) source (e.g., wall power, plug-in power, automobile or vehicle power, etc.). In addition, example voltage clamping circuits described herein may be implemented using low-cost semiconductor manufacturing processes instead of

needing to employ special semiconductor manufacturing processes that support high junction breakdown voltages and/or integrated backgate p-channel field effect transistors (PFETs). (24) FIG. 1A (represented as FIG. 1A, FIG. 1A-1, FIG. 1A-2) is an example voltage converter circuit 100 including a gate driving circuit 102 and a P-well (PW) bias voltage clamp circuit 104 to dynamically control well bias in a semiconductor device 106. The voltage converter circuit 100 may be used to implement an inverting buck-boost (IBB) voltage converter and/or a single-input dual-output (SIDO) voltage converter. The gate driving circuit 102 of example FIG. 1A is a high-side (HS) gate driving circuit 102 that is in circuit with a low-side (LS) gate driving circuit 108. (25) Examples described herein are described in reference to implementing voltage clamp circuits in the high-side (HS) gate driving circuit 102. However, voltage clamp circuits described herein may be implemented in LS gate driving circuits and/or in any other circuit to control well bias in floating voltage domains. For example, examples described herein may be implemented in connection with any floating voltage domain circuits that require well bias voltage to follow a switching node voltage (Vsw) (or a bootstrapped voltage (Vboot)) to prevent latchup and/or junction breakdowns.

- (26) Examples described herein are not limited to high-side gate driver applications, inverting buck-boost voltage converters, or single-input dual-output voltage converters. Instead, examples described herein may be used in connection with any application having a well potential biased by a switching node voltage (or a bootstrapped voltage). Examples of such circuits include inductor-based switching converters such as buck voltage converters, boost voltage converters, charge pump circuits, etc.
- (27) In example FIG. **1**A, the HS gate driving circuit **102** includes the PW voltage clamp circuit **104**, gate driver circuitry **112**, level shifter(s) and controller circuitry **114**, a boot capacitor (Cboot) **116**, and boot capacitor (Cboot) charging circuitry **118**. An input of the gate driver circuitry **112** is connected to an output of the level shifter(s) and controller circuitry **114**. Although shown as a single block, level shifter(s) may be implemented separate from a controller. An input signal to the level shifter(s) and controller circuitry **114** is in a different voltage domain (e.g., relative to ground). Since the floating gate driver circuitry **112** is referenced to a switching voltage (Vsw) which is switching between Vout (negative domain) and Vin (positive domain), the level shifter(s) of the level shifter(s) and controller circuitry **114** level shift the input signal (Vin) from ground to the switching voltage (Vsw).
- (28) The boot capacitor (Cboot) **116** is to assist in creating a floating voltage domain by holding charges to control a bootstrap voltage (Vboot). The boot capacitor (Cboot) **116** can be implemented inside or outside of a chip in which the voltage converter circuit **100** is located. The bootstrap capacitor charging circuitry **118** is to generate a bootstrap voltage (Vboot) by charging the boot capacitor (Cboot) **116**. For example, since the switching voltage (Vsw) is switching between Vout and Vin, Vboot is also moving up and down with the voltage difference charged by the bootstrap capacitor (Cboot) **116**.
- (29) The amount of voltage charged in the bootstrap capacitor (Cboot) **116** is controlled by the bootstrap capacitor charging circuitry **118**. Accordingly, the bootstrap capacitor charging circuitry **118** regulates the voltage across the bootstrap capacitor (Cboot) **116**. To achieve a small drain-source on resistance (RDS (on)) of a high-side (HS) power transistor **130**, the gate-to-source voltage (Vgs) of the HS power transistor **130** is kept as high as possible within its voltage rating. For example, 5 volts can be stored across the bootstrap capacitor (Cboot) **116**, and the bootstrap capacitor charging circuitry **118** can maintain a constant 5 volts while the switching voltage (Vsw) switches between Vout and Vin.
- (30) A bootstrap voltage (Vboot) output of the bootstrap capacitor charging circuitry **118** is connected to the boot capacitor (Cboot) **116**, the level shifter(s) and controller circuitry **114**, and the gate driver circuitry **112** via a bootstrap voltage terminal (**120**). In the illustrated example of FIG. **1**A, the bootstrap voltage (Vboot) is generated internally in a same chip in which the voltage

converter circuit **100** is located. However, it can be generated externally from the chip using, for example, a Schottky diode. If generated externally from the chip of the voltage converter circuit **100**, the bootstrap capacitor charging circuitry **118** is to control the application of the externally generated bootstrap voltage (Vboot) to charge the boot capacitor (Cboot) **116**.

- (31) In example FIG. 1A, the voltage converter circuit 100 includes the high-side (HS) power transistor 130 including a drain (D) terminal, a source(S) terminal, and a gate (G) terminal. The voltage converter circuit 100 also includes a low-side (LS) power transistor 132 including a drain (D) terminal, a source(S) terminal, and a gate (G) terminal, also referred to as a drain, source, and gate. In examples described herein, a power transistor is to control high current-voltage ratings (e.g., high current-voltage ratings that exceed current-voltage ratings of small-current transistors). For example, relative to a small-current transistor, a power transistor has a larger current rating, a larger power dissipation rating, and a larger size to satisfy heat dissipation demands of its high current-voltage rating. In the illustrated example, the power transistors 130, 132 are implemented inside a same chip that includes the voltage converter circuit 100. However, in other examples, the power transistors 130, 132 is located outside of the chip. The drain (D) terminal of the LS power transistor 132 is coupled to the source terminal of the HS power transistor 130 and to a switching voltage (Vsw) terminal 134 which is connected to ground via an inductor 136. In the illustrated example, the inductor 136 is located outside of a chip that includes the voltage converter circuit 100. However, in other examples, the inductor 136 is located inside of the chip.
- (32) An output (OUT) terminal of the gate driver circuitry **112** is connected to the gate (G) terminal of the HS power transistor **130**. An output terminal of the LS gate driving circuit **108** is coupled to the gate (G) terminal of the LS power transistor **132**. The drain (D) terminal of the HS power transistor **130** is coupled to an input voltage (Vin) terminal. The source(S) terminal of the LS power transistor **132** is coupled to an output voltage (Vout) terminal which is connected to ground via a capacitor **138**. The gate driver circuitry **112** is to control on/off states of the HS power transistor **130** based on input signals to the gate driver circuitry **112**. As such, the HS gate driving circuit **102** can be used in inverting buck-boost (IBB) converters. In IBB converters, inverting is performed by generating negative output voltages. Considering the absolute voltage of the output (Vout), to buck is to decrease an output voltage (Vout) to be smaller than the input voltage (Vin) and to boost is to increase the output voltage (Vout) to be greater than the input voltage (Vin).
- (33) The PW voltage clamp circuit **104** includes a diode circuit **140** and a clamp transistor **142**. In examples described herein, the clamp transistor **142** is shown as an NMOS transistor. However, example voltage clamp circuits described herein may be adapted to include a PMOS transistor in place of the NMOS transistor to bias well regions of semiconductor devices in teachings of this description. In example FIG. **1A**, the clamp transistor **142** includes drain (D) terminal, a source(S) terminal, a gate (G) terminal, and a body (B). The drain (D) terminal of the clamp transistor **142** is connected to the level shifter(s) and control circuitry **114**. The drain (D) terminal of the clamp transistor **142** is also connected to a terminal of the bootstrap capacitor (Cboot) **116** that is connected to the bootstrap voltage (Vboot) terminal and the bootstrap capacitor charging circuitry **118**. In addition, the source(S) terminal and the body (B) of the clamp transistor **142** are coupled to the gate driver circuitry **112** and to a first terminal of the diode circuit **140**. The gate (G) terminal of the clamp transistor **142** and a second terminal of the diode circuit **140** are connected to ground.
- (34) The diode circuit **140** is shown in block form in FIG. **1**A to represent that it may be implemented using any suitable circuit configuration to create a diode-like operation. For example, as shown in FIGS. **5**, **7**, **9**, and **11**, the diode circuit **140** may be implemented using a diode component. In alternative examples shown in FIGS. **6**, **8**, **10**, and **12**, the diode circuit **140** may be implemented using a diode-connected transistor. When implemented as a diode component, the terminals of the diode circuit **140** include anode and cathode terminals. When implemented as a diode-connected transistor, the terminals of the diode circuit **140** include a source terminal and a

- drain terminal. Connection configurations for the different examples are described below in connection with FIGS. **5-12**.
- (35) An example transistor-level circuit view of an example gate driver output stage **144** is shown in detail in FIG. **1**A. The gate driver output stage **144** is a final stage of the gate driver circuitry **112** through which the gate driver circuitry **112** provides an output voltage to the HS power transistor **130** via an output (OUT) terminal. The gate driver output stage **144** includes an example bootstrap voltage (Vboot) transistor **146** and an example switching voltage (Vsw) transistor **148**. The labels of Vboot and Vsw for the Vboot transistor **146** and the Vsw transistor **148** are used merely for ease of reference and are based on the Vboot transistor **146** being connected to a bootstrap voltage (Vboot) terminal and the Vsw transistor **148** being connected to a switching voltage (Vsw) terminal.
- (36) In example FIG. **1**A, the Vboot transistor **146** is implemented using a PMOS transistor, and the Vsw transistor **148** is implemented using an NMOS transistor. However, in alternative implementations, the Vboot transistor **146** may be implemented using an NMOS transistor and/or the Vsw transistor **148** may be implemented using a PMOS transistor as suitable for different voltage conversion applications.
- (37) In FIG. **1**A, a source(S) terminal and a body (B) of the Vboot transistor **146** are connected to the bootstrap voltage (Vboot) terminal. A source(S) terminal and a body (B) of the Vsw transistor **148** are connected to the switching voltage (Vsw) terminal. A drain (D) terminal of the Vboot transistor **146** is connected to a drain (D) terminal of the Vsw transistor **148**, forming the output (OUT) terminal of the gate driver output stage **144**. A first terminal of the bootstrap capacitor (Cboot) **116** is connected to the body (B) of the Vboot transistor **146**. A second terminal of the bootstrap capacitor (Cboot) **116** is connected to the drain (D) terminal of the clamp transistor **142** and the switching voltage (Vsw) terminal.
- (38) In the example transistor-level circuit view of the gate driver output stage **144**, the gate driver output stage **144** is shown connected to a parasitic NPN transistor **150** (e.g., labeled NPN**1** in FIG. **1**A). An NPN transistor is formed by a P-type doped semiconductor (e.g., the PW region **154**) between two N-type doped semiconductors (e.g., (1) the NW region **152** and (2) the NBL region **156**). The parasitic NPN transistor **150** is not an actual transistor designed into the circuit. Instead, the symbol of the parasitic NPN transistor **150** connected to the gate driver output stage **144** represents an unintended electrical effect or behavior resulting from the arrangement of different semiconductor materials in a P-well (PW) layer (e.g., the PW region **154**) and an N-well (NW) layer (e.g., the NW region **152**) of the semiconductor device **106**, as described below.
- (39) A collector terminal of the parasitic NPN transistor **150** is designated NW for N-well region (e.g., an NW region **152** described below) and is connected to the body (B) of the Vboot transistor **146** and to a terminal of the boot strap capacitor (Cboot) **116**. A base terminal of the parasitic NPN transistor **150** is designated PW for P-well region (e.g., a PW region **154** described below) and is connected to the source(S) terminal and the body (B) of the clamp transistor **142** and a terminal of the diode circuit **140** of the PW voltage clamp circuit **104**. An emitter terminal of the parasitic NPN transistor **150** is designated NBL for N-type buried layer (e.g., an NBL region **156** described below) and is connected to an isolation voltage (Viso) terminal.
- (40) A detailed multi-layer view of the semiconductor device **106** in FIG. **1**A corresponds to the Vboot transistor **146** and the parasitic NPN transistor **150**. As shown in the detailed multi-layer view of the semiconductor device **106**, the semiconductor device **106** includes an example NW region **152**, an example PW region **154**, an example N-type buried layer (NBL) region **156**, and an example substrate (PSUB) **158**. In the illustrated example, the NW region **152** abuts the PW region **154**, the PW region **154** is between the NW region **152** and the NBL region **156**, and the NBL region **156** is between the PW region **154** and the substrate (PSUB) **158**.
- (41) In the illustrated example, the NW region **152** includes an N-type semiconductor material. An N-type semiconductor material is made by doping a pure semiconductor with one or more

impurities so that the majority of charge carriers in the resulting N-type semiconductor material are free electrons and holes are the minority. The PW region **154** includes a P-type semiconductor material. A P-type semiconductor material is made by doping a pure semiconductor with one or more impurities so that the majority of charge carriers in the resulting P-type semiconductor material are holes and free electrons are the minority.

- (42) The NBL region **156** is an isolation (ISO) region or layer that operates as another NW region to electrically isolate the PW region **154** from other P-type regions. The substrate (PSUB) region **158** is implemented as a P-minus substrate on which the NBL region **156**, the PW region **154**, and the NW region **152** are formed. The NBL region **156** is connected to an isolation voltage (Viso) supply **160** by way of a through-via **162** that is formed through the PW region **154** between a N+ tap and the NBL region **156**. Although the NW region **152**, the PW region **154**, the NBL region **156**, and the substrate (PSUB) region **158** are referred to as regions, these features of the semiconductor **106** may also or alternatively be referred to as layers. For example, each of the regions **152**, **154**, **156**, **158** is formed as a layer in the semiconductor **106** during a semiconductor fabrication process.
- (43) As shown in the detailed multi-layer view of the semiconductor device **106**, the Vboot transistor **146** is formed in the NW region **152**. The parasitic NPN transistor **150** is an NPN transistor effect created by the proximities of the NW region **152**, the PW region **154**, and the NBL region **156** to one another. The collector terminal of the parasitic NPN transistor **150** is formed by the NW region **152**. A base terminal of the parasitic NPN transistor **150** is formed by the PW region **154**. An emitter terminal of the parasitic NPN transistor **150** is formed by the NBL region **156** and its through-via **162** that connects to an isolation voltage (Viso) terminal via an N+ tap. (44) The semiconductor device **106** also includes a parasitic PNP transistor **166** (e.g., labeled PNP**1** in FIG. 1A) that is not an actual transistor designed into the circuit. However, its symbol connected to the Vboot transistor **146** represents an unintended electrical effect or behavior resulting from the arrangement of different semiconductor materials in the PW region **154** and the NW region **152** of the semiconductor device **106**. Accordingly, the parasitic PNP transistor **166** is a PNP transistor effect created by the proximities of the NW region **152** and the PW region **154** to one another. A PNP transistor is formed by an N-type doped semiconductor (e.g., the NW region 152) between two P-type doped semiconductors (e.g., (1) the source(S) terminal of the Vboot transistor 146 and (2) the PW region **154**). A drawback of the parasitic NPN transistor **150** and the parasitic PNP transistor **166** is that their switch-on voltages could be unintentionally satisfied by unintended voltage differences between the NW region 152, the PW region 154, and the NBL region 156. This, in turn, creates an undesired p-n junction forward bias causing latchup between two or more of
- (45) For example, normally the isolation voltage (Viso) supply **160** is held at a sufficiently high voltage to prevent satisfying the switch-on voltages of the parasitic NPN transistor **150** and the parasitic PNP transistor **166**. Referring briefly to FIG. **2**, which shows example waveforms of different node voltages associated with the semiconductor device **106**, an example isolation voltage (Viso) waveform **202** maintains a voltage level greater than a voltage level of a switching voltage (Vsw) waveform **204**. However, if the isolation voltage (Viso) **160** is shorted to ground, moving the isolation voltage (Viso) waveform **202** to ground (e.g., 0V) in FIG. **2**, and the switching voltage (Vsw) transitions to a maximum voltage as shown by the switching voltage (Vsw) waveform **204**, the switching voltage (Vsw) becomes greater than the isolation voltage (Viso) supply **160**. This voltage difference satisfies the switch-on voltage of the parasitic NPN transistor **150**, which causes the parasitic NPN transistor **150** to turn on. This creates an electrical voltage drop (IR drop) across a parasitic resistor Rnw which causes the parasitic PNP transistor **166** to also turn on. In turn, an undesirable p-n junction tunnel is created between the NW region **152** and the PW region **154**. (46) Examples described herein implement the PW voltage clamp circuit **104** to substantially prevent or reduce the likelihood of the switching voltage (Vsw) exceeding the isolation voltage

these regions **152**, **154**, **156**.

- (Viso) supply **160**. For example, as shown in FIG. **2** by voltage wave form PW **206**, the PW voltage clamp circuit **104** clamps the switching voltage (Vsw) to the PW region **154** at a voltage clamp level shown as ground (e.g., 0 V). Using the PW voltage clamp circuit **104** to clamp or limit the voltage to the PW region **154** to ground (as shown by the voltage wave form PW **206**) prevents switching on the parasitic NPN transistor **150** and the parasitic PNP transistor **166** (e.g., prevents the parasitic transistors **150**, **166** from being forward biased). For example, the parasitic transistors **150**, **166** are not switched on even if the isolation voltage (Viso) supply **160** is shorted to ground (moving the isolation voltage (Viso) waveform **202** to ground (e.g., 0V) in FIG. **2**) while the switching voltage (Vsw) transitions to a maximum voltage as shown by the switching voltage (Vsw) waveform **204**.
- (47) FIG. 1B (represented as FIG. 1B, FIG. 1B-1, FIG. 1B-2) is the example voltage converter circuit 100 of FIG. 1A including a gate voltage controller 172 connected to the PW voltage clamp circuit 104 of FIG. 1A. As shown in FIG. 1B, the gate voltage controller 172 is connected to a gate (G) terminal of the clamp transistor 142. The gate voltage controller 172 enables dynamically controlling a voltage range of the PW voltage clamp circuit 104. For example, the gate voltage controller 172 can be used to control a gate voltage of the gate terminal of the clamp transistor 142 to accommodate more negative output voltages for a PW voltage bias of the PW region 154 and more positive output voltages for an NW voltage bias of the NW region 152. An example circuit that may be used to implement the gate voltage controller 172 is described below in connection with FIGS. 7, 8, 11, and 12.
- (48) FIG. **3**A is an example P-well (PW) voltage clamp circuit **300** to control well bias voltage in the PW region **154** of the semiconductor device **106** of FIGS. **1**A and **1**B. The PW voltage clamp circuit **300** may be used to implement the PW voltage clamp circuit **104** of FIGS. **1**A and **1**B. The PW voltage clamp circuit **300** includes a clamp transistor **302** and a diode circuit **304**. The clamp transistor **302** is an NFET transistor and implements the clamp transistor **142** of FIGS. **1**A and **1**B. The diode circuit **304** implements the diode circuit **140** of FIGS. **1**A and **1**B.
- (49) The clamp transistor **302** includes a drain (D) terminal, a gate (G) terminal, a source(S) terminal, and a body. The diode circuit **304** includes a clamp reference terminal **306** and a circuit terminal **308**. In the clamp transistor **302**, the drain (D) terminal is connected to a switching voltage (Vsw) terminal. The gate (G) terminal is connected to a clamp voltage control (Vc) terminal **312**, and the source(S) terminal and the body are connected to the circuit terminal **308** of the diode circuit **304**. The clamp reference terminal **306** of the diode circuit **304** is connected to a well bias voltage clamp (Vclamp) terminal **314**.
- (50) The voltage at the well bias voltage clamp (Vclamp) terminal **314** represents the clamp level of the well bias voltage in the PW region **154** (FIGS. **1**A and **1**B). The voltage at the clamp voltage control (Vc) terminal **312** is approximately equal to the voltage at the well bias voltage clamp (Vclamp) terminal **314**. The PW bias voltage (e.g., the PW bias voltage waveform **320** of FIG. **3**B) follows the switching voltage (Vsw) responsive to the clamp transistor **302** turning on when the switching voltage (Vsw) is below the clamp voltage (Vc) minus the threshold voltage of the clamp transistor **302** (Vc–Vth).
- (51) To prevent the diode circuit **304** from turning on and electrical current flowing into the well bias voltage clamp (Vclamp) terminal **314** through the diode circuit **304** while the clamp transistor **302** is turned on, the voltage at the well bias voltage clamp (Vclamp) terminal **314** is not to be smaller than the clamp voltage (Vc) minus the threshold voltage of the clamp transistor **302** minus one diode voltage drop (e.g., Vc–Vth–one diode voltage drop). Responsive to the switching voltage (Vsw) increasing above the clamp voltage (Vc) minus the threshold voltage of the clamp transistor **302** (Vc–Vth), the clamp transistor **302** turns off and the PW bias voltage (e.g., the PW bias voltage waveform **320**) enters into a floating state. In such instances, the voltage at the voltage clamp (Vclamp) terminal **314** keeps the PW bias voltage (e.g., the PW bias voltage waveform **320**) from increasing above Vclamp plus one diode voltage drop (e.g., the bias clamp voltage level **322**

of FIG. 3B). (52) The clamp voltage (Vc) is determined by considering the gate-to-source voltage (Vgs) breakdown voltage of the clamp transistor **302**. Responsive to the switching voltage (Vsw) becoming the most negative voltage, the PW bias voltage (e.g., the PW bias voltage waveform 320) becomes equal to the switching voltage (Vsw) and Vgs=(Vc-PW)=(Vc-Vsw). Since there is a voltage rating for the Vgs of the clamp transistor **302**, Vc–Vsw is not to exceed that rating. (53) FIG. **3**B is an example PW bias voltage waveform **320** of voltage clamping generated by the PW voltage clamp circuit **300** of FIG. **3**A to control a p-type well bias in, for example, the PW region **154** (FIGS. **1**A and **1**B). The PW bias voltage waveform **320** shows how setting the voltage at the clamp voltage control (Vc) terminal **312** of FIG. **3**A for the PW voltage clamp circuit **300** causes the well bias voltage at the PW region **154** to remain below a bias clamp voltage level **322** and be clamped or limited to the bias clamp voltage level 322, even when the voltage level of a switching voltage (Vsw) **324** exceeds the bias clamp voltage level **322**. (54) For example, responsive to the Vsw voltage level **324** decreases to a voltage below the bias clamp voltage level **322**, the voltage at the drain (D) terminal of the clamp transistor **302** decreases causing the clamp transistor **302** to switch to an on state to generate a voltage bias below the bias clamp voltage level 322 in a PW region (e.g., the PW region 154 of FIGS. 1A and 1B). Since the clamp transistor **302** is switched to an on state, the PW voltage clamp circuit **300** allows the well bias voltage in the PW region 154 to follow the Vsw voltage level 324 below the bias clamp voltage level 322 as shown by the PW bias voltage waveform 320. However, responsive to the Vsw voltage level **324** increasing to a voltage above the bias clamp voltage level **322**, the diode circuit **304** of the PW voltage clamp circuit **300** clamps the well bias voltage of the PW region **154** at or approximately at the bias clamp voltage level 322. This is based on the clamp transistor 302 turning off after the Vsw voltage level **324** increases at the drain (D) terminal of the clamp transistor **302** above the bias clamp voltage level **322** and toward a highest voltage (e.g., toward a positive voltage if the Vc terminal **312** and the Vclamp terminal **314** are tied to ground). (55) In this manner, the PW voltage clamp circuit **300** can be used to limit or clamp the well bias voltage for the PW region 154. This prevents or substantially reduces the likelihood of switching on the parasitic NPN transistor **150** and the parasitic PNP transistor **166** (FIG. **1**A), even if an isolation voltage (Viso) (e.g., the Viso supply **160** of FIG. **1**A) is shorted to ground. In some examples, the clamping of the well bias voltage is approximated to be at the bias clamp voltage level 322 offset by a threshold voltage (Vth) of a transistor and/or offset by a forward drop voltage of a diode due to transistor and/or diode characteristics of the PW voltage clamp circuit **300**. (56) In examples described herein, to control the amount of well bias voltage in the PW region **154**, the voltage at the clamp voltage control (Vc) terminal 312 can be set to any suitable (e.g., selected or target) voltage as long as the voltage at the well bias voltage clamp (Vclamp) terminal **314** is not smaller than the clamp voltage (Vc) minus the threshold voltage of the clamp transistor 302 minus one diode voltage drop (e.g., Vc-Vth-one diode voltage drop). In some examples, the voltage at the clamp voltage control (Vc) terminal **312** can be statically set for the PW voltage clamp circuit **300** by connecting the clamp voltage control (Vc) terminal **312** to a fixed voltage level to limit or clamp the well bias voltage at the PW region **154** to a fixed maximum level. For example, the clamp voltage control (Vc) terminal **312** is connected to ground so that the maximum well bias voltage is ground (e.g., 0V). Alternatively, the clamp voltage control (Vc) terminal 312 may be connected to any other suitable fixed voltage level to limit or clamp the well bias voltage generated by the PW voltage clamp circuit **300** at that voltage level. In other examples, the voltage at the clamp voltage control (Vc) terminal **312** is dynamically changed by connecting the clamp voltage control (Vc) terminal **312** to a gate voltage controller such as the gate voltage controller **172** of FIG. **1**B. In such examples, the maximum well bias voltage generated by the PW voltage clamp circuit 300 is controlled by the gate voltage controller.

(57) FIG. 4A is an example N-well (NW) voltage clamp circuit 400 to control well bias voltage in

the NW region **152** of the semiconductor device **106** of FIGS. **1**A and **1**B. For example, the NW voltage clamp circuit **400** replaces the PW voltage clamp circuit **104** in the example circuits of FIGS. **1**A and **1**B as described below in connection with FIGS. **9-12** to control a well bias voltage in the NW region **152** and/or the NBL region **156**, which is also an NW region. The NW voltage clamp circuit **400** includes a clamp transistor **402** and a diode circuit **404**. The clamp transistor **402** is a PFET transistor. The clamp transistor **402** includes a drain (D) terminal, a gate (G) terminal, a source(S) terminal, and a body. The diode circuit **404** includes a clamp reference terminal **406** and a circuit terminal **408**. In the clamp transistor **402**, the drain (D) terminal is connected to a switching voltage (Vsw) terminal. The gate (G) terminal is connected to a clamp voltage control (Vc) terminal **412**, and the source(S) terminal and the body are connected to the circuit terminal **408** of the diode circuit **404**. The clamp reference terminal **406** of the diode circuit **404** is connected to a well bias voltage clamp (Vclamp) terminal **414**.

- (58) The voltage at the well bias voltage clamp (Vclamp) terminal **414** represents the clamp level of the well bias voltage in the NW region **152**. The voltage at the clamp voltage control (Vc) terminal **412** is approximately equal to the voltage at the well bias voltage clamp (Vclamp) terminal **414**. The NW bias voltage (e.g., the NW bias voltage waveform **420** of FIG. **4B**) follows the switching voltage (Vsw) responsive to the clamp transistor **402** turning on when the switching voltage (Vsw) is above the clamp voltage (Vc) plus the threshold voltage of the clamp transistor **402** (e.g., Vc+Vth). To prevent the diode circuit **404** from turning on and electrical current flowing into the well bias voltage clamp (Vclamp) terminal **414** through the diode circuit **404** while the clamp transistor **402** is turned on, the voltage at the well bias voltage clamp (Vclamp) terminal **414** is not to be greater than the clamp voltage (Vc) plus the threshold voltage of the clamp transistor **402** plus one diode voltage drop (e.g., Vc+Vth+one diode voltage drop).
- (59) Responsive to the switching voltage (Vsw) dropping below the clamp voltage (Vc) plus the threshold voltage of the clamp transistor **402** (Vc+Vth), the clamp transistor **402** turns off and the NW bias voltage (e.g., the NW bias voltage waveform **420**) enters into a floating state. In such instances, the voltage at the voltage clamp (Vclamp) terminal **414** keeps the NW bias voltage (e.g., the NW bias voltage waveform **420**) from dropping below Vclamp minus one diode voltage drop (e.g., the bias clamp voltage level **422** of FIG. **4B**). The clamp voltage (Vc) is determined by considering the gate-to-source voltage (Vgs) breakdown voltage of the clamp transistor **402**. Responsive to the switching voltage (Vsw) becoming the most positive voltage, the NW bias voltage (e.g., the NW bias voltage waveform **420**) becomes equal to the switching voltage (Vsw) and Vgs=(NW-Vc)=(Vsw-Vc). Since there is a voltage rating for the Vgs of the clamp transistor **402**, Vc-Vsw is not to exceed that rating.
- (60) FIG. **4**B is an example NW bias voltage waveform **420** of voltage clamping generated by the NW voltage clamp circuit **400** of FIG. **4**A to control an n-type well bias in, for example, the NW region **152** (FIGS. **1**A and **1**B). The NW bias voltage waveform **420** shows how setting the voltage at the clamp voltage control (Vc) terminal **412** of FIG. **4**A for the NW voltage clamp circuit **400** causes the well bias voltage at the NW region **152** to remain above a bias clamp level **422** and be clamped or limited to the bias clamp level **422**, even when the voltage level of a switching voltage (Vsw) **424** goes below the bias clamp level **422**.
- (61) For example, responsive to the Vsw voltage level **424** increasing to a voltage above the bias clamp voltage level **422**, the voltage at the drain (D) terminal of the clamp transistor **402** increases causing the clamp transistor **402** to switch to an on state. In the on state, the clamp transistor **402** generates a voltage bias above the bias clamp voltage level **422** in an NW region (e.g., the NW region **152** and/or the NBL region **156** (which is also an NW region) of FIGS. **1**A and **1**B). Since the clamp transistor **402** is switched to an on state, the NW voltage clamp circuit **400** allows the well bias voltage in the NW region to follow the Vsw voltage level **424** above the bias clamp voltage level **422** as shown by the NW bias voltage waveform **420**.
- (62) However, responsive to the Vsw voltage level 424 decreasing to a voltage below the bias

clamp voltage level **422**, the diode circuit **404** clamps the well bias voltage of the NW region at or approximately at the bias clamp voltage level **422**. This clamping is responsive to the clamp transistor **402** turning off. The clamp transistor **402** turns off responsive to the Vsw voltage level **424** decreasing at the drain (D) terminal of the clamp transistor **402** below the bias clamp voltage level **422**. For example, the switch off of the clamp transistor **402** is responsive to the Vsw voltage level **424** decreasing toward a lowest voltage (e.g., toward a negative voltage if the Vc terminal **412** and the Vclamp terminal **414** are tied to ground). In this manner, the NW voltage clamp circuit **400** can be used to limit or clamp the well bias voltage for the NW region **152**. This prevents or substantially reduces the likelihood of switching on the parasitic NPN transistor **150** and the parasitic PNP transistor **166** (FIG. **1**A), even if an isolation voltage (Viso) (e.g., the Viso supply **160** of FIG. **1**A) is shorted to ground. In some examples, the clamping of the well bias voltage is approximated to be at the bias clamp voltage level **422** offset by a threshold voltage (Vth) of a transistor and/or offset by a forward drop voltage of a diode due to transistor and/or diode characteristics of the NW voltage clamp circuit **400**.

- (63) In examples described herein, to control the amount of well bias voltage in the NW region **152**, the voltage at the clamp voltage control (Vc) terminal **412** can be set to any suitable (e.g., selected or target) voltage. For example, as long as the voltage at the well bias voltage clamp (Vclamp) terminal **414** is not greater than the clamp voltage (Vc) plus the threshold voltage of the clamp transistor **402** plus one diode voltage drop (e.g., Vc+Vth+one diode voltage drop). In some examples, the voltage at the clamp voltage control (Vc) terminal 412 can be statically set for the NW voltage clamp circuit **400** by connecting the clamp voltage control (Vc) terminal **412** to a fixed voltage level to limit or clamp the well bias voltage at the NW region 152 to a fixed minimum level. For example, the clamp voltage control (Vc) terminal **412** is connected to ground so that the minimum well bias voltage is ground (e.g., 0V). Alternatively, the clamp voltage control (Vc) terminal **412** may be connected to any other suitable fixed voltage level to limit or clamp the well bias voltage generated by the NW voltage clamp circuit **400** at that voltage level. In other examples, the voltage at the clamp voltage control (Vc) terminal 412 can be dynamically changed by connecting the clamp voltage control (Vc) terminal 412 to a gate voltage controller such as the gate voltage controller 172 of FIG. 1B. In such examples, the maximum well bias voltage generated by the NW voltage clamp circuit **400** is controlled by the gate voltage controller. (64) FIG. 5 illustrates the example semiconductor 106 of FIGS. 1A and 1B and the example PW voltage clamp circuit **104** of FIG. **1**A to control well bias in the PW region **154** of the semiconductor device **106**. The example semiconductor **106** includes the substrate **158** which includes the Vboot transistor **146** and the PW region **154** formed thereon. The Vboot transistor **146** is formed in the NW region **152** abutting the PW region **154**. As described above in connection with FIG. 1A, the Vboot transistor 146 is part of the gate driver output stage 144. (65) In FIG. 5, the diode circuit **140** of the example PW voltage clamp circuit **104**, as shown in FIG. **1**A, is implemented using a diode component **502**. The diode component **502** includes an anode (+) terminal and a cathode (-) terminal. In example FIG. 5, the anode (+) terminal of the diode component **502** implements the circuit terminal **308** of the diode circuit **304** as shown in FIG. **3**A, and the cathode (–) terminal of the diode component **502** implements the clamp reference terminal **306** of the diode circuit **304**. The anode (+) terminal is coupled to a P+ tap **504** of the PW region **154**. As used herein, a tap (e.g., a P+ tap, an N+ tap) is an electrically conductive terminal or connection access point in the semiconductor device **106** that allows electrical connectivity to a part of the semiconductor device **106**. For example, a P+ tap allows electrical connectivity to a part of the semiconductor device **106** that includes a p-type semiconductor material. An N+ tap allows electrical connectivity to a part of the semiconductor device **106** that includes an n-type semiconductor material.
- (66) The example PW voltage clamp circuit **104** includes the clamp transistor **142** which includes a drain (D) terminal, a source(S) terminal, a gate (G) terminal, and a body (B). The drain (D)

terminal of the clamp transistor **142** is coupled to a switching voltage (Vsw) supply **508** via a Vsw terminal **512**. The source(S) terminal and the body (B) of the clamp transistor **142** are coupled to the P+ tap **504** of the PW region **154** and to the anode (+) terminal of the diode component **502**. (67) In FIG. **5**, the Vboot transistor **146** includes a source(S) terminal and a body (B), both of which are connected to a bootstrap voltage (Vboot) terminal **514**. Also in FIG. **5**, the drain (D) terminal of the clamp transistor **142** is coupled to the bootstrap voltage (Vboot) terminal **514** via the bootstrap voltage capacitor (Cboot) **116**. The Vboot transistor **146** is shown in FIG. **5** as a p-channel metal-oxide semiconductor (PMOS) transistor. The clamp transistor **142** is shown in FIG. **5** as an n-channel metal-oxide semiconductor (NMOS) transistor.

- (68) However, in other examples, the Vboot transistor **146** and the clamp transistor **142** may be implemented using any other suitable types of transistors.
- (69) In FIG. **5**, the gate (G) terminal of the clamp transistor **142** is coupled to ground. The cathode (–) terminal of the diode component **502** is also coupled to ground. As such, the PW voltage clamp circuit **104** is configured to limit or clamp a well bias voltage for the PW region **154** at ground (e.g., 0 V) as described above in connection with FIG. **3**B. For example, the PW region **154** is biased by an internal voltage generated by the PW voltage clamp circuit **104** to prevent the parasitic transistors **150**, **166** (FIG. **1**A) from being forward biased. Also in FIG. **5**, the NBL region **156**, between the PW region **154** and the substrate **158**, includes an N+ tap **520** coupled to an isolation voltage (Viso) terminal **522** that is coupled to the isolation voltage (Viso) supply **160**. (70) FIG. **6**. is the example semiconductor device **106** of FIGS. **1**A and **1**B and an alternative implementation of the example PW voltage clamp circuit **104** to control well bias in the PW region
- implementation of the example PW voltage clamp circuit **104** to control well bias in the PW region **154** of the semiconductor device **106**. The semiconductor device **106** and the example PW voltage clamp circuit **104** of FIG. **6** are substantially similar in both FIGS. **5** and **6**. For example, the PW voltage clamp circuit **104** is connected to the semiconductor device **106** in FIG. **6** in substantially the same way as described above in connection with FIG. **5**. However, unlike the PW voltage clamp circuit **104** of FIG. **5** which implements the diode circuit **140** shown in FIG. **1**A using a diode component **502**, the PW voltage clamp circuit **104** of FIG. **6** implements the diode circuit **140** shown in FIG. **1**A using a diode-connected transistor **602**. For example, the diode-connected transistor **602** is formed by connecting a gate (G) terminal, a source(S) terminal, and a body (B) of the diode-connected transistor **602** to one another. In this manner, the diode-connected transistor **602** forms a p-n junction diode.
- (71) In FIG. **6**, the gate (G) terminal, the source(S) terminal, and the body (B) of the diodeconnected transistor **602** form an anode (+) terminal connected to the source(S) terminal and the body (B) of the clamp transistor **142** and to the PW region **154** via the P+ tap **504**. In addition, the drain (D) terminal of the diode-connected transistor **602** forms a cathode (-) terminal that is connected to ground. As such, the anode (+) terminal (e.g., the gate (G) terminal, source(S) terminal, and body (B) connected to one another) of the diode-connected transistor **602** is equivalent to the circuit terminal **308** of the diode-connected transistor **602** is equivalent to the clamp reference terminal **306** of the diode circuit **304**.
- (72) In some implementations, a diode-connected transistor such as the diode-connected transistor **602** may be preferable over a diode component because a transistor may be more readily available for fabricating in a semiconductor device using a particular manufacturing process. For example, a particular semiconductor device manufacturing process may not be able to form a diode component in a semiconductor device due to limitations of that fabrication process but is able to form transistors. In addition, a transistor can be implemented using a smaller semiconductor area (e.g., a smaller footprint) than a diode. In addition, a diode may create unwanted parasitic electrical effects that are not created by a diode-connected transistor.
- (73) FIG. **7** is the example semiconductor device **106** and the example PW voltage clamp circuit **104** of FIGS. **1**A and **1**B connected to a gate voltage controller **172***a* which is an example

implementation of the gate voltage controller **172** of FIG. **1**B. The PW voltage clamp circuit **104** is connected to the semiconductor device **106** in FIG. **7** in substantially the same way as described above in connection with FIG. **5**. The gate voltage controller **172***a* may be used to accommodate more negative output voltages of the PW voltage clamp circuit **104** and control well bias in the PW region **154** of the semiconductor device **106**.

- (74) The semiconductor device **106** and the example PW voltage clamp circuit **104** of FIG. **7** are substantially similar in both FIGS. **5** and **7**. However, unlike the PW voltage clamp circuit **104** of FIG. **5** in which the gate (G) terminal of the clamp transistor **142** is connected to ground, the gate (G) terminal of the clamp transistor **142** of FIG. **7** is connected to the gate voltage controller **172**a. In this manner, the gate voltage controller **172**a enables dynamically controlling a voltage range of the PW voltage clamp circuit **104**. For example, the gate voltage controller **172**a can be used to control a gate voltage at the gate (G) terminal of the clamp transistor **142** to accommodate more negative output voltages for a PW voltage bias in a negative voltage domain of the PW region **154**. This is to ensure or increase the likelihood that the voltage in the PW region **154** remains less than or equal to the voltage in the NW region **152**. However, to prevent a parasitic diode between the substrate **158** and the NBL region **156** from turning on, the voltage level in the NBL region **156** is not to be one diode voltage drop below ground.
- (75) In FIG. 7, the gate voltage controller **172***a* includes a first gate voltage control transistor **702** (e.g., an NFET transistor) and a second gate voltage control transistor **704** (e.g., an NFET transistor). The first gate voltage control transistor **702** includes a drain (D) terminal, a source(S) terminal, and a gate (G) terminal. The gate (G) terminal of the first gate voltage control transistor **702** is coupled to ground and the drain (D) terminal of the first gate voltage control transistor **702** is coupled to a low-side gate driver voltage (VLS) terminal **706***a*. The second gate voltage control transistor **704** includes a drain (D) terminal, a source(S) terminal, and a gate (G) terminal. The gate (G) terminal of the second gate voltage control transistor **704** is coupled to a low-side gate driver voltage (VLS) terminal **706***b*. The drain (D) terminal of the second gate voltage control transistor **704** is coupled to ground. The source(S) terminal of the second gate voltage control transistor **704** and the source(S) terminal of the first gate voltage control transistor **702** are coupled to the gate (G) terminal of the clamp transistor **142** of the PW voltage clamp circuit **104**.
- (76) The low-side gate driver voltage (VLS) is generated to maintain a certain voltage within the voltage rating of the LS gate driving circuit 108 (FIG. 1A) relative to the negative output voltage (Vout) of the voltage converter circuit 100. Because the output voltage (Vout) does not vary with the switching voltage (Vsw), which is switching at a switching frequency, the low-side gate driver voltage (VLS) is relatively constant compared to the switching voltage (Vsw). For example, a switching converter (e.g., an inverting buck-boost (IBB) voltage converter) has a switching frequency of, for example, 1 megahertz (MHz). As such, it can generate the output voltage (Vout) by switching at 1 MHz. The output voltage (Vout) is to be stable since it is a regulated voltage. When the output voltage (Vout) is programmed to a different voltage, the IBB voltage converter will try to adjust the output voltage (Vout) and finally settle down to the new output voltage (Vout). In the meantime, to guarantee the voltage ratings of devices in the LS gate driving circuit 108 sitting on the voltage output (Vout) domain, the low-side gate driver voltage (VLS) is defined and generated relative to the voltage output (Vout).
- (77) If the LS gate driving circuit **108** is composed of 5V devices, the low-side gate driver voltage (VLS) is generated to be equal to or less than the voltage output (Vout) plus 5 volts (Vout+5V), where the output voltage (Vout) is a negative voltage. A programming rate of the output voltage (Vout) is much slower than the switching frequency of 1 MHz. In many applications, requiring a constant output voltage (Vout) does not change at all. As such, the low-side gate driver voltage (VLS) does not change either. Because the switching voltage (Vsw) goes negative down to the output voltage (Vout) while switching at 1 MHz, the gate voltage of the clamp transistor **142** is to be protected by defining its gate-to-source voltage (Vgs) within its rating. Because the low-side

gate driver voltage (VLS) is generated relative to the output voltage (Vout) to be safe, the output of the gate voltage controller **172***a* is also generated such that the Vgs of the clamp transistor **142** is protected.

- (78) When the output voltage (Vout) is a very low negative voltage (e.g., $\neg 8V$), the low-side gate driver voltage (VLS) can remain negative (e.g., Vout+5V= $\neg 3V$). This switches on the first gate voltage control transistor **702** while the second gate voltage control transistor **704** turns off, so the output of the gate voltage controller **172***a* becomes $\neg 3V$. When the output voltage (Vout) is a less negative voltage (e.g., $\neg 3V$), the low-side gate driver voltage (VLS) becomes positive (e.g., $\neg 3V + 5V = 2V$). Under this condition, the second gate voltage control transistor **704** turns on and the first gate voltage control transistor **702** turns off. As such, the output of the gate voltage controller **172***a* becomes +2V through the second gate voltage control transistor **704**.
- (79) As shown in FIG. **1B**, the low-side gate driver voltage (VLS) is already available to the LS gate driving circuit **108** of the voltage converter circuit **100** and can be used for the gate voltage controller **172***a*. However, in other implementations, a separately generated voltage can be used in place of the low-side gate driver voltage (VLS) applied to the gate voltage controller **172***a*. In such implementations, the separately generated voltage is to be defined in a manner that protects the Vgs of the clamp transistor **142**. When the output voltage (Vout) of the voltage converter circuit **100** is a more negative voltage (e.g., -8V), the voltage at the well bias voltage clamp (Vclamp) terminal **314** (FIG. **3A**) is to be -3V or below for 5V devices. When the output voltage (Vout) is a less negative voltage like -2V, the voltage at the well bias voltage clamp (Vclamp) terminal **314** is to be +3V or below for 5V devices. The details of the gate voltage controller **172***a* shown in FIG. 7 represent an example of how the gate voltage controller **172***a* may be implemented. In other examples, any other suitable circuit design may be used to implement the gate voltage controller **172***a*.
- (80) FIG. **8** is the example semiconductor device **106** of FIGS. **1**A and **1**B and the alternative example PW voltage clamp circuit **104** of FIG. **6** coupled to the gate voltage controller **172***a* of FIG. **7**. The alternative example PW voltage clamp circuit **104** is to accommodate more negative output voltages and control well bias in the PW region **154** of the semiconductor device **106**. The PW voltage clamp circuit **104** is connected to the semiconductor device **106** in FIG. **8** in substantially the same way as described above in connection with FIG. **5**. For brevity, the circuit details of the gate voltage controller **172***a* described above in connection with FIG. **7** are not repeated here. FIG. **8** illustrates an example of how the gate voltage controller **172***a* may be connected to the gate (G) terminal of the clamp transistor **142** as described above in connection with FIG. **7**. In addition, the source(S) terminal and body (B) of the clamp transistor **142** are connected to the anode (+) terminal of the diode-connected transistor **602** described above in connection with FIG. **6**.
- (81) FIG. **9** is the example semiconductor device **106** of FIGS. **1**A and **1**B and the example NW voltage clamp circuit **400** of FIG. **4**A to control well bias in an n-type well region (e.g., the NBL region **156**) of the semiconductor device **106**. The example semiconductor **106** includes the substrate **158** which includes the Vboot transistor **146** and the NBL region **156** formed thereon. The NBL region **156** is an NW region (e.g., having a similar n-type semiconductor material as the NW region **152**). The Vboot transistor **146** is part of the gate driver output stage **144** (FIG. **1**A). (82) In FIG. **9**, the diode circuit **404** of the example NW voltage clamp circuit **400**, as shown in FIG. **4**A, is implemented using a diode component **902**. The diode component **902** includes a cathode (–) terminal and an anode (+) terminal. In example FIG. **9**, the cathode (–) terminal of the diode component **902** implements the circuit terminal **408** of the diode circuit **404** as shown in FIG. **4**A. The anode (+) terminal of the diode component **902** implements the clamp reference terminal **406** of the diode circuit **404**. The anode (+) terminal is coupled to ground, and the cathode (–) terminal is coupled to an N+ tap **904** of the NBL region **156**. As used herein, a tap (e.g., a P+ tap, an N+ tap) is an electrically conductive terminal or connection access point in the semiconductor

- device **106** that allows electrical connectivity to a part of the semiconductor device **106**. For example, a P+ tap allows electrical connectivity to a part of the semiconductor device **106** that includes a p-type semiconductor material. An N+ tap allows electrical connectivity to a part of the semiconductor device **106** that includes an n-type semiconductor material.
- (83) The example NW voltage clamp circuit **400** includes the clamp transistor **402** which includes a drain (D) terminal, a source(S) terminal, a gate (G) terminal, and a body (B). The drain (D) terminal of the clamp transistor **402** is coupled to the switching voltage (Vsw) supply **508** via the Vsw terminal **512**. The source(S) terminal and the body (B) of the clamp transistor **402** are coupled to the N+ tap **904** of the NBL region **156** and to the cathode (–) terminal of the diode component **002**.
- (84) In FIG. **9**, the Vboot transistor **146** includes a source(S) terminal and a body (B), both of which are connected to the bootstrap voltage (Vboot) terminal **514**. Also in FIG. **9**, the drain (D) terminal of the clamp transistor **402** is coupled to the bootstrap voltage (Vboot) terminal **514** via the bootstrap voltage capacitor (Cboot) **116**. The Vboot transistor **146** is shown in FIG. **9** as a p-channel metal-oxide semiconductor (PMOS) transistor and the clamp transistor **402** is shown in FIG. **9** as a p-channel metal-oxide semiconductor (PMOS) transistor. However, in other examples, the Vboot transistor **146** and the clamp transistor **402** may be implemented using any other suitable types of transistors.
- (85) In FIG. **9**, the gate (G) terminal of the clamp transistor **402** is coupled to ground. The anode (+) terminal of the diode component **902** is also coupled to ground. As such, the NW voltage clamp circuit **400** is configured to limit or clamp a well bias voltage for the NBL region **156** at ground (e.g., 0 V) as described above in connection with FIG. **4B**. For example, the NBL region **156** is biased by an internal voltage generated by the NW voltage clamp circuit **400** to prevent the parasitic transistors **150**, **166** (FIG. **1**A) from being forward biased. Also in FIG. **9**, the NBL region **156**, between the PW region **154** and the substrate **158**, includes an N+ tap **520** coupled to an isolation voltage (Viso) terminal **522** that is coupled to the isolation voltage (Viso) supply **160** (FIG. **5**).
- (86) FIG. 10 is the example semiconductor device 106 of FIGS. 1A and 1B and an alternative implementation of the example NW voltage clamp circuit 400 of FIG. 4A to control well bias in an n-type well region (e.g., the NBL region 156) of the semiconductor device 106. The semiconductor device 106 and the example NW voltage clamp circuit 400 of FIG. 10 are substantially similar in both FIGS. 9 and 10. For example, the NW voltage clamp circuit 400 is connected to the semiconductor device 106 in FIG. 10 in substantially the same way as described above in connection with FIG. 9. However, unlike the NW voltage clamp circuit 400 of FIG. 9 which implements the diode circuit 404 shown in FIG. 4A using a diode component 902, the NW voltage clamp circuit 400 of FIG. 10 implements the diode circuit 404 shown in FIG. 4A using a diode-connected transistor 1002. For example, the diode-connected transistor 1002 is formed by connecting a gate (G) terminal, a source(S) terminal, and a body (B) of the diode-connected transistor 1002 forms a p-n junction diode.
- (87) In FIG. **10**, the drain (D) terminal of the diode-connected transistor **1002** forms a cathode (–) terminal that is connected to the source(S) terminal and the body (B) of the clamp transistor **402** and to the NBL region **156** via the N+ tap **904**. In addition, the gate (G) terminal, the source(S) terminal, and the body (B) of the diode-connected transistor **1002** form an anode (+) terminal connected to ground. As such, the anode (+) terminal (e.g., the gate (G) terminal, source(S) terminal, and body (B) connected to one another) of the diode-connected transistor **1002** is equivalent to the clamp reference terminal **406** of the diode circuit **404** shown in FIG. **4**A, and the cathode (–) (e.g., the drain (D) terminal) of the diode-connected transistor **1002** is equivalent to the circuit terminal **408** of the diode circuit **404**.
- (88) In some implementations, a diode-connected transistor such as the diode-connected transistor

- **1002** may be preferable over a diode component because a transistor may be more readily available for fabricating in a semiconductor device using a particular manufacturing process. For example, a particular semiconductor device manufacturing process may not be able to form a diode component in a semiconductor device due to limitations of that fabrication process but is able to form transistors. In addition, a transistor can be implemented using a smaller semiconductor area (e.g., a smaller footprint) than a diode. In addition, a diode may create unwanted parasitic electrical effects that are not created by a diode-connected transistor.
- (89) FIG. **11** is the example semiconductor device **106** of FIGS. **1**A and **1**B and the example NW voltage clamp circuit **400** of FIG. **9** coupled to a gate voltage controller **172***b*. The gate voltage controller **172***b* of FIG. **11** is an alternative implementation of the gate voltage controller **172** of FIG. **1**B. The gate voltage controller **172***b* is to accommodate more positive output voltages and control well bias in a positive voltage domain of an n-type well region (e.g., the NBL region **156**) of the semiconductor device **106**. This ensures or increases the likelihood that the voltage of the n-type well region (e.g., the NBL region **156**) remains greater than or equal to the voltage in the PW region **154**. However, to prevent a parasitic diode between the substrate **158** and the NBL region **156** from turning on, the voltage level in the NBL region **156** is not to be one diode voltage drop below ground.
- (90) The NW voltage clamp circuit **400** is connected to the semiconductor device **106** in FIG. **11** in substantially the same way as described above in connection with FIG. 9. The gate voltage controller **172***b* illustrated in FIG. **11** is used for positive domain switching voltage converters like boost voltage converters. For example, the gate voltage controller **172***b* of FIG. **11** may be used to accommodate more positive output voltages of the NW voltage clamp circuit 400 and control well bias in the NBL region **156** of the semiconductor device **106**. The semiconductor device **106** and the example NW voltage clamp circuit **400** of FIG. **11** are substantially similar in both FIGS. **9** and **11**. However, unlike the NW voltage clamp circuit **400** of FIG. **9** in which the gate (G) terminal of the clamp transistor **402** is connected to ground, the gate (G) terminal of the clamp transistor **402** of FIG. **11** is connected to the gate voltage controller **172***b*. In this manner, the gate voltage controller **172***b* enables dynamically controlling a voltage range of the NW voltage clamp circuit **400**. For example, the gate voltage controller **172***b* can be used to control a gate voltage at the gate (G) terminal of the clamp transistor **402** to accommodate more positive output voltages for an NW voltage bias of the NBL region 156 (and more negative output voltages for a PW voltage bias of the PW region **154** in connection with the examples of FIGS. **7** and **8** described above). (91) In FIG. 11, the gate voltage controller 172b includes a first gate voltage control transistor 1102 (e.g., a PFET transistor) and a second gate voltage control transistor **1104** (e.g., a PFET transistor). The first gate voltage control transistor **1102** includes a drain (D) terminal, a source(S) terminal, and a gate (G) terminal. The gate (G) terminal of the first gate voltage control transistor **1102** is coupled to ground. The source(S) terminal of the first gate voltage control transistor **1102** is coupled to a high-side gate driver voltage (VHS) terminal **1106***a*. The second gate voltage control transistor **1104** includes a drain (D) terminal, a source(S) terminal, and a gate (G) terminal. The gate (G) terminal of the second gate voltage control transistor **1104** is coupled to a high-side gate driver voltage (VHS) terminal **1106***b*. The source(S) terminal of the second gate voltage control transistor **1104** is coupled to ground. The drain (D) terminal of the second gate voltage control transistor **1104** and the drain (D) terminal of the first gate voltage control transistor **1102** are coupled to the gate (G) terminal of the clamp transistor **402** of the NW voltage clamp circuit **400**. (92) The high-side gate driver voltage (VHS) is generated to maintain a certain voltage within the voltage rating of a HS gate driving circuit such as the gate driving circuit **102** (FIG. **1**A) relative to the positive output voltage (Vout) of the voltage converter circuit **100**. Because the output voltage (Vout) does not vary with the switching voltage (Vsw), which is switching at a switching frequency, the high-side gate driver voltage (VHS) is relatively constant compared to the switching voltage (Vsw). For example, a switching converter (e.g., a boost voltage converter) has a switching

- frequency of, for example, 1 megahertz (MHz). As such, it can generate the output voltage (Vout) by switching at 1 MHz. The output voltage (Vout) is to be stable since it is a regulated voltage. When the output voltage (Vout) is programmed to a different voltage, the boost voltage converter will try to adjust the output voltage (Vout) and finally settle down to the new output voltage (Vout). In the meantime, to guarantee the voltage ratings of devices in the HS gate driving circuit **102** sitting on the voltage output (Vout) domain, the high-side gate driver voltage (VHS) is defined and generated relative to the voltage output (Vout).
- (93) If the HS gate driving circuit **102** is composed of 5V devices, the high-side gate driver voltage (VHS) is generated to be equal to or greater than the voltage output (Vout) minus 5 volts (Vout-5V), where the output voltage (Vout) is a positive voltage. A programming rate of the output voltage (Vout) is much slower than the switching frequency of 1 MHz. In many applications, requiring a constant output voltage (Vout) does not change at all. As such, the high-side gate driver voltage (VHS) does not change either. Because the switching voltage (Vsw) goes positive up to the output voltage (Vout) while switching at 1 MHz, the gate voltage of the clamp transistor **402** is to be protected by defining its gate-to-source voltage (Vgs) within its rating. Because the high-side gate driver voltage (VHS) is generated relative to the output voltage (Vout) to be safe, the output of the gate voltage controller **172***b* is also generated such that the Vgs of the clamp transistor **402** is protected.
- (94) When the output voltage (Vout) is a very high positive voltage (e.g., 8V), the high-side gate driver voltage (VHS) can remain positive (e.g., Vout-5V=3V). This switches on the first gate voltage control transistor **1102** while the second gate voltage control transistor **1104** turns off, so the output of the gate voltage controller **172***b* becomes 3V. When the output voltage (Vout) is a less positive voltage (e.g., 3V), the high-side gate driver voltage (VHS) becomes negative (e.g., 3V-5V=-2V). Under this condition, the second gate voltage control transistor **1104** turns on and the first gate voltage control transistor **1102** turns off. As such, the output of the gate voltage controller **172***b* becomes -2V through the second gate voltage control transistor **1104** which drives the gate (G) terminal of the clamp transistor **402** to ground.
- (95) In high voltage boost converters, an internal floating voltage rail can be used for the high-side gate driver voltage (VHS) terminals **1106***a*,*b*. Using a high-side gate driver voltage (VHS) provides flexibility for the gate voltage controller **172***b* to support a wider voltage range. For example, the gate-to-source voltage (Vgs) for the clamp transistor **402** in the NW voltage clamp circuit **400** is protected by the high-side gate driver voltage (VHS) when the switching voltage (Vsw) rises to the output voltage (Vout) (which could exceed the voltage rating if the gate (G) terminal of the clamp transistor **402** were grounded). Accordingly, the high-side gate driver voltage (VHS) is kept at a level that is greater than or equal to the output voltage (Vout) minus the voltage rating of the clamp transistor **402** (e.g., VHS>=(Vout–voltage rating of clamp transistor **402**)).
- (96) However, in other implementations, a separately generated voltage can be used in place of the high-side gate driver voltage (VHS) applied to the gate voltage controller **172***b*. In such implementations, the separately generated voltage is to be defined in a manner that protects the Vgs of the clamp transistor **402**. When the output voltage (Vout) of the voltage converter circuit **100** is a more positive voltage (e.g., 8V), the voltage at the well bias voltage clamp (Vclamp) terminal **414** (FIG. **4**A) is to be 3V or above for 5V devices. When the output voltage (Vout) is a less positive voltage like 2V, the voltage at the well bias voltage clamp (Vclamp) terminal **414** is to be −3V or above for 5V devices. The details of the gate voltage controller **172***b* shown in FIG. **11** represent an example of how the gate voltage controller **172***b* may be implemented. In other examples, any other suitable circuit design may be used to implement the gate voltage controller **172***b*. (97) FIG. **12** is the example semiconductor device **106** of FIGS. **1**A and **1**B and the alternative
- example NW voltage clamp circuit **400** of FIG. **10** coupled to the gate voltage controller **172***b* of FIG. **11**. The alternative example NW voltage clamp circuit **400** is to accommodate more positive output voltages and control well bias in an n-type well region (e.g., the NBL region **156**) of the

semiconductor device **106**. The NW voltage clamp circuit **400** is connected to the semiconductor device **106** in FIG. **12** in substantially the same way as described above in connection with FIG. **9**. For brevity, the circuit details of the gate voltage controller **172***b* described above in connection with FIG. **11** are not repeated here. FIG. **12** illustrates an example of how the gate voltage controller **172***b* may be connected to the gate (G) terminal of the clamp transistor **402** as described above in connection with FIG. **11**. In addition, the source(S) terminal and body (B) of the clamp transistor **402** are connected to the cathode (–) terminal of the diode-connected transistor **1002** described above in connection with FIG. **10**.

- (98) FIG. 13 is a flowchart of the operation of the example PW voltage clamp circuit 104 of FIGS. 1A, 1B, 3A, and 5-8 to control well bias in a p-type well region (e.g., the PW region 154) of the semiconductor device 106. At block 1302, a switching voltage (Vsw) decreases to a voltage below a bias clamp voltage level. For example, the Vsw supply 508 of FIGS. 5-8 decreases to a voltage below the bias clamp voltage level 322 of FIG. 3B. This decreases the voltage at the drain (D) terminal of the clamp transistor 142 (FIGS. 5-8) causing the clamp transistor 142 to switch to an on state. Responsive to being in the on state, the clamp transistor 142 generates a voltage bias below the bias clamp voltage level 322 in the PW region 154. If the bias clamp voltage level 322 is ground, the Vsw supply 508 of FIGS. 5-8 decreases to a negative voltage below the bias clamp voltage level 322 to generate a negative voltage bias in the PW region 154.
- (99) At block **1304**, a PW region follows the Vsw voltage level to a lowest voltage. For example, because the clamp transistor **142** is switched to an on state, the PW voltage clamp circuit **104** allows the well bias voltage in the PW region **154** of FIGS. **5-8** to follow the Vsw voltage level. Accordingly, the well bias voltage follows the Vsw voltage level below the bias clamp voltage level 322 as shown by the PW bias voltage waveform 320 of FIG. 3B. At block 1306, the Vsw voltage level increases to a voltage above the bias clamp voltage level **322**. For example, if the bias clamp voltage level **322** is ground, the Vsw supply **508** increases to a positive voltage above the bias clamp voltage level **322**. At block **1308**, the well bias voltage of the PW region **154** increases, following the Vsw voltage level but is clamped at the bias clamp voltage level **322**. For example, the PW voltage clamp circuit **104** clamps the well bias voltage of the PW region **154** at the bias clamp voltage level 322, as shown by the PW bias voltage waveform 320 of FIG. 3B. The diode circuit **140** of the PW voltage clamp circuit **104** clamps the well bias voltage of the PW region **154** at the bias clamp voltage level **322**. For example, this clamping is responsive to the clamp transistor **142** turning off after the Vsw voltage level of the Vsw supply **508** increases at the drain (D) terminal of the clamp transistor **142** above the bias clamp voltage level **322** and toward a highest voltage (e.g., toward a positive voltage). If power to the PW voltage clamp circuit **104** is not turned off (block **1310**), the process of FIG. **13** starts again at block **1302**. Otherwise, the process of FIG. 13 ends.
- (100) FIG. **14** is a flowchart of the operation of the example NW voltage clamp circuit **400** of FIGS. **4**A and **9-12** to control well bias in an n-type well region (e.g., the NW region **152** and/or the NBL region **156**) of the semiconductor device **106**. At block **1402**, a switching voltage (Vsw) increases to a voltage above a bias clamp voltage level. For example, the Vsw supply **508** of FIGS. **9-12** increases to a voltage above the bias clamp voltage level **422** of FIG. **4B**. This increases the voltage at the drain (D) terminal of the clamp transistor **402** (FIGS. **9-12**) causing the clamp transistor **402** to switch to an on state. Responsive to being in the on state, the clamp transistor **402** generates a voltage bias above the bias clamp voltage level **422** in the NBL region **156**. If the bias clamp voltage level **422** is ground, the Vsw supply **508** of FIGS. **9-12** increases to a positive voltage above the bias clamp voltage level **422** to generate a positive voltage bias in the NBL region **156**.
- (101) At block **1404**, an NW region follows the Vsw voltage level to a highest voltage. For example, because the clamp transistor **402** is switched to an on state, the NW voltage clamp circuit **400** allows the well bias voltage in the NBL region **156** of FIGS. **9-12** to follow the Vsw voltage

level. Accordingly, the well bias voltage follows the Vsw voltage level above the bias clamp voltage level **422** as shown by the NW bias voltage waveform **420** of FIG. **4B**. At block **1406**, the Vsw voltage level decreases to a voltage below the bias clamp voltage level **422**. For example, if the bias clamp voltage level **422** is ground, the Vsw supply **508** decreases to a negative voltage below the bias clamp voltage level **422**. At block **1408**, the well bias voltage of the NW region (e.g., the NBL region **156**) decreases, following the Vsw voltage level but is clamped at the bias clamp voltage level **422**. For example, the NW voltage clamp circuit **400** clamps the well bias voltage of the NBL region **156** at the bias clamp voltage level **422**, as shown by the NW bias voltage waveform **420** of FIG. **4B**. The diode circuit **404** of the NW voltage clamp circuit **400** clamps the well bias voltage of the NBL region **156** at the bias clamp voltage level **422**. For example, this clamping is responsive to the clamp transistor **402** turning off after the Vsw voltage level of the Vsw supply **508** decreases at the drain (D) terminal of the clamp transistor **402** below the bias clamp voltage level **422** and toward a lowest voltage (e.g., toward a negative voltage). If power to the NW voltage clamp circuit **400** is not turned off (block **1410**), the process of FIG. **14** starts again at block **1402**. Otherwise, the process of FIG. **14** ends.

(102) "Including" and "comprising" (and all forms and tenses thereof) are used herein to be open ended terms. Thus, whenever a claim employs any form of "include" or "comprise" (e.g., comprises, includes, comprising, including, having, etc.) as a preamble or within a claim recitation of any kind, it is to be understood that additional elements, terms, etc., may be present without falling outside the scope of the corresponding claim or recitation. As used herein, when the phrase "at least" is used as the transition term in, for example, a preamble of a claim, it is open-ended in the same manner as the term "comprising" and "including" are open ended. The term "and/or" when used, for example, in a form such as A, B, and/or C refers to any combination or subset of A, B, C such as (1) A alone, (2) B alone, (3) C alone, (4) A with B, (5) A with C, (6) B with C, or (7) A with B and with C. As used herein in the context of describing structures, components, items, objects and/or things, the phrase "at least one of A and B" is intended to refer to implementations including any of (1) at least one A, (2) at least one B, or (3) at least one A and at least one B. Similarly, as used herein in the context of describing structures, components, items, objects and/or things, the phrase "at least one of A or B" is intended to refer to implementations including any of (1) at least one A, (2) at least one B, or (3) at least one A and at least one B. As used herein in the context of describing the performance or execution of processes, instructions, actions, activities and/or steps, the phrase "at least one of A and B" is intended to refer to implementations including any of (1) at least one A, (2) at least one B, or (3) at least one A and at least one B. Similarly, as used herein in the context of describing the performance or execution of processes, instructions, actions, activities and/or steps, the phrase "at least one of A or B" is intended to refer to implementations including any of (1) at least one A, (2) at least one B, or (3) at least one A and at least one B.

(103) As used herein, singular references (e.g., "a", "an", "first", "second", etc.) do not exclude a plurality. The term "a" or "an" object, as used herein, refers to one or more of that object. The terms "a" (or "an"), "one or more", and "at least one" are used interchangeably herein. Furthermore, although individually listed, a plurality of means, elements, or actions may be implemented by, e.g., the same entity or object. Also, although individual features may be included in different examples or claims, these may possibly be combined, and the inclusion in different examples or claims does not imply that a combination of features is not feasible and/or advantageous.

(104) In this description, the term "and/or" (when used in a form such as A, B and/or C) refers to any combination or subset of A, B, C, such as: (a) A alone; (b) B alone; (c) C alone; (d) A with B; (e) A with C; (f) B with C; and (g) A with B and with C. Also, as used herein, the phrase "at least one of A or B" (or "at least one of A and B") refers to implementations including any of: (a) at least one A; (b) at least one B; and (c) at least one A and at least one B.

- (105) In this description, the term "couple" may cover connections, communications, or signal paths that enable a functional relationship consistent with this description. For example, if device A generates a signal to control device B to perform an action: (a) in a first example, device A is coupled to device B by direct connection; or (b) in a second example, device A is coupled to device B through intervening component C does not alter the functional relationship between device A and device B, such that device B is controlled by device A via the control signal generated by device A.
- (106) Numerical identifiers such as "first", "second", "third", etc. are used merely to distinguish between elements of substantially the same type in terms of structure and/or function. These identifiers, as used in the detailed description, do not necessarily align with those used in the claims.
- (107) A device which is "configured to" perform a task or function may be configured (e.g., programmed and/or hardwired) at a time of manufacturing by a manufacturer to perform the function and/or may be configurable (or reconfigurable) by a user after manufacturing to perform the function and/or other additional or alternative functions. The configuring may be through firmware and/or software programming of the device, through a construction and/or layout of hardware components and interconnections of the device, or a combination thereof.
- (108) As used herein, the terms "terminal", "node", "interconnection", "pin", and "lead" are used interchangeably. Unless specifically stated to the contrary, these terms are generally used to mean an interconnection between or a terminus of a device element, a circuit element, an integrated circuit, a device or other electronics or semiconductor component.
- (109) A circuit or device which is described herein as including certain components may instead be adapted to be coupled to those components to form the described circuitry or device. For example, a structure described as including one or more semiconductor elements (such as transistors), one or more passive elements (such as resistors, capacitors, and/or inductors), and/or one or more sources (such as voltage and/or current sources) may instead include only the semiconductor elements within a single physical device (e.g., a semiconductor die and/or integrated circuit (IC) package) and may be adapted to be coupled to at least some of the passive elements and/or the sources to form the described structure either at a time of manufacture or after a time of manufacture, for example, by an end-user and/or a third-party.
- (110) Circuits described herein are reconfigurable to include the replaced components to provide functionality at least partially similar to functionality available prior to the component replacement. Components shown as resistors, unless otherwise stated, are generally representative of any one or more elements coupled in series and/or parallel to provide an amount of impedance represented by the shown resistor. For example, a resistor or capacitor shown and described herein as a single component may instead be multiple resistors or capacitors, respectively, coupled in parallel between the same nodes. For example, a resistor or capacitor shown and described herein as a single component may instead be multiple resistors or capacitors, respectively, coupled in series between the same two nodes as the single resistor or capacitor. While certain elements of the described examples are included in an integrated circuit and other elements are external to the integrated circuit, in other examples, additional or fewer features may be incorporated into the integrated circuit. In addition, some or all of the features illustrated as being external to the integrated circuit may be included in the integrated circuit and/or some features illustrated as being internal to the integrated circuit may be incorporated outside of the integrated. As used herein, the term "integrated circuit" means one or more circuits that are: (i) incorporated in/over a semiconductor substrate; (ii) incorporated in a single semiconductor package; (iii) incorporated into the same module; and/or (iv) incorporated in/on the same printed circuit board.
- (111) Uses of the phrase "ground" in the foregoing description include a chassis ground, an Earth ground, a floating ground, a virtual ground, a digital ground, a common ground, and/or any other form of ground connection applicable to, or suitable for, the teachings of this description. Unless

otherwise stated, "about," "approximately," or "substantially" preceding a value means+/-10 percent of the stated value, or, if the value is zero, a reasonable range of values around zero. (112) Modifications are possible in the described examples, and other examples are possible, within

the scope of the claims.

(113) From the foregoing, it will be appreciated that example systems, apparatus, articles of manufacture, and methods have been described that substantially reduce or eliminate unwanted p-n junction breakdowns and/or latchups in circuits. Such unwanted p-n junction breakdowns and/or latchups in circuits are substantially reduced or eliminated by described example PW voltage clamping circuits that control well bias voltage in p-type well regions of semiconductor devices and/or described example NW voltage clamping circuits that control well bias voltage in n-type well regions of semiconductor devices. Described systems, apparatus, articles of manufacture, and methods are accordingly directed to one or more improvement(s) in the operation of a machine such as a computer or other electronic and/or mechanical device.

(114) The following claims are hereby incorporated into this Detailed Description by this reference. Although certain example systems, apparatus, articles of manufacture, and methods have been described herein, the scope of coverage of this patent is not limited thereto. On the contrary, this patent covers all systems, apparatus, articles of manufacture, and methods fairly falling within the scope of the claims of this patent.

Claims

- 1. A circuit comprising: a substrate including a first transistor of a gate driver output stage, the substrate including a first well region; a diode circuit including a first terminal and a second terminal, the first terminal coupled to a first tap of the first well region; and a second transistor including a first terminal, a second terminal, and a body, the first terminal of the second transistor coupled to a switching voltage terminal, and the second terminal and the body of the second transistor coupled to the first tap of the first well region and to the first terminal of the diode circuit.
- 2. The circuit of claim 1, wherein the first transistor includes a first terminal and a body, the first terminal and the body coupled to a bootstrap voltage terminal.
- 3. The circuit of claim 1, wherein the first terminal of the second transistor is coupled to a bootstrap voltage terminal via a bootstrap capacitor.
- 4. The circuit of claim 1, wherein the first transistor is a p-channel metal-oxide semiconductor (PMOS) transistor, the second transistor is an n-channel metal-oxide semiconductor (NMOS) transistor.
- 5. The circuit of claim 1, wherein a third terminal of the second transistor is coupled to ground.
- 6. The circuit of claim 1, comprising: a third transistor including a first terminal, a second terminal, and a third terminal, the third terminal of the third transistor coupled to ground, the first terminal of the third transistor coupled to a gate driver voltage terminal; and a fourth transistor including a first terminal, a second terminal, and a third terminal, the third terminal of the fourth transistor coupled to the gate driver voltage terminal, the first terminal of the fourth transistor coupled to ground, the second terminal of the fourth transistor and the second terminal of the third transistor coupled to a third terminal of the second transistor.
- 7. The circuit of claim 1, wherein the diode circuit is a diode-connected transistor, the second terminal of the diode circuit is a first terminal of the diode-connected transistor, the first terminal of the diode circuit is a second terminal of the diode-connected transistor coupled to a body and a third terminal of the diode-connected transistor.
- 8. The circuit of claim 1, comprising an isolation region between the first well region and the substrate, the isolation region including a second tap, the second tap coupled to an isolation voltage terminal.
- 9. The circuit of claim 1, comprising a gate driving circuit including bootstrap capacitor charging

circuitry and a level shifter, the bootstrap capacitor charging circuitry coupled to a bootstrap voltage terminal, the level shifter coupled to a gate driver that includes the gate driver output stage. 10. A system comprising: a first power transistor including a first terminal and a second terminal, the first terminal of the second power transistor including a first terminal and a second terminal, the first terminal of the second power transistor connected to the second terminal of the first power transistor; gate driver; a level shifter; and a voltage clamp circuit, the voltage clamp circuit including: a diode circuit; and a third transistor including a first terminal, a second terminal, and a body, the first terminal of the third transistor coupled to the level shifter, and the second terminal and the body of the third transistor coupled to the gate driver and to a first terminal of the diode circuit.

- 11. The system of claim 10, wherein the third transistor is an n-channel metal-oxide semiconductor (NMOS) transistor.
- 12. The system of claim 10, comprising a bootstrap capacitor including a first terminal and a second terminal, the first terminal coupled to the first terminal of the third transistor.
- 13. The system of claim 12, comprising a bootstrap capacitor charging circuit coupled to the second terminal of the bootstrap capacitor.
- 14. The system of claim 10, comprising: a fourth transistor including a first terminal, a second terminal, and a third terminal, the third terminal of the fourth transistor coupled to ground, the first terminal of the fourth transistor coupled to a gate driver voltage terminal; and a fifth transistor including a first terminal, a second terminal, and a third terminal, the third terminal of the fifth transistor coupled to the gate driver voltage terminal, the first terminal of the fifth transistor coupled to ground, the second terminal of the fifth transistor and the second terminal of the fourth transistor coupled to a third terminal of the third transistor.
- 15. The system of claim 10, comprising wherein the diode circuit is a diode-connected transistor, a second terminal of the diode circuit is a first terminal of the diode-connected transistor, the first terminal of the diode circuit is a second terminal of the diode-connected transistor coupled to a body and a third terminal of the diode-connected transistor.
- 16. The system of claim 10, wherein the first terminal of the third transistor is connected to the first terminal of the second power transistor and to the second terminal of the first power transistor.
- 17. The system of claim 10, wherein the first terminal of the third transistor is connected to a switching voltage terminal.
- 18. A method to dynamically control well bias, the method comprising: after a switching voltage decreases toward a negative voltage, controlling a voltage bias in a first well region of a semiconductor to follow the switching voltage, the controlling of the voltage bias based on a voltage clamp circuit, the voltage clamp circuit including a diode circuit coupled to a transistor, a first terminal of the transistor coupled to the switching voltage, a second terminal of the transistor coupled to a first terminal of the diode circuit, the decrease of the switching voltage at the first terminal of the transistor causing the transistor to switch to an on state to generate a negative voltage bias in the first well region; and after an increase of the switching voltage toward a positive voltage: controlling the voltage bias in the first well region of the semiconductor based on the voltage clamp circuit to follow the switching voltage; and clamping the voltage bias in the first well region of the semiconductor to a clamp voltage based on the transistor turning off after the switching voltage increases at the first terminal of the transistor toward the positive voltage.
- 19. The method of claim 18, wherein the clamp voltage is ground.
- 20. The method of claim 18, comprising controlling a gate voltage at a third terminal of the transistor to at least one of increase or decrease the clamp voltage.
- 21. The method of claim 18, wherein the clamping of the voltage bias includes preventing a junction breakdown between the first well region and a second well region of the semiconductor.

 22. The method of claim 18, wherein the clamping of the voltage bias includes preventing latcher.
- 22. The method of claim 18, wherein the clamping of the voltage bias includes preventing latchup in a gate driver of a gate driving circuit.