

Tegile IntelliFlash API Reference Guide

Version 2.1

Notice

Copyright

2017 [©] Western Digital Corporation or its affiliates, all rights reserved.

Notice: No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or stored in a database or retrieval system for any purpose, without the express written permission of Tegile Systems, Inc. (hereinafter referred to as "Tegile").

Tegile reserves the right to make changes to this document at any time without notice and assumes no responsibility for its use. Tegile products and services can be ordered only under the terms and conditions of Tegile's applicable agreements. All of the features described in this document may not be currently available. Refer to the latest product announcement or contact your local Tegile sales office for information on feature and product availability. This document includes the latest information available at the time of publication.

Tegile, IntelliFlash, IntelliFlash HD, IntelliCare, IntelliShell, Zebi, and MASS are trademarks of Tegile Systems, Inc. in the United States and other countries.

All other trademarks, service marks, and company names in this document are properties of their respective owners.

Tegile Systems, Inc. | 7999 Gateway Blvd. | Suite 120 | Newark, CA 94560 | 1-855-5-TEGILE (1-855-583-4453) | www.tegile.com

Contents

Audience	ADOUT THIS GRIDE	9
Chapter 1: Introduction to the IntelliFlash API API Version History	Audience	9
Chapter 1: Introduction to the IntelliFlash API 1 API Version History. 2 Key Features. 8 Scope of the API. 9 Unified APIs. 10 Error Codes 10 curl Syntax. 11 Using the API Examples. 11 Creating a Volume and Exposing It. 12 Backing Up a Volume. 13 Chapter 2: Sample Programs. 15 Sample Python Program. 16 Sample PowerShell Program. 19 Chapter 3: User and Group Methods. 21 changeUserPassword. 22 createGroup. 23 createUser	Tegile Documentation	9
API Version History	Document Revision History	10
API Version History	Chapter 1: Introduction to the IntelliFlash A	API 1
Key Features. 8 Scope of the API. 9 Unified APIs. 10 Error and Exception Handling in the API. 10 Error Codes. 10 curl Syntax. 11 Using the API Examples. 11 Creating a Volume and Exposing It. 12 Backing Up a Volume. 13 Chapter 2: Sample Programs 15 Sample Perl Script. 16 Sample PowerShell Program. 16 Sample PowerShell Program. 19 Chapter 3: User and Group Methods. 21 changeUserPassword. 22 createGroup. 23 createGroup. 24 createUser. 26 createUser. 27 createUserAndGroup. 29 deleteGroup. 30 deleteGroup. 30 deleteGroup. 33 listGroups. 33 listUsers. 34 Chapter 4: SAN Methods. 37 addinitiatorTolnitiatorGroup. 31 createlScilnitiator. 39 creat	-	
Scope of the API. 9 Unified APIs. 10 Error and Exception Handling in the API. 10 Error Codes. 10 curl Syntax. 11 Using the API Examples. 11 Creating a Volume and Exposing It. 12 Backing Up a Volume. 13 Chapter 2: Sample Programs 15 Sample Perl Script. 16 Sample PowerShell Program 16 Sample PowerShell Program 19 Chapter 3: User and Group Methods 21 changeUserPassword 22 createGroup 23 createUser 26 createUser 26 createUser 27 createUserAndGroup 29 deleteUser 32 listGroups 33 listUsers 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createlECInitiator 39 createlScSilnitiator 42 createlSCSITarget 43		
Error and Exception Handling in the API		
Error Codes. 10 curl Syntax. 11 Using the API Examples. 12 Creating a Volume and Exposing It. 12 Backing Up a Volume. 13 Chapter 2: Sample Programs. 15 Sample Perl Script. 16 Sample Python Program. 16 Sample PowerShell Program. 19 Chapter 3: User and Group Methods. 21 changeUserPassword. 22 createGroup. 23 createGroup. 24 createUser. 26 createUser. 27 createUserAndGroup. 29 deleteUser. 30 deleteUser. 32 listGroups. 33 listUsers. 34 Chapter 4: SAN Methods. 37 addInitiatorToInitiatorGroup. 38 createlScilitiator. 39 createlScilitiator. 42 createlScilitiator. 42 createlScilitiator. 43	Unified APIs	10
curl Syntax 11 Using the API Examples. 11 Creating a Volume and Exposing It 12 Backing Up a Volume 13 Chapter 2: Sample Programs 15 Sample Perl Script 16 Sample Python Program 16 Sample PowerShell Program 19 Chapter 3: User and Group Methods 21 changeUserPassword 22 createGroup 23 createGroup 24 createUser 26 createUser 27 createUser 27 createUser 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorToInitiatorGroup 38 createFCInitiator 39 createlinitiatorGroup 41 createlScSiTarget 43		
Using the API Examples		
Creating a Volume and Exposing It		
Backing Up a Volume		
Chapter 2: Sample Programs		
Sample Perl Script 16 Sample Python Program 16 Sample PowerShell Program 19 Chapter 3: User and Group Methods 21 changeUserPassword 22 createGroup 23 createUser 26 createUser 27 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createlScsilnitiator 42 createlSCSITarget 43	Backing Up a Volume	13
Sample Perl Script 16 Sample Python Program 16 Sample PowerShell Program 19 Chapter 3: User and Group Methods 21 changeUserPassword 22 createGroup 23 createUser 26 createUser 27 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createlScsilnitiator 42 createlSCSITarget 43		
Sample Perl Script 16 Sample Python Program 16 Sample PowerShell Program 19 Chapter 3: User and Group Methods 21 changeUserPassword 22 createGroup 23 createUser 26 createUser 27 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createlScsilnitiator 42 createlSCSITarget 43	Chapter 2: Sample Programs	15
Sample Python Program. 16 Sample PowerShell Program. 19 Chapter 3: User and Group Methods. 21 changeUserPassword. 22 createGroup. 23 createUser. 26 createUser. 27 createUserAndGroup. 29 deleteGroup. 30 deleteUser. 32 listGroups. 33 listUsers. 34 Chapter 4: SAN Methods. 37 addInitiatorToInitiatorGroup. 38 createFCInitiator. 39 createInitiatorGroup. 41 createlscsilnitiator. 42 createlSCSITarget. 43	· · · · · · · · · · · · · · · · · · ·	
Sample PowerShell Program.19Chapter 3: User and Group Methods.21changeUserPassword.22createGroup.23createUser.26createUser.27createUserAndGroup.29deleteGroup.30deleteUser.32listGroups.33listUsers.34Chapter 4: SAN Methods.addInitiatorToInitiatorGroup.38createFCInitiator.39createIscsilnitiator.41createIscsilnitiator.42createIsCSITarget.43		
changeUserPassword 22 createGroup 23 createUser 24 createUser 26 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsilnitiator 42 createISCSITarget 43	, ,	
changeUserPassword 22 createGroup 23 createUser 24 createUser 26 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsilnitiator 42 createISCSITarget 43	·	
changeUserPassword 22 createGroup 23 createUser 24 createUser 26 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorTolnitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsilnitiator 42 createISCSITarget 43	Chanter 2: User and Group Methods	21
createGroup. 23 createGroup. 24 createUser. 26 createUserAndGroup. 29 deleteGroup. 30 deleteUser. 32 listGroups. 33 listUsers. 34 Chapter 4: SAN Methods. 37 addInitiatorTolnitiatorGroup. 38 createFCInitiator. 39 createInitiatorGroup. 41 createIscsilnitiator. 42 createISCSITarget. 43	• • • • • • • • • • • • • • • • • • •	
createGroup 24 createUser 26 createUser 27 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorToInitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsilnitiator 42 createISCSITarget 43	•	
createUser 26 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorToInitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsiInitiator 42 createISCSITarget 43		
createUser 27 createUserAndGroup 29 deleteGroup 30 deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorToInitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsilnitiator 42 createISCSITarget 43	·	
createUserAndGroup. 29 deleteGroup. 30 deleteUser. 32 listGroups. 33 listUsers. 34 Chapter 4: SAN Methods. 37 addInitiatorToInitiatorGroup. 38 createFCInitiator. 39 createInitiatorGroup. 41 createIscsiInitiator. 42 createISCSITarget. 43		
deleteGroup		
deleteUser 32 listGroups 33 listUsers 34 Chapter 4: SAN Methods 37 addInitiatorToInitiatorGroup 38 createFCInitiator 39 createInitiatorGroup 41 createIscsiInitiator 42 createISCSITarget 43		
listUsers34Chapter 4: SAN Methods37addInitiatorToInitiatorGroup38createFCInitiator39createInitiatorGroup41createIscsiInitiator42createISCSITarget43	•	
Chapter 4: SAN Methods37addInitiatorToInitiatorGroup38createFCInitiator39createInitiatorGroup41createIscsiInitiator42createISCSITarget43	listGroups	าา
addInitiatorToInitiatorGroup	113COI Oup3	33
addInitiatorToInitiatorGroup		
addInitiatorToInitiatorGroup		
createFCInitiator	listUsers	34
createInitiatorGroup41 createIscsiInitiator42 createISCSITarget43	Chapter 4: SAN Methods	34 37
createlscsilnitiator	Chapter 4: SAN MethodsaddInitiatorToInitiatorGroup	
createlSCSITarget43	Chapter 4: SAN Methods	
	Chapter 4: SAN Methods	
	Chapter 4: SAN Methods	

	createMappingForVolume	
	createMappingForVolume	
	createTargetGroup	
	deleteInitiatorGroup	54
	deletelSCSIInitiator	
	deletelSCSITarget	58
	deleteMappingFromVolume	
	deleteTargetGroup	
	getInitiatorGroup	
	getProjectDefaultFclTView	
	getProjectDefaultlscsilTView	
	getVolumeITView	
	initiatorGroupExists	
	listFCInitiators	
	listFCInitiatorGroups	
	listFCTargets	
	listFCTargetGroups	
	listInitiatorGroups	
	listISCSIInitiatorGroups	
	listISCSIInitiators	
	listInitiatorsInInitiatorGroup	
	listISCSITargetGroups	
	listISCSITargets	
	listTargetsInTargetGroup	
	modifyISCSITargetAlias	
	moveTargetToTargetGroup	85
Ch	napter 5: Dataset Methods	91
Ch	napter 5: Dataset Methods	
Ch	abortCopy	93
Ch	abortCopycheckPoolIntegrity	93 94
Ch	abortCopycheckPoolIntegritycopyDataset	93 94 96
Ch	abortCopycheckPoolIntegritycopyDatasetcreateProject	93 94 96
Ch	abortCopycheckPoolIntegritycopyDatasetcreateProjectcreateMappingForProject	93 94 96 99
Ch	abortCopycheckPoolIntegritycopyDatasetcreateProjectcreateMappingForProjectcreateShare.	93 96 99 101
Ch	abortCopycheckPoolIntegritycopyDatasetcreateProjectcreateMappingForProjectcreateSharecreateSharecreateSharecreateSharecreateSharecreateSharecreateSharecreateSharecreateShare	93 94 99 101 105
Ch	abortCopycheckPoolIntegritycopyDatasetcreateProjectcreateMappingForProjectcreateShare.	
Ch	abortCopy	

	getPoolSpaceInfo	132
	getProject	134
	getProjectProperty	136
	getShare	138
	getShareProperty	141
	getVolume	143
	getVolumeProperty	145
	importPool	147
	inheritPropertyFromProject	149
	isProjectExposedOverNFS	151
	isProjectExposedOverSMB	153
	isShareExposedOverNFS	
	isShareExposedOverSMB	
	listAllCopyOperations	158
	listLunsByld	159
	listPools	161
	listProjects	162
	listRunningCopyOperations	163
	listShares	
	listSharesByMountPoints	167
	listVolumes	169
	modifyProjectProperties	170
	modifyShareProperties	172
	modifyVolumeProperties	175
	resetPoolError	
	setNFSSharingOnProject	178
	setNFSSharingOnShare	181
	setSMBSharingOnProject	183
	setSMBSharingOnShare	186
Cha	pter 6: Snapshot Methods	1 20
Ciia		
	cloneProjectSnapshot	
	cloneReplicaProjectSnapshot	
	cloneReplicaSubProjectSnapshot	
	cloneShareSnapshot	
	cloneVolumeSnapshot	
	cloneVolumeSnapshot	
	createProjectSnapshot	
	createShareSnapshot	
	createSnapshotSchedule	
	createVolumeSnapshotdelateProjectSnapshot	
	deleteProjectSnapshotdeleteShareSnapshot	
	deleteShareSnapshotSchodula	
	deleteSnapshotScheduledeleteSnapshotSchedules	
	deleteSnapshotSchedulesdelete\(\lambda \) \(\lambd	
	deleteVolumeSnapshotgotProjectClopeStatus	
	getProjectCloneStatusgetProjectSpanshotCroationStatus	
	getProjectSnapshotCreationStatus	44 U

	getShareSnapshotCreationStatus	222
	getSnapshotSchedule	224
	getVolumeSnapshotCreationStatus	227
	inheritSnapshotSettingsFromProject	
	isSnapshotSchedulesInheritedFromProject	
	listDependenciesAndSnapshotCountOnDelete	
	listDependenciesAndSnapshotCountOnRollback	
	listSnapshots	
	rollBackToProjectSnapshot	237
	rollBackToShareSnapshot	
	rollBackToVolumeSnapshot	
C	Chapter 7: Replication Methods	241
_	getReplicationConfigList	
	getReplicationStatus	
	startReplication	
	startive prication	243
C	Chapter 8: System Methods	247
	getDiskCountgetDiskCount	248
	getDisksgetDisks	248
	getDisksByChassis	251
	getUpgradeHistory	253
	identifyDisk	254
	identifyDiskByIndex	255
	listSystemProperties	257
C	Chapter 9: Network ACL Methods	259
_	addNFSNetworkACLOnProject	
	addNFSNetworkACLOnShare	
	addSMBNetworkACLOnProject	
	addSMBNetworkACLOnShare	
	getNFSNetworkACLsOnProject	
	getNFSNetworkACLsOnShare	
	getSMBNetworkACLsOnProject	
	getSMBNetworkACLsOnShare	
	inheritNetworkACLsettingsFromProject	
	removeAllNFSNetworkACLsOnProject	
	removeAllNFSNetworkACLsOnShare	
	removeAllSMBNetworkACLsOnProject	
	removeAllSMBNetworkACLsOnShare	
	removeNFSNetworkACLOnProject	
	removeNFSNetworkACLONShare	
	removeSMBNetworkACLOnProjectremoveSMBNetworkACLOnShare	
	setNFSNetworkACLsOnProjectsetNFSNetworkACLsOnShare	298 301
	SELVE MIELWORK ALL SUITSHALE	3111

	setSMBNetworkACLsOnProject	305
	setSMBNetworkACLsOnShare	309
Ch	napter 10: SNMP Methods	313
C	addSNMPTrapListener	
	disableSNMPService	
	enableSNMPService	
	getSNMPSettings	
	isSNMPServiceEnabled	
	modifySNMPCommunityString	
	recreateSNMPTables	
	removeSNMPTrapListener	
	resyncSNMPTables	
Ch	antor 11. Objects	220
CII	hapter 11: Objects	
	ArrayUpgrade_V2_1 CopyDestination_V2_1	
	CopySource_V2_1	
	CopyStatus_V2_1	
	DatasetProperty_V2_1	
	DatasetSpaceInfo_V2_1	
	DatasetStatus	
	Disk_V2_1	
	FCInitiator_V2_1	
	FCTarget_V2_1	
	InitiatorGroup_V2_1	
	Iscsilnitiator_V1_0	
	ISCSIInitiator_V2_1	
	ISCSITarget_V2_1	
	ISCSITargetCreate_V2_1	
	ITView_V2_1	
	LocalGroup_V1_2	
	LocalUser_V1_2	
	LunStatus	
	NetworkACL_V2_1	
	Pool_V1_0	
	PoolSpaceInfo_V2_1	
	Project_V1_0	
	Project_V1_2	
	Project_V2_1	
	ProjectCloneProgressStatus_v1_2	
	ReplicationConfig_V1_2	
	ReplicationStatus_v1_2	
	Schedule_V2_1	
	Share_V1_0	
	Share_V2_1	
	ShareOptions	

SharePermissions	355
SnapShotDeletionStatus	
SnapshotProgressStatus	
SnapshotSchedule_V2_1	
SNMP_Setting_V2_1	
Volume_V1_0	
Volume_V2_1	
UserACL (Read Only) v2.1	
, , , , , , , , , , , , , , , , , , ,	
Chantay 42: Franciscosticus	262
Chapter 12: Enumerations	
CLEANUP_STATUS	
CLONE_PROGRESS_STATUS	
COMMAND_STATUS	
Mode_enum	
OVERWRITE_STATUS	
Permission_type_enum	
Replication_Scope_Option	
SNAPSHOT_DELETION_STATUS	
SNAPSHOT_PROGRESS_STATUS	
State	
ZEBI_SYSTEM_PROPERTY	368
Appendix A: Appendix A	369
JSON Quick Reference	370
Appendix B: Appendix B	373
Deprecated APIs	
•	
·	
•	
cionesnapsnoc	560

About this Guide

The Tegile IntelliFlash API Reference Guide contains detailed information about using the Tegile IntelliFlash REST APIs.



Note: To reference older versions of the software, this document uses the term IntelliFlash instead of Zebi, except where noted.

Audience

The Tegile IntelliFlash API Reference Guide is intended for developers and solution engineers who will be creating applications using the IntelliFlash REST APIs.

Tegile Documentation

The following table, *Tegile Documentation*, lists the technical documentation types available for Tegile arrays and expansion shelves.

Table 1: Tegile Documentation

Name	Description
Tegile T4000 Series and IntelliFlash HD Hardware Guide	Contains detailed descriptions, hardware specifications, and rack installation instructions for Tegile storage arrays and expansion shelves.
Tegile IntelliFlash User Guide	Contains detailed instructions on how to configure, use, and administer Tegile arrays.
Tegile IntelliFlash API Reference Guide	Contains detailed description of the Tegile REST API.
Tegile IntelliFlash Configuration Wizard Guide	Contains instructions on how to initially configure a Tegile array using the Configuration Wizard.
Tegile IntelliFlash Release Notes	Provides details on enhancements, fixed issues, and known issues for a release.

Document Revision History

Table 2: IntelliFlash API Guide Revisions

Date	Description
11/17/2017	 Document changes include: Chapter 1: Introduction to the IntelliFlash API [updated; includes a new topic, API Version History.] Chapter 11: Objects [updated Project_V2_1] Throughout guide: Added "First Available Version" section in all the API method descriptions.
10/10/2017	Update for the new APIs included in IntelliFlash REST API version 2.1. IntelliFlash 3.7.0.x uses version 2.1 of the IntelliFlash APIs.
	Document changes include:
	 Chapter 1: Introduction to the IntelliFlash API [updated; Supercedes previous Chapter 2: Common Workflows, Chapter 3: Using the API Method Reference, and Chapter 13: IntelliFlash API Error Codes.] Chapter 4: SAN Methods [updated] Chapter 5: Dataset Methods [updated] Chapter 6: Snapshot Methods [updated] Chapter 8: System Methods [updated] Chapter 9: Network ACL Methods [new] Chapter 10: SNMP Methods [new] Chapter 11: Objects [updated]
07/31/2017	Miscellaneous changes: Updated examples, descriptions, and tables throughout the document.
07/08/2016	Updated for IntelliFlash version 3.5.0.1. Three new APIs added: rollBackToProjectSnapshot, rollBackToVolumeSnapshot, and rollBackToShareSnapshot. Enhanced listSystemProperties API and updated parameters for ZEBI_SYSTEM_PROPERTY and Using the API Examples.

Date	Description	
01/26/2015	Initial release for IntelliFlash REST APIs version 2.0. The changes in this version are the following:	
	 Added cloneVolumeSnapshot API. Removed Best practices for accessing the controllers using the API section. Added Unified APIs section. Changed the path/v1/ to/v2/ for all the APIs. 	

Chapter 1

Introduction to the IntelliFlash API

Topics:

- API Version History
- Key Features
- Scope of the API
- Unified APIs
- Error and Exception Handling in the API
- Error Codes
- curl Syntax
- Using the API Examples
- Creating a Volume and Exposing It
- Backing Up a Volume

The IntelliFlash API provides an interface to securely configure and provision storage on IntelliFlash using a programming or scripting language. It enables you to integrate Tegile arrays with third-party software. It also allows you to automate common and repetitive tasks, such as retrieving a list of volumes and their status, provisioning new volumes, and creating and managing snapshots.



Important: You can use either version 2.1 or 2.0 of the IntelliFlash REST APIs with Tegile arrays that are running IntelliFlash version 3.7.x.

API Version History

The following table lists the new API methods, the API version and the corresponding IntelliFlash version in which they were introduced.

APIs	Introduced in API Version	First Available Version
abortCopy	2.1	IntelliFlash 3.7.0.x
addNFSNetworkACLOnProject		
addNFSNetworkACLOnShare		
addSMBNetworkACLOnProject		
addSMBNetworkACLOnShare		
addSNMPTrapListener		
checkPoolIntegrity		
cloneReplicaProjectSnapshot		
cloneReplicaSubProjectSnapshot		
copyDataset		
createFCInitiator	2.1	IntelliFlash 3.7.0.x
createISCSITarget		
createISCSITargetForGroup		
createMappingForVolume		
createProject		
createMappingForProject		
createSnapshotSchedule		
createTargetGroup		

APIs	Introduced in API Version	First Available Version
deleteDataset	2.1	IntelliFlash 3.7.0.x
deleteInitiatorGroup		
deletelSCSIInitiator		
deletelSCSITarget		
deleteMappingFromProject		
deletePool		
deleteProject		
deleteShare		
deleteSnapshotSchedule		
deleteSnapshotSchedules		
deleteTargetGroup		
deleteVolume		
disableSNMPService		
enableSNMPService		
exportPool		

APIs	Introduced in API Version	First Available Version
getCopyStatus	2.1	IntelliFlash 3.7.0.x
getDatasetSpaceInfo		
getDiskCount		
getDisks		
getDisksByChassis		
getNFSNetworkACLsOnProject		
getNFSNetworkACLsOnShare		
getPoolSpaceInfo		
getProject		
getProjectDefaultFcITView		
getProjectDefaultIscsiITView		
getProjectProperty		
getShare		
getShareProperty		
getSMBNetworkACLsOnProject		
getSMBNetworkACLsOnShare		
getSnapshotSchedule		
getSNMPSettings		
getUpgradeHistory		
getVolume		
getVolumeITView		
getVolumeProperty		

APIs	Introduced in API Version	First Available Version
identifyDisk	2.1	IntelliFlash 3.7.0.x
identifyDiskByIndex		
importPool		
inheritNetworkACLsettingsFromProject		
inheritPropertyFromProject		
inheritSnapshotSettingsFromProject		
<i>isProjectExposedOverNFS</i>		
isProjectExposedOverSMB		
isShareExposedOverNFS		
isShareExposedOverSMB		
isSnapshotSchedulesInheritedFromProject		
isSNMPServiceEnabled		
listAllCopyOperations	2.1	IntelliFlash 3.7.0.x
listDependenciesAndSnapshotCountOnDelete		
listDependenciesAndSnapshotCountOnRollback		
listFCInitiators		
listFCTargets		
listInitiatorGroups		
listISCSIInitiators		
listISCSITargets		
listRunningCopyOperations		
listSharesByMountPoints		
modifyISCSITargetAlias		
modifyProjectProperties		
modifyShareProperties		
modifySNMPCommunityString		
modifyVolumeProperties		
moveTargetToTargetGroup		

APIs	Introduced in API Version	First Available Version
recreateSnmpTables	2.1	IntelliFlash 3.7.0.x
removeAlINFSNetworkACLsOnProject		
removeAlINFSNetworkACLsOnShare		
removeAllSMBNetworkACLsOnProject		
removeAllSMBNetworkACLsOnShare		
removeNFSNetworkACLOnProject		
removeNFSNetworkACLOnShare		
removeSMBNetworkACLOnProject		
removeSMBNetworkACLOnShare		
removeSNMPTrapListener		
resetPoolError	2.1	IntelliFlash 3.7.0.x
resyncSnmpTables		
setNFSNetworkACLsOnProject		
setNFSNetworkACLsOnShare		
setNFSSharingOnProject		
setNFSSharingOnShare		
setSMBNetworkACLsOnProject		
setSMBNetworkACLsOnShare		
setSMBSharingOnProject		
setSMBSharingOnShare		
recreateSNMPTables	2.1	IntelliFlash 3.7.0.x
resyncSNMPTables		IntelliFlash 3.5.4.0
rollBackToProjectSnapshot	2.0	IntelliFlash 3.5.0.1
rollBackToShareSnapshot		
rollBackToVolumeSnapshot		
cloneVolumeSnapshot	2.0	IntelliFlash 3.5.0.0

APIs	Introduced in API Version	First Available Version
changeUserPassword	1.2	IntelliFlash 2.1.2.1
cloneProjectSnapshot		
cloneShareSnapshot		
cloneVolumeSnapshot		
cloneVolumeSnapshot		
createGroup		
createProjectSnapshot		
createShareSnapshot		
createUser		
createUserAndGroup		
createVolumeSnapshot		
deleteGroup	1.2	IntelliFlash 2.1.2.1
deleteProjectSnapshot		
deleteShareSnapshot		
deleteUser		
deleteVolumeSnapshot		
getProjectCloneStatus		
getProjectSnapshotCreationStatus		
getReplicationConfigList		
getReplicationStatus		
getShareSnapshotCreationStatus		
getVolumeSnapshotCreationStatus		
listGroups		
listUsers		
startReplication		

APIs	Introduced in API Version	First Available Version
addInitiatorToInitiatorGroup	1.0	IntelliFlash 2.1.0.0
cloneSnapshot		
createInitiatorGroup		
createlscsilnitiator		
createMappingForVolume		
createSnapshots		
createVolume		
deleteDataset		
deleteMappingFromVolume		
deleteSnapshots		
deleteVolume		
getInitiatorGroup		
initiatorGroupExists		
listFCInitiatorGroups	1.0	IntelliFlash 2.1.0.0
listFCTargetGroups		
listInitiatorsInInitiatorGroup		
listISCSIInitiatorGroups		
listISCSITargetGroups		
listLunsById		
listPools		
listProjects		
listShares		
listSnapshots		
listSystemProperties		
listTargetsInTargetGroup		
listVolumes		

Key Features

The key features of the IntelliFlash API are:

- **REST (Representational State Transfer) API**: The API uses HTTP 1.1 request methods. Because HTTP is a well-known protocol and many scripting languages support it, it simplifies the task of building scripts and applications that use the API.
- **JSON (JavaScript Object Notation) data structures**: The API uses JSON as the data exchange format. All parameters in requests sent by the client must use JSON. Similarly, the responses sent by the server (including error responses) are JSON data structures.
- **HTTPS**: The API uses HTTPS to secure the communication between the client and the server.
- **Basic Authentication**: The API uses HTTP Basic authentication over Transport Layer Security (TLS)/Secure Sockets Layer (SSL). This allows only authorized personnel/programs to securely access the API.
- 0

Warning: Because the API requires the IntelliFlash Web UI administrator credentials for authentication, make sure to adequately secure the machine and the user account from which the client programs/scripts are run. Administrators must ensure that the credentials are not compromised by someone reading the script.

Scope of the API

The IntelliFlash REST APIs enable you to do the following tasks:

- List pools, projects, volumes, users, groups, LUNs, shares, snapshots, initiators, initiator groups, targets, target groups, and system properties.
- Create users, groups, volumes, snapshots, initiator groups, mapping for volumes, and iSCSI initiators.
- Clone snapshots.
- Roll back project, share, and volume snapshots.
- Delete users, groups, snapshots, volumes, shares, mapping for volume, volume snapshot, share snapshot, and other datasets.
- Check whether an initiator group exists.
- Add an initiator to an initiator group.
- Retrieve the initiator group for an initiator.
- Obtain replication configuration list, status, and to start replication.
- View history of IntelliFlash installations and upgrades to the array
- Delete, export, import, or expand pools
- Create or delete projects
- View, modify, or manage projects and dataset properties
- Add, set, or modify ACLs on projects and shares
- Create or move target groups
- Clone replica datasets
- Obtain IT views on SAN volumes and projects
- View space info for pools and datasets
- Create or delete mappings for projects and volumes
- View or identify disks
- View, create, inherit, or delete snapshot schedules
- View, create, or delete SAN targets, target groups, and initiators

- Enable or disable SNMP services
- Add or remove SNMP trap listeners
- Copy datasets, list or abort any ongoing copy operations
- Promote clones before deleting a share or LUN

Unified APIs

IntelliFlash REST APIs run on and obtain results from both controllers in a Tegile array. For example, the **listProjects** API returns projects belonging to a pool, irrespective of the controller on which the pool currently resides (Controller-A or Controller-B).



Note: The IntelliFlash REST APIs are unified starting from API version 2.0. Previous versions of the IntelliFlash REST APIs—version 1.0 and version 1.2—could access only one controller in an API request.

Invoking the Unified API with the array management IP address

You are required to use the array management IP address instead of the controller management IP addresses for the unified API to work correctly.

URL changes across the API versions

APIs in version 2.x include "/v2/" in the API endpoint. For example:

https://<ArrayManagementHostNameOrIPAddress>/zebi/api/v2/<APIname>

Error and Exception Handling in the API

In situations where a method does not succeed, the API will return one or more of the following responses:

- An HTTP status code that indicates an error. Possible status codes include:
 - 400 (bad request)
 - 404 (not found).
 - 500 (internal server error).
- An integer that indicates an error (for example the values listed in the COMMAND_STATUS, CLEANUP_STATUS, and SNAPSHOT_PROGRESS_STATUS enumerations.)
- A JSON object that contains a enumeration field that indicates an error.

Error Codes

The IntelliFlash API uses the following error codes.

Error Code	Description
EZEBI_GENERAL	Indicates a general error.

Error Code	Description
EZEBI_INVALID_ARGUMENT	Indicates invalid arguments.
EZEBI_PERMISSION_DENIED	Indicates that permission is denied.
EZEBI_NOMEMORY	Indicates that no memory is left.
EZEBI_NOSPACE	Indicates that no space is left on device.
EZEBI_RESOURCE_SUSPENDED	Indicates that resource operation is suspended.
EZEBI_RESOURCE_BUSY	Indicates that resource is busy.
EZEBI_RESOURCE_INUSE	Indicates that resource required is being used by others.
EZEBI_RESOURCE_EXIST	Indicates that target already exists.
EZEBI_RESOURCE_CORRUPTED	Indicates that resource is corrupted.
EZEBI_RESOURCE_NOT_FOUND	Indicates that resource is not found.
EZEBI_REQUEST_EXIST	Indicates that request is in progress already.
EZEBI_REQUEST_INTERRUPTED	Indicates that request is interrupted.
EZEBI_REQUEST_TIMEOUT	Indicates that request is timed out.
EZEBI_HOST_UNREACHABLE	Indicates that host is unreachable.
EZEBI_HOST_UNKNOWN	Indicates that host is unknown.

curl Syntax

The examples use the **curl** command to represent the HTTP requests.

The curl examples include the HTTP headers, the JSON data sent in the request, and the endpoint of the API.

Tegile arrays use a self-signed certificate. This may prevent the **curl** command from working. As a workaround, you can use the **-k** parameter with the **curl** command to ignore the warnings/errors generated due to the self-signed certificate.

Using the API Examples

The documentation for each API method includes examples.

The examples use the **curl** command for the requests. The documentation for most API methods includes two types of examples:

- Working examples with sample responses.
- Erroneous examples with error responses. These examples are erroneous because they use incorrect data for a particular context. The purpose of the erroneous examples is only to illustrate some of the responses that a Tegile array will return if it receives incorrect data.

Before using the examples in your scripts and programs, ensure that you make the following changes:

 Use the authentication token returned by your Tegile array instead of the dummy token (AUTH_TOKEN) given in the examples. The authentication token must be encoded as a Base64 string to use the REST API. For example, you can use the following Linux command (that is part of the Linux coreutils package) to convert your credentials to Base64.

```
# echo -n 'username:password' | base64
```

- Use data that is relevant to your environment and requirements instead of the dummy data given in the examples.
- Use the Array Management IP address instead of the dummy IP address given in the examples.

Creating a Volume and Exposing It

You can create a volume and expose it using the IntelliFlash API.

Prerequisites

To accomplish this, you must first ensure that the Tegile array contains the following:

- A pool
- A project in that pool
- An FC or iSCSI target
- An FC or iSCSI target group
- A mapping between the target and the target group

After ensuring that the prerequisites listed above are met, use the IntelliFlash API to:

- 1. Create a volume using the *createVolume* method.
- 2. Create an iSCSI initiator using the *createlscsilnitiator* method.
- 3. Create an initiator group using the *createInitiatorGroup* method.



Note: You do not need to create FC initiators. If the FC fabric configurations are correct, the initiators automatically log in to the target ports.

- 4. Associate the initiator with the initiator group using the *addInitiatorToInitiatorGroup* method.
- 5. Map the volume to a target group and an initiator group using the *createMappingForVolume* method.

Backing Up a Volume

You can back up an existing IntelliFlash volume using the IntelliFlash API.

To accomplish this, use the IntelliFlash API to complete the following steps:

- 1. Create a volume snapshot using the *createVolumeSnapshot* method.
- 2. Create a clone from the volume snapshot using the *cloneVolumeSnapshot* method.
- 3. Mount the newly cloned volume and take a backup.
- 4. Clean up the cloned volume using the *deleteVolume* method.
- 5. Clean up the snapshot from which the clone was created using the *deleteVolumeSnapshot* method.

Chapter 2

Sample Programs

Topics:

- Sample Perl Script
- Sample Python Program
- Sample PowerShell Program

The following sample programs illustrate how to access the IntelliFlash API using Perl and Python.



Note: The IntelliFlash API uses basic authentication over HTTPS. If you are using self-signed certificates on the Tegile array, the program that invokes the IntelliFlash APIs must include instructions to trust the SSL certificate.

Sample Perl Script

The following Perl script illustrates how to authenticate, accept (trust) the self-signed certificate, and invoke the *listPools* API.

```
use REST::Client;
use JSON;
use Data::Dumper;
use MIME::Base64;
# next line is for ignoring the certificate if it is self-signed.
$ENV{PERL LWP SSL VERIFY HOSTNAME}=0;
$username = 'admin';
$password = 't';
my $host= "https://198.51.100.10";
my $url = "/zebi/api/v2/listPools";
my $json data = "";
# Below line is for basic authentication
my $headers = { Accept => 'application/json',
     Authorization => 'Basic '. encode base64($username . ':' .
$password) };
my $client = REST::Client->new();
$client->setHost($host);
$client->setTimeout(60);
# For API Call
$client->POST($url,($json data,$headers));
print Dumper ($client->responseContent());
```



You must replace the IP address (198.51.100.10) with your Array Management IP address.

Sample Python Program

The following Python program illustrates how to authenticate, accept (trust) the self-signed certificate, and invoke the following APIs:

- listPools
- listProjects
- listVolumes
- createVolumeSnapshot
- cloneVolumeSnapshot
- getReplicationConfigList

- startReplication
- getReplicationStatus

```
import httplib2;
import base64;
import json;
##h = httplib2.Http();
h = httplib2.Http(disable_ssl_certificate_validation=True);
auth = base64.encodestring('admin' + ":" + "t");
url = "https://198.51.100.10/zebi/api/v2/listPools";
method = "GET";
headerMap = {'content-type':'application/json', 'Authorization' : 'Basic ' +
auth};
resp, content = h.request(url, method, headers=headerMap);
poolArray = json.loads(content);
# List projects inside a the pool
url = "https://198.51.100.10/zebi/api/v2/listProjects";
method = "POST";
poolName = poolArray[0]["name"];
#Prepare Parameter Array
paramArray = [];
paramArray.append(poolName);
paramArray.append(True);
paramJSONData = json.dumps(paramArray);
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
projectArray = json.loads(content);
print resp.status;
print content;
#List Volumes inside a project
url = "https://198.51.100.10/zebi/api/v2/listVolumes";
method = "POST";
projectName = projectArray[0]["name"];
paramArray = [];
paramArray.append(poolName);
paramArray.append(projectName);
paramArray.append(True);
paramJSONData = json.dumps(paramArray);
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
volumeArray = json.loads(content);
#Create a volume snapshot
url = "https://198.51.100.10/zebi/api/v2/createVolumeSnapshot";
method = "POST";
snapName = "API-SNAP";
```

```
firstVolume = volumeArray[0];
paramArray = [];
paramArray.append(firstVolume);
paramArray.append(snapName);
paramArray.append(False);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
print resp.status;
print content;
url = "https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot";
method = "POST";
snapshotPath = firstVolume["datasetPath"] + "@" + "Manual-V-" + snapName;
volumeCloneName = "API-Clone";
paramArray = [];
paramArray.append(snapshotPath);
paramArray.append(volumeCloneName);
paramArray.append(False);
paramArray.append(True);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
print resp.status;
print content;
#Replication configs
url = "https://198.51.100.10/zebi/api/v2/getReplicationConfigList";
method = "POST";
projectName = "vdi";
paramArray = [];
paramArray.append(poolName);
paramArray.append(projectName);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
replicationConfigArray = json.loads(content);
firstReplicationConfig = replicationConfigArray[0];
#Trigger replication
url = "https://198.51.100.10/zebi/api/v2/startReplication";
method = "POST";
projectName = "vdi";
paramArray = [];
paramArray.append(firstReplicationConfig);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
print resp.status;
print content;
url = "https://198.51.100.10/zebi/api/v2/getReplicationStatus";
method = "POST";
```

```
projectName = "vdi";

paramArray = [];
paramArray.append(firstReplicationConfig);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);

print resp.status;
print content;
```



Note: You must replace the IP address (198.51.100.10) with the IP address of your Tegile array.

Sample PowerShell Program

The following PowerShell program illustrates how to authenticate, accept (trust) the self-signed certificate, and invoke the *createShare* API.

```
$bytes = [System.Text.Encoding]::UTF8.GetBytes("admin:s")
$token = [System.Convert]::ToBase64String($bytes)
$headers = @{"Authorization"="Basic $token"; "Content-Type"="application/
$url = "https://198.51.100.10/zebi/api/v2/createShare"
$method = "POST"
[System.Net.ServicePointManager]::ServerCertificateValidationCallback =
[System.Net.ServicePointManager]::SecurityProtocol =
[System.Net.SecurityProtocolType]::Tls12;
$shareOptions = @{}
$shareOptions.add("blockSize", "64KB")
$shareOptions.add("quota", -1)
$shareOptions.add("reservation", -1)
#This group should already exist on the array.
#A better approach is to obtain the group list using the listGroups API and
then
#use the needed group, instead of hard-coding like below
qroup = Q{}
$group.add("groupName", "group01")
$group.add("groupId", 104)
$groupList = @($group)
$sharePermission = @{}
$sharePermission.add("groupList", $groupList)
$sharePermission.add("sharePermissionEnum", 2) #2 is group permission
$sharePermission.add("sharePermissionMode", 0) #0 is "Allow"
$sharePermissionArray = @($sharePermission)
$parameters = "pool-b","test-project","APIShare",$shareOptions,
$sharePermissionArray
$jsonString = ConvertTo-Json -Compress -Depth 4 $parameters
```

\$jsonString

Invoke-RestMethod -Method \$\footnote{\text{Method}} - \text{Headers \$\text{Pleaders} - Uri \$\text{Uri } - \text{Body}
\$\footnote{\text{Body}}\$



Note: You must replace the IP address (198.51.100.10) with the IP address of your Tegile array.

Chapter 3

User and Group Methods

Topics:

- changeUserPassword
- createGroup
- createGroup
- createUser
- createUser
- createUserAndGroup
- deleteGroup
- deleteUser
- listGroups
- listUsers

The following sections describe User and Group API methods, parameters and return types. They also include examples with sample responses.

changeUserPassword

Sets a new password for the specified user (a "Local User" that was created on the Tegile array.)

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listUsers

Parameters

userName

Name of the user.

password

Password of the new user. The '/' and space characters and the empty and null strings are not allowed in password.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["UserName", "Password"]' \
https://198.51.100.10/zebi/api/v2/changeUserPassword -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '["IncorrectUserName", "Password"]' \
https://198.51.100.10/zebi/api/v2/changeUserPassword -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
message: "User IncorrectUserName does not exist."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

createGroup

Creates a user group with the specified group name and group ID.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listGroups, createGroup, createUserAndGroup, deleteGroup, listUsers, deleteUser.

Parameters

groupName

Name of the group. The characters /, \setminus , !, @, #, \$, %, $^$, *, (,), :, :, \cdot , are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

gid

Group ID of the group. The group ID should be a number less than 99999999.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '["NewGroup", 1234]' \
https://198.51.100.10/zebi/api/v2/createGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewGroup", 1234]' \
  https://198.51.100.10/zebi/api/v2/createGroup -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "The specified group Id already belongs to another group."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

createGroup

Creates a user group with the specified group name. The group ID is generated by the system.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listGroups, createGroup, createUserAndGroup, deleteGroup, listUsers, deleteUser.

Parameters

groupName

Name of the group. The characters /, \setminus , !, @, #, \$, %, $^$, *, (,), :, :, \cdot , are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["AnotherNewGroup"]' \
  https://198.51.100.10/zebi/api/v2/createGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[""]' https://198.51.100.10/zebi/api/v2/createGroup -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
message: "Invalid Group Name."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

createUser

Creates a user with given username, user ID, group name, and password.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listUsers, listGroups, createUser, createUserAndGroup, deleteUser.

Parameters

userName

Username of the new user. The characters /, \\, !, @, #, \$, %, ^, *, (,), :, ;, \, are not allowed in the username. The empty and "guest" strings and the null value are also not allowed in the username.

uid

User ID of the new user.

groupName

password

Password of the new user. The '/' and space characters and the empty and null strings are not allowed in password.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["UserName", 123, "GroupName", "newpwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["UserName", 123, "IncorrectGroupName", "newpwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Group IncorrectGroupName does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

createUser

Creates a user with given username, group name, and password. The user ID is generated by the system.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listUsers, listGroups, createUser, createUserAndGroup, deleteUser.

Parameters

userName

Username of the user that will be created. The characters /, \setminus , !, @, #, %, $^$, $^$, (,), :, :, \cdot , are not allowed in the username. The empty and "guest" strings and the null value are also not allowed in the username.

groupName

Name of the group in which the new user will be included. The characters /, \\, !, @, #, \$, %, ^, *, (,), :, ;, \, are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

password

Password of the new user. The '/' and space characters and the empty and null strings are not allowed in password.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewUserName", "ExistingGroupName", "NewUserPwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewUserName", "NotAGroupName", "NewUserPwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Group TechPub does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
```

createUserAndGroup

Creates user and group with auto generated user ID and group ID. The group will be created first and then the user. The user will be associated with the group. If the group with given group name already exists, the user will be created and associated with the existing group.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listUsers, listGroups, createGroup, createGroup, deleteGroup, createUser, createUser, deleteUser.

Parameters

userName

Username of the new user. The characters /, $\backslash \backslash$, !, @, #, %, $^$, $^$, $^$, (,), :, :, \downarrow , are not allowed in the username. The empty and "guest" strings and the null value are also not allowed in the username.

password

Password of the new user.

groupName

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2", "testpwd2", "testGroup2"]' \
  https://198.51.100.10/zebi/api/v2/createUserAndGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2", "testpwd2", "testGroup2"]' \
  https://198.51.100.10/zebi/api/v2/createUserAndGroup -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "UX: /usr/sbin/useradd: ERROR: testUser2 is already in use.
Choose another.\ 9"
  extendedData: {
  details: ""
  code: "EZEBI_GENERAL"
}
```

deleteGroup

Deletes the specified user group (a "Local Group" that was created on the Tegile array). If the group contains existing users, all the users would not be part of this group.



Warning:

- The delete operation is not reversible.
- If you do not require the users in this group, it is recommended to delete the users before deleting the group.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listGroups, listUsers, deleteUser, createUserAndGroup.

Parameters

groupName

Name of the group that has to be deleted. The characters /, \backslash , !, @, #, %, $^$, $^$, (,), :, :, \downarrow , are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewGroup"]' \
  https://198.51.100.10/zebi/api/v2/deleteGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewGroup"]' \
  https://198.51.100.10/zebi/api/v2/deleteGroup -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Group NewGroup does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

deleteUser

Deletes the specified user (a "Local User" that was created on the Tegile array.)



Warning: The delete operation is not reversible.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listUsers, listGroups, deleteGroup.

Parameters

userName

Name of the user. The characters /, \setminus , !, @, #, \$, %, * , (,), :, :, \cdot , are not allowed in the username. The empty and "guest" strings and the null value are also not allowed in the username.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2"]' \
  https://198.51.100.10/zebi/api/v2/deleteUser -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '["testUser2"]' \
https://198.51.100.10/zebi/api/v2/deleteUser -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
message: "User testUser2 does not exist."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

listGroups

Lists all the local groups and the users included in each group. This is an HTTP GET method.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createGroup, createGroup, deleteGroup, createUserAndGroup, listUsers.

Parameters

None

Returns

Returns an array of JSON objects. Each object has the group name, group ID, and users of a group. The user list itself is a JSON array containing the names of users in a group.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listGroups -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
"groupName":"nfsgrp1",
"groupId":104,
"userList":["nfsuser1"]
},
{
"groupName":"nfsgrp4",
"groupId":106,
"userList":["nfsuser4"]
},
{
"groupName":"nfsgrp5",
"groupId":105,
"userList":["nfsuser5"]
},
{
"groupName":"nfsgrp2",
"groupId":108,
"userList":["nfsuser2"]
},
{
"groupName":"nfsgrp3",
"groupId":107,
"userList":["nfsuser3"]
}
```

listUsers

Lists all the local users with their user ID, group name, and group ID. This is an HTTP GET method.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listGroups, createUser, createUser, createUserAndGroup, deleteUser.

Parameters

None

Returns

Returns an array of JSON objects. Each object has the user name, user ID, group name, and group ID of a local user.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
https://198.51.100.10/zebi/api/v2/listUsers -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
{
"userName":"nfsuser1",
"groupName":"nfsgrp1",
"userId":104,"groupId":104
}
,
{"userName":"nfsuser5",
"groupName":"nfsgrp5",
"userId":105,
"groupId":105
},
{
"userName":"nfsuser4",
"groupName":"nfsgrp4",
"userId":106,
"groupId":106),
{
"userName":"nfsuser3",
"groupName":"nfsgrp3",
"userId":107,
"groupName":"nfsuser2",
"groupName":"nfsuser2",
"groupName":"nfsgrp2",
"userId":108,
groupId":108
}
]
```

Chapter 4

SAN Methods

Topics:

- addInitiatorToInitiatorGroup
- createFCInitiator
- createInitiatorGroup
- createlscsilnitiator
- createISCSITarget
- createISCSITargetForGroup
- createMappingForVolume
- createMappingForVolume
- createTargetGroup
- deleteInitiatorGroup
- deletelSCSIInitiator
- deletelSCSITarget
- deleteMappingFromVolume
- deleteTargetGroup
- getInitiatorGroup
- getProjectDefaultFcITView
- getProjectDefaultIscsilTView
- getVolumeITView
- initiatorGroupExists
- listFCInitiators
- listFCInitiatorGroups
- listFCTargets
- listFCTargetGroups
- listInitiatorGroups
- listISCSIInitiatorGroups
- listISCSIInitiators
- listInitiatorsInInitiatorGroup
- listISCSITargetGroups
- listISCSITargets
- listTargetsInTargetGroup
- modifyISCSITargetAlias
- moveTargetToTargetGroup

The following sections describe SAN methods, parameters and return types. They also include examples with sample responses.

addInitiatorToInitiatorGroup

Associates an initiator with an initiator group. If the initiator group is not present, then this method attempts to create it. If the initiator does not exist, then the method fails.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

initiatorGroupExists, addInitiatorToInitiatorGroup

Parameters

initiatorName

The name of an initiator.

initiatorGroupName

A string: the name of an initiator group.

Returns

Returns an integer, where:

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- · 2 indicates that the request failed

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["iqn.2012-11.com.tegile.iscsi:Initiator1", "iscsi-TestGroup"]' \
https://198.51.100.10/zebi/api/v2/addInitiatorToInitiatorGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer 0 indicating success.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["iqn.2012-11.com.tegile.iscsi:Initiator2", "iscsi-TestGroup2"]'\
https://198.51.100.10/zebi/api/v2/addInitiatorToInitiatorGroup -k
```

Error Response

In the above request, the initiator already exists in the group. So the request returns the HTTP status code 400 (bad request) and the following message:

createFCInitiator

Creates the Fibre Channel (FC) Initiator on the IntelliFlash Array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listFCInitiators, deletelSCSIInitiator, listInitiatorGroups, createlscsiInitiator

Parameters

initiatorName

The name of the fibre channel initiator you want to create. This must be in the format wwn.<16 hex digits>. For example, wwn.5001438001FF7742.

initiatorGroupName

The name of the fibre channel initiator group to add the initiator as a member.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified initiator group is not found.

EZEBI_RESOURCE_EXIST

This exception is thrown if the specified initiator already exists.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the initiator group is over 512 characters long
- If the initiator group has invalid characters such as *,#,/,\\,!,@,~,(,),[,],{,},=, and %.
- If the initiator name is not in the format of wwn.
 alpha-numeric-hex characters>

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["wwn.5001438001ffbbbb", "fc-igroup"]' \
https://198.51.100.10/zebi/api/v2/createFCInitiator -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the initiator was created in the specified initiator group.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["wwn.5001438001ffbbbb", "fc-igroup"]' \
  https://198.51.100.10/zebi/api/v2/createFCInitiator -k
```

Error Response

In this example, the fibre channel initiator already exists. So the request returns the HTTP status code 400 (bad request) and the following response:

```
{"code":"EZEBI_RESOURCE_EXIST","details":"",
"message":"The Fibre Channel initiator [wwn.5001438001ffbbbb]
already exists, but must not exist for this operation
[create initiator].","extendedData":{}}
```

createInitiatorGroup

Creates an initiator group on a Tegile array.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

createlscsilnitiator, listlnitiatorsInInitiatorGroup, addInitiatorToInitiatorGroup

Parameters

initiatorGroupName

A string: name of the new initiator group. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, ^,*,(,), ~,+, =, \$, |, \$, ',\, \", _, & are not allowed in initiatorgroupname. The empty and space characters and the null values are not allowed in initiatorgroupname.

Returns

Returns an integer, where:

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- 2 indicates that the request failed

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '[ "APIInitiatorGroup" ]' \
https://198.51.100.10/zebi/api/v2/createInitiatorGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and the integer 0 indicating success.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[ "API_InitiatorGroup" ]' \
  https://198.51.100.10/zebi/api/v2/createInitiatorGroup -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

createlscsilnitiator

Creates an iSCSI initiator object on the Tegile array. If the initiator name already exists, then the method fails.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

initiatorGroupExists, addInitiatorToInitiatorGroup

Parameters

iscsilnitiator

A JSON object of type *Iscsilnitiator_V1_0* that contains the name of the initiator and optional CHAP information.

Returns

Returns an integer, where

- · 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- 2 indicates that the request failed

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and an integer 0 indicating success.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[{"initiatorName":"","chapUserName":"","chapSecret":""}]' \
  https://198.51.100.10/zebi/api/v2/createIscsiInitiator -k
```

Error Response

In the above request, the initiator name is empty. So the request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Initiator name is not valid.",
   "extendedData": {}
}
```

createlSCSITarget

Creates an iSCSI target with the specified target group, chap authentication, alias, and network bindings.

This API allows the user to specify all the attributes of the target in the JSON *ISCSITargetCreate_V2_1* parameter object passed.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITargetForGroup, deleteISCSITarget, modifyISCSITargetAlias, listISCSITargets

Parameters iscsiTarget

A JSON object of type *ISCSITargetCreate_V2_1* that contains the attributes of the iSCSI target to create.

The JSON fields of the iSCSI target object parameter are

- targetSuffixName
- targetAlias
- targetGroupName
- targetAuthenticationMode
- targetChapName
- targetChapSecret
- targetNetworkBinding

The target suffix name is the user specified portion after the iqn target name colon character. For example, iqn.2012-02.com.tegile:myTargetSuffix.

Specify only a target suffix and not the full target name because the iSCSI target prefix is pre-defined for all targets on the array. The alias is the user friendly alternate name of the target.

The authentication mode is a value of 'none', 'chap', or 'mutual'. The chapName and chapSecret must be set depending on whether the authentication mode is set. Only if 'mutual' authentication is set, the chapName and chapSecret must be specified. The network binding (IP:PORT) can be any of the bindings associated with the target group name's pool. The default target group cannot be modified or used here.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified iSCSI target group does not exist.

EZEBI_RESOURCE_EXIST

This exception is thrown if the specified target already exists.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the default group is being modified

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[{
    "targetSuffixName": "test",
    "targetAlias": "testAlias",
    "targetGroupName": "iscsi-tgroup",
    "targetAuthenticationMode": "none",
    "targetChapName": "",
    "targetChapSecret": "",
    "targetNetworkBinding": [
        "10.68.97.211:3260"
    ] } ]' \
https://198.51.100.10/zebi/api/v2/createISCSITarget -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:test" was created in the specified target group "iscsi-tgroup".

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[{
    "targetSuffixName": "test3",
    "targetAlias": "testAlias",
    "targetGroupName": "iscsi-tgroup",
    "targetAuthenticationMode": "invalidauth",
    "targetChapName": "",
    "targetChapSecret": "",
    "targetNetworkBinding": [
        "10.68.97.211:3260"
    ] } ] ' \
https://198.51.100.10/zebi/api/v2/createISCSITarget -k
```

Error Response

In this example, the chap authentication is an invalid type value. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "createISCSITarget.arg0.targetAuthenticationMode value
'invalidauth':
   Chap authentication should be one of the values:none, chap, or mutual createISCSITarget.arg0 value

'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$ISCSITargetCreate_V2_1@45b06d12':
   Invalid CHAP authentication passed[invalidauth],
   supported values are: none, chap, or mutual.",
   "message":
   "Chap authentication should be one of the values:none, chap, or mutual
   Invalid CHAP authentication passed[invalidauth],
   supported values are: none, chap, or mutual.",
   "extendedData": {
        "EX_CAUSE_MESSAGE": null
   }
}
```

createlSCSITargetForGroup

Creates an ISCSI target for the specified target group.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITarget

Parameters

targetNameSuffix

The iSCSI target name suffix.

This is the portion of the iSCSI iqn name that comes after the colon. This is the user specified part of the target name.

targetAlias

The iSCSI alias user friendly name used to refer to the target.

This is typically the same as the target suffix.

targetGroupName

Existing iSCSI target group that the new target will be a member of.

New targets created here cannot be added to the default target group. So the name here cannot be the default target group.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified target group does not exist.

EZEBI_RESOURCE_EXIST

This exception is thrown if the specified target already exists.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the target group has invalid characters such as *,#,/,\\,!,@,~,(,),[,],{,},=, and %.
- If the target group is the default target group
- If the target group is over 512 characters long

EZEBI GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["myTargetSuffix", "myTargetAlias", "myTargetGroup" ]' \
  https://198.51.100.10/zebi/api/v2/createISCSITargetForGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:myTargetSuffix" was created in the specified target group "myTargetGroup".

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myTargetSuffix", "myTargetAlias", "group-does-not-exist-yet" ]' \
https://198.51.100.10/zebi/api/v2/createISCSITargetForGroup -k
```

Error Response

In this example, the target group does not exist. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "Failed to find target group [group-does-not-exist-yet].",
  "message": "Failed to setup iSCSI target for creation on target group:
  group-does-not-exist-yet",
  "extendedData":
  {
     "EX_CAUSE_MESSAGE":
     "Failed to find target group [group-does-not-exist-yet].",
     "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
  }
}
```

createMappingForVolume

Maps a volume to an initiator group and a target group.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

deleteMappingFromVolume, initiatorGroupExists, listISCSIInitiatorGroups, listISCSITargetGroups, createVolume.

Parameters

datasetPath

The dataset path of the volume. This is a string. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume_V1_0*.

initiatorGroupName

The name of the initiator group to which the volume must be mapped. This is a string.

targetGroupName

The name of the target group to which the volume must be mapped. This is a string.

lunNumber

The LUN number for the newly defined LUN. To assign a LUN number automatically (default), use the value -1. This is an integer.

Returns

Returns an integer, where

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[ "pooll/Local/TechPubs/TechPubsLUN", \
   "api_InitiatorGroup", \
   "iqn.2014-11.com.tegile.iscsi:testtargetgroup-group", -1]' \
https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

Response

```
0
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[ "pool1/Local/TechPubs/TechPubsLUN2", \
  "api_InitiatorGroup", \
  "iqn.2014-11.com.tegile.iscsi:testtargetgroup-group", -1]' \
  https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

Error Response

If the initiator group is not found, the above request returns the HTTP status code 200 (OK) and no data.

createMappingForVolume

Creates a mapping for a volume, with the option for it to be read only.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createMappingForProject, deleteMappingFromProject

Parameters

datasetPath

Path of the LUN. The format is <poolName>/Local///<lunName>.

This operation is not allowed for Replica datasets.

initiatorGroupName

Name of the initiator group in the existing mapping.

targetGroupName

Name of the target group in the existing mapping.

LUNNumber

LUN number to use. Pass a value of -1 if you want the system to assign an available LUN number.

readOnly

Whether mapping is read-only. The values are True and False.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project, initiator group, or target group cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for any of the following reasons:

- The path specified belongs to a replica dataset.
- The volume protocol does not match the protocol of the SAN groups.
- The mapping does not exist.
- The mapping for this target group already exists (when trying to make All mapping).
- The mapping with 'All' initiator groups already exists on this target group for this LUN.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject/demoLUN", "All", "demoiSCSITargetGroup", 1, true
  ]' \
```

```
https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject/demoLUN", "All", "default-pool-a-iscsi-target-group", 1, true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

Error Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"",
  "message":"View already exists with different read only value: true",
  "extendedData":{}
}
```

Example 3

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"",
   "message":"Cannot create mapping: volume protocol does not match
protocol
   of specified initiator group.",
   "extendedData":{}
}
```

createTargetGroup

Creates a target group with the specified target group name in the resource group containing the named pool.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

moveTargetToTargetGroup, listFCTargetGroups, listISCSITargetGroups

Parameters

targetGroupName

Name of the new target group.

poolName

Specifies the pool resource group to place the target group.

The poolName applies to iSCSI target groups only. For FC target groups, specify an empty string or null.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified pool cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in either the targetGroupName or poolName.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["aCoolTargetGroup", "pool63a"]' \
https://198.51.100.10/zebi/api/v2/createTargetGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating a succesful request to create an iSCSI target group.

Example 2

Erroneous Request (curl)

```
curl -X POST \
   -H 'authorization: Basic AUTH_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '["aBad#TargetGroup", "pool63a"]' \
https://198.51.100.10/zebi/api/v2/createTargetGroup -k
```

Error Response

The above request contains invalid characters. So the request returns HTTP status code 400 (bad request) and the following ISON exception:

```
"code": "EZEBI_INVALID_ARGUMENT",
"details": "createTargetGroup.arg0 value
'aBad#TargetGroup': Target group name cannot have
special characters like *,#,/,\\,!,@,~,(,),[,],{,},=,%...",
"message":
"Target group name cannot have special characters like
   *,#,/,\\,!,@,~,(,),[,],{,},=,%...",
"extendedData": {
   "EX_CAUSE_MESSAGE": null
}
```

deleteInitiatorGroup

Deletes the initiator group specified from the IntelliFlash Array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listInitiatorGroups, deletelSCSIInitiator, createInitiatorGroup

Parameters

initiatorGroupName

The name of the initiator group you want to delete.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified initiator group is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the initiator group is over 512 characters long

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myInitiatorGroupToDelete"]' \
https://198.51.100.10/zebi/api/v2/deleteInitiatorGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the initiator group 'mylnitiatorGroupToDelete' was deleted.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["myGroupToDeleteDoesNotExist"]' \
  https://198.51.100.10/zebi/api/v2/deleteInitiatorGroup -k
```

Error Response

In this example, the initiator group does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

deletelSCSIInitiator

Deletes an ISCSI initiator with the specified initiator name.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deletelscsilnitiator, listISCSIInitiatorGroups, listISCSITargets, createlscsilnitiator

Parameters

initiatorName

The name of the initiator you want to delete. For example, iqn.1991-05.com.microsoft:test.tegile.com. The 'initiatorName' is returned by listISCSIInitiators API.

Values returned

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified iSCSI target does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the default group is being modified

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["iqn.1991-05.com.microsoft:test.tegile.com"]' \
  https://198.51.100.10/zebi/api/v2/deleteISCSIInitiator -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:test" was deleted.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.1991-05.com.microsoft:doesnotexist.tegile.com"]' \
https://10.68.97.100/zebi/api/v2/deleteISCSIInitiator -k
```

Error Response

In this example, the initiator does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
"details":"ISCSI Initiator was not found.",
"message":"Failed to find iSCSI Initiator to delete
[iqn.1991-05.com.microsoft:doesnotexist.tegile.com].",
"extendedData":{"EX_CAUSE_MESSAGE":"ISCSI Initiator was not found.",
"EX_CAUSE_CODE_NAME":"EZEBI_RESOURCE_NOT_FOUND"}}
```

deletelSCSITarget

Deletes an iSCSI target with the specified target name.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITargetForGroup, createISCSITarget, modifyISCSITargetAlias, listISCSITargets

Parameters targetName

The name of the target you want to delete. For example, iqn.2012-02.com.tegile:myTargetSuffix.

The targetName is returned by listISCSITargets API. Targets in default target group cannot be deleted.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified iSCSI target does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the default group is being modified

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["iqn.2012-02.com.tegile:test"]' \
  https://198.51.100.10/zebi/api/v2/deleteISCSITarget -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:test" was deleted.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["iqn.2012-02.com.tegile:doesnotexist"]' \
  https://10.68.97.100/zebi/api/v2/deleteISCSITarget -k
```

Error Response

In this example, the target does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to find iSCSI
Target[iqn.2012-02.com.tegile:doesnotexist].
The target must exist for this operation to succeed.",
"extendedData":{}}
```

deleteMappingFromVolume

Deletes the view (mapping) between the given volume, initiator group, and target group.



Note: The delete operation deletes the mapping. But you can add the original mapping again.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

createMappingForVolume, initiatorGroupExists, listISCSIInitiatorGroups, listISCSITargetGroups, listVolumes.

Parameters

datasetPath

A string: the dataset path for the volume. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see listVolumes and Volume_V1_0.

initiatorGroupName

A string. The name of an initiator group.

targetGroupName

A string. The name of a target group.

Returns

Returns an integer, where

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- 2 indicates that the request failed

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
 -H Content-Type:application/json \
 -d '["pool1/Local/TechPubs/TechPubsLUN", \
 "iscsi-initiatorGroup", \
```

```
"iscsi-TargetGroup"]' \
https://198.51.100.10/zebi/api/v2/deleteMappingFromVolume -k
```

Response

The above request returns an integer 0, which indicates success.

Example 2

Erroneous Request

Error Response

```
HTTP Status Code: 500
{
   "message": "Unable to open pool1/Local/TechPubs2 : dataset does not exist",
   "extendedData": {
    "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
    "EX_CAUSE_MESSAGE": "Unable to open pool1/Local/TechPubs2 : dataset does not exist",
    "EX_CAUSE_CODE_NUMBER": "2009"
    },
    "details": "Unable to open pool1/Local/TechPubs2 : dataset does not exist",
    "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

deleteTargetGroup

Deletes the target group specified from the IntelliFlash Array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITarget

Parameters

targetGroupName

The name of the target group you want to delete.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified target group is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the target group is over 512 characters long
- If the target group is the default target group

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myTargetGroupToDelete"]' \
https://198.51.100.10/zebi/api/v2/deleteTargetGroup -k
```

Response:

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target group 'myTargetGroupToDelete' was deleted.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myTargetGroupToDeleteDoesNotExist"]' \
```

```
https://198.51.100.10/zebi/api/v2/deleteTargetGroup -k
```

Error Response

In this example, the target group does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to find target group
[myTargetGroupToDeleteDoesNotExist].",
"extendedData":{}}
```

getInitiatorGroup

Gets the name of the initiator group to which the initiator belongs.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listInitiatorsInInitiatorGroup, createIscsiInitiator, addInitiatorToInitiatorGroup

Parameters

initiatorName

The name of the initiator. This is a string.

Returns

Returns a JSON string. The string has the name of the initiator group associated with the given initiator.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:api-initiator-1"]' \
  https://198.51.100.10/zebi/api/v2/getInitiatorGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
iqn.2012-11.com.tegile.iscsi:testinigroup-group
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:api-initiator-2"]' \
  https://198.51.100.10/zebi/api/v2/getInitiatorGroup -k
```

Error Response

If the initiator name is not found, the request returns the HTTP status code 200 (OK) and no data.

getProjectDefaultFcITView

Lists all of the existing default Fibre Channel views given a project's dataset path.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getVolumeITView, getProjectDefaultIscsiITView

Parameters

datasetPath

A string representing the project dataset path.

A project dataset must start with a letter followed by a series of alpha-numeric. It can contain only the following characters: 'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/'. The dataset, however, should not end with '/'.

Returns

A list of *ITView_V2_1* objects.

Exceptions Thrown

EZEBI RESOURCE NOT FOUND

If the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

If an invalid character is detected in the project dataset path.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/fctest"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultFcITView -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of the ITView_V2_1 objects:

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Local/nonExistentTestProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultFcITView -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
```

```
"message": "Cannot find the specified project 'pool63b/Local/
nonExistentTestProject'.",
   "extendedData": {}
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Lo+cal/testProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultFcITView -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "getProjectDefaultFcITView.arg0
  value 'pool63b/Lo+cal/testProject':
  Dataset path is not in the expected format that starts with a letter
  followed by alpha-numeric and may contain only the following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "message": "Dataset path is not in the expected format that starts
  with a letter followed by alpha-numeric and may contain only the
  following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "extendedData": {
    "EX_CAUSE_MESSAGE": null
  }
}
```

getProjectDefaultIscsilTView

Returns all the existing default iSCSI views for the specified project dataset path.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getVolumeITView, getProjectDefaultFcITView

Parameters datasetPath

A string representing the project dataset path.

A project dataset must start with a letter followed by a series of alphanumeric. It can contain only the following characters: 'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/'. The dataset, however, should not end with '/'.

Returns

A list of ITView_V2_1 objects.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in the project dataset path.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-test/Local/proj_snap"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultIscsiITView -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of *ITView_V2_1* objects if found.

```
"hostGroupName": "All",
    "targetGroupName": "default-pool-test-iscsi-target-group",
    "lunNbr": -1,
    "readOnly": false
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
```

```
-H 'authorization: Basic Auth TOKEN' \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '["pool63b/Local/nonExistentTestProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultIscsiITView -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Cannot find the specified project
  'pool63b/Local/nonExistentTestProject'.",
  "extendedData": {}
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Lo+cal/testProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultIscsiITView -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "getProjectDefaultIscsiITView.arg0
  value 'pool63b/Lo+cal/testProject':
  Dataset path is not in the expected format that starts with a letter
  followed by alpha-numeric and may contain only the following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "message": "Dataset path is not in the expected format that starts
  with a letter followed by alpha-numeric and may contain only the
  following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "extendedData": {
    "EX_CAUSE_MESSAGE": null
  }
}
```

getVolumeITView

Lists all the existing default iSCSI views for the specified volume dataset path.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getProjectDefaultIscsilTView, getProjectDefaultFclTView

Parameters datasetPath

A string representing the volume dataset path.

A volume dataset must start with a letter followed by a series of alpha-numeric characters. It can contain only the following characters: 'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/'. The dataset, however, should not end with '/'.

Returns

A list of ITView_V2_1 objects.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in the volume dataset path.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified volume doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Local/testProject/LUN1"]' \
https://198.51.100.10/zebi/api/v2/getVolumeITView -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of ITView_V2_1 objects.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Local/testProject/nonExistentLlun"]' \
https://198.51.100.10/zebi/api/v2/getVolumeITView -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "",
"message": "Cannot find the specified volume
'pool63b/Local/testProject/nonExistentLun'.",
"extendedData": {}
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Lo+cal/testProject/nonExistentLun"]' \
https://198.51.100.10/zebi/api/v2/getVolumeITView -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
"details": "getVolumeITView.arg0 value
'pool63b/Lo+cal/testProject/nonExistentLun':
```

```
Dataset path is not in the expected format that starts with a letter followed by alpha-numeric and may contain only the following:

'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",

"message": "Dataset path is not in the expected format that starts with a letter followed by alpha-numeric and may contain only the following:

'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",

"extendedData": {

"EX_CAUSE_MESSAGE": null
}
```

initiatorGroupExists

Checks if an initiator group exists on the Tegile array.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listInitiatorsInInitiatorGroup, addInitiatorToInitiatorGroup

Parameters

initiatorGroupName

A string: the name of the initiator group.

Returns

Returns a boolean value: **true** if the group exists, and **false** if it does not.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:testinigroup-group"]' \
  https://198.51.100.10/zebi/api/v2/initiatorGroupExists -k
```

Response

If the initiator group exists, the above request returns the HTTP status code 200 (OK) and the following data:

```
true
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json -d '[2012]' \
  https://198.51.100.10/zebi/api/v2/initiatorGroupExists -k
```

Response

If the initiator group does not exist, the above request returns the HTTP status code 200 (OK) and the following data:

```
false
```

listFCInitiators

Lists the FC initiators on the IntelliFlash array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createFCInitiator, listFCInitiatorGroups, listInitiatorsInInitiatorGroup, listTargetsInTargetGroup

Parameters

initiatorNamePattern

The name of the FC initiator you want to retrieve, or a regular expression pattern to retrieve more than one FC initiator name.

For example:

- "wwn.21000024FF279210" lists a specific initiator.
- ".*" lists all Fibre Channel initiators.
- "wwn.123.*" lists FC initiators starting with wwn.123.
- ".*89112" lists initiators ending with 89112.

Returns

A JSON array of the *FCInitiator_V2_1* objects that contain the details of the ISCSI initiators that currently exist.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '[".*"]' \
  https://198.51.100.10/zebi/api/v2/listFCInitiators -k
```

Response:

The above request returns the HTTP status code 200 (OK) and an array of JSON *FCInitiator_V2_1* objects for all the FC initiators found on the array. For example:

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["wwn.5001438001FCCCCCC"]' \
https://198.51.100.10/zebi/api/v2/listFCInitiators -k
```

Error Response

In this example, the initiator pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of array of JSON *FCInitiator_V2_1* objects.

Example 3

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[""]' \
https://198.51.100.10/zebi/api/v2/listIFCInitiators -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "listFCInitiators.arg0 value '':
   Pattern name is not valid, an invalid null, empty or blank pattern name
was detected.",
   "message": "Pattern name is not valid,
   an invalid null, empty or blank pattern name was detected.",
   "extendedData": {
        "EX_CAUSE_MESSAGE": null
   }
}
```

listFCInitiatorGroups

Lists the names of all Fibre Channel initiator groups created on a Tegile array. This is an HTTP GET method.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listFCTargetGroups, listInitiatorsInInitiatorGroup, createMappingForVolume.

Parameters

None

Returns

Returns an array of JSON strings. Each string in this list is a group name within the complete list of Fibre Channel Initiator group names found on the Tegile array.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[]' https://198.51.100.10/zebi/api/v2/listFCInitiatorGroups -k
```

Response

```
[
"fcinigroup",
"fcinigroup1"
]
```

listFCTargets

Lists the Fibre Channel (FC) targets on the IntelliFlash array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listTargetSInTargetGroup, createTargetGroup, moveTargetToTargetGroup

Parameters

targetNamePattern

The name of the FC target you want to retrieve, or a regular expression pattern to retrieve more than one FC target name.

For example:

- "wwn.1234567890123456" lists a specific FC target.
- ".*" retrieves all the FC targets.
- "wwn.210.*" retrieves targets starting with wwn.210.
- ".*89112" retrieves targets ending with 89112.

Returns

A JSON array of the *FCTarget_V2_1* objects that contains the details of the available FC targets.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://198.51.100.10/zebi/api/v2/listFCTargets -k
```

Response

The above request returns the HTTP status code 200 (OK) and an array of JSON *FCTarget_V2_1* objects for all the FC targets found on the array. For example:

```
[
        "targetName": "wwn.21000042BB326F3C",
        "targetStatus": "online",
        "targetNode": "controller-a",
        "targetGroupName": "default-fc-target-group",
        "targetSpeed": "4Gb"
        "targetPortType": "HBA"
    },
        "targetName": "wwn.31C5A0BE4F7D7463",
        "targetStatus": "offline",
        "targetNode": "controller-b",
        "targetGroupName": "",
        "targetSpeed": "not established"
        "targetPortType": "NPIV"
    },
]
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["wwn.5001438001FCCCCC"]' \
https://198.51.100.10/zebi/api/v2/listFCTargets -k
```

Error Response

In this example, the target pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of the JSON *FCTarget_V2_1* objects.

Example 3

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '[""]' \
  https://198.51.100.10/zebi/api/v2/listIFCTargets -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "listFCTargets.arg0 value '':
  Pattern name is not valid, an invalid null,
  empty or blank pattern name was detected.",
  "message": "Pattern name is not valid, an invalid null,
  empty or blank pattern name was detected.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

listFCTargetGroups

Lists all Fibre Channel Target groups available on a Tegile array. This is an HTTP GET method.

First Available Version

API v1.0, IntelliFlash 2.1.1.1

Related APIs

listFCInitiatorGroups, createMappingForVolume.

Parameters

None

Returns

Returns an array of JSON strings. Each string returned is the name of one Fibre Channel (FC) target group within the list of all FC target groups on the array. If the array does not have any FC card, an empty array is returned.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listFCTargetGroups -k
```

Response

```
[
"default-fc-target-group"
]
```

listInitiatorGroups

Lists all initiator groups available on the IntelliFlash array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deleteInitiatorGroup

Parameters

None

Returns

A list of *InitiatorGroup_V2_1* objects.

Examples

Example 1

Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '[]' \
https://198.51.100.10/zebi/api/v2/listInitiatorGroups -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of *InitiatorGroup_V2_1* objects if found.

listISCSIInitiatorGroups

Lists all the iSCSI initiator groups available on a Tegile array. This is an HTTP GET method.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listISCSITargetGroups, *initiatorGroupExists*, *addInitiatorToInitiatorGroup*, *createMappingForVolume*.

Parameters

None

Returns

Returns an array of JSON strings. Each string has the names of all iSCSI Initiator groups on the Tegile array.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
https://198.51.100.10/zebi/api/v2/listISCSIInitiatorGroups \
-k
```

Response

```
[
"inigrp1",
"testinigroup"
]
```

listISCSIInitiators

Lists the iSCSI initiator details on the IntelliFlash array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deletelscsilnitiator, listISCSIInitiatorGroups, listInitiatorsInIntiatorGroup, listISCSITargets, createlscsiInitiator

Parameters

initiatorNamePattern

The name of the iSCSI initiator you want to retrieve, or a regular expression pattern to retrieve more than one iSCSI initiators.

For example, "iqn.1991-05.com.microsoft:myHost" lists a specific initiator, ".*" retrieves all the initiators, "iqn.1991-05.com.microsoft:.*" retrieves initiators with that prefix, ".*myHost.*" retrieves initiators that contain 'myHost' in the name.

Returns

A JSON array of the *ISCSIInitiator_V2_1* objects that contain the details of the ISCSI initiators that currently exist.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://10.68.89.10/zebi/api/v2/listISCSIInitiators -k
```

Response:

The above request returns the HTTP status code 200 (OK) and an array of JSON *ISCSIInitiator_V2_1* objects for all the ISCSI initiators found on the array. For example:

```
[
    "initiatorName": "eui.1543553633737272",
    "initiatorGroupName": "",
    "chapUserName": null,
    "chapSecret": null
},
    "initiatorName": "iqn.1991-05.com.microsoft:a.tegile.com",
    "initiatorGroupName": "iscsi-igroup1",
    "chapUserName": "myChapName",
    "chapSecret": null
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.2012-02.com.tegile:does-not-exist"]' \
https://10.68.89.10/zebi/api/v2/listISCSIInitiators -k
```

Error Response

In this example, the initiator pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of JSON *ISCSIInitiator_V2_1* objects.

Example 3

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["*()(&^%$"]' \
https://10.68.89.10/zebi/api/v2/listISCSIInitiators -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "listISCSIInitiators.arg0 value '*()(&^%$':
  Invalid regular expression argument was detected.
  Please check the regular expression syntax.",
  "message": "Invalid regular expression argument was detected.
  Please check the regular expression syntax.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

listInitiatorsInInitiatorGroup

Lists all initiators belonging to the specified initiator group.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

initiatorGroupExists, getInitiatorGroup, listTargetSInTargetGroup.

Parameters

initiatorGroupName

A string: name of an iSCSI or a Fibre Channel initiator group.

Returns

Returns an array of JSON strings. Each string returned has a name of an initiator in the specified initiator group.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["APIInitiatorGroup"]' \
  https://198.51.100.10/zebi/api/v2/listInitiatorsInInitiatorGroup -k
```

Response

```
[
"iqn.1998-01.com.vmware:esx99",
"iqn.1998-01.com.vmware:esx98"
]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:testinigroup-grp"]' \
  https://198.51.100.10/zebi/api/v2/listInitiatorsInInitiatorGroup -k
```

Error Response

If the initiator group is not found, the above request returns the HTTP status code 200 (OK) and no data.

listISCSITargetGroups

Lists all the iSCSI target groups available on an array. This is an HTTP GET method.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listISCSIInitiatorGroups, createMappingForVolume.

Parameters

None

Returns

Returns an array of JSON strings. Each string returned is a name of an iSCSI target group found within the list of all iSCSI target groups found on the array.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listISCSITargetGroups -k
```

Response

```
[
"default-plaut-iscsi-target-group",
"tgtgrp1","testtargetgroup"
]
```

listISCSITargets

Lists the iSCSI target details on the IntelliFlash array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITarget, createISCSITargetForGroup, deleteISCSITarget

Parameters

targetNamePattern

The name of the target you want to retrieve, or a target name regular expression pattern to retrieve a list of targets.

For example, "iqn.2012-12.com.acme:atarget" lists a specific target, ".*" retrieves all the iSCSI targets, "iqn.2012-12.com.tegile:.*" retrieves targets with the prefix iqn.2012-12.com.tegile, ".*pool-a.*" retrieves targets with 'pool-a' in the name.

Returns

A JSON array of *ISCSITarget_V2_1* objects that contain the details of the ISCSI targets.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://10.68.89.10/zebi/api/v2/listISCSITargets -k
```

Response:

The above request returns the HTTP status code 200 (OK) and a JSON array of *ISCSITarget_V2_1* objects for all the ISCSI targets found on the array. For example:

```
[ {
       "targetSuffixName": "test",
       "targetAlias": "iscsi-alias",
       "targetGroupName": "iscsi-tgroup",
       "targetAuthenticationMode": "none",
       "targetChapName": "",
        "targetChapSecret": null,
        "targetNetworkBinding": [
            "10.68.97.211:3260"
        "targetName": "iqn.2012-02.com.tegile:test"
    },
       "targetSuffixName": "pool-demo",
        "targetAlias": "pool-demo",
        "targetGroupName": "default-pool-demo-iscsi-target-group",
        "targetAuthenticationMode": "none",
        "targetChapName": "",
        "targetChapSecret": null,
        "targetNetworkBinding": [
            "10.68.97.212:3260"
        "targetName": "iqn.2012-02.com.tegile:pool-demo"
    } ]
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.2012-02.com.tegile:no-exist"]' \
https://10.68.89.10/zebi/api/v2/listISCSITargets -k
```

Error Response

In this example, the target pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of JSON ISCSITarget_V2_1 objects for ISCSI targets found on the array.

listTargetsInTargetGroup

Lists all targets associated with the target group.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listInitiatorsInInitiatorGroup, createMappingForVolume.

Parameters

targetGroupName

A string: name of an iSCSI or a Fibre Channel target group.

Returns

Returns an array of JSON strings. Each string returned is a name of a target in the specified target group.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iscsitarget61"]' \
https://198.51.100.10/zebi/api/v2/listTargetsInTargetGroup \
  -k
```

Response

```
[
"iqn.2012-02.com.tegile:iscsitarget61",
"iqn.2012-02.com.tegile:test",
"iqn.2012-02.com.tegile:test1"
]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["default-test1-iscsi-target-group"]' \
  https://198.51.100.10/zebi/api/v2/listTargetsInTargetGroup \
  -k
```

Error Response

If the target group is not found, the above request returns the HTTP status code 200 (OK) and no data.

modifyISCSITargetAlias

Modifies the iSCSI target alias (or user friendly name) of the target to newly specified name.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITarget, createISCSITargetForGroup, deleteISCSITarget, listISCSITargets

Parameters

targetName

The name of the target you want to modify. For example, "iqn.2012-02.com.tegile:myTargetSuffix". The targetName is returned by listISCSITargets API. The targets in default target group cannot be modified.

targetAlias

The new target alias name.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified iSCSI target does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the default target is being modified

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.2012-02.com.tegile:test","rename-this-alias"]' \
https://10.68.89.10/zebi/api/v2/modifyISCSITargetAlias -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the user friendly alias of the target "iqn.2012-02.com.tegile:test" has been renamed to "rename-this-alias".

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["iqn.2012-02.com.tegile:does-not-exist","new-alias"]' \
  https://10.68.89.10/zebi/api/v2/modifyISCSITargetAlias -k
```

Error Response

In this example, the target does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"Failed to find iSCSI Target[iqn.2012-02.com.tegile:does-not-exist].
The target must exist for this operation to succeed.",
  "message":"Failed to find iSCSI Target to modify
  [iqn.2012-02.com.tegile:does-not-exist].",
  "extendedData":{"EX_CAUSE_MESSAGE":
  "Failed to find iSCSI Target[iqn.2012-02.com.tegile:does-not-exist]. T
  he target must exist for this operation to succeed.",
  "EX_CAUSE_CODE_NAME":"EZEBI_RESOURCE_NOT_FOUND"}}
```

moveTargetToTargetGroup

Moves a target specified with targetName to a new target group specified with newTargetGroupName.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createTargetGroup, listFCTargetGroups, listISCSITargetGroups

Parameters

targetName

Name of the target to move.

newTargetGroupName

Name of the destination target group.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the target or target group do not exist.

EZEBI INVALID ARGUMENT

This exception is thrown if an invalid character is detected in either the targetName or newTargetGroupName.

Examples

Exampe 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testtarget1", "aCoolTargetGroup"]' \
https://198.51.100.10/zebi/api/v2/moveTargetToTargetGroup -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testtarget1", "aNonExistentTargetGroup"]' \
https://198.51.100.10/zebi/api/v2/moveTargetToTargetGroup -k
```

Erroneous Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
   "code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Cannot find target group: aNonExistentTargetGroup",
   "extendedData": {}
}
```

Chapter 5

Dataset Methods

Topics:

- abortCopy
- checkPoolIntegrity
- copyDataset
- createProject
- createMappingForProject
- createShare
- createShare
- createVolume
- deleteDataset
- deleteDataset
- deleteMappingFromProject
- deletePool
- deleteProject
- deleteShare
- deleteShare
- deleteVolume
- deleteVolume
- exportPool
- getCopyStatus
- getDatasetSpaceInfo
- getPoolSpaceInfo
- getProject
- getProjectProperty
- getShare
- getShareProperty
- getVolume
- getVolumeProperty
- importPool
- inheritPropertyFromProject
- isProjectExposedOverNFS
- isProjectExposedOverSMB
- isShareExposedOverNFS
- isShareExposedOverSMB
- listAllCopyOperations
- listLunsByld
- listPools
- listProjects

The following sections describe Dataset methods, parameters and return types. They also include examples with sample responses.

- listRunningCopyOperations
- listShares
- listSharesByMountPoints
- listVolumes
- modifyProjectProperties
- modifyShareProperties
- modifyVolumeProperties
- resetPoolError
- setNFSSharingOnProject
- setNFSSharingOnShare
- setSMBSharingOnProject
- setSMBSharingOnShare

abortCopy

Aborts a running copy operation.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

copyDataset, getCopyStatus, listRunningCopyOperations, listAllCopyOperations

Parameters

taskGUID

The GUID of the copy operation task to be aborted.

Returns

Returns the HTTP status code 200 (OK) and return code 0.

Exceptions Thrown

EZEBI_GENERAL

This exception is thrown if the task GUID is invalid for the array.

Examples

Example 1

Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '["europa:84944c8a-8bc1-4705-809e-144363797a57"]'
https://198.51.100.10/zebi/api/v2/abortCopy -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["europa1:84944c8a-8bc1-4705-809e-144363797a57"]'
https://198.51.100.10/zebi/api/v2/abortCopy -k
```

Error Response

The above request returns HTTP status code 400 with the following message:

```
{
   "code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Cannot find copy task
'europ1a:84944c8a-8bc1-4705-809e-144363797a57'
   in pool: europa1.",
   "extendedData": {}
}
```

checkPoolIntegrity

Validates the integrity of the disks associated with a pool.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

importPoool, exportPool, resetPoolError

Parameters

poolName

Name of the pool where you want to clear the errors.

start

An integer which specifies whether to start (1) or stop (0) the pool integrity check.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the pool does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in the pool name or a start value is not 0 or 1.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool6a", 1]' \
https://198.51.100.10/zebi/api/v2/checkPoolIntegrity -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a", 1]' \
https://198.51.100.10/zebi/api/v2/checkPoolIntegrity -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "Pool not found.",
"message": "The pool [nonExistentPool6a] was not found.",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Pool not found.",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

```
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a", 0]' \
https://198.51.100.10/zebi/api/v2/checkPoolIntegrity -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_GENERAL",
  "details": "",
  "message": "Failed to check pool [pool63a] integrity.
  This could be due to an invalid scan pool state transition request",
  "extendedData": {}
}
```

copyDataset

Starts a copy operation.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getCopyStatus, listRunningCopyOperations, listAllCopyOperations, abortCopy

Parameters

CopySource_V2_1

CopyDestination_V2_1

Returns

A task GUID for the copy operation.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified source dataset is not available.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an invalid character is present in the CopySource_V2_1 or the CopyDestination_V2_1 field.
- If the specified source dataset is not available.
- If the dataset names are invalid.
- · If the host is invalid.
- If the start and end subproject suffix numbers are invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '[{"poolName": "europa",
"projectName": "images",
"subProjectName": "template"
"hostName": "10.68.132.120",
"poolName": "napa",
"projectName": "remotecopy",
"subProjectNamePrefix": "prod",
"subProjectNameNumberStart": 1,
"subProjectNameNumberEnd": 3,
"subProjectNameWildcard": ""
]'\
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

Response

The above request returns the HTTP status code 200 (OK) and a string. The returned string is the copy operation's GUID:

```
'84944c8a-8bc1-4705-809e-144363797a57'
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN' \
 -H 'cache-control: no-cache' \overline{\ \ }
 -H 'content-type: application/json' \
 -d '[{"poolName": "europal",
"projectName": "images",
"subProjectName": "template"
},
"hostName": "10.68.132.120",
"poolName": "napa",
"projectName": "remotecopy",
"subProjectNamePrefix": "prod",
"subProjectNameNumberStart": 1,
"subProjectNameNumberEnd": 3,
"subProjectNameWildcard": ""
]'\
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

Error Response

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Unable to find project images in europal",
   "extendedData": {}
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST \
 -H 'authorization: Basic Auth_TOKEN' \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '[{"poolName": "europa1@",
"projectName": "images",
"subProjectName": "template"
},
"hostName": "10.68.132.120",
"poolName": "napa",
"projectName": "remotecopy",
"subProjectNamePrefix": "prod",
"subProjectNameNumberStart": 1,
"subProjectNameNumberEnd": 3,
"subProjectNameWildcard": ""
]'\
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

Error Response

The above request returns the HTTP status code 400 and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "copyDataset.arg0.poolName value 'europal@':
  Pool name is not in the expected format
  that starts with a letter followed by alpha-numeric,_,-...",
  "message": "Pool name is not in the expected format
  that starts with a letter followed by alpha-numeric,_,-...",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

createProject

Creates a generic project with given parameters.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getProject, modifyProjectProperties, getProjectProperty

Parameters

Project

A *Project_V2_1* object for which project needs to be created.

If the parameters are not specified, default values are used. "poolName", "projectName" are mandatory. You can configure other general properties in *Project_V2_1* that are not marked as "read only".

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

If the parameters are invalid (when the key-value pair is not supported by *Project_V2_1*).

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and an integer 0.

Example 2

Erroneous Request (curl)

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "createProject.arg0 value
  'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$Project_V2_1@1778db80':
  Invalid Compression Algorithm, disable compression by passing in 'Off'
  or enable compression by using one of the following: Lzjb, Gzip-2, Gzip,
  Gzip-9, Lz4.",
  "message": "Invalid Compression Algorithm, disable compression by passing
  in 'Off'
  or enable compression by using one of the following: Lzjb, Gzip-2, Gzip,
  Gzip-9, Lz4.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
    }
}
```

createMappingForProject

Creates a project-level default mapping.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deleteMappingFromProject, createMappingForVolume

Parameters

datasetPath

Path of the project. The format is <poolName/Local/<projectName>.

This operation is not allowed for replica project datasets.

initiatorGroupName

Name of the initiator group.

targetGroupName

Name of the target group.

readOnly

Whether mapping is read-only. The values are True and False.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success or if the desired view already exists.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project, initiator group, or target group cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for any of the following reasons:

- The path specified belongs to a replica dataset.
- The target group and initiator group have different protocols.
- The target group and initiator group are either iSCSI or FC protocols (unknown).
- The view already exists with the wrong read-only type.
- The mapping for this target group already exists (when trying to make All mapping).
- The mapping with 'All' initiator groups already exists on this target group.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "All", "default-pool-a-iscsi-target-group",
  true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "demoiSCSIInitiatorGroup",
  "demoiSCSITargetGroup", true
```

```
]' \
https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

Error Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"",
   "message":"Specified initiator and target groups are not the same
protocol.
   Initiator protocol: Unknown. Target protocol: iSCSI",
   "extendedData":{}
}
```

Example 3

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject", "All", "default-pool-a-iscsi-target-group", true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

Error Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
    "details":"createMappingForProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are 'pool-name/
Local/project-name'
    or 'pool-name/Local/project-name/share-or-lun-name'.",
    "message":"Local dataset path expected. For example, valid formats are
    'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject", "All", "default-pool-a-iscsi-target-group", true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

Error Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

Example 5

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "demoFCInitiatorGroup", "demoiSCSITargetGroup",
  true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

Error Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
{
```

createShare

Creates a share with the specified share options and share permissions.



Important:

In an SMB3 enabled environment, if a project has both NFS and SMB sharing enabled, creating share using **createShare** API is not supported. To enable share creation, turn off any one of these protocols on the project.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listShares, createShare, deleteShare.

Parameters

poolName

A string: the name of the pool in which the share is created.

projectName

A string: the name of the project in which the share is created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, * ,',,\, * ,-,+, =, }, |, :, {, [,], ;, \', \", & are not allowed in projectname. The empty and space characters and the null values are not allowed in projectname.

shareName

A string: the share name.

shareOptions

A *ShareOptions* object that specifies the mount point, block size, quota, and reservation. This parameter is optional. If some of the settings included in this parameter are not specified, the defaults are as follows:

• If Block Size is null or is an empty string ("") then the block size of the new share is set to 32KB and the override record (Block) size flag is set to false.

- If the Mount Point is not specified or is an empty string ("") then the default mountpoint is used and the override mountpoint flag is set to false.
- If the Quota and Reservation are not specified or is set to "-1" then no quota or reservation is applied to the new share.

sharePermissions

An array of the *SharePermissions* object that defines permissions for the new share using ACLs.

Returns

Returns an integer: the number 0, if the request succeeds.

Examples

Example 1

Request (curl)

Response

HTTP Status Code: 200

```
0
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

Error Response

HTTP Status Code: 400

```
"message": "Error while saving: shareName.
    Reason: Unable to open BadPoolName/Local/projectName:
    dataset does not exist",
    "extendedData": { },
    "details": "",
    "code": "EZEBI_GENERAL"
}
```

createShare

Creates a share with the default share properties (A block size of 32 KB; no quota; no reservation).



Important:

In an SMB3 enabled environment, if a project has both NFS and SMB sharing enabled, creating share using **createShare** API is not supported. To enable share creation, turn off any one of these protocols on the project.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listShares, createShare, deleteShare.

Parameters

poolName

A string: the name of the pool in which the share is created.

projectName

A string: the name of the project in which the share is created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, * ,',, \, * , -, +, =, }, |, :, {, [,], ;, \', \", & are not allowed in projectname. The empty and space characters and the null values are not allowed in projectname.

shareName

A string: the share name.

sharePermissions

An array of the *SharePermissions* object that defines permissions for the new share using ACLs.

Returns

An integer: The number 0 if the request succeeds.

Examples

Example 1

Request (curl)

Response

HTTP Status Code: 200

```
0
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

Error Response

HTTP Status Code: 400

```
"message": "Error while saving: shareName.
    Reason: Unable to open BadPoolName/Local/projectName:
    dataset does not exist",
    "extendedData": { },
    "details": "",
    "code": "EZEBI_GENERAL"
}
```

createVolume

Creates a volume with the specified settings.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

initiatorGroupExists, addInitiatorToInitiatorGroup

Parameters

volume

A JSON object of type *Volume_V1_0* that contains the parameters required to create the volume.

inheritSANViewSettingsFromProject

Indicates whether to copy the view settings related to the intended protocol (iSCSI or FC) from the project. The default views created on the project are copied over if this parameter is true. If this parameter is false, then the volume is created with no views attached to it. This is a boolean value.

Returns

Returns an integer, where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Examples

Example 1

Request (curl)

Response

0

Example 2

Erroneous Request

Error Response

```
HTTP Status Code: 400
{
   "message": "A volume/share with the same name pool1/Local/TechPubs/
   api_createVolume_name already exists.",
   "extendedData": {},
   "details": "",
   "code": "EZEBI_GENERAL"
}
```

deleteDataset

Deletes the specified dataset.



Caution: If the **recursive** parameter is set to **true** all dependent objects are deleted. For example, if the **datasetPath** points to a project all shares and LUNs in the project, and their snapshots and clones are deleted.



Warning: The delete operation is not reversible.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listVolumes

Parameters

datasetPath

A string: the path to the dataset. The dataset path has the format: PoolName/Local/ProjectName/VolumeName.

recursive

A boolean value: indicates whether the dependents (for example clones of the dataset) of this dataset should be removed (if true) before trying to delete the dataset or not (if false). Deletion might fail if the dataset has dependents.

errorlfNotExist

A boolean value: indicates whether to raise (if true) an exception if the path specified by datasetPath does not exist.

Returns

Returns no data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubsTest",true, true]' \
  https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

Response

On success, the above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/ \
  -d '["pool1/Local/TechPubs/api_createVolume_name", \
    false, false]' \
  https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"message": "Unable to delete pool1/Local/TechPubs/api_createVolume_name",
    "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_BUSY",
        "EX_CAUSE_MESSAGE": "dataset is busy",
        "EX_CAUSE_CODE_NUMBER": "2007"
        },
    "details": "dataset is busy",
    "code": "EZEBI_GENERAL"
}
```

deleteDataset

Promotes dependents as specified, and deletes the dataset whose path is supplied as an argument.

Dependents are deleted as well if promote is false.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deleteShare, deleteVolume

Parameters datasetPath

This string uniquely identifies the dataset on the IntelliFlash array.

recursive

Defines whether to remove the dependants (clones for example) and LUN of the dataset before trying to delete it. Deletion might fail if there are dependants or a LUN exists on a dataset.

errorlfNotExist

Defines whether to raise an exception if the datasetPath to delete doesn't exist.

promote

Defines whether to promote dependents.

Returns

COMMAND_STATUS.COMMAND_SUCCEED(0) on success.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified dataset doesn't exist.

EZEBI_RESOURCE_INUSE

This error is thrown for the following conditions:

- · If replication is currently running
- If replication configuration exists and the project to delete is local
- If deleting replication configuration fails

EZEBI_RESOURCE_SUSPENDED

This error is thrown if the pool is suspended.

EZEBI_INVALID_ARGUMENT

This error is thrown for the following conditions:

- If the dataset is empty
- If the dataset length is greater than the maximum length
- If the dataset contains invalid characters

EZEBI_GENERAL

This error is thrown if deletion failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-dataset", false, true, true
        ]'
https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-dataset", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "No such dataset exists.",
   "extendedData": {}
}
```

deleteMappingFromProject

Deletes an existing project mapping.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createMappingForProject, createMappingForVolume

Parameters

datasetPath

Path of the project. The format is <poolName/Local/<projectName>.

initiatorGroupName

Name of the initiator group in the existing mapping.

targetGroupName

Name of the target group in the existing mapping.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project, initiator group, or target group cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for any of the following reasons:

- The target group and initiator group have different protocols.
- The target group and initiator group are either iSCSI or FC protocols (unknown).
- The view or mapping does not exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "demoiSCSIInitiatorGroup",
  "demoiSCSITargetGroup"
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteMappingFromProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

Error Response

In this example, the request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"",
   "message":"Did not find the view to delete.
   Project=pool-a/Local/demoProject.
   Initiator group=demoiSCSIInitiatorGroup .Target
group=demoiSCSITargetGroup",
   "extendedData":{}
}
```

Example 3

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \( \)
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Specified target group 'UNKNOWNiSCSITargetGroup' does not
exist.",
    "extendedData":{}
}
```

deletePool

Deletes a pool.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

importPool, exportPool, resetPoolError, checkPoolIntegrity

Parameters

poolName

Name of the pool to delete.

force

A boolean, which specifies whether to force the deletion of the pool with its dependents.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

If the pool does not exist.

EZEBI_INVALID_ARGUMENT

If an invalid character is detected in the pool name.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool6a", false]' \
https://198.51.100.10/zebi/api/v2/deletePool -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a", false]' \
https://198.51.100.10/zebi/api/v2/deletePool -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "Pool not found.",
  "message": "The pool [nonExistentPool63a] was not found.",
  "extendedData": {
     "EX_CAUSE_MESSAGE": "Pool not found.",
     "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
  }
}
```

deleteProject

Deletes a project

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createProject, listProjects

Parameters projectDatasetpath

The path for the project dataset.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project doesn't exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in the project dataset path.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a/Local/testProject"]' \
https://198.51.100.10/zebi/api/v2/deleteProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a/Local/nonExistentProject"]' \
https://198.51.100.10/zebi/api/v2/deleteProject -k
```

Example 2

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Cannot find the specified project 'pool63a/Local/
nonExistentProject'.",
  "extendedData": {}
}
```

deleteShare

Promotes dependents as specified, and then deletes the share whose dataset path is supplied as an argument.

Dependents are deleted as well if promote is false.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deleteDataset

Parameters

datasetPath

This string identifies the share on the IntelliFlash array.

recursive

Whether to remove the dependents of the dataset before deleting it.

errorlfNotExist

Whether to raise an exception if the datasetPath to delete doesn't exist.

promote

Whether to remove the dependents of the dataset before deleting it.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if a dataset is not found.

EZEBI_RESOURCE_INUSE

This exception is thrown if the replication is currently running.

EZEBI_RESOURCE_SUSPENDED

This exception is thrown if the pool is suspended.

EZEBI_GENERAL

This exception is thrown if deletion failed.

EZEBI INVALID ARGUMENT

This exception is thrown for the following conditions:

- If the dataset is empty
- If the length is greater than the maximum length
- If it contains invalid characters

Examples

Example 1

Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-share", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteShare -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-share", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteShare -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the

following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "No such share exists.",
   "extendedData": {}
}
```

deleteShare

Deletes the specified share, and optionally, any dependents of the share.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the given share) are also deleted.



Warning: The delete operation is not reversable.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

listShares, createShare, createShare.

Parameters

datasetPath

A string: the path which uniquely identifies the share. The dataset path has the format: PoolName/Local/ProjectName/ShareName. You can obtain the datasetPath from the listShares API. For more information, see *listShares* and *Share_V1_0*.

recursive

A boolean: a **true** specifies that dependents of the share should be deleted before deleting the share or not (**false**)

errorlfNotExist

A boolean value: that specifies if an exception is raised (if true) if the given dataset path does not exist or not (if false).

Returns

Returns no data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["Pool1/Local/Project1/Share1", false, false]' \
  https://198.51.100.10/zebi/api/v2/deleteShare -k
```

Response

On success, the above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["test/Local/KKKK/NoSuchShare", false, false]' \
  https://198.51.100.10/zebi/api/v2/deleteShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

deleteVolume

Deletes the specified volume, and optionally, any dependents of the volume.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the given volume) are also deleted.



Warning: The delete operation is not reversible.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listVolumes, createVolume.

Parameters

datasetPath

A string: the path which uniquely identifies the volume on the Tegile array. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume_V1_0*.

recursive

A boolean: indicates whether the dependents (for example, clones of the dataset) of the dataset should be removed (if true) before trying to delete the dataset. This API fails if you try to delete a volume that has dependents and the recursive parameter is set to **false**.

errorlfNotExist

A boolean value: indicates whether to raise (if true) an exception if the path specified by the dataset parameter does not exist.

Returns

Returns no data.

Examples

Example 1

Request (curl)

curl -X POST -H "Authorization:Basic Auth TOKEN" \

```
-H Content-Type:application/json \
-d '["pool1/Local/TechPubs/api_createVolume_name_2", \
    true,true]' \
https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/api_createVolume_", \
    true,true]' \
  https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
   "message": "Unable to delete pool1/Local/TechPubs/api_createVolume_
because it does not exist",
   "extendedData": {},
   "details": "",
   "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

deleteVolume

Promotes the specified dependent and then deletes the volume whose dataset path is supplied as an argument. Dependents are deleted as well if promote is false.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deleteDataset

Parameters datasetpath

The string that uniquely identifies the volume on the IntelliFlash array.

recursive

Whether to remove the dependants (for example, clones) and lun of the dataset before trying to delete it. Deletion might fail if there are dependants or lun existing on the dataset.

errorlfNotExist

Whether to raise an exception if the datasetPath to delete doesn't exist.

promote

Whether to promote clone before deletion

Returns

COMMAND_STATUS.COMMAND_SUCCEED(0) on success

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the dataset is not found.

EZEBI_RESOURCE_INUSE

This exception is thrown if replication is currently running.

EZEBI_RESOURCE_SUSPENDED

This exception is thrown if pool is suspended.

EZEBI_GENERAL

This exception is thrown if deletion failed.

EZEBI INVALID ARGUMENT

This exception is thrown for the following conditions:

- If the dataset is empty
- If the length is greater than the maximum length
- If it contains invalid characters

Examples

Example 1

Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-volume", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-volume", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

Error Response

The above request returns the HTTP status code 404 and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "No such volume exists.",
   "extendedData": {}
}
```

exportPool

Exports a pool.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deletePool, importPool, resetPoolError, checkPoolIntegrity

Parameters

poolName

Name of the pool to export.

Returns

Returns an integer status where:

• 0 indicates that the request succeeded.

• 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

If the pool does not exist.

EZEBI_INVALID_ARGUMENT

If an invalid character is detected in the poolName.

EZEBI_RESOURCE_EXIST

If an active pool with the same name exists already.

EZEBI_OPERATION_NOT_ALLOWED

If pool is in a state where export cannot be done.

EZEBI_GENERAL

Examples

Example 1

Request (curl):

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool6a"]' \
https://198.51.100.10/zebi/api/v2/exportPool -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a", false]' \
https://198.51.100.10/zebi/api/v2/exportPool -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and thefollowing message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "Pool requested for export was not found",
  "message": "Failed to export the pool [nonExistentPool6a].",
  "extendedData": {
     "EX_CAUSE_MESSAGE": "Pool requested for export was not found",
     "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
  }
}
```

getCopyStatus

Returns the status of a copy operation task.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

copyDataset, listRunningCopyOperations, listAllCopyOperations, abortCopy

Parameters taskGUID

The GUID of the copy operation task.

Returns

Returns the *CopyDestination_V2_1* object.

Exceptions Thrown EZEBI_GENERAL

This exception is thrown if the task GUID is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["europa:84944c8a-8bc1-4705-809e-144363797a57"]' \
```

```
https://198.51.100.10/zebi/api/v2/getCopyStatus -k
```

Response

The above request returns the HTTP status code 200 (OK) and the *CopyDestination_V2_1* object.

```
"numberOfCopies": 3,
"completedCopies": 3,
"status": "COMPLETED",
"allDatasets": [
   "napa/Local/remotecopy/prod1",
    "napa/Local/remotecopy/prod2",
    "napa/Local/remotecopy/prod3"
"completedDatasets": [
    "napa/Local/remotecopy/prod1",
    "napa/Local/remotecopy/prod2",
   "napa/Local/remotecopy/prod3"
"pendingDatasets": [],
"percentComplete": 100,
"errorCode": null,
"startTime": "2017-07-10T11:00:16-07:00",
"endTime": "2017-07-10T11:01:03-07:00"
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["euro:84944c8a-8bc1-4705-809e-144363797a57"]' \
https://198.51.100.10/zebi/api/v2/getCopyStatus -k
```

Error Response

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_GENERAL",
   "details": "",
   "message": "Pool euro is not mounted.",
   "extendedData": {}
}
```

getDatasetSpaceInfo

Returns a *DatasetSpaceInfo_V2_1* object if the specified dataset exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getPoolSpaceInfo

Parameters

Dataset-path

A string specifying path to the dataset (share or volume).

Returns

A DatasetSpaceInfo_V2_1 object.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This error is thrown if the parameters are invalid (if dataset name contains special characters).

EZEBI_GENERAL

This error is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified dataset doesn't exist.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and a *DatasetSpaceInfo_V2_1* object.

```
"originalUsedByDataAndSnapshot": 30208,
   "usedByDataAndSnapshot": 30208,
   "compressionSavingsPercentage": 0,
   "available": 1202104,
   "usedByData": 13824,
   "usedBySnapshot": 16384,
   "usedByReservation": 0,
   "quota": 1232312,
   "volSize": 0
}
```

Example 2

Erroneous Request (curl)

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Cannot find dataset: pool-a/Local/my-project/non-exist",
   "extendedData": {}
}
```

getPoolSpaceInfo

Returns a *PoolSpaceInfo_V2_1* object if it exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getDatasetSpaceInfo

Parameters

Pool-name

A string specifying pool name.

Returns

A *PoolSpaceInfo_V2_1* object.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This error is thrown if the parameters are invalid (pool name contains special characters).

EZEBI_GENERAL

This error is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified pool doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a"
  }
} https://198.51.100.10/zebi/api/v2/getPoolSpaceInfo -k
```

Response

The above request returns the HTTP status code 200 (OK) and a *PoolSpaceInfo_V2_1* object.

```
"totalPoolSize": 1024173568,
  "originalUsedByDataAndSnapshot": 899392896,
  "usedByDataAndSnapshot": 248960000,
  "compressionSavingsPercentage": 72.32,
  "dedupeSavingsPercentage": 0,
  "totalSavingsPercentage": 72.32,
```

```
"usedByAll": 252706816,
  "available": 771466752,
  "usedByData": 248025600,
  "usedBySnapshot": 934400,
  "usedByReservation": 0,
  "totalMetaSize": 0,
  "usedMeta": 0
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-non-exist"
  }
]' https://198.51.100.10/zebi/api/v2/getPoolSpaceInfo -k
```

Error Response

The above request returns the HTTP status code 404 (Not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Cannot find the pool: pool-non-exist",
   "extendedData": {}
}
```

getProject

Returns a *Project_V2_1* object if the project exists.

Related APIs

createProject, modifyProjectProperties, getProjectProperty

Parameters pool-name

A string specifying the name of the pool

Project-name

A string specifying the name of the project.

Is-local

A Boolean value indicating whether the project is local or replica.

project

The name of the project.

Returns

A Project_V2_1 object.

Exceptions thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or pool name contains special characters).

EZEBI_GENERAL

This exception is thrown if operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if specified project doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
   -H 'authorization: Basic YOUR_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
        "pool-a", "my-project", true
]' https://YOUR_IP/zebi/api/v2/getProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and a *Project_V2_1* object.

```
"quotaEnabled": false,
    "dedup": "on",
    "copies": "1",
    "primaryCache": "all",
    "secondaryCache": "all",
    "readonly": "off",
    "logbias": "latency",
    "aclInherit": "off",
    "aclMode": "passthrough",
    "krbStatus": false,
    "defaultVolumeSizeInByte": 1073741824,
    "defaultVolumeBlockSize": "4KB",
    "defaultThinProvisioning": true,
    "sync": "standard",
    "zfsDataSetName": "pool-a/Local/my-project ",
    "recordSize": "16KB",
    "quota": 0,
    "quotaMetric": "GB",
    "defaultVolumeSize": 1,
    "defaultVolumeSizeUnit": "GB"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic YOUR_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
     "pool-a", "non-exist", true
]' https://YOUR_IP/zebi/api/v2/getProject -k
```

Error Response

The above request returns the HTTP status code 404 (Not found) and the following message:

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "Cannot find the specified project 'pool-a/Local/non-exist'.",
    "extendedData": {}
}
```

getProjectProperty

Returns a *DatasetProperty_V2_1* object if the project exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createProject, modifyProjectProperties, getProject

Parameters

Dataset-path

A string specifying the project path.

Property-name

A string specifying the property to query.

Returns

A *DatasetProperty_V2_1* object that contains the query key and value.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or property name contains invalid characters).

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Local/my-project", "dedup"
    ]'
https://198.51.100.10/zebi/api/v2/getProjectProperty -k
```

Response

The above request returns the HTTP status code 200 (OK) and a <code>DatasetProperty_V2_1</code> object.

```
{
    "propertyKey": "dedup",
    "propertyValue": "on"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Local/my-project", "non-exist-property"
    ]'
https://198.51.100.10/zebi/api/v2/getProjectProperty -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Can't get property:non-exist-property.
   Please supply a valid project property.
   Check API documents for more details",
   "extendedData": {}
}
```

getShare

Returns a *Share_V2_1* object if it exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createShare, modifyShareProperties, getShareProperty

Parameters Share-path

A string specifying path to share.

Returns

A *Share_V2_1* object.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or share name contains special characters).

EZEBI_GENERAL

This exception is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-share"
  }
]' https://198.51.100.10/zebi/api/v2/getShare -k
```

Response

The above request returns the HTTP status code 200 (OK) and a *Share_V2_1* object.

```
"name": "my-share",
"poolName": "pool-a",
"projectName": "my-project ",
"purpose": "custom",
"guid": "07ee6f26-f701-4e98-8db6-778736e72df8",
"compression": "lz4",
"overrideCompression": false,
"localDataset": true,
"reservationInByte": 43,
"reservation": 0.00004100799560546875,
"reservationMetric": "MB",
"reservationEnabled": true,
"dedup": "on",
"overrideDedup": false,
"copies": "1",
"overrideCopies": false,
"primaryCache": "metadata",
"overridePrimaryCache": true,
"secondaryCache": "all"
"overrideSecondaryCache": false,
"readonly": "off",
"overrideReadonly": false,
"logbias": "throughput",
"overrideLogbias": true,
"sync": "standard",
"overrideSync": false,
```

```
"overrideProjectSnapshotSettings": false,
    "zfsDataSetName": "pool-a/Local/my-project /my-share ",
    "compressedLog": "off",
    "overrideCompressedLog": true,
    "overrideMountPoint": true,
    "quotaInByte": 1232312,
    "quota": 1.1752243041992188,
    "quotaMetric": "MB",
    "quotaEnabled": true,
    "mountPoint": "/export/my-project/my-share",
    "availableSize": 1202104,
    "totalSize": 1232312,
    "overrideSharenfs": true,
    "overrideSharesmb": true,
    "krbStatus": false,
    "cifsDisplayName": "my-share",
    "guestStatus": false,
    "aclInherit": "off",
    "overrideAclInherit": false,
    "recordSize": "16KB",
    "overrideRecordSize": false,
    "atime": "on",
    "nbmand": "off",
    "aclList": [
            "id": 0,
            "controllerId": null,
            "aclType": "Group",
            "aclUser": null,
            "aclGroup": "dasd",
            "aclValDisplay": "rwxpdDaARWcCos",
            "aclVal": 2032127,
            "aclMode": "Allow",
            "aclInheritanceFlag": "Default",
            "includeSubShares": false,
            "userId": 0,
            "groupId": 104
        },
            "id": 0,
            "controllerId": null,
            "aclType": "User",
            "aclUser": "user1",
            "aclGroup": null,
"aclValDisplay": "rwxpdDaARWcCos",
            "aclVal": 2032127,
            "aclMode": "Allow",
            "aclInheritanceFlag": "Default",
            "includeSubShares": false,
            "userId": 104,
            "groupId": 0
        }
    "containerName": "Local"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/non-exist"
  }
]' https://198.51.100.10/zebi/api/v2/getShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "Unable to open pool-a/Local/my-project/non-exist: dataset
does not exist",
   "message": "Unable to open pool-a/Local/my-project/non-exist: dataset
does not exist",
   "extendedData": {
        "EX_CAUSE_MESSAGE": "Unable to open pool-a/Local/
            my-project/non-exist: dataset does not exist",
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_CODE_NUMBER": "2009"
   }
}
```

getShareProperty

Returns a *DatasetProperty_V2_1* if it exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createVolume, modifyVolumeProperties, getVolumeProperty, getProjectProperty

Parameters

Share-path

A string specifying the path to share.

Returns

A *DatasetProperty_V2_1* contains the query key and value.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This error is thrown if the parameters are invalid (project or share name contains special characters)

EZEBI_GENERAL

This error is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified share doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
   {
     "pool-a/Local/my-project/my-share",
          "quotaInByte"
   }
]' https://198.51.100.10/zebi/api/v2/getShareProperty -k
```

Response

The above request returns the HTTP status code 200 (OK) and a *DatasetProperty V2_1* object.

Example 2

Erroneous Request

```
curl -X POST \
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Can't get property:non-exist-property is not a valid
field!.
   Please supply a valid property. Check API documents for more details",
   "extendedData": {}
}
```

getVolume

Returns a *Volume_V2_1* object if it exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createVolume, modifyVolumeProperties, getVolumeProperty

Parameters

Volume-path

A string specifying the path to volume.

Returns

A *Volume_V2_1* object.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

EZEBI GENERAL

This exception is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified volume doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-volume"
  }
]' https://198.51.100.10/zebi/api/v2/getVolume -k
```

Response

The above request returns the HTTP status code 200 (OK) and a *Volume_V2_1* object.

```
"name": "my-volume",
"poolName": "pool-a",
"projectName": "my-project",
"purpose": "custom",
"quid": "007ef1b2-cae6-41ff-9523-de0d81249819",
"compression": "lz4",
"overrideCompression": false,
"localDataset": true,
"reservationInByte": 0,
"reservation": 0,
"reservationMetric": null,
"reservationEnabled": false,
"dedup": "off",
"overrideDedup": false,
"copies": "1",
"overrideCopies": false,
"primaryCache": "all",
"overridePrimaryCache": false,
"secondaryCache": "all",
"overrideSecondaryCache": false,
"readonly": "off",
"overrideReadonly": false,
"logbias": "latency",
"overrideLogbias": false,
"sync": "standard",
"overrideSync": false,
"overrideProjectSnapshotSettings": false,
"zfsDataSetName": "pool-a/Local/my-project/ my-volume ",
"compressedLog": "off",
"overrideCompressedLog": false,
```

```
"volSize": 33285996544,
  "luId": "600144F087EC75370000594058180013",
  "usedSize": 48733696,
  "thinProvisioning": true,
  "blockSize": "32KB",
  "writeBackCache": "enable",
  "overrideViews": false,
  "protocol": "iSCSI",
  "containerName": "Local"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/non-exist"
  }
]' https://198.51.100.10/zebi/api/v2/getVolume -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

getVolumeProperty

Returns a *DatasetProperty_V2_1* object if it exists.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createVolume, modifyVolumeProperties, getShareProperty, getProjectProperty

Parameters

Volume-path

A string specifying path to volume.

Returns

A DatasetProperty V2 1 object that contains the guery key and value.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

EZEBI_GENERAL

This exception is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified volume doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Local/my-project/my-volume",
"dedup"
]' https://198.51.100.10/zebi/api/v2/getVolumeProperty -k
```

Response

The above request returns the HTTP status code 200 (OK) and a DatasetProperty_V2_1 object.

```
{
   "propertyKey": "dedup",
   "propertyValue": "off"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
      "pool-a/Local/my-project/my-volume",
      "non-exist-property"
      ]'
https://198.51.100.10/zebi/api/v2/getVolumeProperty -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Can't get property:non-exist-property is not a valid
field!.
   Please supply a valid property. Check API documents for more details",
   "extendedData": {}
}
```

importPool

Imports a pool.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deletePool, exportPool, resetPoolError, checkPoolIntegrity

Parameters poolName

Name of the pool to import.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the pool does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in the poolName.

EZEBI_RESOURCE_EXIST

This exception is thrown if an active pool with the same name exists already.

EZEBI_OPERATION_NOT_ALLOWED

This exception is thrown if pool is in a state that doesn't permit import.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
   -H 'authorization: Basic AUTH_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '["pool6a"]' \
https://198.51.100.10/zebi/api/v2/importPool -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a", false]' \
https://198.51.100.10/zebi/api/v2/importPool -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "Pool requested for import was not found",
"message": "Failed to import the pool [nonExistentPool6a].",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Pool requested for import was not found",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

inheritPropertyFromProject

Reverts share or volume configuration value to parent configuration value.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createProject, modifyProjectProperties, getProjectProperty, modifyShareProperties, modifyVolumeProperties

Parameters

Dataset-path

A string specifying path to the dataset (either share or volume).

Property-name

A string specifying the property to revert.

Valid property name includes Compression, Dedup, Copies, PrimaryCache, SecondaryCache, Readonly, Logbias, Sync, CompressedLog, ProjectSnapshotSettings, MountPoint, Sharenfs, Sharesmb, AclInherit, and Views.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or share name contains special characters).

EZEBI_GENERAL

This exception is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified dataset doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-dataset",
        "Dedup"
    }
]'
https://198.51.100.10/zebi/api/v2/inheritPropertyFromProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-dataset",
        "non-supported-property"
  }
]'
https://198.51.100.10/zebi/api/v2/inheritPropertyFromProject -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code": "EZEBI_INVALID_ARGUMENT",
```

```
"details": "inheritPropertyFromProject.arg1 value 'non-supported-
property':
    Supported Inheritable Properties includes: Compression, Dedup, Copies,
PrimaryCache,
    SecondaryCache, Readonly, Logbias, Sync, CompressedLog,
ProjectSnapshotSettings,
    MountPoint, Sharenfs, Sharesmb, AclInherit, Views.",
    "message": "Supported Inheritable Properties includes:
    Compression, Dedup, Copies, PrimaryCache, SecondaryCache, Readonly,
Logbias, Sync,
    CompressedLog, ProjectSnapshotSettings, MountPoint, Sharenfs, Sharesmb,
AclInherit, Views.",
    "extendedData": {
        "EX_CAUSE_MESSAGE": null
    }
}
```

isProjectExposedOverNFS

Returns whether the NFS protocol is enabled for a project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, getNFSNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

Returns

Returns True or False based on whether NFS protocol is enabled.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to replica dataset.

EZEBI GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/isProjectExposedOverNFS -k
```

Response

The above request returns the HTTP status code 200 (OK) and returns a true or false value indicating whether NFS is enabled over the specified project.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/isProjectExposedOverNFS -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

isProjectExposedOverSMB

Returns whether the SMB protocol is enabled for a project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, getSMBNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

Returns

Returns True or False based on whether SMB protocol is enabled.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to replica dataset.

EZEBI GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
```

```
]' \
https://198.51.100.10/zebi/api/v2/isProjectExposedOverSMB -k
```

Response:

The above request returns the HTTP status code 200 (OK) and returns a true or false value indicating whether SMB is enabled over the specified project.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/isProjectExposedOverSMB -k
```

Error Response:

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

isShareExposedOverNFS

Returns whether the NFS protocol is enabled for the share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, getNFSNetworkACLsOnShare

Parameters datasetPath

Path of the share. The format is <poolName>/Local//Local/

This operation is not allowed for replica share datasets.

Returns

Returns True or False based on whether the NFS protocol is enabled.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare"
    ]' \
  https://198.51.100.10/zebi/api/v2/isShareExposedOverNFS -k
```

Response:

The above request returns the HTTP status code 200 (OK) and the following response:

```
true
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
```

```
-H 'authorization: Basic Auth_TOKEN \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/Project/UNKNOWNShare"
   ]' \
https://198.51.100.10/zebi/api/v2/isShareExposedOverNFS -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

isShareExposedOverSMB

Returns whether the SMB protocol is enabled for a share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, getSMBNetworkACLsOnShare

Parameters datasetPath

Path of the share. The format is <poolName>/Local//Local//Local/

Returns

Returns True or False based on whether the SMB protocol is enabled.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare"
    ]' \
  https://198.51.100.10/zebi/api/v2/isShareExposedOverSMB -k
```

Response

The above request returns the HTTP status code 200 (OK) and returns the following response:

```
true
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare"
    ]' \
  https://198.51.100.10/zebi/api/v2/isShareExposedOverSMB -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

listAllCopyOperations

Lists all copy operations.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

copyDataset, getCopyStatus, listRunningCopyOperations, abortCopy

Parameters

None

Returns

Lists the GUIDs of all copy operations.

Exceptions Thrown

None

Examples

Example 1

Request (curl)

```
curl -X GET \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
https://198.51.100.10/zebi/api/v2/listAllCopyOperations -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of GUIDs.

```
"europa:aeca7e25-a74e-4a81-860d-e1f3640f2ad5",
"europa:2282afb2-97b2-4ff8-86e5-10e3368766a3",
"europa:69bc5f81-242d-4908-9b5c-5a4029cadd7d",
"europa:a621708c-9a09-44da-b4d8-733a9e4883b5",
"europa:bb8602e3-1431-4507-b83e-63e7a4ae2bf5",
"europa:0e7b6bc7-5337-4974-83db-6f9e179034ea",
"europa:42a85c00-d067-42c9-9947-883e853d0862",
"europa:12bebd45-ae3c-451d-98ea-befdd595568a",
"europa:825ae7b1-f596-400d-89bc-a4f7466badc3",
"europa:1e1bc102-d8cc-4f8e-88b0-a0cc41f224fc",
"europa:69bc5f81-242d-4908-9b5c-5a4029cadd7d"
```

listLunsByld

Lists LUN details for the specified LUN IDs.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listPools, listProjects, listVolumes, listShares, createVolume.

Parameters

lunids

An array of strings where each string contains the logical unit ID of a LUN on the array. For example, "600144F0FA2A820000004FF35C280003".

Returns

A JSON array of *LunStatus* objects that contain details of the requested LUNs.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
   -H Content-Type:application/json \
   -d
   '[["600144F0B4510D0000005631F7DB0001","600144F0B4510D0000005631F7E80002"]]'
   https://198.51.100.10/zebi/api/v2/listLunsById -k
```

Response

```
{
    "viewCount" : 1,
    "operationalStatus" : 2,
    "metaFile" : null,
    "commandStatus" :0,
    "size" :"1073741824",
    "vendorId" : null,
    "writeCacheDisable" : false,
    "dataFile" : "/dev/zvol/rdsk/pool-a/Local/smb nfs/llun1",
    "guid" : "600144F0B4510D0000005631F7DB0001",
    "accessState" :0,
    "commandException" : null,
    "blockSize" : null,
    "productId" :null,
    "serialNumber" : null,
    "writeProtect" : false,
    "alias" :"/dev/zvol/rdsk/pool-a/Local/smb_nfs/llun1",
    "mgmtURL" :"",
    "datasetPath" : "pool-a/Local/smb_nfs/llun1"
},
    "viewCount" : 1,
    "operationalStatus" :2,
    "metaFile" : null,
    "commandStatus" : 0,
    "size" : "",
    "vendorId" : null,
    "writeCacheDisable" :false,
    "dataFile" : "/dev/zvol/rdsk/pool-a/Local/smb_nfs/lun2",
    "guid" : "600144F0B4510D0000005631F7E80002",
    "accessState" :0,
    "commandException" : null,
    "blockSize" : null,
"productId" :null,
    "serialNumber" : null,
    "writeProtect" : false,
    "alias" : "/dev/zvol/rdsk/pool-a/Local/smb_nfs/lun2",
    "mgmtURL" :"",
    "datasetPath" : "pool-a/Local/smb nfs/lun2"
]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[["600144F012190100000052D92EC20165"]]' \
  https://198.51.100.10/zebi/api/v2/listLunsById -k
```

Error Response

```
HTTP Status Code: 200
```

```
"commandStatus": 2,
    "commandException": {
        "code": "EZEBI RESOURCE NOT FOUND",
        "details": "",
        "extendedData": {},
        "message": "Lun 600144F012190100000052D92EC20165 doesn't exist"
    "guid": null,
    "alias": null,
    "dataFile": null,
    "metaFile": null,
    "vendorId": null,
    "productId": null,
    "mgmtURL": null,
    "serialNumber": null,
    "viewCount": 0,
    "size": null,
    "blockSize": null,
    "writeProtect": false,
    "writeCacheDisable": false,
    "operationalStatus": 0,
    "accessState": 0,
    "datasetPath": null
1
```

listPools

Lists all the pools on the array. This is an HTTP GET method.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listProjects, listVolumes, listLunsByld, listShares.

Parameters

None

Returns

Returns a JSON array of *Pool_V1_0* objects that contains details of all the pools.

Example

Request (curl)

```
curl -X GET -H "Authorization:Basic Auth TOKEN" \
  -H Content-Type:application/json -d '[] \
  https://198.51.100.10/zebi/api/v2/listPools -k
```

Response

```
[
{
"name":"pool-a",
"availableSize":3931776248832,
"totalSize":3931908341760
},
{
"name":"pool-b",
"availableSize":1965925029376,
"totalSize":1965954170880
}
```

listProjects

Lists all the local or replicated projects in a pool.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listPools, listVolumes, listLunsByld, listShares.

Parameters

poolName

A string: the name of the pool for which projects need to be listed.

local

A boolean: a **true** returns the local projects only; a **false** returns the replicated projects only.

Returns

Returns a JSON array of *Project_V1_0* objects that contains details of all the local or replicated projects in the specified pool.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["plaut", true]' \
  https://198.51.100.10/zebi/api/v2/listProjects -k
```

Response

```
[
{
"poolName":"plaut",
"name":"CIFS_TEST",
"local":true
},
{
"poolName":"plaut",
"name":"new_proj",
"local":true
}
]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json -d '["pool11",true]' \
  https://198.51.100.10/zebi/api/v2/listProjects -k
```

Error Response

```
HTTP Status Code: 500
{
    "message": "Unable to open pool11/Local : dataset does not exist",
    "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool11/Local : dataset does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
    "details": "Unable to open pool11/Local : dataset does not exist",
    "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

listRunningCopyOperations

Lists all running copy operations.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

copyDataset, getCopyStatus, listAllCopyOperations, abortCopy

Parameters

None

Returns

Lists the GUIDs of all currently running operations. Copy operations that are completed or aborted are not listed.

Exceptions Thrown

None

Examples

Example 1

Request (curl)

```
curl -X GET \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  https://198.51.100.10/zebi/api/v2/listRunningCopyOperations -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of GUIDs. For example:

```
[
"europa:137b93ca-280f-4693-a4d8-a39496827d9e",
"europa:69bc5f81-242d-4908-9b5c-5a4029cadd7d"
]
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[{"poolName": "europa1",
  "projectName": "images",
  "subProjectName": "template"
},
{
  "hostName": "10.68.132.120",
  "poolName": "napa",
  "projectName": "remotecopy",
```

Error Response

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Unable to find project images in europal",
   "extendedData": {}
}
```

listShares

Lists all the local and replicated shares in a project.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listPools, listProjects, listVolumes, listLunsByld, createShare, createShare.

Parameters

poolName

A string: the name of the pool that contains the project specified by the projectName parameter.

projectName

A string: the name of the project for which shares need to be listed.

local

A boolean: a **true** returns the local shares only; a **false** returns the replicated shares only.

Returns

Returns a JSON array of *Share_V1_0* objects that contains details of all the local or replicated shares in the specified pool and project.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["plaut","project2", true]' \
  https://198.51.100.10/zebi/api/v2/listShares -k
```

Response

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool0","TechPubs", true]' \
  https://198.51.100.10/zebi/api/v2/listShares -k
```

Error Response

```
HTTP Status Code: 500
{
   "message": "Unable to open pool0/Local/TechPubs : dataset does not exist",
   "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool0/Local/TechPubs : dataset
   does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
   "details": "Unable to open pool0/Local/TechPubs : dataset does not exist",
   "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

listSharesByMountPoints

Lists all shares available for given mountpoints or mountpoint patterns.

Sample valid patterns include:

- /export/project/share1, /export/project/*, /export/project?/Share[1-3]
- /export/project/{share1,newshare}, *Project*

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listShares

Parameters

mountPointPatterns

An array of of mount points patterns.

Returns

A list of key value pairs, which consists of a mount point and its associated *Share_V2_1* object.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specific resource (pool, project, or share) is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the mountpoint pattern is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[["/export/*"]]' \
https://198.51.100.10/zebi/api/v2/listSharesByMountPoints -k
```

Response

The above request returns the HTTP status code 200 (OK) and a list of key-value pairs that consists of a mount point and its associated *Share_V2_1* object.

```
"/export/*": [
    "poolName": "pool63b",
    "projectName": "testProject",
    "name": "testShare",
    "availableSize": 1930781823488,
    "totalSize": 1945635603968,
    "datasetPath": "pool63b/Local/testProject/testShare",
"mountpoint": "/export/testProject/testShare",
    "local": true
    "poolName": "pool63a",
    "projectName": "doNotCreateMeAgain",
    "name": "firstShare",
    "availableSize": 1073693696,
     "totalSize": 1073741824,
    "datasetPath": "pool63a/Local/doNotCreateMeAgain/firstShare", "mountpoint": "/export/doNotCreateMeAgain",
     "local": true
]
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[["export/*"]]' \
https://198.51.100.10/zebi/api/v2/listSharesByMountPoints -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Mountpoint Pattern is not valid.
  It can begin with '/', '[', '{' or '*'.
  Example: /export/ExampleProject , *export/*.",
  "extendedData": {}
}
```

listVolumes

Lists all the local or replicated volumes within a Project.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Related APIs

listPools, listProjects, listLunsByld, listShares, createVolume.

Parameters

poolName

A string: the name of the pool that contains the project specified by the **projectName** parameter.

projectName

A string: the name of the project for which volumes need to be listed.

local

A boolean: a **true** returns the local volumes only; a **false** returns the replicated volumes only.

Returns

Returns a JSON array of *Volume_V1_0* objects that contains details of all the local or replicated volumes within the requested project.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["plaut", "project1", true]' \
  https://198.51.100.10/zebi/api/v2/listVolumes -k
```

Response

```
[
    "poolName":"plaut",
    "projectName":"project1",
    "name":"iscsilun_0",
    "luId":"600144F0DE8CCA000000561C554A0006",
    "volSize":1073741824,
```

```
"blockSize":"4KB",
   "thinProvision":false,
   "protocol":"iSCSI",
   "datasetPath":"plaut/Local/project2/iscsilun_0",
   "local":true
}
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool0","TechPubs", true]' \
  https://198.51.100.10/zebi/api/v2/listVolumes -k
```

Error Response

```
HTTP Status Code: 500
{
    "message": "Unable to open pool0/Local/TechPubs : dataset does not exist",
    "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool0/Local/TechPubs : dataset
does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
    "details": "Unable to open pool0/Local/TechPubs : dataset does not exist",
    "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

modifyProjectProperties

Modifies project properties with given values.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createProject, getProject, getProjectProperty

Parameters

Project-path

A string specifying the path of the project.

Project

A *Project_V2_1* object as key-value collection of properties to change.

You can modify other properties in *Project_V2_1* that are not marked as "read only".

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

If the parameters are invalid (when an invalid key-value pair is not supported by *Project_V2_1*).

EZEBI_RESOURCE_NOT_FOUND

If the specified project doesn't exist.

Examples

Example 1

Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/my-project",
  {
    "quotaInByte":42949672960,
    "compression":"gzip-9",
    "recordSize":"128Kb",
    "dedup":"on"
  }
]' https://198.51.100.10/zebi/api/v2/modifyProjectProperties -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

modifyShareProperties

Returns a *Share_V2_1* object if it exists.

You can configure other general properties in *Share V2 1* that is not marked as "read only".

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createShare, getShare

Parameters

Share-path

A string specifying the path to share.

Share

A Share_V2_1 object as key-value collection of properties to change.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or share name contains special characters).

EZEBI_GENERAL

This exception is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share doesn't exist.

Examples

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-share",
        {
             "sync":"always",
             "quotaInByte":123456789
        }
     ]'
https://198.51.100.10/zebi/api/v2/modifyShareProperties -k
```

Response

The above request returns the HTTP status code 200 (OK) and an integer.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '[
    "pool-a/Local/my-project/my-share",
    {
        "non-exist-property":"always",
        "quotaInByte":123456789
     }
]'
https://198.51.100.10/zebi/api/v2/modifyShareProperties -k
```

Error Response

The above request returns the HTTP status code 404 (Not found) and the following message:

```
"code": "EZEBI_GENERAL",
  "details": "No suitable method found. Please check if method name
  and arguments are correct.",
  "message": "No suitable method found. Please check if method name
  and arguments are correct.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": "No suitable method found. Please check if
  method name and arguments are correct."
  }
}
```

Example 3

Erroneous Request (curl)

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "modifyShareProperties.arg1 value 'com.tegile.skywalk.api.v2.
  IPublicAPI_V2_1$Share_V2_1@1c8df8ce': Supported Data Sync Preference
  includes: Standard, Always.",
  "message": "Supported Data Sync Preference includes: Standard, Always.",
  "extendedData":
  {
    "EX_CAUSE_MESSAGE": null
```

```
}
```

modifyVolumeProperties

Modifies volume properties with given values.

You can configure other general properties in *Volume_V2_1* that is not marked as "read only".

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createVolume, getVolume

Parameters

Volume-path

A string specifying the path of the volume.

Volume

A *Volume_V2_1* object as key-value collection of properties to change.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

EZEBI GENERAL

This exception is thrown if the operation failed with internal reasons.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified volume doesn't exist.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and an integer.

Example 2

Erroneous Request (curl)

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code": "EZEBI_INVALID_ARGUMENT",
    "details": "createProject.arg0 value
    'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$Project_V2_1@1778db80':
```

```
Invalid Compression Algorithm, disable compression by passing in
   'Off' or enable compression by using one of the following:
   Lzjb, Gzip-2, Gzip, Gzip-9, Lz4.",
   "message": "Invalid Compression Algorithm, disable compression by
passing in 'Off' or enable
   compression by using one of the following: Lzjb, Gzip-2, Gzip, Gzip-9,
Lz4.",
   "extendedData": {"EX_CAUSE_MESSAGE": null}
}
```

resetPoolError

Clears errors associated with a pool.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

deletePool, exportPool, importPool, checkPoolIntegrity

Parameters

poolName

Name of the pool where you want to clear the errors.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the pool does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if an invalid character is detected in the poolName.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a"]' \
https://198.51.100.10/zebi/api/v2/resetPoolError -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a"]' \
https://198.51.100.10/zebi/api/v2/resetPoolError -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "Pool not found.",
  "message": "The pool [nonExistentPool6a] was not found.",
  "extendedData": {
     "EX_CAUSE_MESSAGE": "Pool not found.",
     "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
  }
}
```

set NFS Sharing On Project

Enables or disables NFS protocol for project. If you disable NFS protocol for a project, any existing network ACLs on the project are removed as well.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLonProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

turnOn

Enables or disables NFS protocol on the project.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
   "pool-a/Local/demoProject", true
    ]' \
   https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This enables NFS sharing on the specified project.

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", false
   ]' \
  https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This disables NFS sharing on the specified project.

Example 3

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", true
    ]' \
  https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
```

```
-H 'content-type: application/json' \
-d '[
"pool-a/Replica/replicaProject", true
   ]' \
https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"setNFSSharingOnProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are
    'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
    "message":"Local dataset path expected.
    For example, valid formats are 'pool-name/Local/project-name' or
    'pool-name/Local/project-name/share-or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

setNFSSharingOnShare

Enables or disables NFS protocol for a share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLsOnShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

Parameters datasetPath

Path of the project. The format is <poolName>/Local/projectName>/
<shareName>.

This operation is not allowed for replica project datasets.

turnOn

Enables or disables NFS protocol on the share.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/demoShare", true]'
    https://198.51.100.10/zebi/api/v2/setNFSSharingOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/UNKNOWNShare", true]'
    https://198.51.100.10/zebi/api/v2/setNFSSharingOnShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
```

Example 3

Erroneous Request

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Replica/replicaProj/replicaShare", true]'
    https://198.51.100.10/zebi/api/v2/setNFSSharingOnShare -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

setSMBSharingOnProject

Enables or disables SMB protocol for project. If you disable SMB protocol for a project, any existing network ACLs on the project are removed as well.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

turnOn

Enables or disables SMB protocol on the project.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This enables SMB sharing on the specified project.

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", false
   ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This disables CMB sharing on the specified project.

Example 3

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Local/UNKNOWNProject", true
  ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \( \)
```

```
-H 'content-type: application/json' \
-d '[
"pool-a/Replica/replicaProject", true
    ]' \
https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"setSMBSharingOnProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are
    'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
    "message":"Local dataset path expected.
    For example, valid formats are 'pool-name/Local/project-name' or
    'pool-name/Local/project-name/share-or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

setSMBSharingOnShare

Enables or disables SMB protocol for share. If the dataset contains any network ACLs, they are removed as well.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

Parameters

datasetPath

Path of the project. The format is <poolName>/Local//cal// <shareName>.

This operation is not allowed for replica project datasets.

turnOn

Enables SMB protocol on the project.

displayName

Display name of the share.

enableGuestMode

Enables guests mode for the share.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/demoShare", true, "test", true]'
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/UNKNOWNShare", true, "test", true]'
    https://198.51.100.10/zebi/api/v2/setSMBSharingOnShare -k
```

Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

Example 3

Erroneous Request

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Replica/replicaProj/replicaShare", true, "test", true]'
    https://198.51.100.10/zebi/api/v2/setSMBSharingOnShare -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{"code":"EZEBI_INVALID_ARGUMENT",
"details":"setSMBSharingOnShare.arg0 value
'pool-a/Replica/replicaProj/replicaShare': Local dataset path expected.
For example, valid formats are 'pool-name/Local/project-name' or
'pool-name/Local/project-name/share-or-lun-name'.",
"message":"Local dataset path expected.
For example, valid formats are 'pool-name/Local/project-name' or
'pool-name/Local/project-name/share-or-lun-name'.", "extendedData":
{"EX_CAUSE_MESSAGE":null}}
```

Chapter 6

Snapshot Methods

Topics:

- cloneProjectSnapshot
- cloneReplicaProjectSnapshot
- cloneReplicaSubProjectSnapshot
- cloneShareSnapshot
- cloneVolumeSnapshot
- cloneVolumeSnapshot
- createProjectSnapshot
- createShareSnapshot
- createSnapshotSchedule
- createVolumeSnapshot
- deleteProjectSnapshot
- deleteShareSnapshot
- deleteSnapshotSchedule
- deleteSnapshotSchedules
- deleteVolumeSnapshot
- getProjectCloneStatus
- getProjectSnapshotCreationStatus
- getShareSnapshotCreationStatus
- getSnapshotSchedule
- getVolumeSnapshotCreationStatus
- inheritSnapshotSettingsFromProject
- isSnapshotSchedulesInheritedFromProject
- listDependenciesAndSnapshotCountOnDelete
- listDependenciesAndSnapshotCountOnRollback
- listSnapshots
- rollBackToProjectSnapshot
- rollBackToShareSnapshot
- rollBackToVolumeSnapshot

The following sections describe Snapshot methods, parameters and return types. They also include examples with sample responses.

cloneProjectSnapshot

Clones the specified project-level snapshot. This creates new datasets at the share and volume levels for all shares and volumes that have a snapshot with the specified name.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

getProjectCloneStatus, createProjectSnapshot, deleteProjectSnapshot.

Parameters

snapshotPath

Path of the project-level snapshot that has to be cloned. The snapshot path has the format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

cloneName

A string that is used to create names of the new datasets. The clone name is appended to the resultant share and volume names. The characters ,, /, $\$, ?, @, <, >, #, \$, ',%, ^,*,(,), ~,+, =, }, |, :, {, [,], ;, \', \", & are not allowed in clonename. The empty and space characters and the null values are not allowed in clonename.

inheritProjectSettings

A boolean value that indicates whether the new dataset will inherit project settings.

Returns

No Data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@Manual-P-NewTPSS", \
  "mkclone", false]' \
  https://198.51.100.10/zebi/api/v2/cloneProjectSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@NewTPSS", \
   "mkclone2", false]' \
  https://198.51.100.10/zebi/api/v2/cloneProjectSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/sProj@NewTPSS: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

Example 3

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@Manual-P-NewTPSS", \
  "", false]' \
  https://198.51.100.10/zebi/api/v2/cloneProjectSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
message: "Clone name is not valid."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

cloneReplicaProjectSnapshot

Clones a replica project by its specified snapshot.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

cloneReplicaSubProjectSnapshot

Parameters

snapshotPath

Snapshot path of the project to clone from. The path can be pool/container/project@snapshot or pool/project@snapshot.

cloneName

The name of the clone project.

readOnly

Read only clone.

inheritSettings

Inherit project settings.

keepLuGuid

Keep LUN GUID

Returns

COMMAND_STATUS.COMMAND_SUCCEED(0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specific project is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the snapshot path is invalid.

EZEBI_RESOURCE_INUSE

This exception is thrown if the target project name or target project mount point already exists.

EZEBI_REQUEST_INTERRUPTED

This exception is thrown if the clone failed.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKENY' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Replica/my-project@my-snapshot", "my-clone", false, true, true
]' https://198.51.100.10/zebi/api/v2/cloneReplicaProjectSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as an integer indicating a successful operation.

Example 2

Erroneous Request (curl)

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_GENERAL",
   "details": "Failed to clone from pool-a/Replica/my-project@non-exist-
snapshot to
    pool-a/Local/myclone.
    Result message: Failure: cannot open 'pool-a/Replica/my-project@non-
exist-snapshot':
    dataset does not exist",
    "message": "Failed to clone Project 'my-project' when cloning
    'pool-a/Replica/my-project@non-exist-snapshot'.",
    "extendedData": {"EX_CAUSE_MESSAGE": "Failed to clone from
    pool-a/Replica/my-project@non-exist-snapshot to pool-a/Local/myclone.
```

```
Result message: Failure: cannot open 'pool-a/Replica/my-project@non-
exist-snapshot':
    dataset does not exist", "EX_CAUSE_CODE_NAME":"EZEBI_GENERAL"}
}
```

cloneReplicaSubProjectSnapshot

Clones a replica sub-project by the specified snapshot.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

cloneReplicaProjectSnapshot

Parameters

snapshotPath

Snapshot path of the project to clone from. The path could be pool/container/project@snapshot or pool/project@snapshot.

cloneName

The name of the clone project.

readOnly

Read-only clone.

inheritSettings

Inherit project settings.

keepLuGuid

Keep LUN GUID

Returns

COMMAND_STATUS.COMMAND_SUCCEED(0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specific project is not found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the snapshot path is invalid.

EZEBI RESOURCE INUSE

This exception is thrown if the target project name or target project mount point already exists.

EZEBI_REQUEST_INTERRUPTED

This exception is thrown if the clone failed.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Replica/my-project/my-dataset@my-snapshot", "my-clone", false, true, true
    ]'
https://198.51.100.10/zebi/api/v2/cloneReplicaSubProjectSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Replica/my-project/my-dataset@non-exist-snapshot",
    "my-clone", false, true, true
    ]'
https://198.51.100.10/zebi/api/v2/cloneReplicaSubProjectSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
   "code": "EZEBI_REQUEST_INTERRUPTED",
```

```
"details": "Failed to clone from pool-a/Replica/my-project/my-
dataset@non-exist-snapshot
    to pool-a/Local/myclone/my-dataset. Result message: Failure: cannot
open
    'pool-a/Replica/my-project/my-dataset@non-exist-snapshot': dataset does
not exist",
    "message": "Failed to clone share 'pool-a/Replica/my-project/my-
dataset@non-exist-snapshot'.",
    "extendedData": {"EX_CAUSE_MESSAGE": "Failed to clone from
    pool-a/Replica/my-project/my-dataset@non-exist-snapshot to pool-a/
Local/myclone/my-dataset.
    Result message: Failure: cannot open 'pool-a/Replica/my-project/my-
dataset@non-exist-snapshot':
    dataset does not exist", "EX_CAUSE_CODE_NAME":"EZEBI_GENERAL"}
}
```

cloneShareSnapshot

Clones the specified share-level snapshot.

First Available Version

API v1.2. IntelliFlash 2.1.2.1

Related APIs

createShareSnapshot, deleteShareSnapshot.

Parameters

snapshotPath

Path of the share-level snapshot that has to be cloned. The snapshot path has the format: PoolName/Local/ProjectName/ShareName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

cloneName

A string that is used to create the name of the new dataset. The clone name is appended to the resultant share name. The characters ,, /,\\, !, ?, @, <, >, #, \$, ', %, * ,

inheritShareSettings

A boolean value that indicates whether the new dataset will inherit the share settings.

Returns

No Data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj/TP_Check@Manual-P-NewTPSS", \
"mk32", false]' \
https://198.51.100.10/zebi/api/v2/cloneShareSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj/TP_Check/Manual-P-NewTPSS", \
"mk11", false]'
https://198.51.100.10/zebi/api/v2/cloneShareSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

cloneVolumeSnapshot

Clones the specified snapshot of a volume.

First Available Version

API v2.0, IntelliFlash 3.5.0.0

Related APIs

cloneVolumeSnapshot, createVolumeSnapshot, deleteVolumeSnapshot.

Parameters

snapshotPath

The snapshot path of the volume dataset to be cloned. The snapshot path has the format: PoolName/Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

cloneName

inheritViewsFromVolume

A boolean value that indicates whether the new dataset will inherit views from the volume.

inheritViewsFromProject

A boolean value that indicates whether the new dataset will inherit views from the project.

protocol

A boolean value that indicates protocol to be set for the clone. Valid values are **true** for iSCSI and **false** for FC.

Returns

No Data.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and no data.

cloneVolumeSnapshot

Clones the specified snapshot of a volume.

First Available Version

API v1.2. IntelliFlash 2.1.2.1

Related APIs

cloneVolumeSnapshot,createVolumeSnapshot, deleteVolumeSnapshot.

Parameters

snapshotPath

The snapshot path of the volume dataset to be cloned. The snapshot path has the format: PoolName/Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

cloneName

A string that is used to create the name of the new dataset. The clone name is appended to the resultant volume name. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, ,* ,(,), $^,+$, =, }, |, :, {, [,], ;, \', \", & are not allowed in clonename. The empty and space characters and the null values are not allowed in clonename.

inheritViewsFromVolume

A boolean value that indicates whether the new dataset will inherit views from the volume.

inheritViewsFromProject

A boolean value that indicates whether the new dataset will inherit views from the project.

Returns

No Data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/vProj/vol2\
```

```
@Manual-V-vProj_S3", "mkclone2", false, false]' \
https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/vProj/vol2\
@vProj_S3","mkclone2", false]' \
https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

Example 3

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/vProj/vol2@vProj","mkclone2", false]' \
https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unknown error cloning volume."
  extendedData: { }
```

```
details: ""
code: "EZEBI_GENERAL"
}
```

createProjectSnapshot

Recursively creates snapshots of the specified project and the datasets within the project. The string "Manual-P-" is prefixed to the names of the snapshots created.

Related APIs

First Available Version

API v1.2, IntelliFlash 2.1.2.1

getProjectSnapshotCreationStatus, listSnapshots, createVolumeSnapshot, createShareSnapshot, deleteProjectSnapshot.

Parameters

project

A *Project_V1_2* object that specifies the project for which the snapshots are created.

snapshotName

Name for the new snapshots that are created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, * ,', (,), * ,+, =, }, |, :, {, [,], :, \', \", & are not allowed in snapshotName. The empty and space characters and the null values are not allowed in snapshotName.

quiesce

A boolean that specifies whether the snapshot is quiesced or not.

Returns

No Data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[{"name": "sProj", "local": true, \
  "poolName": "pool1"}, "NewTPSS9", false]' \
```

```
https://198.51.100.10/zebi/api/v2/createProjectSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[{"name": "sProj", "local": true, \
    "poolName": "NotExistantPool"}, "NewTPSS9", false]' \
    https://198.51.100.10/zebi/api/v2/createProjectSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NotExistantPool/Local/sProj: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

createShareSnapshot

Recursively creates snapshot of the specified share. The string "Manual-S-" is prefixed to names of the snapshots created.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

getShareSnapshotCreationStatus, listSnapshots, deleteShareSnapshot, cloneShareSnapshot.

Parameters

share

The *Share_V1_0* object that specifies the share for which the snapshots are created.

snapshotName

Name for the new snapshots that are created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, ^,*,(,), ~,+, =, }, |, :, {, [,], :, \', \", & are not allowed in snapshotName. The empty and space characters and the null values are not allowed in snapshotName.

quiesce

A boolean value that specifies whether the snapshots are quiesced or not.

Returns

No Data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[{"poolName": "pool1", "projectName": "sProj", \
"name": "TP_Check-newclone", "availableSize": 0, \
"totalSize": 7794361020176, \
"datasetPath": "pool1/Local/sProj/TP_Check-newclone", \
"mountpoint": null, "local": true }, \
"NewShareSnapShot", false]' \
https://198.51.100.10/zebi/api/v2/createShareSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[{"poolName": "pool1", "projectName": "sProj", \
"name": "TP_Check-newclone", "availableSize": 0, \
"totalSize": 7794361020176, \
"datasetPath": "pool1/Local/sProj/TP_Check-newclone", \
"mountpoint": null, "local": true }, \
"NewShareSnapShot", false]' \
https://198.51.100.10/zebi/api/v2/createShareSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{ message: "Unable to open NotAPool/Local/sProj/TP_s1:
   dataset does not exist."
   extendedData: { }
   details: ""
   code: "EZEBI_GENERAL"}
```

createSnapshotSchedule

Creates a snapshot schedule for the specified dataset.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getSnapshotSchedule, deleteSnapshotSchedules, deleteSnapshotSchedule

Parameters

schedule

Snapshot schedule definition.

This operation is not allowed for replica project datasets.

Returns

Returns a schedule ID.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified dataset does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the schedule is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
```

```
-H 'authorization: Basic Auth TOKEN \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
{
    "scheduleId":0,
    "retentionPeriod": 6,
    "scheduleIntervalType": "Week",
    "repeatInterval": 1,
    "startDate": "2017-08-09",
    "startTime": "10:00",
    "endTime": "",
    "daysOfWeek": "2,3,4,5,6",
    "dayOfMonth": 0,
    "weekdayOfMonth": "",
    "datasetPath": "pool-a/Local/demoProject",
    "quiesce": "Off"
  ]'\
https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

Response:

The above request returns the HTTP status code 200 (OK) and a new schedule ID. For example, 44.

Example 2

Erroneous Request (curl)

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN \
 -H 'cache-control: no-cache' \
 -H 'content-type: application/json' \
 {
     "scheduleId":0,
     "retentionPeriod": 6,
     "scheduleIntervalType": "Hour",
     "repeatInterval": 1,
     "startDate": "2017-08-10",
     "startTime": "10:00",
     "endTime": "",
     "daysOfWeek": "",
     "dayOfMonth": 0,
     "weekdayOfMonth": "",
     "datasetPath": "pool-a/Local/demoProject",
     "quiesce": "Off"
   ]'\
 https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"createSnapshotSchedule.arg0
   value
'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$SnapshotSchedule_V2_1@10ed209':
   Invalid end time. End time should be in 24HR HH:MM format.",
   "message":"Invalid end time. End time should be in 24HR HH:MM format.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

Example 3

Erroneous Request

```
curl -X POST \
 -H 'authorization: Basic Auth_TOKEN \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '[
 {
      "scheduleId":0,
      "retentionPeriod": 6,
      "scheduleIntervalType": "Monthly",
      "repeatInterval": 1,
      "startDate": "2017-08-10",
      "startTime": "10:00",
      "endTime": "20:00",
      "daysOfWeek": "",
      "dayOfMonth": 0,
      "weekdayOfMonth": "",
      "datasetPath": "pool-a/Local/demoProject",
      "quiesce": "Off"
 https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"createSnapshotSchedule.arg0 value

'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$SnapshotSchedule_V2_1@5b6c021e':
   Invalid schedule interval type.
   Possible values are: Minute, Hour, Day, Week, Month.",
   "message":"Invalid schedule interval type.
   Possible values are: Minute, Hour, Day, Week, Month.",
```

```
"extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

Example 4

Erroneous Request

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 {
     "scheduleId":0,
     "retentionPeriod": 6,
     "scheduleIntervalType": "Hour",
     "repeatInterval": 1,
     "startDate": "2017-08-10",
     "startTime": "10:00",
     "endTime": "20:00",
     "daysOfWeek": "",
     "dayOfMonth": 0,
      "weekdayOfMonth": "",
      "datasetPath": "pool-a/Local/UNKNOWNProject",
      "quiesce": "Off"
    ]'\
 https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"",
  "message":"Dataset does not exist.",
  "extendedData":{}
}
```

createVolumeSnapshot

Recursively creates snapshot of the specified volume. The string "Manual-V-" is prefixed to the names of the snapshots created.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

getProjectSnapshotCreationStatus, listSnapshots, createProjectSnapshot, createShareSnapshot, deleteProjectSnapshot.

Parameters

volume

A *Volume_V1_0* object for which snapshot needs to be created.

snapshotName

Name for the new snapshots that are created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%, ^,*,(,), ~,+, =, }, |, :, {, [,], ;, \', \", & are not allowed in snapshotName. The empty and space characters and the null values are not allowed in snapshotName.

quiesce

A boolean value that specifies whether the snapshots are quiesced or not.

Returns

No Data.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
  -H "Content-Type:application/json" \
  -d '[{"poolName": "pool1", \
    "projectName": "vProj", "name": "vol2", \
    "luId": "600144F0A6308900000053BD51250002", \
    "volSize": 161061273600, "blockSize": "32KB", \
    "thinProvision": false, "protocol": "FC", \
    "datasetPath": "pool1/Local/vProj/vol2", \
    "local": true}, "vProj_S3", false]' \
    https://198.51.100.10/zebi/api/v2/createVolumeSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
  -H "Content-Type:application/json" \
  -d '[{"poolName": "NotaPool", \
```

```
"projectName": "vProj", "name": "vol2", \
    "luId": "600144F0A6308900000053BD51250002", \
    "volSize": 161061273600, "blockSize": "32KB", \
    "thinProvision": false, "protocol": "FC", \
    "datasetPath": "NotaPool/Local/vProj/vol2", \
    "local": true}, "vProj_S3", false]' \
https://198.51.100.10/zebi/api/v2/createVolumeSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

deleteProjectSnapshot

Deletes the specified project snapshot.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified project snapshot) are also deleted.



Warning: The delete operation is not reversable.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createProjectSnapshot.

Parameters

projectSnapshotPath

Dataset path of the project snapshot. The dataset path of a project snapshot has the following format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

recursive

A boolean value that specifies whether dependents of the snapshot are deleted before the snapshot is deleted.

Returns

A JSON object of type *SnapShotDeletionStatus* that contains information about the snapshot deletion status.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@Manual-P-NewTPSS2", \
    true]' \
  https://198.51.100.10/zebi/api/v2/deleteProjectSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@NewTPSS2", true]' \
  https://198.51.100.10/zebi/api/v2/deleteProjectSnapshot -k
```

Error Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
snapshotDeletionStatus: 2
deletedList: [ ]
failedToDeleteList: ["pool1/Local/sProj@NewTPSS2"]
}
```

Example 3

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/Manual-P-NewTPSS2", \
    true]' \
  https://198.51.100.10/zebi/api/v2/deleteProjectSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NotAPool/Local/sProj: dataset does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

deleteShareSnapshot

Deletes the specified share snapshot.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified share snapshot) are also deleted.



Warning: The delete operation is not reversable.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createShareSnapshot.

Parameters

shareSnapshotPath

Dataset path of the share snapshot. The dataset path of a share snapshot has the following format: PoolName/
Local/ProjectName/ShareName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see listSnapshots.

recursive

A boolean value that specifies whether dependents of the snapshot are deleted before deleting the snapshot.

Returns

A JSON object of type SnapShotDeletionStatus.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/proj1/share1@Manual-P-snap1", false]' \
  https://198.51.100.10/zebi/api/v2/deleteShareSnapshot -k
```

Response

```
{
snapshotDeletionStatus: 0
deletedList: ["pool1/Local/proj1/share1@Manual-P-snap1"]
failedToDeleteList: [ ]
}
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/proj1/NoSuchShare@Manual-P-snap1", false]' \
https://198.51.100.10/zebi/api/v2/deleteShareSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  snapshotDeletionStatus: 2
  deletedList: [ ]
  failedToDeleteList: [
    "pool1/Local/proj1/NoSuchShare@Manual-P-snap1"
  ]
}
```

deleteSnapshotSchedule

Deletes the snapshot schedule for the dataset path, specified by the snapshot ID.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createSnapshotSchedule, getSnapshotSchedule, deleteSnapshotSchedules

Parameters

datasetPath

Full path of the dataset or project.

This operation is not allowed for replica project datasets.

scheduleId

ID of the snapshot schedule.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified dataset does not exist.

EZEBI INVALID ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset or if the dataset path is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", 41
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedule -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", 100
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedule -k
```

Error Response

In this example, the request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"",
   "message":"Specified schedule id does not exist.",
   "extendedData":{}
}
```

Example 3

Erroneous Request

```
curl -X POST \
```

```
-H 'authorization: Basic Auth_TOKEN \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Replica/replicaProject", 10
]' \
https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedule -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"deleteSnapshotSchedule.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
   "message":"Local dataset path expected. For example,
   valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}}
```

deleteSnapshotSchedules

Deletes all snapshot schedules for the specified dataset.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createSnapshotSchedule, getSnapshotSchedule, deleteSnapshotSchedule

Parameters datasetPath

Full path of the dataset or project.

This operation is not allowed for replica project datasets.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified dataset does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset or if the dataset path is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedules -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedules -k
```

Response

In this example, the request returns the HTTP status code 404 (Not Found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
```

```
"message":"Dataset does not exist.",
    "extendedData":{}
}
```

Example 3

Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedules -k
```

Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"deleteSnapshotSchedule.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
   "message":"Local dataset path expected. For example,
   valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

deleteVolumeSnapshot

Deletes the specified volume snapshot.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified volume snapshot) are also deleted.



Warning: The delete operation is not reversable.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createVolumeSnapshot

Parameters

volumeSnapshotPath

Dataset path of the volume snapshot. The dataset path of a volume snapshot has the following format: PoolName/
Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see listSnapshots.

recursive

A boolean value that specifies whether dependents of the snapshot are deleted before deleting the snapshot.

Returns

A JSON object of type *SnapShotDeletionStatus*.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[{"pool1/Local/proj1/vol1@Manual-V-snap1", false}]' \
https://198.51.100.10/zebi/api/v2/deleteVolumeSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
  snapshotDeletionStatus: 0
  deletedList: ["pool1/Local/proj1/vol1@Manual-V-snap1"]
  failedToDeleteList: [ ]
}
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[{"pool1/Local/NoProj/vol1@Manual-V-snap1", false}]' \
https://198.51.100.10/zebi/api/v2/deleteVolumeSnapshot -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/NoProj/vol1@Manual-V-snap1: dataset
does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

getProjectCloneStatus

Gets the status of a clone request on the specified project snapshot.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

cloneProjectSnapshot.

Parameters

snapshotPath

Path to a project snapshot. The snapshot path has the format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

cloneName

Name of the new dataset.

Returns

A JSON object of type *ProjectCloneProgressStatus_v1_2*.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj@Manual-P-NewTPSS", \
"mkclone"]' \
```

```
https://198.51.100.10/zebi/api/v2/getProjectCloneStatus -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
  failedSubProjects: 1
  totalSubProjects: 6
  projectCloneState: 3
}
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj@NewTPSS","mkclone"]' \
https://198.51.100.10/zebi/api/v2/getProjectCloneStatus -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/sProj@NewTPSS: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

getProjectSnapshotCreationStatus

Gets the status of a project snapshot creation request.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createProjectSnapshot.

Parameters

dataSetPath

Dataset path of the project. The dataset path has the format: PoolName/Local/ProjectName. You can get the datasetPath from the listProjects API. For more information, see *listProjects*.

snapshotName

Name of the project snapshot for which status is required. You must use the name that you specified while invoking the *createProjectSnapshot* API, because this API prefixes the string "Manual-P-" to the name before getting the status.

Returns

A JSON object of type SnapshotProgressStatus.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj", "NewTPSS111"]' \
  https://198.51.100.10/zebi/api/v2/\
getProjectSnapshotCreationStatus -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool/Local/sProj", ""]' \
  https://198.51.100.10/zebi/api/v2/\
getProjectSnapshotCreationStatus -k
```

Error Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
   snapshotProgressStatus: 2
}
```

Example 3

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool/Local/sProj", "NewTPSS111"]' \
  https://198.51.100.10/zebi/api/v2/\
getProjectSnapshotCreationStatus -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/sProj2: dataset does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

getShareSnapshotCreationStatus

Gets the status of a share snapshot creation request.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createShareSnapshot.

Parameters

dataSetPath

Dataset path of the share. The dataset path has the format: PoolName/Local/ProjectName/ShareName. You can get the datasetPath from the listShares API. For more information, see *listShares* and *Share_V1_0*.

snapshotName

Name of the share snapshot for which status is required. You must use the name that you specified while invoking the *createShareSnapshot* API, because this API prefixes the string "Manual-S-" to the name before getting the status.

Returns

A JSON object of type *SnapshotProgressStatus*.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/TP_Check-newclone", \
"NewShareSnapShot"]' \
  https://198.51.100.10/zebi/api/v2/\
getShareSnapshotCreationStatus -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
     {
         snapshotProgressStatus: 0
      }
]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/TP_Check", \
"NotASnapShot"]' \
  https://198.51.100.10/zebi/api/v2/\
getShareSnapshotCreationStatus -k
```

Error Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
{
    snapshotProgressStatus: 2
}
```

]

Example 3

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool/Local/sProj/TP_Check", \
"NotASnapShot"]' \
  https://198.51.100.10/zebi/api/v2/\
getShareSnapshotCreationStatus -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NotAPool/Local/sProj/TP_Check: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

getSnapshotSchedule

Returns snapshot schedules for a dataset.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

createSnapshotSchedule, deleteSnapshotSchedules, deleteSnapshotSchedule

Parameters

datasetPath

Full path of the dataset.

This operation is not allowed for replica project datasets.

Returns

Returns a list of snapshot schedules for the specified dataset path.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified dataset does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSnapshotSchedule -k
```

Response:

The above request returns the HTTP status code 200 (OK) and a schedule object as shown below.

```
"scheduleId": 42,
    "retentionPeriod": 6,
    "scheduleIntervalType": "Week",
    "repeatInterval": 1,
    "startDate": "2017-08-09",
    "startTime": "00:00",
    "endTime": "00:00",
    "daysOfWeek": "2,3,4,5,6",
    "dayOfMonth": 0,
    "weekdayOfMonth": null,
    "datasetPath": "pool-a/Local/demoProject",
    "quiesce": "Off"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
```

```
-H 'authorization: Basic Auth_TOKEN \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/UNKNOWNProject"
   ]' \
https://198.51.100.10/zebi/api/v2/getSnapshotSchedule -k
```

Response

The above request returns the HTTP status code 404 (Not Found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"",
  "message":"Dataset does not exist.",
  "extendedData":{}
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/getSnapshotSchedule -k
```

Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"getSnapshotSchedule.arg0 value
  'pool-a/Replica/replicaProject': Local dataset path expected.
  For example, valid formats are 'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "message":"Local dataset path expected.
  For example, valid formats are 'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

getVolumeSnapshotCreationStatus

Gets the status of a volume snapshot creation request.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

createVolumeSnapshot.

Parameters

dataSetPath

Dataset path of the volume. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume_V1_0*.

snapshotName

Name of the volume snapshot for which status is required. You must use the name that you specified while invoking the *createVolumeSnapshot* API, because this API prefixes the string "Manual-V-" to the name before getting the status.

Returns

A JSON object of type *SnapshotProgressStatus*.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/vProj/vol2", \
  "vProj_S3"]' \
  https://198.51.100.10/zebi/api/v2/\
  getVolumeSnapshotCreationStatus -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data.

]

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/vProj/vol2", \
  "vProj_S"]' \
  https://198.51.100.10/zebi/api/v2/\
  getVolumeSnapshotCreationStatus -k
```

Error Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{snapshotProgressStatus: 2}
```

Example 3

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NoPool/Local/vProj/vol2", \
  "vProj_S3"]' \
  https://198.51.100.10/zebi/api/v2/\
  getVolumeSnapshotCreationStatus -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NoPool/Local/vProj/vol2: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

inheritSnapshotSettingsFromProject

Inherits project snapshot settings for local dataset.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

isSnapshotSchedulesInheritedFromProject

Parameters datasetPath

This string uniquely identifies the dataset on the IntelliFlash array.

Returns

COMMAND_STATUS.COMMAND_SUCCEED(0) on success.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified dataset doesn't exist.

EZEBI_INVALID_ARGUMENT

This error is thrown if the path specified belongs to a replica dataset.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-dataset"
        ]'
https://198.51.100.10/zebi/api/v2/inheritSnapshotSettingsFromProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
```

```
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
    "pool-a/Local/my-project/non-exist-dataset"
]'
https://198.51.100.10/zebi/api/v2/inheritSnapshotSettingsFromProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Invalid dataset path. ",
   "extendedData": {}
}
```

isSnapshotSchedulesInheritedFromProject

Checks whether the dataset is currently inheriting project snapshot settings.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

inheritSnapshotSettingsFromProject

Parameters datasetPath

This string uniquely identifies the dataset on the IntelliFlash array.

Returns

TRUE, if the snapshot schedule is inherited from project

FALSE, if the snapshot schedule is overridden by the project rule

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified dataset doesn't exist.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-dataset"
        ]'
https://198.51.100.10/zebi/api/v2/isSnapshotSchedulesInheritedFromProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and a boolean (true or false).

Example 2

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Local/my-project/non-exist-dataset"
    ]'
https://198.51.100.10/zebi/api/v2/isSnapshotSchedulesInheritedFromProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Invalid dataset path. ",
   "extendedData": {}
}
```

list Dependencies And Snapshot Count On Delete

Lists all the dependents affected by the delete operation.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listDependenciesAndSnapshotCountOnRollback

Parameters

path

The project path, share or volume path, or snapshot path to delete.

Returns

A Dependencies object.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified project path, share or volume path, or snapshot path is not found.

EZEBI_INVALID_ARGUMENT

This error is thrown if the specified path is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-01/Local/genericProject"
        ]'
https://198.51.100.10/zebi/api/v2/listDependenciesAndSnapshotCountOnDelete -k
```

Response

```
"deleteableSnapCount": {
    "pool-01/Local/genericProject/clone2": 2,
    "pool-01/Local/genericProject/genericLun-genericProject-clone": 38,
    "pool-01/Local/genericProject/clone3": 1,
    "pool-01/Local/genericProject/genericLun": 4351,
    "pool-01/Local/genericProject/genericLun-genericProjectClone": 2,
    "pool-01/Local/genericProject": 3,
    "pool-01/Local/genericProject/
        genericLun-genericProject/
        genericLun-genericProject-clone-genericProjectClone": 1
},

"deleteableClonesWithSnapCount": {
    "pool-01/Local/genericProject/clone2": 2,
    "pool-01/Local/genericProject/clone3": 1,
    "pool-01/Local/genericProject/genericLun-genericProjectClone": 2,
    "pool-01/Local/genericProject/genericLun": 4351,
    "pool-01/Local/genericProject/clone2-rollbackclone": 0,
```

```
"pool-01/Local/genericProject/
    genericLun-genericProjectClone-rollbackclone": 0,
    "pool-01/Local/genericProject/
    genericLun-genericProject-clone-genericProjectClone": 1,
    "pool-01/Local/genericProject/clone3-rollbackclone": 0,
    "pool-01/Local/genericProject/genericLun-rollbackclone": 0,
    "pool-01/Local/genericProject/
    genericLun-genericProject-clone-genericProjectClone-rollbackclone": 0,

"pool-01/Local/genericProject/
    genericLun-genericProject-clone-rollbackclone": 0
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-01/Local/non-exist-project"
]'
https://198.51.100.10/zebi/api/v2/listDependenciesAndSnapshotCountOnDelete -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Dataset does not exist. ",
  "extendedData": {}
}
```

list Dependencies And Snapshot Count On Rollback

Lists all the dependents affected by the rollback operation.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listDependenciesAndSnapshotCountOnDelete

Parameters snapshotPath

The project path, share or volume path, or snapshot path to roll back to.

Returns

A Dependencies object.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This error is thrown if the specified snapshot is not found.

EZEBI_INVALID_ARGUMENT

This error is thrown if the specified snapshot path is invalid.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ""pool-01/Local/genericProject@Manual-P-ss""
    ]'
https://198.51.100.10/zebi/api/v2/listDependenciesAndSnapshotCountOnRollback
  -k
```

Response

```
"deleteableSnapCount": {
    "pool-01/Local/genericProject/genericLun-genericProject-clone": 1,
    "pool-01/Local/genericProject/genericLun": 1,
    "pool-01/Local/genericProject": 1
},
    "deleteableClonesWithSnapCount": {
        "pool-01/Local/genericProject/genericLun-rollbackclone": 0,
        "pool-01/Local/genericProject/genericLun-genericProject-clone-rollbackclone": 0
    }
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ""pool-01/Local/genericProject@non-exist-snapshot""
    ]'
https://198.51.100.10198.51.100.10/zebi/api/v2/
listDependenciesAndSnapshotCountOnRollback -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Dataset does not exist. ",
   "extendedData": {}
}
```

listSnapshots

Lists names of snapshots (from the specified dataset) that match with the given regex pattern.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Parameters

datasetPath

A string that contains the dataset path. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume_V1_0*.

snapshotPattern

A string that contains a regex pattern for matching snapshot names. Use an empty string to list all snapshots.

Returns

A JSON array of strings that contains names of snapshots (from the specified dataset) that match with the given regex pattern.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubsLUN",".*"]' \
  https://198.51.100.10/zebi/api/v2/listSnapshots -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
    "Auto-LF-Day-011714-21:15",
    "Auto-LF-Day-011814-21:15",
    "Auto-LF-Day-011914-21:15",
    "Auto-LF-Week-011914-21:30",
    "Auto-LF-Day-012014-21:15",
    "Auto-LF-Day-012114-21:15"]
]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubs",""]' \
  https://198.51.100.10/zebi/api/v2/listSnapshots -k
```

Error Response

```
HTTP Status Code: 500
{
    "message": "Unable to open pool1/Local/TechPubs/TechPubs : dataset does not exist",
    "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool1/Local/TechPubs/TechPubs : dataset does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
    "details": "Unable to open pool1/Local/TechPubs/TechPubs : dataset does not exist",
    "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

rollBackToProjectSnapshot

Reverts the project state to the point-in-time state when the snapshot was taken.



Caution: If the **deleteDependents** parameter is set to **true**, all dependent objects (snapshots and clones of the specified project snapshot) are also deleted.

First Available Version

API v2.0, IntelliFlash 3.5.0.1

Related APIs

createProjectSnapshot, listSnapshots, deleteProjectSnapshot

Parameters

snapshotPath

Path of the project-level snapshot that has to be rolled back. The snapshot path has the format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

deleteDependents

A boolean value: indicates whether to delete the snapshot dependents.

If the **deleteDependents** is set to **false** and rollback is invoked, the method throws an error if there are existing dependents for the snapshot.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test@Manual-P-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToProjectSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data.

0

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test1@Manual-P-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToProjectSnapshot -k
```

Error Response

```
{"message":"Snapshot
    pool-2-mirror/Local/proj-test1@Manual-P-test does not
    exist.","extendedData":{},"details":"","code":"EZEBI_GENERAL"}
```

rollBackToShareSnapshot

Reverts the share state to the point-in-time state when the snapshot was taken.



Caution: If the **deleteDependents** parameter is set to **true**, all dependent objects (snapshots and clones of the specified share snapshot) are also deleted.

First Available Version

API v2.0, IntelliFlash 3.5.0.1

Related APIs

createShareSnapshot, listSnapshots, deleteShareSnapshot

Parameters

snapshotPath

Path of the share-level snapshot that has to be rolled back. The snapshot path has the format: PoolName/Local/ProjectName/ShareName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

deleteDependents

A boolean value: indicates whether to delete the snapshot dependents.

If the **deleteDependents** is set to **false** and rollback is invoked, the method throws an error if there are existing dependents for the snapshot.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/share1@Manual-S-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToShareSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data.

```
0
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/share_test@Manual-S-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToShareSnapshot -k
```

Error Response

```
{"message":"Snapshot
    pool-2-mirror/Local/proj-test/share_test@Manual-S-test does not
    exist.","extendedData":{},"details":"","code":"EZEBI_GENERAL"}
```

rollBackToVolumeSnapshot

Reverts the volume state to the point-in-time state when the snapshot was taken.



Caution: If the **deleteDependents** parameter is set to **true**, all dependent objects (snapshots and clones of the specified volume snapshot) are also deleted.

First Available Version

API v2.0, IntelliFlash 3.5.0.1

Related APIs

createVolumeSnapshot, listSnapshots, deleteVolumeSnapshot

Parameters

snapshotPath

Path of the volume-level snapshot that has to be rolled back. The snapshot path has the format: PoolName/
Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see listSnapshots.

deleteDependents

A boolean value: indicates whether to delete the snapshot dependents.

If the **deleteDependents** is set to **false** and rollback is invoked, the method throws an error if there are existing dependents for the snapshot.

Returns

Returns an integer: the number 0 if the request succeeds.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/lun_test@Manual-V-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToVolumeSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data.

```
0
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/lun_test_dummy@Manual-V-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToVolumeSnapshot -k
```

Error Response

```
{"message":"Snapshot
    pool-2-mirror/Local/proj-test/lun_test_dummy@Manual-V-test does not
    exist.","extendedData":{},"details":"","code":"EZEBI_GENERAL"}
```

Chapter 7

Replication Methods

Topics:

- getReplicationConfigList
- getReplicationStatus
- startReplication

The following sections describe Replication methods, parameters and return types. They also include examples with sample responses.

getReplicationConfigList

Lists all the replication configurations for the specified project.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

getReplicationStatus.

Parameters

poolName

Name of a pool.

projectName

Name of a project within the specified pool.

Returns

A JSON object of type *ReplicationConfig_V1_2*.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1","p1"]' \
  https://198.51.100.10/zebi/api/v2/getReplicationConfigList -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
id: 1
  projectName: "p1"
  projectGuid: "f55553354-2a91-4533-8e98-1cd52b1da3d6"
  poolName: "pool1"
  baseDataSetName: "pool1/Local/p1"
  scopeOption: 0
  remoteHost: "198.51.100.11"
  lastSnapshotName: ""
  remotePoolName: "san-pool"
  remoteProjectName: "p1"
```

```
remoteBaseDataSetName: "san-pool/Replica/p1"
}
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["NotAPool","Failover_LUN"]' \
https://198.51.100.10/zebi/api/v2/getReplicationConfigList -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

getReplicationStatus

Gets the replication status for the specified replication configuration.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

getReplicationConfigList, startReplication.

Parameters

replicationConfig

An object of type *ReplicationConfig_V1_2* that contains the replication configuration. You can get the list of replication configurations from the **getReplicationConfigList** API. For more information, see *getReplicationConfigList*.

Returns

A JSON object of type *ReplicationStatus_v1_2*.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
currentStatus: 1
startTimestamp: 1410165951163
completeTimestamp: 1410165951163
updateTimestamp: 1410165951120
dataSent: 0
sendSpeed: 0
taskSize: 0
completedTask: 0
}
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ \
{ \
"id": 1, \
"projectName": "p2", \
"projectGuid": "f5553354-2a91-4533-8e98-1cd52b1da3d6", \
"poolName": "pool-22", \
"baseDataSetName": "pool1/Local/p1", \
"scopeOption": 0, \
"remoteHost": "10.7.1.16", \
"lastSnapshotName": "", \
```

```
"remotePoolName": "san-pool", \
"remoteProjectName": "p1", \
"remoteBaseDataSetName": "san-pool/Replica/p1" \
} \
] ' https://198.51.100.10/zebi/api/v2/getReplicationStatus -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
message: "Pool pool-22 is not mounted."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

startReplication

Starts a replication for the specified replication configuration.

First Available Version

API v1.2, IntelliFlash 2.1.2.1

Related APIs

getReplicationConfigList, getReplicationStatus.

Parameters

replicationConfig

An object of type *ReplicationConfig_V1_2* that contains the replication configuration.

Returns

No Data.

Examples

Example 1

Request (curl)

```
"remoteProjectName": "replica_project", \
"remoteBaseDataSetName": "testpool/Replica/replica_project", \
"poolName": "pool1", \
"lastSnapshotName": "", \
"scopeOption": 1, \
"remoteHost": "198.51.100.20", \
"baseDataSetName": "plaut-1/Local/rep_project", \
"id": 1, \
"projectGuid": "9d6b46ce-05dd-4df1-9ca9-4924bfeb9473", \
"remotePoolName": "testpool" \
} \
]' \
https://198.51.100.10/zebi/api/v2/startReplication -k
```

The above request returns the HTTP status code 200 (OK) and no data.

Example 2

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
message: "Pool pool-22 is not mounted."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

Chapter 8

System Methods

Topics:

- getDiskCount
- getDisks
- getDisksByChassis
- getUpgradeHistory
- identifyDisk
- identifyDiskByIndex
- listSystemProperties

The following sections describe the System methods, parameters and return types. They also include examples with sample responses.

getDiskCount

Returns the count of disks connected to the IntelliFlash Array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getDisksByChassis, getDisks, identifyDisk, identifyDiskByIndex

Parameters

None

Returns

An integer count of all the disks found on the IntelliFlash array.

Exceptions Thrown

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" -d '[]' \
-H 'cache-control: no-cache' \
https://10.68.97.100/zebi/api/v2/getDiskCount -k
```

Response

The above request returns the HTTP status code 200 (OK) and a numeric count of the disks detected. For example, 27.

getDisks

Returns the details of disks connected to the IntelliFlash Array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getDisksByChassis, getDiskCount, identifyDisk, identifyDiskByIndex

Parameters

diskAliasPattern

The disk name (alias) to obtain detailed JSON disk objects. This is the same disk alias name shown in IntelliFlash Web UI for each disk.

This parameter can be a complete specific disk name or partial regular expression to match several disks.

For example, you can specify <code>c2t5000C50040CF0707d0</code> to obtain a specific disk, ".*" to obtain all disks, <code>c2t5000C50040.*</code> to obtain disks starting with <code>c2t5000C50040.*</code> to obtain disks starting with <code>c2t5000C50040CF07.*</code> to obtain disks that contain <code>5000C50040CF07</code> in the name.

Returns

A JSON array of the *Disk_V2_1* objects that contain the details of the requested disks.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameters are invalid (for example, bad format or blank), or if the requested wild card regular expression is in an invalid format.

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the disk requested does not exist.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

curl -X POST -H "Authorization:Basic Auth TOKEN" \

```
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://198.51.100.10/zebi/api/v2/getDisks -k
```

The above request returns the HTTP status code 200 (OK) and a list of all disks on that IntelliFlash array. For example:

```
{
       "diskChassisIndex": 0,
       "diskBayIndex": 1,
       "diskChassisName": "IS1201-0022[HA2100]",
       "diskSize": "1.82 TB",
       "poolName": "ZebiSystem",
       "diskType": "HDD",
       "diskAlias": "c2t5000C50040CF04E7d0",
       "deviceId": "n5000c50040cf04e7"
   },
       "diskChassisIndex": 0,
       "diskBayIndex": 2,
       "diskChassisName": "IS1201-0022[HA2100]",
       "diskSize": "1.82 TB",
       "poolName": "vmpool",
       "diskType": "HDD",
       "diskAlias": "c2t5000C50040CF0707d0",
       "deviceId": "n5000c50040cf0707"
   },
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["c2t5000c50040cF0F97d0" ]' \
  https://198.51.100.10/zebi/api/v2/getDisks -k
```

Error Response

In this example, the disk "c2t5000C50040CF0F97d0" does not exist. So the request returns the HTTP status code 404 (not found) and the following response :

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to pass a valid disk alias parameter.","extendedData":{}}
```

getDisksByChassis

Lists the disks connected to the specified disk chassis. The chassis are the IntelliFlash array itself (head) and the JBOD chassis connected to the array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getDisks, getDiskCount, identifyDisk, identifyDiskByIndex

Parameters

chassisIndex

The chassis index on the array that contains the disk bays to enumerate. Often the array has only one disk chassis, which would be chassis index 0. But an array with 3 chassis might typically have chassis index 0, 1, and 2, depending how they are connected. The chassis index can be retrieved by calling getDisks API first in the returned JSON array of *Disk_V2_1* objects.

Returns

A JSON array of the *Disk_V2_1* objects that contain the details of the disks found on the requested chassis.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the requested disk chassis index does not exist, or is out of range.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[0]' \
```

```
https://198.51.100.10/zebi/api/v2/getDisksByChassis -k
```

The above request returns the HTTP status code 200 (OK) and a JSON array of *Disk_V2_1* objects on the first chassis. For example:

```
{
        "diskChassisIndex": 0,
        "diskBayIndex": 1,
        "diskChassisName": "IS1201-0022[HA2100]",
        "diskSize": "1.82 TB",
        "poolName": "ZebiSystem",
        "diskType": "HDD",
        "diskAlias": "c2t5000C50040CF04E7d0",
        "deviceId": "n5000c50040cf04e7"
},
        "diskChassisIndex": 0,
        "diskBayIndex": 2,
        "diskChassisName": "IS1201-0022[HA2100]",
        "diskSize": "1.82 TB",
        "poolName": "vmpool",
        "diskType": "HDD",
        "diskAlias": "c2t5000C50040CF0707d0",
        "deviceId": "n5000c50040cf0707"
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[500]' \
https://198.51.100.10/zebi/api/v2/getDisksByChassis -k
```

Error Response

As the chassis index 500 does not exist, the request returns the HTTP status code 404 (not found) and the following exception:

```
{
"code":"EZEBI_RESOURCE_NOT_FOUND",
"details":"",
"message":"Failed to find the disk chassis requested (500).",
"extendedData":{}
}
```

getUpgradeHistory

Returns the history of IntelliFlash Software installs and upgrades for the array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

listSystemProperties

Parameters

N/A

Returns

A JSON array of the *ArrayUpgrade_V2_1* objects that contain the upgrades done on the IntelliFlash array.

Exceptions Thrown EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
   -d '[]' \
  https://198.51.100.10/zebi/api/v2/getUpgradeHistory -k
```

Response:

The above request returns the HTTP status code 200 (OK) and the *ArrayUpgrade_V2_1* objects that contain the upgrades done on the IntelliFlash array. For example:

```
"version": "3.7.0.0.170619",
    "timeInstalledOnNodeA": "Tue Jun 20 14:19:39 PDT 2017",
    "timeInstalledOnNodeB": "Tue Jun 20 13:43:25 PDT 2017"
```

```
},
{
    "version": "3.7.0.0.170425",
    "timeInstalledOnNodeA": "Wed Apr 26 22:07:17 PDT 2017",
    "timeInstalledOnNodeB": "Wed Apr 26 21:31:57 PDT 2017"
},
{
    "version": "3.6.0.0.170215",
    "timeInstalledOnNodeA": "Wed Feb 15 13:09:10 PST 2017",
    "timeInstalledOnNodeB": "Wed Feb 15 16:28:39 PST 2017"
}
```

identifyDisk

Identifies a disk connected to the IntelliFlash Array by flashing the bay light of the disk.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getDisks, getDisksByChassis, getDiskCount, identifyDiskByIndex

Parameters diskAlias

The name of the disk, which you want to identify. For example, c2t5000C50040CF0707d0 could be the disk name.

This is the same disk alias name shown in the IntelliFlash Web UI for each disk.

Returns

Returns an integer status, where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified disk was not found.

EZEBI GENERAL

This exception is thrown if the operation failed.

EZEBI INVALID ARGUMENT

This exception is thrown if the disk name parameter is invalid (bad format or blank).

Examples

Example 1

Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["c2t5000C500409B5663d0",true]' \
https://198.51.100.10/zebi/api/v2/identifyDisk -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0. This indicates that the blinking disk light for the disk "c2t5000C500409B5663d0" was successfully turned on.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["XYZ",true]' \
https://198.51.100.10/zebi/api/v2/identifyDisk -k
```

Error Response

In this example, the disk "XYZ" does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to find the disk requested (XYZ).","extendedData":{}}
```

identifyDiskByIndex

Identifies a disk connected to the IntelliFlash Array by flashing the bay light of the disk.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

getDisks, getDisksByChassis, getDiskCount, identifyDisk

Parameters

diskBayIndex

The disk bay index number of the disk you want to identify.

This is the same number displayed in the IFA Web UI and same disk index number returned in the disk objects by the getDisks API

chassisIndex

The disk chassis index number of the disk you want to identify. This is the same disk chassis index number returned in the disk objects by the getDisks API and displayed in the IntelliFlash Array Web UI.

blinkLED

JSON boolean to indicate whether to turn on or turn off the disk bay light used to identify the disk.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the chassis index or disk bay index is out of range or not found.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[2,2,true]' \
```

```
https://198.51.100.10/zebi/api/v2/identifyDiskByIndex -k
```

The above request returns the HTTP status code 200 (OK) and 0. This indicates that the blinking disk light was successfully turned on.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[2,10000,true]' \
https://198.51.100.10/zebi/api/v2/identifyDiskByIndex -k
```

Error Response

In this example, 10000 is not a valid existing disk chassis index. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to find the disk requested,
diskBay:2 chassis:10000.","extendedData":{}}
```

listSystemProperties

Lists values of the requested system properties for a Tegile array.

First Available Version

API v1.0, IntelliFlash 2.1.0.0

Parameters

properties

An array of strings where each string is a predefined string literal indicating a system property. The enumeration *ZEBI_SYSTEM_PROPERTY* defines the string literals that can be requested.

Returns

A JSON array of strings that contains values of the requested system properties. The error "EZEBI_RESOURCE_NOT_FOUND" is returned if a requested system property is not available.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["ZEBI_API_VERSION","ZEBI_APPLIANCE_VERSION"]]' \
https://198.51.100.10/zebi/api/v2/listSystemProperties -k
```

Response

```
[ "1.2", "A1"]
```

Example 2

Erroneous Request

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["ZEBI_API_VERSIONS"]]' \
https://198.51.100.10/zebi/api/v2/listSystemProperties -k
```

Error Response

```
[
"EZEBI_RESOURCE_NOT_FOUND"
]
```

Chapter 9

Network ACL Methods

Topics:

- addNFSNetworkACLOnProject
- addNFSNetworkACLOnShare
- addSMBNetworkACLOnProject
- addSMBNetworkACLOnShare
- getNFSNetworkACLsOnProject
- getNFSNetworkACLsOnShare
- getSMBNetworkACLsOnProject
- getSMBNetworkACLsOnShare
- inheritNetworkACLsettingsFromProject
- removeAlINFSNetworkACLsOnProject
- removeAlINFSNetworkACLsOnShare
- removeAllSMBNetworkACLsOnProject
- removeAlISMBNetworkACLsOnShare
- removeNFSNetworkACLOnProject
- removeNFSNetworkACLOnShare
- removeSMBNetworkACLOnProject
- removeSMBNetworkACLOnShare
- setNFSNetworkACLsOnProject
- setNFSNetworkACLsOnShare
- setSMBNetworkACLsOnProject
- setSMBNetworkACLsOnShare

The following sections describe Network ACL methods, parameters and return types. They also include examples with sample responses.

addNFSNetworkACLOnProject

Adds network ACL to the NFS project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, removeNFSNetworkACLonProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

isRoot

Whether ACL is root access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "FQDN", "www.example.com", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

Response:

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
  ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
   ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

Example 5

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addNFSNetworkACLOnProject.arg3
    value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

addNFSNetworkACLOnShare

Adds network ACL to the NFS share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnShare, setNFSNetworkACLsOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local//Local/

This operation is not allowed for replica share datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

isRoot

Whether ACL is root access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "FQDN", "www.example.com", "rw", true
   ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \( \)
```

```
-H 'content-type: application/json' \
-d '[
"pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true
    ]' \
https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true]'
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified share
   'pool-a/Local/Project/demoShare'.",
   "extendedData":{}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

Example 5

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addNFSNetworkACLOnShare.arg3
    value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

add SMBNetwork ACL On Project

Adds network ACL to the SMB project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnProject, setSMBNetworkACLsOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
```

```
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/demoProject", "FQDN", "www.example.com", "rw", true
]' \
https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"SMB sharing is not enabled on the specified dataset.
  Please enable SMB sharing on the dataset and then try the operation again.",
  "message":"SMB sharing is not enabled for the specified project
```

```
'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255", "rw", true
  ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

Example 5

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "read-write", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addSMBNetworkACLOnProject.arg3
```

```
value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

addSMBNetworkACLOnShare

Adds a network ACL to the SMB share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnShare, setSMBNetworkACLsOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local//Local/

This operation is not allowed for replica share datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "FQDN", "www.example.com", "rw", true
  ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true
  ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 3

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
```

```
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true
]' \
https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"SMB sharing is not enabled on the specified dataset.
   Please enable SMB sharing on the dataset and then try the operation
again.",
   "message":"SMB sharing is not enabled for the specified project
   'pool-a/Local/Project/demoShare'.",
   "extendedData":{}
}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

Example 5

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addSMBNetworkACLOnShare.arg3
    value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

getNFSNetworkACLsOnProject

Returns all the network ACLs of the NFS project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS

Parameters datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

Returns

List of network ACLs objects of type NetworkACL_V2_1.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
   "pool-a/Local/demoProject"
    ]' \
   https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and returns the list of NFS network ACL objects.

```
"hostType":"IP",
    "host":"198.51.100.255",
    "accessMode":"ro",
    "rootAccessForNFS":true
},

{
    "hostType":"FQDN",
    "host":"www.example.com",
    "accessMode":"rw",
    "rootAccessForNFS":true
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '[
"pool-a/Local/UNKNOWNProject"
   ]' \
https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

getNFSNetworkACLsOnShare

Returns all the network ACLs of the NFS share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS

Parameters datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

Returns

List of network ACLs objects of type NetworkACL_V2_1.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare"
   ]' \
  https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK) and returns the list of NFS network ACL objects.

```
[
    "hostType":"IP",
        "host":"198.51.100.255",
        "accessMode":"ro",
        "rootAccessForNFS":true
},
{
    "hostType":"FQDN",
        "host":"www.example.com",
        "accessMode":"rw",
        "rootAccessForNFS":true
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare"
   ]' \
  https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

getSMBNetworkACLsOnProject

Returns all the network ACLs of the SMB project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

Returns

List of network ACL objects of type *NetworkACL_V2_1*.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnProject -k
```

Response:

The above request returns the HTTP status code 200 (OK) and returns the list of SMB network ACL objects.

```
[
    "hostType":"IP",
    "host":"198.51.100.255",
    "accessMode":"ro",
    "rootAccessForNFS":true
},
{
    "hostType":"FQDN",
    "host":"www.example.com",
    "accessMode":"rw",
    "rootAccessForNFS":true
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
```

```
"details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

getSMBNetworkACLsOnShare

Returns all the network ACLs of the SMB share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB

Parameters

datasetPath

Path of the share. The format is <poolName>/Local/

Returns

List of network ACL objects of the *NetworkACL_V2_1* type.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
```

```
"pool-a/Local/Project/demoShare"
    ]' \
    https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK) and the following response:

```
"hostType":"IP",
    "host":"198.51.100.255",
    "accessMode":"ro",
    "rootAccessForNFS":true
},
{
    "hostType":"FQDN",
    "host":"www.example.com",
    "accessMode":"rw",
    "rootAccessForNFS":true
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \( \)
  -H 'content-type: application/json' \
  -d '[
"pool-a/Local/Project/UNKNOWNShare"
  ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

inheritNetworkACLsettingsFromProject

Enables or disables NFS protocol for a share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

Parameters datasetPath

Path of the project. The format is <poolName>/Local//cal// <shareName>.

This operation is not allowed for replica share datasets.

Values returned

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
```

```
-H 'Content-Type:application/json' \
-d '["pool-a/Local/project/demoShare"]' \
    https://198.51.100.10/zebi/api/v2/inheritNetworkACLsettingsFromProject
-k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/UNKNOWNShare"]'
    https://198.51.100.10/zebi/api/v2/inheritNetworkACLsettingsFromProject
  -k
```

Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

Example 3

Erroneous Request

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Replica/replicaProj/replicaShare"]'
        https://198.51.100.10/zebi/api/v2/inheritNetworkACLsettingsFromProject
  -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

removeAllNFSNetworkACLsOnProject

Removes all network ACLs from an NFS project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

Parameters datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the specified project does not support the protocol.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnProject -k
```

Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

removeAlINFSNetworkACLsOnShare

Removes all network ACLs from an NFS share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local//Local/

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the specified share does not support the protocol.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/demoShare"]'
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/UNKNOWNShare"]'
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnShare -k
```

Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"",
  "NFS sharing is not enabled on the specified dataset.
  Please enable NFS sharing on the dataset and then try the operation
again.",
  "message":"NFS sharing is not enabled for the specified share
  'pool-a/Local/project/UNKNOWNShare'.","extendedData":{}}}
```

removeAllSMBNetworkACLsOnProject

Removes all network ACLs from an SMB project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

Parameters datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the specified project does not support the protocol.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnProject -k
```

Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

removeAllSMBNetworkACLsOnShare

Removes all network ACLs from an SMB share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local//Local/

This operation is not allowed for replica share datasets.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI INVALID ARGUMENT

This exception is thrown if the specified share does not support the protocol.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/demoShare"]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/UNKNOWNShare"]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnShare -k
```

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"SMB sharing is not enabled on the specified dataset.
  Please enable SMB sharing on the dataset and then try the operation again.",
  "message":"SMB sharing is not enabled for the specified share
  'pool-a/Local/project/UNKNOWNShare'.","extendedData":{}}
```

removeNFSNetworkACLOnProject

Removes network ACL from an NFS project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLonProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found, or if the specified ACL does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

Example 3

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "FQDN", "www.example.com"
   ]' \
  https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
   "code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
```

```
"message":"The specified ACL 'www.example.com' does not belong to the
dataset.",
   "extendedData":{}
}
```

removeNFSNetworkACLOnShare

Removes network ACL from an NFS share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local//Local/

This operation is not allowed for replica share datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found, or if the specified ACL does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified share
   'pool-a/Local/project/demoShare'.","extendedData":{}}
```

removeSMBNetworkACLOnProject

Removes network ACL from an SMB project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found, or if the specified ACL does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnProject -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnProject -k
```

Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

Example 3

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255"
```

```
]' \
https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnProject -k
```

Error Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"The specified ACL '@198.51.100.255' does not belong to the
dataset.",
   "extendedData":{}
}
```

removeSMBNetworkACLOnShare

Removes network ACL from an SMB share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

Parameters datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

This operation is not allowed for replica share datasets.

type

Type of network ACL host, whether IP or FQDN.

host

The host to use for providing access.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found, or if the specified ACL does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the share specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnShare -k
```

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"SMB sharing is not enabled on the specified dataset.
Please enable SMB sharing on the dataset and then try the operation
again.",
  "message":"SMB sharing is not enabled for the specified share
  'pool-a/Local/project/demoShare'.","extendedData":{}}
```

setNFSNetworkACLsOnProject

Set the network ACLs on the NFS project. If the dataset contains any existing network ACLs, they are replaced with the new ones.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

networkACLs

Array of Network ACLs. Each object in the array is of the NetworkACL_V2_1 type.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 3

Erroneous Request (curl)

```
curl -X POST \
```

Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

Example 4

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
```

```
"details":"setNFSNetworkACLsOnProject.arg1[0] value
'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
Internet Protocol Network Address is in the wrong format.
Expecting a address in the NNN.NNN.NNN format, where each
address whole number is no greater than 255.",
"message":"Internet Protocol Network Address is in the wrong format.
Expecting a address in the NNN.NNN.NNN format, where each address
whole number is no greater than 255.",
"extendedData":{"EX_CAUSE_MESSAGE":null}
```

Example 5

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"setNFSNetworkACLsOnProject.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "message":"Local dataset path expected.
   For example, valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

setNFSNetworkACLsOnShare

Set the network ACLs on the NFS share. If the dataset contains any existing network ACLs, they are replaced with the new ones.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setNFSSharingOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLOnShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local//Local/

This operation is not allowed for replica project datasets.

networkACLs

Array of Network ACLs. Each object in the array is of the NetworkACL_V2_1 type.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

curl -X POST \

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

Error Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":

"NFS sharing is not enabled on the specified dataset.

Please enable NFS sharing on the dataset and then try the operation again.

","message":"NFS sharing is not enabled for the specified share
'pool-a/Local/project/demoShare'.","extendedData":{}}
```

Example 3

Erroneous Request

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/demoShare",
       [{"hostType": "IP", "host":"198.51.100.255", "accessMode":"ro",
       "rootAccessForNFS":true},
       {"hostType": "FQDN", "host":"www.example.com",
       "accessMode":"rw", "rootAccessForNFS":true}]]'
```

```
https://198.51.100.10/zebi/api/v2/setNFSNetworkACLsOnShare -k
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setNFSNetworkACLsOnShare.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

Example 4

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"setNFSNetworkACLsOnShare.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "message":"Local dataset path expected.
   For example, valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

Example 5

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

setSMBNetworkACLsOnProject

Sets the network ACLs on the SMB project.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

Parameters

datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

networkACLs

Array of Network ACLs. Each object in the array is of type NetworkACL_V2_1.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified project cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

Example 2

Erroneous Request (curl)

Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"SMB sharing is not enabled on the specified dataset.
   Please enable SMB sharing on the dataset and then try the operation again.",
   "message":"SMB sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

Example 3

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setSMBNetworkACLsOnProject.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

Example 4

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"setSMBNetworkACLsOnProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are
    'pool-name/Local/project-name' or
    'pool-name/Local/project-name/share-or-lun-name'.",
    "message":"Local dataset path expected.
    For example, valid formats are 'pool-name/Local/project-name' or
    'pool-name/Local/project-name/share-or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

setSMBNetworkACLsOnShare

Sets the network ACLs on the SMB share.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

setSMBSharingOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

Parameters

datasetPath

Path of the share. The format is <poolName>/Local/<projectName/ <shareName>.

This operation is not allowed for replica share datasets.

networkACLs

Array of Network ACLs. Each object in the array is of type NetworkACL_V2_1.

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the specified share cannot be found.

EZEBI_INVALID_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

Response

The above request returns the HTTP status code 200 (OK).

Example 2

Erroneous Request (curl)

Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
   "code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"SMB sharing is not enabled on the specified dataset.
   Please enable SMB sharing on the dataset and then try the operation again.",
   "message":"SMB sharing is not enabled for the specified share
   'pool-a/Local/Project/demoShare'.",
```

```
"extendedData":{}
}
```

Example 3

Erroneous Request

Error Response

The above request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setSMBNetworkACLsOnShare.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

Example 4

Erroneous Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject/replicaShare",
        [{"hostType": "IP", "host":"198.51.100.255",
        "accessMode":"ro", "rootAccessForNFS":true},
```

Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setSMBNetworkACLsOnShare.arg0 value
  'pool-a/Replica/replicaProject/replicaShare':
  Local dataset path expected. For example, valid formats are
  'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "message":"Local dataset path expected.
  For example, valid formats are 'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

Chapter 10

SNMP Methods

Topics:

- addSNMPTrapListener
- disableSNMPService
- enableSNMPService
- getSNMPSettings
- isSNMPServiceEnabled
- modifySNMPCommunityString
- recreateSNMPTables
- removeSNMPTrapListener
- resyncSNMPTables

The following sections describe SNMP methods, parameters and return types. They also include examples with sample responses.

addSNMPTrapListener

Adds an SNMP trap listener address that receives the SNMP event notifications.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

Parameters

trapListenerIp

IP address of the Trap listener.

Only up to 10 listeners are allowed. Must be a valid IPv4 address. The IP address cannot be any of the reserved addresses. For example, addresses such as 127.0.0.1, 0.0.0.0 and 255.255.255 are not allowed.

trapListenerPort

Port number of the Trap listener. The trap port must be in the 1-65535 range.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI RESOURCE EXIST

This exception is thrown if the trap listener you added already exists.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the IPv4 address of the listener is invalid (incorrectly blank, invalid IPv4 format, the trap port not in the 1-65535 range, or the SNMP service not enabled).

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.10",162]' \
https://198.51.100.10/zebi/api/v2/addSNMPTrapListener -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that it successfully added the SNMP trap listener.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.10",162]' \
https://198.51.100.10/zebi/api/v2/addSNMPTrapListener -k
```

Response

In this example, the requested SNMP trap listener already exists. So the request returns the HTTP status code 400 (bad request) and the following response:

```
{
    "code": "EZEBI_RESOURCE_EXIST",
    "details": "",
    "message":
    "Trap listener 10.68.50.10:162 already exists in SNMP settings and cannot be added",
    "extendedData": {}
}
```

Example 3

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.500.500",162]' \
https://198.51.100.10/zebi/api/v2/addSNMPTrapListener -k
```

Response

In this example, the SNMP trap was requested for an invalid IP address. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "addSNMPTrapListener.arg0 value '10.68.500.500':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format,
  where each address whole number is no greater than 255.",
  "message": "Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format,
  where each address whole number is no greater than 255.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

disableSNMPService

Disables the SNMP service on the IntelliFlash array.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

enableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

Parameters

None

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown EZEBI GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
   -d '[]' \
https://198.51.100.10/zebi/api/v2/disableSNMPService -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that the API successfully disabled the service.

enableSNMPService

Enables the SNMP service on the IntelliFlash array and sets the SNMP community string.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

Parameters communityString

Community string to be used on the enabled SNMP service. The SNMP community string cannot be longer than 64 characters. It cannot have special characters such as $*,\#,/,\backslash,!,@,\sim,(,),[,],{,},=,$ and %.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown EZEBI_INVALID_ARGUMENT

This exception is thrown if the parameter is invalid. The SNMP community string is invalid when it is incorrectly blank or beyond 64 characters long, or has non-alphanumeric characters other than, dash, underscore or period.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
   -d '["public"]' \
https://198.51.100.10/zebi/api/v2/enableSNMPService -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that the API successfully enabled the service.

Example 2

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
-H "Content-Type:application/json" \
  -d '["public#!@~"]' \
https://198.51.100.10/zebi/api/v2/enableSNMPService -k
```

Response

In this example, the requested SNMP community string format was invalid. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "enableSNMPService.arg0 value 'public#!@~'':
  SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "message": "SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
```

}

getSNMPSettings

Returns the SNMP settings of the current SNMP service.

This includes the trap listeners and the SNMP community string in the JSON object *SNMP_Setting_V2_1*.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, modifySNMPCommunityString

Parameters

None

Returns

Returns the JSON object *SNMP_Setting_V2_1*, which contains an array of the SNMP trap listener ip:port values, and the SNMP community string.

Exceptions Thrown EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[]' \
https://198.51.100.10/zebi/api/v2/getSNMPSettings -k
```

Response

The above request returns the HTTP status code 200 (OK) and a JSON object *SNMP_Setting_V2_1*. For example:

```
{
   "communityString": "public3",
   "trapListeners": [
       "10.68.97.43:162",
       "10.68.97.44:162",
       "10.68.97.45:162",
       "10.68.97.46:162",
       "10.68.50.10:10000"
]
}
```

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H 'cache-control: no-cache' \
-H "Content-Type:application/json" \
-d '[]' \
https://198.51.100.10/zebi/api/v2/getSNMPSettings -k
```

Response

In this example, the requested SNMP service is not running. So the request returns the HTTP status code 400 (bad request) and the following response:

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "SNMP Service must be enabled for this operation. Please
enable SNMP and try again.",
    "extendedData": {}
}
```

isSNMPServiceEnabled

Checks whether the SNMP Service is enabled.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

enableSNMPService, disableSNMPService, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

Parameters

None

Returns

Returns a JSON boolean status where:

- False indicates that the service is not enabled.
- True indicates that the service is enabled.

Exceptions Thrown

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '[]' \
  https://198.51.100.10/zebi/api/v2/isSNMPServiceEnabled -k
```

Response

The above request returns the HTTP status code 200 (OK) and JSON boolean result (true = SNMP enabled), indicating that the service is enabled.

modifySNMPCommunityString

Modifies the SNMP community string to be a new value.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings

Parameters

communityString

Community string to be used on the enabled SNMP service. The SNMP community string cannot be longer than 64 characters. It cannot have special characters such as $*,\#,/,\backslash,!,@,\sim,(,),[,],{,},=,$ and %.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_INVALID_ARGUMENT

This exception is thrown if the community string parameter is invalid. The SNMP community string is invalid when it is incorrectly blank or beyond 64 characters long, or has non-alphanumeric characters other than dash, underscore or period.

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["public2"]' \
https://198.51.100.10/zebi/api/v2/modifySNMPCommunityString -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that it successfully modified the SNMP community string to "public2".

Example 2

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["public#!@~"]' \
https://198.51.100.10/zebi/api/v2/modifySNMPCommunityString -k
```

Response

In this example, the requested SNMP community string format was invalid. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "enableSNMPService.arg0 value 'public#!@~'':
  SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "message": "SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

recreateSNMPTables

Recreates the SNMP entries. After deletion or creation of objects, the SNMP table entries might have gaps in the indices. Use this API to re-index the table entries.

First Available Version

API v2.1, IntelliFlash 3.5.4.0/3.7.0.x

Related APIs

resyncSNMPTables

Parameters

None

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI GENERAL

This exception is thrown if the operation failed or SNMP is not enabled.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \( \)
  -H 'content-type: application/json' \
  -d '[
    ]' \
  https://198.51.100.10/zebi/api/v2/recreateSNMPTables -k
```

Response:

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This initiates the SNMP table recreation in the background in asynchronous mode.

removeSNMPTrapListener

Removes an SNMP trap listener address that would have received SNMP event notifications.

First Available Version

API v2.1, IntelliFlash 3.7.0.x

Related APIs

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

Parameters

trapListenerIp

IP address of the Trap listener.

Only up to 10 listeners are allowed. Must be a valid IPv4 address. The IP address cannot be any of the reserved addresses. For example, addresses such as 127.0.0.1, 0.0.0.0 and 255.255.255 are not allowed.

trapListenerPort

Port number of the Trap listener. The trap port must be in the 1-65535 range.

Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

Exceptions Thrown

EZEBI_RESOURCE_NOT_FOUND

This exception is thrown if the trap listener does not exist.

EZEBI_INVALID_ARGUMENT

This exception is thrown if the IPv4 address of the listener is invalid (incorrectly blank, invalid IPv4 format, the trap port not in the 1-65535 range, or the SNMP service not enabled).

EZEBI_GENERAL

This exception is thrown if the operation failed.

Examples

Example 1

Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.10",162]' \
https://198.51.100.10/zebi/api/v2/removeSNMPTrapListener -k
```

Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that it successfully removed the SNMP trap listener.

Example 2

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.28",162]' \
```

```
https://198.51.100.10/zebi/api/v2/removeSNMPTrapListener -k
```

Response

In this example, the requested SNMP trap listener does not exist. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Failed to find SNMP trap listener to remove",
  "extendedData": {}
}
```

resyncSNMPTables

Resyncs the SNMP entries between the two controllers of the array. SNMP queries can be sent to the management IP address or the individual controller IP address. If querying the individual controllers for the same OID (SNMP Object Index) fetches different response, use this API to resync the table entries between the controllers.

First Available Version

API v2.1, IntelliFlash 3.5.4.0/3.7.0.x

Related APIs

recreateSNMPTables

Parameters

None

Returns

COMMAND_STATUS.COMMAND_SUCCEED (0) on success.

Exceptions Thrown EZEBI_GENERAL

This exception is thrown if the operation failed, or SNMP is not enabled.

Examples

Example 1

Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ]' \
  https://198.51.100.10/zebi/api/v2/resyncSNMPTables -k
```

Response:

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This initiates the SNMP table resync between controllers in the background in asynchronous mode.

Chapter 11

Objects

Topics:

- ArrayUpgrade_V2_1
- CopyDestination_V2_1
- CopySource_V2_1
- CopyStatus_V2_1
- DatasetProperty_V2_1
- DatasetSpaceInfo_V2_1
- DatasetStatus
- Disk_V2_1
- FCInitiator_V2_1
- FCTarget_V2_1
- InitiatorGroup_V2_1
- Iscsilnitiator_V1_0
- ISCSIInitiator_V2_1
- ISCSITarget_V2_1
- ISCSITargetCreate_V2_1
- ITView_V2_1
- LocalGroup_V1_2
- LocalUser_V1_2
- LunStatus
- NetworkACL_V2_1
- Pool_V1_0
- PoolSpaceInfo_V2_1
- Project_V1_0
- Project_V1_2
- Project_V2_1
- ProjectCloneProgressStatus_v1_2
- ReplicationConfig_V1_2
- ReplicationStatus_v1_2
- Schedule_V2_1
- Share_V1_0
- Share_V2_1
- ShareOptions
- SharePermissions
- SnapShotDeletionStatus
- SnapshotProgressStatus
- SnapshotSchedule_V2_1
- SNMP_Setting_V2_1

The following sections describe the objects used by the IntelliFlash API.

- Volume_V1_0
- Volume_V2_1
- UserACL (Read Only) v2.1

ArrayUpgrade_V2_1

This class represents the upgrade and install history of the array. Each object instance is one IntelliFlash OS install or upgrade.

Field	Туре	Description
Version	String	Version of the install or upgrade.
timeInstalledOnNodeA	String	Date and time the upgrade or install was done for node A.
timeInstalledOnNodeB	String	Date and time the upgrade or install was done for node B.

CopyDestination_V2_1

Object defining destination datasets.

Field	Description
hostName	Destination partner system name.
	Leave this field empty for same array.
poolName	Destination pool.
projectName	Destination project.
subProjectNamePrefix	Destination sub project name prefix.
	Leave this field empty for project copy.
subProjectNameNumberStart	Destination sub project name suffix start. The value should be a number.
subProjectNameNumberEnd	Destination sub project name suffix end. The value should be a number.
subProjectNameWildcard	Destination sub project name wildcard (bash style).

CopySource_V2_1

Object defining the source dataset.

Field	Description
poolName	Source dataset pool.
projectName	Source dataset project.
subProjectName	Source sub project name. Leave this field empty for project copy.

CopyStatus_V2_1

Object representing the current status of the copy operation.

Field	Description
completedCopies	Completed copies for the task.
status	Current status of the task.
	It has the following values:
	 Unknown Start Connected Sending Local Replication Completed Error Paused
allDatasets	All datasets created by the task.
completedDatasets	Datasets completed by the task.
pendingDatasets	Datasets yet to be created by the task.
percentComplete	Percentage of task completion.
errorCode	Error code of the task, if there is any error.
startTime	Start time of the task.
endTime	End time of the task.

DatasetProperty_V2_1

Field	Description
propertyKey	Key of the property
propertyValue	Value of the property

DatasetSpaceInfo_V2_1

Field	Description
originalUsedByDataAndSnapshot	Original used by dataset data and snapshot before compression (bytes).
usedByDataAndSnapshot	Amount used by the dataset data and snapshot after compression (bytes).
compressionSavingsPercentage	Amount saved from compression as a percentage.
available	For datasets with a quota, this represents the amount of space remaining in the quota.
	For shares and luns without a quota, this represents the amount of space remaining in the project's quota (if it exists).
	If a quota does not exist on a project, this value represents the amount of space (in bytes) remaining on the pool.
usedByData	Amount used by this dataset's data after compression (bytes).
usedBySnapshot	Amount used by this dataset's snapshots after compression (bytes).
usedByReservation	Share and project field. Amount used by reservation (bytes).
quota	Share and project field. The user assigned quota for the dataset (bytes). The quota is 0 if it doesn't exist.
volSize	Volume only field. The size of the volume (bytes).

DatasetStatus

Field	Туре	Description
cleanupException	String	Contains details of the exception, if an exception occurs.
cleanupStatus	Integer	An integer return value as defined in <i>CLEANUP_STATUS</i> .
commandException	String	Contains details of the exception, if an exception occurs.
commandStatus	Integer	An integer return value as defined in <i>COMMAND_STATUS</i> .
datasetPath	String	A string that contains the dataset path. A dataset path should have the format PoolName/Local/ProjectName/VolumeName for volumes and PoolName/ Local/ProjectName/ShareName for shares.
overwriteException	String	Contains details of the exception, if an exception occurs.
overwriteStatus	Integer	An integer value as defined in OVERWRITE_STATUS.

Disk_V2_1

Field	Туре	Description
diskChassisIndex	Integer	Index of the chassis to enumerate, as listed by getDisks() API.
diskBayIndex	Integer	Disk bay index relative to each disk chassis (as listed by the Web UI, and is zero relative).
diskChassisName	String	Name of the disk chassis as given by • Web UI • serial number [chassis name]
diskSize	String	Disk size with units (for example, 2TB).
poolName	String	Pool that is using the disk currently.
diskType	String	Disk type (for example, HDD or RW_META_SSD).
diskAlias	String	Disk name used to identify the disk. For example, "c2t5000CCA013067A90d0".
deviceId	String	Disk device id that is unique across array controllers.

FCInitiator_V2_1

This class represents the initiator for the FC protocol.

Field	Туре	Description
initiatorName	String	Initiator name (for example, "wwn.5001438001FFAAAA").
initiatorGroupName	String	Initiator group name.

FCTarget_V2_1

This class represents the target for the FC protocol.

Field	Туре	Description
targetName	String	Target name (for example, "wwn.21000024FF236C15")
targetStatus	String	Target status (for example, "online" or "offline").
targetNode	String	Node (or IntelliFlash controller) where the target is active.
targetGroupName	String	Target group name.
targetSpeed	String	Target speed (for example, 4GB, 8GB, or "not established").
targetPortType	String	Whether the target port type is HBA or NPIV.

InitiatorGroup_V2_1

Field	Туре	Description
initiatorGroupName	String	Initiator group name as listed in the Web UI.
intendedProtocol	String	The protocol the initiator group is configured to use (e.g. iSCSI, FC, or Unknown)

Iscsilnitiator_V1_0

Field	Туре	Description
chapSecret	String	Optional CHAP secret if the initiator uses CHAP for authentication.
chapUserName	String	Optional CHAP username if the initiator uses CHAP for authentication.

Field	Туре	Description
initiatorName	String	Standard initiator names can have either of these two formats:
		• iqn.yyyy-mm.[reverse-domain-name] • eui.02004567A425678D (EUI-64 identifier - 16 ASCII-encoded hexadecimal digits)
		The characters ,, /,\ !, ?, @, <, >, #, \$, ',%, ^,*, (,), ~,+, =, }, , {, [,], ;, \', \", $_$, & are not allowed in initiatorgroupname. The empty and space characters and the null values are not allowed in initiatorgroupname.

ISCSIInitiator_V2_1

This class represents the ISCSI initiator attributes.

Field	Туре	Description
initiatorName	String	Initiator Name (iqn or eui iscsi name)
		This must be in the iqn.yyyy.mmm.[reverse-domain-name]:unique-name or eui.16-hexadecimal-digits and no more than 255 characters.
initiatorGroupName	String	Initiator or host group name.
		This cannot have special characters such as '', *, #, /, \ !, @, \sim , (,), [,], {, }, =, and %. The string must be between 1 to 512 characters long.
chapUserName	String	Optional chap user name if the initiator uses chap for authentication.
		If specified this chap user name can't be blank or cannot have special characters such as ' ', \ /, !, #, \$, %, ^, &, *, (,), :, ;, and @.
chapSecret	String	Optional chap secret if the initiator uses CHAP authentication. This is only used on write-modify-create methods. The string is always null or empty for read methods.
		The chap secret must between 12 and 16 characters if specified, and cannot have special characters such as such as '', \ /, !, #, \$, %, ^, &, *, (,), :, ;, and @.

ISCSITarget_V2_1

This class represents the target for the iSCSI protocol and is returned when enumerating iSCSI targets.

Field	Туре	Description
targetName	String	This is the full ISCSI target name enumerated in the format:
		<pre>iqn.yyyy-mm.[reverse-domain-name]:user- specified-suffix.</pre>
targetSuffixName	String	Target suffix or user-specified portion of the iSCSI target name after the iqn colon.
		For example, iqn.2012-12.com.tegile:targetSuffixName.
targetAlias	String	Target Alias, as alternate user friendly name of target.
		This is often the same as the target name suffix.
targetGroupName	String	Target group name.
targetAuthenticationMode	String	Target authentication type.
		The values must be 'none', 'chap', or 'mutual' string names.
		'none' indicates no user or password required, 'chap' indicates one way authentication (no user or password required), 'mutual' is two way authentication (provide chap user and secret).
targetChapName	String	User name for the chap authentication. Only required if 'mutual' chap authentication is chosen.
targetChapSecret	String	Password for the chap authentication. Only required if 'mutual' chap authentication is chosen.
targetNetworkBinding	String[]	Network binding string (ip:port) indicating the network ports to bind the target with.

ISCSITargetCreate_V2_1

This class represents the target for iSCSI protocol and can be used to create an iSCSI target.

Field	Туре	Description
targetSuffixName	String	Target suffix. This is just the user specified portion of the iSCSI target name after the iqn colon.
		For example, iqn.2012-12.com.tegile:targetSuffixName.
		This cannot have special characters such as '',*,#,/,\!,@,~, (,),[,],{,},=, and %. The string must be between 1 to 255 characters long.
targetAlias	String	Target Alias, as alternate user friendly name of target (often same as target name suffix).
targetGroupName	String	Target group name
		This cannot have special characters such as *, #, /, \ !, @, \sim , (,), [,], {, }, =, and %. The string must be 1 to 512 characters long.
targetAuthenticationMode	String	Target authentication type, which must be 'none', 'chap', or 'mutual' string names.
		'none' indicates no user or password required, 'chap' indicates one way authentication (no user or password required), and 'mutual' is two way authentication (provide chap user and secret).
targetChapName	String	Optional user name for the chap authentication.
		Only required if 'mutual' chap authentication was chosen. If specified this chap user name can't be blank or cannot have special characters such as ' ', \ $/$, $!$, $\#$, $\%$, $^$, $\&$, $^$, $($, $)$, $:$, $:$, and $@$.

Field	Туре	Description
targetChapSecret	String	Optional password for the chap authentication. Only required if 'mutual' chap authentication is chosen. This is only set on write or modify operations. For read operations, this string is null. The chap secret must between 12 and 16 characters if specified, and cannot have special characters such as ' ', \ /, !, #, \$, %, ^, &, *, (,), :, ;, and @.
targetNetworkBinding	String[]	Network Binding (in ip:port format) string indicating the network ports to bind target with.

ITView_V2_1

Field	Туре	Description
hostGroupName	String	Name of the host group
targetGroupName	String	Name of the target group
lunNbr	Integer	LUN number associated with the mapping. Populated with the default lun number -1 for project default mappings
readOnly	Boolean	Flag that indicates whether the view is read only. True for read only, false for read-write.

LocalGroup_V1_2

Field	Туре	Description
groupId	Integer	Group ID of the group
groupName	String	Name of the group
userList	List	List of users associated to the group

LocalUser_V1_2

Field	Туре	Description
groupId	Integer	Group ID of the group
groupName	String	Name of the group
userId	Integer	User ID of the user
userName	String	Name of the user

LunStatus

Field	Туре	Description
accessState	Integer	An integer indicating whether the LUN is:
		 active (0) active to standby (1) standby (2) standby to active (3)
alias	String	The LUN alias, if specified.
blockSize	String	The block size of the LUN.
commandException	String	Contains details of the exception, if an exception occurs.
commandStatus	Integer	An integer return value as defined in COMMAND_STATUS.
dataFile	String	The data file path for the LUN.
datasetPath	String	A string that contains the path to the dataset. The dataset path should have the format PoolName/Local/ProjectName/VolumeName for LUNs.
guid	String	The lunld of the LUN.
metaFile	String	The meta file path of the LUN.
mgmtURL	String	The management URL of the LUN.
operationalStatus	Integer	 Operational status of the LU. Stmf (SCSI target mode framework) logical unit offline (0) Stmf logical unit offlining (1) Stmf logical unit online (2) Stmf logical unit onlining (3) Stmf logical unit unregistered (4)
productId	String	Field not used.

Field	Туре	Description
serialNumber	String	Field not used.
size	String	The size of the LUN.
vendorld	String	Field not used.
viewCount	Integer	The number of mappings defined for the LUN.
writeCacheDisable	Boolean	A boolean that indicates if the data write cache is disabled.
writeProtect	Boolean	A boolean that indicates if write protect is enabled or disabled.
		Read-Only (True)Write (False)

NetworkACL_V2_1

Field	Туре	Description
hostType	String	Type of network ACL host, IP address or FQDN.
host	String	Host to which access is provided.
accessMode	String	Access mode. 'ro' for read-only access, 'rw' for read-write access.
rootAccessForNFS	String	Flag that indicates whether the NFS ACL has root access.
		Note: This is applicable only for NFS ACLs.

Pool_V1_0

Field	Туре	Description
availableSize	Long	The available size of the pool in bytes.
name	String	Name of the storage pool.
totalSize	Long	The total size of the pool in bytes.

PoolSpaceInfo_V2_1

Field	Description
totalPoolSize	Total size of the pool (bytes).
originalUsedByDataAndSnapshot	Original used by data and snapshot before compression and deduplication (bytes).
usedByDataAndSnapshot	Amount used by data and snapshot after compression and deduplication (bytes).
compressionSavingsPercentage	Amount saved from compression as a percentage.
dedupeSavingsPercentage	Amount saved from deduplication as a percentage.
totalSavingsPercentage	Amount saved from compression and deduplication as a percentage.
usedByAll	Amount used for data and reservation (bytes).
available	Amount of available space left on the pool (bytes).
usedByData	Amount used by data after compression and deduplication (bytes).
usedByReservation	Amount used by reservation (bytes).
usedBySnapshot	Amount used by snapshot after compression and deduplication (bytes).
totalMetaSize	Total metadata size (bytes).
usedMeta	Used metadata (bytes).

Project_V1_0

Field	Туре	Description
local	Boolean	Indicates whether the project belongs to the current array.
name	String	Name of the project.
poolName	String	The pool in which the project exists.

Project_V1_2

Field	Туре	Description
local	boolean	Indicates whether the project belongs to the current array.

Field	Туре	Description
name	String	Name of the project.
poolName	String	The pool in which the project exists.

Project_V2_1

Field	Description
poolName	Name of the pool. This field is mandatory while creating a project. The field becomes read only after creation.
projectName	Name of the project. This field is mandatory while creating a project. The field becomes read only after creation.
localDataset	Indicates whether it is a local project or a replica from a remote system. True indicates local, while False indicates replica. This field is read only.
purpose	Purpose of the project. Project created by createProject API has a "generic" purpose. This field is read only.
mountpoint	Mount point of the project on file system. This field is read only.
compression	Compression algorithm applied on the project. Supported values: off lzjb gzip-2 gzip zip lzip lzip

Field	Description	
compressedLog	Log compression algorithm for the project.	
	Supported values:	
	Iz4 off (default)	
intendedProtocolList	Adds protocol features to the project. This field is a list of string values, and is read only.	
	The default value is "NFS, SMB, FC, iSCSI". The value can also be a combination of any of the following protocols:	
	FCiSCSINFS	
	• SMB	
	Note: After you create a project, you cannot dynamically modify this property.	
quotalnByte	Enables quota on the project if intended for NFS use.	
	The value should be greater than 1 MB (1048576 bytes). The default value is 0 (no limit).	
quotaEnabled	Checks whether quota is enabled on the project.	
	This field is read only.	
quota	Quota number.	
	This field is read only.	
quotaMetric	Quota metric unit.	
	This field is read only.	
dedup	Turns on or off deduplication on the project.	
	Supported values:	
	on (default)off	
copies	Specifies number of the project copies.	
	Supported values:	
	1 (default) 2	
	• 3	

Field	Description
primaryCache	Specifies primary cache type.
	Supported values:
	All (default)
	NoneMetadata
secondaryCache	Specifies secondary cache type.
	Supported values:
	All (default) None
	Metadata
readonly	Specifies whether project is read only.
	Supported values:
	• On
	• Off
logbias	Specifies log bias type.
	Supported values:
	• Latency (default)
	Throughput
aclInherit	Turns on or off ACL inheritance on the project.
	Supported values:
	On (default) Off
IN 4 I -	
aclMode	Checks the ACL mode on the project.
	This field is read only.
krbStatus	Checks the krb status if SMB is enabled.
	This field is read only.
defaultVolumeSizeInByte	Default volume size.
	The value should be greater than 1 MB (1048576 bytes). The default value is 1 GB.
defaultVolumeSize	Volume size number.
	This field is read only.

Field	Description	
defaultVolumeSizeUnit	Volume size unit.	
	This field is read only.	
defaultVolumeBlockSize	Sets default volume block size.	
	Supported values:	
	• 4 KB	
	• 8 KB • 16 KB	
	• 32 KB (default)	
	• 64 KB	
	• 128 KB	
defaultThinProvisioning	Sets default thin provisioning for volume. The value is either True or False.	
sync	Checks synchronization mode.	
	This field is read only.	
zfsDataSetName	Returns ZFS dataset path name.	
	This field is read only.	
recordSize	Default share block size.	
	Supported values:	
	• 4 KB	
	• 8 KB	
	16 KB32 KB (default)	
	• 64 KB	
	• 128 KB	

ProjectCloneProgressStatus_v1_2

Field	Туре	Description
failedSubProjects	Integer	Number of sub projects (shares and volumes) for which clone snapshot has failed.
projectCloneState	Integer	The integer return value is defined in CLONE_PROGRESS_STATUS.
totalSubProjects	Integer	Total number of sub projects for the given project.

ReplicationConfig_V1_2

Field	Туре	Description
baseDataSetName	String	Base Dataset name
id	Long	Replication config ID
lastSnapshotName	String	Last snapshot name
poolName	String	Pool name
projectGuid	String	Project Guid
projectName	String	Project name
remoteBaseDataSetName	String	Remote dataset name
remoteHost	String	Target(Remote) host
remotePoolName	String	Remote pool name
remoteProjectName	String	Remote project name
scopeOption	Integer	The integer return value is defined in Replication_Scope_Option.

ReplicationStatus_v1_2

Field	Туре	Description
completedTask	Integer	Number of tasks completed.
completeTimestamp	Date	Time stamp indicating when replication was completed.
currentStatus	Integer	Current status of replication.
		The integer return value is defined in State
dataSent	Long	Total data sent.
sendSpeed	Long	Replication data send speed.
startTimestamp	Date	Time stamp indicating when replication started.
taskSize	Integer	Total task size.
updateTimestamp	Date	Time stamp indicating when replication was last updated.

Schedule_V2_1

Field	Туре	Description	
scheduleId	Integer	Schedule ID. Read-Only field.	
retentionPeriod	Integer	Maximum period to retain snapshots.	
		Schedule Interval Type	Retention Period Unit
		Minutes	Days
		Hourly	Days
		Daily	Weeks
		Weekly	Months
		Monthly	Years
scheduleIntervalTypeString		Type of schedule interval. The possible values are minutes, hours, days, weeks, or months.	
repeatInterval	Integer	How often the schedule should recur.	
		Schedule Interval Type	Retention Interval
		Minutes	Minutes
		Hourly	Hours
		Daily	Days
		Weekly	Weeks
		Monthly	Months
startDate	String	Start date for scheduling a snapshot in future. Should be specified in YYYY-MM-DD format. Start date can be either current date or a date in future.	
startTime	String	Start time for the schedule. This should be in 24HR HH:MM format. The date cannot be a past date.	
endTime	String	End time for the schedule. This should be in 24HR HH:MM format. This is applicable only for Minutes and Hourly Schedule interval types.	

Field	Туре	Description	
daysOfWeek	String	Days of the Week.	
		This is for the Weekly Schedule interval types.	
		Should be specified in comma-separated numbers and each number specifying day of the week.	
		For example:	
		Sunday:1, Monday:2, Tuesday:3 and so on.	
		For Weekdays Only: 2,3,4,5,6	
		For Weekend Only: 1,7	
		For Mon-Wednesday only: 2,4	
dayOfMonth	String	Day of the month.	
		This is for the monthly schedule interval types and the value indicates the date of each month when the schedule should be run.	
		If the specified date does not exist in the s month, the job is not run and is scheduled to next month, depending on the repeat interval specified.	
		For example, not each month has 31 days, so the job is skipped fo those months.	
		Either this field or weekdayOfMonth can be specified, but not both.	
weekdayOfMonth	String	Weekday of the month. This should be in W:D format.	
		This is for the monthly schedule interval types.	
		Examples:	
		Sunday:1, Monday:2, Tuesday:3 and so on.	
		2nd Monday of the Month : 2:2	
		4th Thursday of the Month : 4:5	
		This field could also contain the value "LAST" to indicate that the job has to run on the last day of the month.	
		Either this field or the dayOfWeek can be specified, but not both.	

Share_V1_0

Field	Туре	Description
availableSize	Long	The available size of the share in bytes.

Field	Туре	Description	
datasetPath	String	This field is a string that uniquely identifies the share on a Tegile array. A dataset path should have the format: PoolName/Local/ProjectName/ShareName.	
local	Boolean	This boolean identifies whether the share belongs to a local project or a replicated project.	
mountpoint	String	This string exposes the mountpoint of the share on a Tegile array.	
name	String	Name of the share.	
poolName	String	The pool that contains this share.	
projectName	String	The project that contains this share.	
totalSize	Long	The total size of the share in bytes.	

Share_V2_1

Field	Description	
name	Name of the dataset.	
	This field is read only.	
poolName	Name of the parent storage pool.	
	This field is read only.	
projectName	Name of the project.	
	This field is read only.	
purpose	Purpose of the dataset.	
	This field is read only.	
guid	Global unique identifier of the dataset.	
	This field is read only.	

Field	Description	
compression	Compression algorithm that applies on the dataset. Supported values: off lzjb gzip-2 gzip gzip zip-9 lz4	
overrideCompression	Checks whether compression algorithm overrides parent project. This field is read only.	
localDataset	Indicates whether the dataset is local or replica. This field is read only.	
reservationInByte	Enables reservation on the dataset. This value should be greater than 1 MB (1048576 bytes) or set to 0 (no limit).	
reservationEnabled	Checks whether reservation is enabled on the dataset. This field is read only.	
reservation	Reservation number. This field is read only.	
reservationMetric	Reservation metric unit. This field is read only.	
dedup	Turns on or off deduplication on the dataset. Supported values: on off	
overrideDedup	Check whether deduplication overrides parent project. This field is read only.	

Field	Description	
primaryCache	Specifies primary cache type.	
	Supported values:	
	• All	
	NoneMetadata	
overridePrimaryCache	Checks whether primary cache overrides parent project.	
	This field is read only.	
secondaryCache	Specifies secondary cache type.	
	Supported values:	
	All None	
	NoneMetadata	
overrideSecondaryCache	Checks whether secondary cache overrides parent	
overnaesecondary eache	project.	
readonly	Specifies whether the dataset is read only.	
	Supported values:	
	• On	
	• Off	
overrideReadonly	Checks whether read only overrides parent project.	
	This field is read only.	
logbias	Specifies log bias type.	
	Supported values:	
	• Latency	
	Throughput	
overrideLogbias	Checks whether log bias overrides parent project.	
	This field is read only.	
sync	Checks the synchronization mode.	
	This field is read only.	
overrideSync	Checks whether sync mode overrides parent project.	
	This field is read only.	

Field	Description	
overrideProjectSnapshot	Checks whether snapshot settings override parent project.	
Settings	This field is read only.	
zfsDataSetName	Returns ZFS dataset path name.	
	This field is read only.	
compressedLog	Log compression algorithm for the dataset.	
	Supported values:	
	Iz4off	
overrideCompressedLog	Checks whether log compression algorithm overrides parent project.	
	This field is read only.	
containerName	Checks current dataset container name.	
	This field is read only.	
mountPoint	Checks current mount point.	
	This field is read only.	
overrideMountPoint	Check whether mount point overrides default.	
	This field is read only.	
quotalnByte	Enables quota on the share if intended for NFS use.	
	This value should be greater than 1 MB (1048576 bytes) or set to 0 (no limit).	
quotaEnabled	Checks whether quota is enabled on the share.	
	This field is read only.	
quota	Quota number.	
	This field is read only.	
quotaMetric	Quota metric unit.	
	This field is read only.	
availableSize	Checks current available share size.	
	This field is read only.	
totalSize	Checks current total share size.	
	This field is read only.	

Field	Description	
overrideSharenfs	Checks whether NFS sharing overrides project setting.	
	This field is read only.	
overrideSharesmb	Checks whether SMB sharing overrides project setting.	
	This field is read only.	
krbStatus	Checks current Kerberos status of the share if SMB is enabled.	
	This field is read only.	
cifsDisplayName	Checks CIFS display name.	
	This field is read only.	
guestStatus	Checks guest status of the share.	
	This field is read only.	
aclinherit	Turns on or off ACL inheritance on the project.	
	Supported values:	
	• On	
	• Off	
overrideAclInherit	Check whether aclinherit overrides parent project setting.	
	This field is read only.	
recordSize	Default share block size.	
	Supported values:	
	• 4 KB	
	• 8 KB • 16 KB	
	• 32 KB	
	• 64 KB	
	• 128 KB	
overrideRecordSize	Check whether share block size overrides parent projec	
	This field is read only.	
atime	Checks access time.	
	This field is read only.	
nbmand	Checks non-blocking mandatory locks.	
	This field is read only.	

Field	Description	
aclList	A list of UserACL objects.	
	Checks current ACLs applied to the share.	
	This field is read only.	

ShareOptions

Field	Туре	Description	
blockSize	String	Block size of the share. Valid values are 4KB, 8KB, 16KB, 32KB, 64KB, or 128KB.	
mountPoint	String	Mount point of the share	
quota	Long	Maximum amount of storage space (in bytes) the share can use. If set to "-1", no quota limit is set on the share.	
reservation	Long	Amount of storage space (in bytes) reserved for the share. If set to "-1", no storage space is reserved for the share.	

SharePermissions

Field	Туре	Description
groupList	Array	A JSON array of LocalGroup_V1_2 object. You can use the response of the listGroups method for this paramater. This will be used if the sharePermissionEnum parameter (Permission_type_enum) is set to GROUP.
sharePermissionEnum	Integer	User ACL permission type. Valid values are defined by the Permission_type_enum enumeration.
sharePermissionMode	Integer	User ACL mode. Valid values are defined by the <i>Mode_enum</i> enumeration.

Field	Туре	Description
userList	Array	A JSON array of LocalUser_V1_2 object. You can use the response of the listUsers method for this parameter. This will be used if the sharePermissionEnum parameter (Permission_type_enum) is set to USER.

SnapShotDeletionStatus

Field	Туре	Description
deletedList	List	Deleted snapshots list
failedToDeleteList	List	Not deleted snapshots list
snapshotDeletionStatus	Integer	The integer return value is defined in SNAPSHOT_DELETION_STATUS

SnapshotProgressStatus

Field	Туре	Description
snapshotProgressStatus		An integer from the enumeration SNAPSHOT_PROGRESS_STATUS that indicates the snapshot progress status.

SnapshotSchedule_V2_1

Field	Туре	Description
datasetPath	String	Dataset path. It can be a project, LUN or a share.
		This should not be a replica dataset.
quiesce	String	Quiesce on or off.

SNMP_Setting_V2_1

This class represents the SNMP service settings (community string and trap listeners).

Field	Туре	Description
communityString	String	SNMP Community String.
		This must be 1 to 64 alpha-numeric characters, or should be * _, -, . (default='public'))
trapListeners	String[]	List of Trap listeners strings in IP:Port_Number format.

Volume_V1_0

Field	Туре	Description
blockSize	String	The block size of the volume.
datasetPath	String	This field is a string that uniquely identifies the volume on a Tegile array. A dataset path should have the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see <i>listVolumes</i> . The datasetPath is not required for <i>createVolume</i> API.
local	Boolean	This boolean identifies whether the volume belongs to a local project or a replicated project. The local boolean is not required for <i>createVolume</i> API.
luld	String	The unique identifier for the lun. The luld is not required for <i>createVolume</i> API.
name	String	Name of the volume.
poolName	String	The pool that contains this volume.
projectName	String	The project that contains this volume.
protocol	String	This is the protocol on which the volume will be exposed. The valid values are iSCSI, FC, and Unknown.
thinProvision	Boolean	Indicates whether this volume is thin provisioned or thick provisioned.
volSize	Long	The size of the volume in bytes.

Volume_V2_1

Field	Description	
name	Name of the dataset.	
	This field is read only.	
poolName	Name of the parent storage pool.	
	This field is read only.	
projectName	Name of the project.	
	This field is read only.	
purpose	Purpose of the dataset.	
	This field is read only.	
guid	Global unique identifier of the dataset.	
	This field is read only.	
compression	Compression algorithm applied on the dataset.	
	Supported values:	
	• off	
	Izjbgzip-2	
	• gzip	
	• gzip-9	
	• Iz4	
overrideCompression	Checks whether compression algorithm overrides parent project.	
	This field is read only.	
localDataset	Indicates whether the dataset is local or replica.	
	This field is read only.	
reservationInByte	Enables reservation on the dataset.	
	The value should be greater than 1 MB (1048576 bytes) or set to 0 (no limit).	
reservationEnabled	Checks whether reservation is enabled on the dataset.	
	This field is read only.	

Field	Description	
reservation	Reservation number.	
	This field is read only.	
reservationMetric	Reservation metric unit.	
	This field is read only.	
dedup	Turns on or off deduplication on the dataset.	
	Supported values:	
	onoff	
overrideDedup	Checks whether deduplication overrides parent project.	
	This field is read only.	
primaryCache	Specifies primary cache type.	
	Supported values:	
	• All	
	NoneMetadata	
overridePrimaryCache	Checks whether primary cache overrides parent project.	
overrider rimary eache	This field is read only.	
secondaryCache	Specifies secondary cache type.	
- Secondary cucine	Supported values:	
	• All	
	• None	
	Metadata	
overrideSecondaryCache	Checks whether secondary cache overrides parent project.	
	This field is read only.	
readonly	Specifies whether it is read only.	
	Supported values:	
	• on	
	• off	
overrideReadonly	Checks whether read only overrides parent project.	
	This field is read only.	

Field	Description
logbias	Specify log bias type.
	Supported values:
	• Latency
	Throughput
overrideLogbias	Checks whether log bias overrides parent project.
	This field is read only.
sync	Checks synchronization mode.
	This field is read only.
overrideSync	Checks whether sync mode overrides parent project.
	This field is read only.
overrideProjectSnapshotSetting	SChecks whether snapshot settings override parent project.
	This field is read only.
zfsDataSetName	Returns ZFS dataset path name.
	This field is read only.
compressedLog	Log compression algorithm for the dataset.
	Supported values:
	• Iz4
	• off
overrideCompressedLog	Checks whether log compression algorithm overrides parent project.
	This field is read only.
containerName	Checks current dataset container name.
	This field is read only.
volSize	Volume size in bytes.
VOISIZE	This field is read only.
luld	Unique identifier for the lun.
luiu	This field is read only.
dc:	-
usedSize	Used Volume size in bytes.
	This field is read only.

Field	Description	
thinProvisioning	Indicates whether this volume is thin provisioned.	
	This field is read only.	
blockSize	Sets volume block size.	
	Supported values:	
	 4 KB 8 KB 16 KB 32 KB 64 KB 128 KB 	
writeBackCache	Enables or disables disk write back cache.	
	Supported values:	
	EnableDisable	
overrideViews	Checks whether initiator-target view overrides parent project.	
	This field is read only.	
Protocol	Checks current protocol for the volume.	
	This field is read only.	

UserACL (Read Only) v2.1

Field	Description
id	Trivia
controllerId	Trivia
aclType	Group/User/Everyone
aclUser	If type is User, show user name
aclGroup	If type is Group, show group name
aclValDisplay	String of ACL value. For example, rwxpdDaARWcCos.
aclVal	Integer value of aclValDisplay.
aclMode	Allow or deny

Field	Description
aclInheritanceFlag	Inheritance type.
	Default/Files/Directories/Both
includeSubShares	True/False

Chapter 12

Enumerations

Topics:

- CLEANUP_STATUS
- CLONE_PROGRESS_STATUS
- COMMAND_STATUS
- Mode_enum
- OVERWRITE_STATUS
- Permission_type_enum
- Replication_Scope_Option
- SNAPSHOT_DELETION_STATUS
- SNAPSHOT_PROGRESS_STATUS
- State
- ZEBI_SYSTEM_PROPERTY

The following sections describe the enumerations used by the IntelliFlash API.

CLEANUP_STATUS

Status	Returned Value	Description
CLEANUP_NONE	0	Indicates cleanup is not needed.
CLEANUP_NEEDED	1	Indicates that cleanup is needed.
CLEANUP_DONE	2	Indicates that cleanup is completed.
CLEANUP_FAILED	3	Indicates that cleanup has failed.

CLONE_PROGRESS_STATUS

Indicates the status of a clone project snapshot request.

Status	Returned Value	Description
INPROGRESS	0	Indicates that the <i>cloneProjectSnapshot</i> request is in progress.
SUCCESS	1	Indicates that all of the project snapshots are cloned successfully.
PARTIAL	2	Indicates that some of the project snapshots are cloned successfully
FAILURE	3	Indicates that none of the project snapshots are cloned.

Related APIs, Objects, and Enumerations

A value from this enumeration is returned by the *getProjectCloneStatus* API to indicate the status of a project clone request.

getProjectCloneStatus, cloneProjectSnapshot, ProjectCloneProgressStatus_v1_2.

COMMAND_STATUS

Status	Returned Value	Description	
COMMAND_SUCCEED	0	Indicates that command (request) succeeded.	
COMMAND_NOT_ATTEMPTED	1	Indicates that command (request) not attempted.	

Status	Returned Value	Description
COMMAND_FAILED	2	Indicates that command (request) failed.

Mode_enum

Indicates the mode for ACLs supplied using the SharePermissions object to the createShare methods.

Value	Returned Value	Description
ALLOW	0	Indicates that permission should be granted to the specified set of users.
DENY	1	Indicates that permission should be denied to the specified set of users.

Related APIs, Objects, and Enumerations

createShare, createShare, SharePermissions.

OVERWRITE_STATUS

Status	Returned Value	Description	
OVERWRITE_NONE	0	Indicates overwrite is not required.	
OVERWRITE_DONE	1	Indicates overwrite completed.	
OVERWRITE_FAILED	2	Indicates overwrite failed.	

Permission_type_enum

Indicates the scope of ACLs supplied using the SharePermissions object to the createShare methods.

Value	Returned Value	Description
EVERYONE	0	Indicates that the supplied ACL is for everyone.
USER	1	Indicates that the supplied ACL is for the specified user.
GROUP	2	Indicates that the supplied ACL is for the specified group.

Related APIs, Objects, and Enumerations

createShare, createShare, SharePermissions.

Replication_Scope_Option

Specifies the condition that determines which datasets in a project will be replicated when you start replication on the project.

Value	Returned Value	Description
FULL	0	All datasets in the project will be replicated
INCLUDE	1	All selected datasets will be replicated
EXCLUDE	2	All selected datasets will not be replicated

Related APIs, Objects, and Enumerations

getReplicationConfigList, getReplicationStatus, startReplication, ReplicationConfig_V1_2.

SNAPSHOT_DELETION_STATUS

Indicates the status of a snapshot deletion request.

Status	Returned Value	Description
SUCCESS	0	Indicates that the snapshot deletion succeeded.
PARTIAL	1	This value is applicable only to the deleteProjectSnapshot API. It indicates that only some of the snapshots could be deleted (other snapshots that were selected for deletion could not be deleted.)
FAILURE	2	Indicates that the snapshot deletion has failed.

Related APIs, Objects, and Enumerations

deleteProjectSnapshot, deleteVolumeSnapshot, deleteShareSnapshot.

SNAPSHOT_PROGRESS_STATUS

Status	Returned Value	Description
SUCCESS	0	The snapshot request completed successfully.
INPROGRESS	1	The snapshot request is in progress.
ERROR	2	The snapshot request failed due to an error.

State

The **State** enumeration indicates the state of a replication request.

Status	Returned Value	Description	
UNKNOWN	0	Indicates that the replication task exited due to an unknown error.	
START	1	Indicates that the replication task has started.	
RESTART	2	Indicates that an interrupted replication task has restarted.	
SENDING	3	Indicates that the system is sending replication data.	
COMPLETING	4	Indicates that data transfer for replication is complete, and the replication task is finishing.	
COMPLETED	5	Indicates that the replication task is complete.	
ERROR	6	Indicates that the replication task exited with an error due to system, network, or other issues.	
ABORTING	7	Indicates that the initial state (before ABORTED) of an aborted replication. You cannot restart the replication task if it is aborting.	
ABORTED	8	Indicates that you have aborted the replication. If you abort a replication, the system rolls back to the previous replication snapshot completely.	
ABANDONING	9	Indicates that the system is ABANDONING a running replication task. The system abandons a replication if you manually switchover the pool or if the pool goes offline for any reason.	

States of a replication task

An uninterrupted and successful replication task goes through the start, sending, completing, and completed states. If the task fails due to an error or if you abort a running task, you can restart it at a later time.

Related APIs, Objects, and Enumerations

getReplicationConfigList, getReplicationStatus, startReplication, ReplicationConfig_V1_2, ReplicationStatus_v1_2.

ZEBI_SYSTEM_PROPERTY

Value	Description
ZEBI_APPLIANCE_MODEL	Indicates the array model.
ZEBI_APPLIANCE_VERSION	Indicates the array version.
ZEBI_GUI_VERSION	The IntelliFlash Web UI version.
ZEBI_SUPPORTED_TDPS_API_VERSIONS	The Tegile Data Protection Service (TDPS) versions supported by this version of the IntelliFlash API.
ZEBI_API_MINOR_VERSION	Indicates the minor version of the IntelliFlash API.
ZEBI_API_VERSION	Indicates the full version of the IntelliFlash API.
INTELLIFLASH_ARRAY_GUID	Indicates the GUID of the IntelliFlash array.
INTELLIFLASH_ARRAY_FQDN	Indicates the FQDN of the IntelliFlash array.

Appendix

A

Appendix A

Topics:

• JSON Quick Reference

JSON Quick Reference

This quick reference includes some JSON examples for users who are not familiar with the JSON syntax.

All JSON data sent in HTTP requests must be enclosed within square brackets ([]). For example, to send a single string, use the following:

```
["pool1"]
```



Note: As JSON ignores whitespace, such as newlines, tabs, and spaces, you can also send the following:

```
"pool1"
```

Boolean

true

false

Integers

213

String

```
"pool1"
```

Array of strings

```
"string1","string2","string3"
]
```

Objects

```
"lunNumber":-1,
"name":"testVol",
"local":true,
```

Array of objects

```
{"lunNumber":-1, "name":"testVol", "local":true},
{"lunNumber":-1, "name":"testVol", "local":true}
]
```

Mixed

```
"DatasetPath",
[{"lunNumber":-1,"name":"testVol","local":true}],
true
```

Appendix B

Appendix B

Topics:

• Deprecated APIs

Deprecated APIs

The following APIs have been deprecated. Instead of the deprecated APIs, use one of the alternate APIs suggested.

createSnapshots

Creates a snapshot for the specified dataset using the specified snapshot name. It can also delete previously-created snapshots, if an error occurs.

Alternate APIs

The createSnapshots API is deprecated. Use the *createVolumeSnapshot*, *createProjectSnapshot*, or *createShareSnapshot* APIs instead.

Related APIs

getProjectSnapshotCreationStatus, getVolumeSnapshotCreationStatus, getShareSnapshotCreationStatus, listSnapshots, cloneSnapshot.

Parameters

snapshotPaths

An array of strings that specify the dataset path (including the name of the snapshot to be created.) This string should have the format: datasetPath@SnapshotName. The datasetPath should identify a share or a volume.

override

A boolean value that indicates whether a snapshot is regenerated (if true) if a snapshot with the same name already exists.

cleanupOnError

A boolean value that indicates whether to clean up (if true) previously-created snapshots if an error happens.

Returns

A JSON array of *DatasetStatus* objects that contain the dataset path of the newly created snapshot and the results of the operation.

Examples

Request (curl):

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
```

```
-d '[["pool1/Local/TechPubs/TechPubsTest@api_SnapShotName_1"], \
false, false]' \
https://198.51.100.10/zebi/api/v2/createSnapshots -k
```

Response

```
[
    "datasetPath": "pool1/Local/TechPubs/
TechPubsTest@api_SnapShotName_1",
    "overwriteStatus": 0,
    "overwriteException": null,
    "commandStatus": 0,
    "commandException": null,
    "cleanupStatus": 0,
    "cleanupException": null
}
]
```

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["pool1/Local/TechPubs/TechPubs@api_SnapShotName_4"], \
false, false]' \
https://198.51.100.10/zebi/api/v2/createSnapshots -k
```

Error Response

```
[
        "datasetPath": "pool1/Local/TechPubs/
TechPubs@api SnapShotName 4",
        "overwriteStatus": 0,
        "overwriteException": null,
        "commandStatus": 2,
        "commandException": {
            "code": "EZEBI RESOURCE NOT FOUND",
            "details": "Unable to open pool1/Local/TechPubs/
TechPubs : dataset does not exist",
            "extendedData": {
                "EX CAUSE CODE NAME": "EZFS NOENT",
                "EX CAUSE MESSAGE": "Unable to open pool1/Local/
TechPubs/TechPubs : dataset does not exist",
                "EX CAUSE CODE NUMBER": "2009"
            "message": "Unable to open pool1/Local/TechPubs/
TechPubs : dataset does not exist"
        "cleanupStatus": 0,
        "cleanupException": null
```

]

deleteSnapshots

Deletes the specified snapshots and optionally, all dependent snapshots.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified snapshot) are also deleted.

Alternate APIs

The deleteSnapshots API is deprecated. Use the *deleteShareSnapshot* or *deleteVolumeSnapshot* APIs instead.

Related APIs

createSnapshots

Parameters

snapshotPaths

An array of strings that contains paths to snapshots to be deleted. This snapshot paths should have the format: datasetPath@SnapshotName. The datasetPath should be a path to a valid share or volume.

recursive

A boolean value that indicates whether to remove the dependents (if true) of this snapshot before trying to delete it.

errorlfNotExist

A boolean that indicates whether to raise an exception (if true) if any of the given snapshot path does not exist.

Returns

A JSON array of *DatasetStatus* objects that contain the dataset path of the deleted snapshot and results of the operation.

Examples

Request (curl):

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["pool1/Local/TechPubs/TechPubsTest@api_SnapShotName_1"], \
false, true]' \
https://198.51.100.10/zebi/api/v2/deleteSnapshots -k
```

Response

```
[
{
  "datasetPath": "pool1/Local/TechPubs/
  TechPubsTest@api_SnapShotName_1",
  "overwriteStatus": 0,
  "overwriteException": null,
  "commandStatus": 0,
  "commandException": null,
  "cleanupStatus": 0,
  "cleanupException": null
}
]
```

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["pool1/Local/TechPubs/TechPubs@api_SnapShotName_1"], \
false, true]' \
https://198.51.100.10/zebi/api/v2/deleteSnapshots -k
```

Error Response

```
"datasetPath": "pool1/Local/TechPubs/
TechPubs@api_SnapShotName_1",
"overwriteStatus": 0,
"overwriteException": null,
"commandStatus": 2,
"commandException": {
"code": "EZEBI RESOURCE NOT FOUND",
"details": "Unable to open pool1/Local/TechPubs/
TechPubs@api SnapShotName 1 : dataset does not exist",
"extendedData": {
"EX_CAUSE_CODE_NAME": "EZFS NOENT",
"EX CAUSE MESSAGE": "Unable to open pool1/Local/TechPubs/
TechPubs@api_SnapShotName 1 : dataset does not exist",
"EX CAUSE CODE NUMBER": "2009"
"message": "Dataset pool1/Local/TechPubs/
TechPubs@api SnapShotName 1 does not exists"
"cleanupStatus": 0,
"cleanupException": null
]
]
```

deleteSnapshots

Deletes snapshots (and optionally all dependent snapshots in the specified path) whose names match with the given pattern.



Caution: If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified snapshot) are also deleted.

Alternate APIs

The deleteSnapshots API is deprecated. Use the *deleteShareSnapshot* or *deleteVolumeSnapshot* APIs instead.

Related APIs

createSnapshots

Parameters

datasetPath

A string that contains the dataset path of the snapshot. The dataset path has the format: PoolName/Local/ProjectName/VolumeName.

snapshotPattern

A regular expression (regex) for matching snapshot names. Use an empty string to delete all snapshots in the given path.

recursive

A boolean value that indicates whether to remove (if true) dependents of the matching snapshots before deleting the snapshots themselves.

errorlfNotExist

A boolean value that indicates whether to raise an exception (if true) if the path specified by datasetPath does not exist.

Returns

A JSON array of *DatasetStatus* objects that contain the dataset path of the deleted snapshot and results of the operation.

Examples

Request (curl):

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["pool1/Local/TechPubs/TechPubsTest", "api*", \
false, true]' \
```

https://198.51.100.10/zebi/api/v2/deleteSnapshots -k

Response

```
"datasetPath": "api SnapShotName 1",
"overwriteStatus": \overline{0},
"overwriteException": null,
"commandStatus": 2,
"commandException": {
"code": "EZEBI RESOURCE NOT FOUND",
"details": "Unable to open api_SnapShotName_1 : dataset does not
exist",
"extendedData": {
 "EX CAUSE CODE NAME": "EZFS NOENT",
 "EX CAUSE MESSAGE": "Unable to open api SnapShotName 1:
 dataset does not exist",
 "EX CAUSE CODE NUMBER": "2009"
"message": "Dataset api SnapShotName 1 does not exists"
"cleanupStatus": 0,
"cleanupException": null
"datasetPath": "Auto-LF-Day-012114-21:15",
"overwriteStatus": 0,
"overwriteException": null,
"commandStatus": 2,
"commandException": {
"code": "EZEBI RESOURCE NOT FOUND",
"details": "Unable to open Auto-LF-Day-012114-21:15 : dataset
does not exist",
"extendedData": {
"EX CAUSE CODE NAME": "EZFS_NOENT",
"EX CAUSE MESSAGE": "Unable to open Auto-LF-Day-012114-21:15:
dataset does not exist",
"EX CAUSE CODE NUMBER": "2009"
"message": "Dataset Auto-LF-Day-012114-21:15 does not exists"
"cleanupStatus": 0,
"cleanupException": null
```

Erroneous Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["pool1/Local/TechPubs/TechPubs", "api*", \
false, true]' \
https://198.51.100.10/zebi/api/v2/deleteSnapshots -k
```

Error Response

```
{
"message": "Unable to open pool1/Local/TechPubs/TechPubs :
  dataset does not exist",
"extendedData": {
  "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
  "EX_CAUSE_MESSAGE": "Unable to open pool1/Local/TechPubs/
TechPubs : dataset does not exist",
  "EX_CAUSE_CODE_NUMBER": "2009"
},
"details": "Unable to open pool1/Local/TechPubs/TechPubs :
  dataset does not exist",
  "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

cloneSnapshot

Clones a snapshot to a new dataset.

Alternate APIs

The cloneSnapshot API is deprecated. Use the *cloneProjectSnapshot*, *cloneShareSnapshot*, or *cloneVolumeSnapshot* APIs instead.

Related APIs

listSnapshots, createSnapshots.

Parameters

snapshotPath

A string that identifies the path for the snapshot that needs to be cloned. The snapshot path has the format: datasetPath@snapshotName. The datasetPath must be a valid path to a share or a volume.

cloneName

A string that contains the name of the new dataset.

clonesSettings

A boolean value that indicates whether to clone the settings that are required to share the new dataset.

readOnly

A boolean value that indicates whether to make the new dataset a read-only clone.

promotesIt

A boolean value that indicates whether to promote the new dataset so that it is possible to remove to old dataset.

Returns

If the dataset is a volume, the LUN ID (GUID) of the new volume is returned. If the dataset is a share, nothing is returned.

Examples

Request (curl):

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["pool1/Local/TechPubs/TechPubsTest@api_SnapShotName_1", \
"api_CloneName_1", false, false, false]' \
https://198.51.100.10/zebi/api/v2/cloneSnapshot -k
```

Response

The above request returns the HTTP status code 200 (OK) and no data.

Erroneous Request 1 (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["pool1/Local/TechPubs/TechPubsTest@api_SnapShotName-Bad", \
"api_CloneName_1", false, false, false]' \
https://198.51.100.10/zebi/api/v2/cloneSnapshot -k
```

Error Response

```
HTTP Status Code: 400
{
   "message": "An entity with the same name already exists.",
   "extendedData": {},
   "details": "",
   "code": "EZEBI_GENERAL"
}
```

Erroneous Request 2 (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["pool1/Local/TechPubs/TechPubs@api_SnapShotName", \
"api_CloneName_1", false, false, false] \
https://198.51.100.10/zebi/api/v2/cloneSnapshot -k
```

Error Response

```
{
   "message": "Unable to open pool1/Local/TechPubs/TechPubs:
   dataset does not exist",
   "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool1/Local/
TechPubs/TechPubs: dataset does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
      },
   "details": "Unable to open pool1/Local/TechPubs/TechPubs:
   dataset does not exist",
   "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```