
ENS1161 Computer Fundamentals Module 4 Basic computation in computers



ENS1161 Computer Fundamentals

Moving forward..

- Last module:
 - how various types of data are formatted
 - the general format of instructions
 - methods by which operands are retrieved for the processor to use (addressing modes)
- Focus of this module: How data is processed
 - Mainly numerical processing





Module Objectives

On completion of this module, students should be able to:

- Carry out binary addition of unsigned and signed 2s complement integers
- Describe the function and structure of a basic ALU
- Describe how the ALU generates flags from binary addition, where they are stored and how they are used
- Work out the flags set from binary addition and accordingly represent results correctly when out of range conditions occur
- Describe how basic arithmetic and logic functions work and can be used
- Explain the how flags relate conditional branch instructions
- Describe factors that affect computing power and methods of measuring it

School of Engineering



ENS1161 Computer Fundamentals

Introduction

Module Scope

- Binary addition, including the generation of C, N, V flags
- Arithmetic and logic operations
 - Addition, subtraction, multiplication, division, AND, OR, XOR, shifting, rotate
- Status/flags register, interpretation of flags in in computation



Data & Instructions (recap)


- Bytes stored in the memory unit of a computer can represent a number of different things:
 - Binary numerical data
 - Coded data (text, images, sound, video, etc)
 - Instruction codes
 - Operand or program branching addresses
- Difference lies only in context
 - · How it is used / interpreted
- Else they cannot be differentiated
 - Just a bunch of bits

School of Engineering



Primarily input and output data

Related to program instructions



ENS1161 COMPUTER FUNDAMENTALS

Numerical data (recap)

Integer data

- Value of the number in binary
- The larger the word size the greater the range of values that can be represented
 - · More bit patterns possible

Unsigned integers

- with an 8-bit word size the largest value is 255 (28-1)
- with 16-bits it is 65,535 (216-1), and so on

Signed integers

- 2's-complement system used to represent signed integers
- The most significant bit represents the sign bit
- an 8-bit signed word can represent numbers from -128 to +127
- a 16-bit signed word numbers from -32,768 to +32,767


School of Engineering



Unsigned integers in binary (recap)

- Each bit (place value) represents an increasing power of 2
- Each place value multiplied by 1 or 0
 - According to the bits in the number
- Terminology:
 - LSB: Least Significant Bit
 - The rightmost bit (Bit 0), represents 2^o
 - MSB: Most Significant Bit
 - Leftmost bit
 - Value depends on number of bits in number
 - For n bits, MSB represents 2ⁿ⁻¹

School of Engineering



ENS1161 COMPUTER FUNDAMENTALS

Signed 2s complement numbers (recap)

- Most common method of representing signed numbers in computers
- Split the binary combinations between positive and negative numbers

MSB = 0 for positive


MSB = 1 for negative

2s complement process

- 1. Invert all bits (complement)
- 2. Add 1
- The process converts numbers

+ve to –ve

-ve to +ve



ENS1161 COMPUTER FUNDAMENTALS



Binary Addition (review)

▶ 1st column: 0 + 0 = 0

 $2^{nd}/3^{rd}$ column: 1 + 0 = 0 or 0 + 1 = 1

 4^{th} column: 1 + 1 = 10

• Result is 0

• Carry out 1 to next bit addition

▶ 5th /6th column: add two 1s (including carry in bit) so result is 10

> 7th column: 1 + 1 + 1 = 11

• Result is 1


Carry out 1 to next bit addition

School of Engineering



ENS1161 COMPUTER FUNDAMENTALS

Simplified Diagram of a Processor (recap)




School of Engineering



The Arithmetic Logic Unit (ALU) (recap)

- Electronic hardware designed to perform operations
 - Arithmetic operations: add, subtract, multiply, etc.
 - Logic operations : AND, OR, NOT, etc.
 - Binary data operations : Shift left/right, rotate, etc.




- Data to operate on (called operands) come from connected registers
 - Can have one or two operands, depending on operation
- What operation to perform is determined by signals from the Control unit
 - Based on current instruction
- ▶ The result is stored in a register (most commonly the *accumulator*)

School of Engineering

ENS1161 COMPUTER FUNDAMENTALS


Generic ALU structure




Adder circuits

- Full adder circuit
 - Adds 1 bit from each data word and carry in from previous
 - Produces a sum (1 bit) and carry out
- Each full adder circuit adds 1 bit
- Half adder circuit
 - Same as full adder except no carry in
- The ALU has a number of these adder circuits cascaded together for Add function
- Note: Details of Full adder and half adder circuits are outside the scope of this unit

School of Engineering







ENS1161 Computer Fundamentals

Carry in to

Carry flag, C

- There is a carry bit generated from the last bit (MSB)
- This 'extra' bit gets stored in the Carry flag
- The Carry flag is 1 bit in the Flags register
 - Can either be 1 (True) or 0 (False)
- C = 1 (Carry is True)
 - means the answer is too big to store in the result bits generated by the ALU if interpreted as an unsigned integer
 - Need more bits to store the answer








Extending unsigned integer results

Interpreting sum as *unsigned integers*



- Result bits do not make sense as they are
- Carry flag = 1
 - Answer too big to fit
- Need to extend answer (double number of bits) and add carry in there

$$\checkmark$$
 326 \leftarrow 00000001 0 1 0 0 1 1 0


Answer is now correct

School of Engineering

ENS1161 Computer Fundamentals

ALUs 'blind' addition

- The ALU (hardware) does the binary addition of the bits without consideration of what the bits represent
 - How to correctly use and interpret the result is in the hands of the programmer
 - Same for any other function / operation
- What if the bits being added are meant to represent *signed integers* (2s complement format) and not unsigned integers?
- How to handle out of range answers?
- ALU provides 2 other flags (automatically)
 - N flag Negative
 - V flag oVerflow



School of Engineering

Range of integer values (recap)

- An *n*-bit number can have 2ⁿ different patterns
- For unsigned integers, this is from 0 to $2^{n}-1$
- For signed integers, the patterns are split into two
 - Half for positive (including zero)
 - Half for negative

Range of integers	8-bit	16-bit
Unsigned	0 to 255	0 to 65535
Signed	-128 to +127	-32768 to +32767

Signed	Unsigned	2's Complement
+5	5	0000 0101
+4	4	0000 0100
+3	3	0000 0011
+2	2	0000 0010
+1	1	0000 0001
0	0	0000 0000
-1	255	1111 1111
-2	254	1111 1110
-3	253	1111 1101
-4	252	1111 1100
-5	251	1111 1011


School of Engineering



ENS1161 Computer Fundamentals

Adding signed integers

- Interpreting sum as signed integers
- N flag = 0
 - Answer is positive
- ▶ V flag = MSB Carry in \oplus MSB Carry out
 - ∘ ⊕ is Exclusive-OR (XOR) function
- ▶ So in example, V flag = $1 \oplus 1 = 0$
 - i.e. number is in valid range
- .: Answer is correct



N flag Truth table for XOR

V flag calculated


р	q	p⊕q
0 0	0	0
1	0	1
1	1	0

School of Engineering



Extending signed integer results

- Interpreting sum as signed integers
- N flag = 0
 - Flag means answer is positive
 - Answer does not make sense!
- V flag = $0 \oplus 1 = 1$
 - i.e. number is NOT in valid range
 - Needs to be extended to accommodate answer
- Double number of bits, extra bits are OPPOSITE of N flag





School of Engineering

ENS1161 Computer Fundamentals

V flag calculated

from these 2 bits

Other ALU generated flags

- Some flags are automatically generated by the ALU
 - Stored in the flags register
 - E.g. C, N, and V flags
- Zero (Z) flag
 - set to 1 (true) if ALU operation result = 0
 - A most common (and useful) ALU generated flag
- Half carry (H) flag
 - set to 1 (true) if there is a carry out from bit 3 into bit 4
- These flags are generated every time the ALU performs an operation
 - It is up to the program(mer) to decide how to use these flags
 - Based on the type of data and what needs to be done

School of Engineering

Flags register

- Flags register is a special register where each bit represents a particular flag
- A flag is a Boolean variable (1 bit)
 - Can either be 1 (True) or 0 (False)
- Flags normally indicate some kind of condition or status
 - Flags register also known as condition code register (CCR) or status register
- Some flags are related to ALU operations and some have other purposes
 - E.g. control purposes such as enabling or disabling interrupts (I flag)
- Each processor may have slightly different names for the common flags
 - The flags will also be stored in different bit positions in the flags register


Example Flags register



School of Engineering

ENS1161 COMPUTER FUNDAMENTALS

8088 flags register (example)



- 6 conditional flags, indicate some condition resulting after an instruction executes CF, PF, AF, ZF, SF, and OF
- Other 3 control flags, control the operation of instructions before they are executed.



8088 flags register (example)

Conditional flags

```
    O = Overflow flag : set if signed result is out of range
```

S = Sign flag : high for negative 2's complement values

Z = Zero flag : set if any result = 0

A = Auxiliary carry flag : carry from b3 to b4, used for BCD calculations

P = Parity flag : set if any result has even parity

• **C** = Carry flag : set if any calculation generates a carry

Control flags

- D = Direction flag : used for certain instructions (0 = Up)
- = Interrupt enable flag: to enable/disable external interrupt requests
- T = Trap flag : used for debugging

School of Engineering

ENS1161 Computer Fundamentals


Arithmetic Instructions

- All processors include some basic arithmetic operations
- Many early processors included only addition and subtraction instructions
 - These were only for fixed point arithmetic
 - Other more complex arithmetic operations must be carried out in software by performing appropriate sequences of these simple instructions
- Subsequent processors included multiplication and division instructions
- Floating point operations were later added
 - Initially carried out by 'maths co-processors' separate special function processors
- Some examples of basic arithmetic and logic instructions given following
 - Based on the old 8086, but still exist in current generation processors (e.g. Core i7)



The 8086/8088 Architecture

Programming Model of the 8086/8088 – Registers



School of Engineering

ENS1161 Computer Fundamentals

25

Addition and Subtraction

- ADD destination, source
 - Adds the two specified data values and places the result into the destination

```
    dest ← dest + src
    E.g. ADD AL, 55h
    ADD BH, AH
    ; AL + 55h, result in AL, 55h is an immediate value
    ; BH + AH, result in BH, BH and AH both registers
```


- ▶ **ADC** destination, source (Add with Carry)
 - Adds value of Carry flag as Carry In to first bit
 - o dest ← dest + src + C
- SUB destination, source
 - Used in the same way as the ADD instruction, but performs subtraction
 - dest ← dest src



Arithmetic Instructions and flags

ADD Instruction

- Example of flags set
- ADD AL, BL



• What are the C, N, V, H and Z flag values after the operation above?

School of Engineering

ENS1161 COMPUTER FUNDAMENTALS

Increment and Decrement

- ▶ The most common arithmetic operations are incrementing (+1) or decrementing (-1) a register or variable
- These generally have their own (optimised) instruction
 - No need to specify / fetch a second operand
- ► INC dest
 - Adds 1 to the destination
 - dest ← dest + 1 E.g. INC AL ; AL = AL + 1
- ▶ DEC dest
 - Subtracts 1 from the destination
 - dest ← dest 1



Multiplication

- When multiplying 2 numbers, the result may need double the number of digits
 - E.g. Multiplying 2 single-digit decimal numbers may result in a 2 digit answer • $9 \times 9 = 81$
 - Same principle applies in binary answer requires double the number of bits
 - E.g. MUL operand
 - Second number by default is in the AL (8-bit) or AX (16-bit) register
 - If operand is 8-bit : 8 bit 16 bit result operand * AL \rightarrow AX
 - If operand is 16-bit: 16 bit **32 bit result**: concatenation of 2 16-bit registers operand * $AX \rightarrow DX:AX$
 - N.B. The IMUL instruction should be used for operations on signed data values

School of Engineering



ENS1161 Computer Fundamentals

Division

- When dividing numbers, there are 2 parts to the result
 - The quotient (whole number answer)
 - The remainder
 - E.g. 53 / 5 = 10 remainder 3
 - E.g. DIV operand

Source: mathsteacher.com.au

- The dividend by default is in AX (16-bit) register or DX:AX (32-bit)
- If operand (divisor) is 8-bit: 16 bit $AX \div operand = quotient \rightarrow AL$, remainder $\rightarrow AH$
- If operand is 16-bit: $DX:AX \div operand = quotient \rightarrow AX$, remainder $\rightarrow DX$
- N.B. The IDIV instruction should be used for operations on signed data values



Logical Instructions

- ▶ All processors have a number of instructions that perform bitwise logical operations
- ▶ AND / OR / XOR dest, source (8086 example)
 - Performs the logical operation bit-by-bit between all bits of the specified operands
 - The result is stored in the first specified operand

```
MOV AL, 01010101b
                                          ; puts the specified bits in AL
E.g.
              AND AL, 10101011b
                                          ; AND with bits in operand
```

This will result in AL= 00000001b

School of Engineering


ENS1161 Computer Fundamentals

Logical Instructions

AND Masking

- Common use for the AND instructions
- To selectively *clear* specific bits of a data word
- Done by AND-ing the data word with another word called a mask
 - contains 0s in the bit positions to be cleared
 - 1s everywhere else
- Common application: masking of network addresses

		_
Mnemonic	Comments	_
MOV AL, 55h	; AL <= 0101 0101b	_
AND AL, 0Fh	; 0Fh = 0000 1111b	
	; AL <= 0000 0101b (05h)	





Logical Instructions

OR Masking

- OR instructions can be used to selectively set specific bits of a data word
- The OR mask should have
 - 1s in the bit positions to be set
 - Os everywhere else

Mnemonic		Comments	
MOV CH, 05h	; CH <=	0000 0101b	
OR CH, 30h	; 30h =	0011 0000b	
	; CH <=	0011 0101b	
	; = 35h		

р	q	p OR q
0	0	0
0	1	1
1	0	1
1	1	1

School of Engineering




ENS1161 COMPUTER FUNDAMENTALS

Logical Instructions

Selective Inversion

- XOR instructions can be used to selectively invert specific bits of a data word
- The mask should contain
 - 1s in the bit positions to be inverted
 - 0s everywhere else

Mnemonic	Comments
IN AL, 0F7h	; Load data from input device at F7h
XOR AL, 0Fh	; Invert data in low nibble of AL





Shift Instructions

- Logical Shift
 - SHL dest, 1 (Logical Shift Left)
 - Shifts all bits in the destination 1 place to the left.
 - MSB gets shifted into C flag, Bit 0 is cleared
 - Effectively multiplies the value by 2

		b7	b6	b5	b4	b3	b2	b1	b0
before left shift	c	1	Q	1	1	ρ	,1	1	,1
after left shift	1	0	1	1	0	1	1	1	0
			_		-				

Mnemonic	Comments			
MOV AL, \$05	; AL <= 0000 0101b (05 hex)			
SHL AL, 1	; AL <= 0000 1010b (0Ah, 10 dec)			
SHL AL, 1	; AL <= 0001 0100b (14h, 20 dec)			


School of Engineering



ENS1161 Computer Fundamentals

Shift Instructions

- Logical Shift
 - (Logical Shift Right) • SHR dest, 1
 - Shifts all bits in the destination 1 place to the right.
 - Bit 0 gets shifted into C flag, MSB is cleared
 - Effectively divides the unsigned value by 2






Shift Instructions

Arithmetic Shift

- SAL dest, 1 (Arithmetic Shift Left)
 - Works exactly the same as Logical Shift Left
 - Shifts all bits in the destination 1 place to the left.
 - MSB gets shifted into C flag, Bit 0 is cleared
 - Effectively multiplies the value by 2



School of Engineering

ENS1161 Computer Fundamentals

Shift Instructions

Arithmetic Shift


- SAR dest, 1 (Arithmetic Shift Right)
 - Works similar (but not exactly the same) as SHR
 - Shifts all bits in the destination 1 place to the right, Bit 0 into C flag
 - Also effectively divides the value by 2 but assumes a signed number
 - So sign bit is fed into MSB to ensure that sign stays the same


b7 b6 b5 b4 b3 b2 b1 b0 before arithmetic shift 1 1 after arithmetic shift

School of Engineering

Rotate Instructions

- ROL / ROR dest, 1 (Rotate Left / Right)
 - · Performs left or right rotations on the register
 - Similar to shift left / right, except that bit that 'falls out' moved to the opposite end






School of Engineering

ENS1161 Computer Fundamentals

20

Rotate Instructions

- RCL / RCR dest, 1 (Rotate through Carry Left / Right)
 - Similar to ROL / ROR except that Carry flag is included in the rotation





Instructions that only set flags

Compare Instruction

- CMP operand 1, operand 2
 - Performs a pseudo-subtraction: operand 1 operand 2
 - The S, C, O, Z and P flags are set based on the result
 - · But the result is not actually stored anywhere
 - The flags can then be checked / used via branch instructions
 - · Refer 2 slides down for more details on conditional branching

E.g. CMP AL, BL

	c/s	Z
AL > BL	0	0
AL = BL	0	1
AL < BL	1	0

School of Engineering

ENS1161 Computer Fundamentals

Instructions that only set flags

Test Instruction

- TEST operand 1, operand 2
 - Performs a bit-by-bit pseudo-AND: operand 1 AND operand 2
 - The Z, S and P flags are set accordingly
 - · The result is not actually stored anywhere
 - AND masking can be used to isolate and test one or more bits
 - Check whether they are set or cleared
 - · Does not affect its contents

E.g. TEST AL, 00001000b ; Test bit 3 in AL

JNZ Somewhere; Jump if it is set (Not Zero)

NB: The Z flag will be set if bit 3 in AL is 0, and cleared if it is 1





- Most conditional branch instructions are designed to be used after a CMP or arithmetic operation between two operands
 - · e.g. A and B
 - Action whether to branch (jump) or not based on particular flags

Mne	monic	Condition	Mnemonic	Condition
	JA	A > B (unsigned)	1C	C flag = 1
	JAE	A ≥ B (unsigned)	JNC	C flag = 0
	JB	A < B (unsigned)	JNO	O flag = 0
	JBE	A ≤ B (unsigned)	JNP	P flag = 0
	JE	A = B (Z = 1)	JNS	S flag = 0
	JG	A > B (signed)	JNZ	Z flag = 0
	JL	A < B (signed)	JO	O flag = 1
	NA	A ≯ B (unsigned)	JPE	P flag = 1
	INE	A ≠ B	JS	S flag = 1
	INL	A ₹ B	JZ	Z flag = 1

School of Engineering

ENS1161 COMPUTER FUNDAMENTALS

40

Use of Conditional Branching

- Conditional branching instructions are the basis of important programming concepts like:
 - Conditional statements (IF ... THEN ... ELSE..)
 - Loops
- This will be covered in the next module



Multipliers and their Symbols

'Normal' decimal

Binary multipliers – used in computing

Multiplier	Name	Symbol
10 ³	kilo	k
10 ⁶	mega	M
10 ⁹	giga	G
10 ¹²	tera	Т
10 ¹⁵	peta	Р
10 ¹⁸	exa	E

Multiplier	Value	Name	Symbol
2 ¹⁰	$1024 \approx 10^3$	kilo	K (or Ki)
2 ²⁰	$1,048,576 \approx 10^6$	mega	M (or Mi)
2 ³⁰	≈ 10 ⁹	giga	G (or Gi)
2 ⁴⁰	≈ 10 ¹²	tera	T (or Ti)
2 ⁵⁰	≈ 10 ¹⁵	peta	P (or Pi)
2^{60}	≈ 10 ¹⁸	exa	E (or Ei)

While they use the same symbols, the values of each multiplier differ slightly

Multiples of 1000 vs multiples 1024

School of Engineering



ENS1161 Computer Fundamentals

Decimal vs binary multipliers

- Which multiplier to use depends on the context
 - Normal physical parameters vs parameters within the computer
 - E.g. Physical: 1 GHz clock = 109 Hz (cycles / second)
 - E.g. Computing: $4GB RAM = 4 \times 2^{30}$ bytes = 4,294,967,296 bytes
- Number of bits in address bus defines the addressable memory
 - E.g. 16 bits address bus, addressable memory = 2^{16} = $2^6 \cdot 2^{10}$ = 64 KB memory

Address bus size	Addressable memory	Equivalent
16-bit	$2^{16} = 2^6 \cdot 2^{10}$	64 KB <i>(or KiB)</i>
24-bit	$2^{24} = 2^4 \cdot 2^{20}$	16 MB (or MiB)
32-bit	$2^{32} = 2^2 \cdot 2^{30}$	4 GB (or GiB)
64-bit	$2^{64} = 2^4 \cdot 2^{60}$	16 EB (or EiB)

School of Engineering



Other multipliers and their Symbols

'Normal' decimal

Multiplier	Name	Symbol
10-3	milli	m
10 ⁻⁶	micro	μ
10-9	nano	n
10 ⁻¹²	pico	р
10 ⁻¹⁵	femto	f
10 ⁻¹⁸	atto	a

These are used in measuring physical parameters

• E.g. memory access time in *ns* (nanoseconds)

School of Engineering




ENS1161 COMPUTER FUNDAMENTALS

Factors that affect computing power

ALU width

- Number of bits the ALU can process at one time
 - 8-bit, 16 bit, 32 bit, 64 bit
- Normally matches the size of the internal data bus and registers



Number of computing operations that can be performed in a second

- Depends on a number of factors
 - Clock speed, number of microprogram steps per instruction
- Also depends what each operation can do
 - E.g. integer addition vs. floating point multiplication



Some measures of computing power

Clock Speed

- Simplest measure of processor power
- Least meaningful as each instruction may take different number of clock cycles
- Also does not take into account processors may have multiple cores

Millions of Instructions per second (MIPS)

- Generally based on integer only computation
- Only meaningful if processors being compared have similar architecture
 - · ALU width, etc.

Floating-point Operations Per Second (FLOPS)

- Floating point operations form basis of 'real' computations including graphics
- All these measures are only indicative many other factors come into play





ENS1161 Computer Fundamentals

Module Objectives

On completion of this module, students should be able to:

- Carry out binary addition of unsigned and signed 2s complement integers
- Describe the function and structure of a basic ALU
- Describe how the ALU generates flags from binary addition, where they are stored and how they are used
- Work out the flags set from binary addition and accordingly represent results correctly when out of range conditions occur
- Describe how basic arithmetic and logic functions work and can be used
- Explain the how flags relate conditional branch instructions
- Describe factors that affect computing power and methods of measuring it

