

CHIPKIT UNO 32: DIGITAL READ SERIAL

Author: Umashankar Shetty C

This example shows you how to monitor the state of a switch by establishing <u>serial</u> communication between your Chipkit UNO32 and your computer over USB.

Hardware Required:


- Chipkit UNO32 Board
- A momentary switch, button, or toggle switch
- 10k ohm resistor
- breadboard
- hook-up wire

Hardware Connection:

Connect three wires to the Chipkit UNO32 board. The first two, red and black, connect to the two long vertical rows on the side of the breadboard to provide access to the 5 volt supply and ground. The third wire goes from digital pin 2 to one leg of the pushbutton. That same leg of the button connects through a pull-down resistor (here 10K Ohms) to ground. The other leg of the button connects to the 5 volt supply.

Pushbuttons or switches connect two points in a circuit when you press them. When the pushbutton is open (unpressed) there is no connection between the two legs of the pushbutton, so the pin is connected to ground (through the pull-down resistor) and reads as LOW, or 0. When the button is closed (pressed), it makes a connection between its two legs, connecting the pin to 5 volts, so that the pin reads as HIGH, or 1.

If you disconnect the digital i/o pin from everything, the LED may blink erratically. This is because the input is "floating" - that is, it doesn't have a solid connection to voltage or ground, and it will randomly return either HIGH or LOW. That's why you need a pull-down resistor in the circuit.



Code:

In the program below, the very first thing that you do will in the setup function is to begin serial communications, at 9600 bits of data per second, between your Chipkit UNO32 and your computer with the line: Serial.begin(9600);

Next, initialize digital pin 2, the pin that will read the output from your button, as an input: pinMode(2,INPUT);

Now that your setup has been completed, move into the main loop of your code. When your button is pressed, 5 volts will freely flow through your circuit, and when it is not pressed, the input pin will be connected to ground through the 10-kilohm resistor. This is a digital input, meaning that the switch can only be in either an on state (seen by your Chipkit UNO32 as a "1",

or HIGH) or an off state (seen by your Chipkit UNO32 as a "0", or LOW), with nothing in between.

The first thing you need to do in the main loop of your program is to establish a variable to hold the information coming in from your switch. Since the information coming in from the switch will be either a "1" or a "0", you can use an <u>int datatype</u>. Call this variable sensorValue, and set it to equal whatever is being read on digital pin 2. You can accomplish all this with just one line of code:

```
int sensorValue = digitalRead(2);
```

Once the Chipkit UNO32 has read the input, make it print this information back to the computer as a decimal (DEC) value. You can do this with the command Serial.println() in our last line of code:

```
Serial.println(sensorValue, DEC);
```

Now, when you open your Serial Monitor in the Chipkit UNO32 environment, you will see a stream of "0"s if your switch is open, or "1"s if your switch is closed.

```
DigitalReadSerial
Reads a digital input on pin 2, prints the result to the serial monitor
This example code is in the public domain.
*/
// digital pin 2 has a pushbutton attached to it. Give it a name:
int pushButton = 2;
// the setup routine runs once when you press reset:
void setup() {
// initialize serial communication at 9600 bits per second:
 Serial.begin(9600);
// make the pushbutton's pin an input:
 pinMode(pushButton, INPUT);
}
// the loop routine runs over and over again forever:
void loop() {
// read the input pin:
 int buttonState = digitalRead(pushButton);
 // print out the state of the button:
 Serial.println(buttonState);
}
```