

Computer Architecture

Faculty of Computer Science & Engineering - HCMUT

Chapter 1 Computer Abstractions and Technology

Binh Tran-Thanh

thanhbinh@hcmut.edu.vn

The Computer Revolution

- Progress in computer technology
 - Underpinned by Moore's Law
- Makes novel applications feasible
 - Computers in automobiles
 - Cell phones
 - Human genome project
 - World Wide Web
 - Search Engines
- Computers are pervasive




History of Computer Development

- First generation 1945 1955
 - vacuum tubes, plug boards
- Second generation 1955 1965
 - transistors, batch systems
- Third generation 1965 1980
 - ICs and multiprogramming
- Fourth generation 1980 present
 - personal computers (Desk, Lap)
 - SuperComp.,
 - DataCenter, Clusters, etc.




The Moore's Law





2-Jan-23

The History: at the very beginning





ENIAC, 1943, 30 tons, 200KW, ~1000 ops/sec Faculty of Computer Science and Engineering

The History: Now

Typical 2021 laptop ~ 1kg, 10W, 10 billion ops/sec

















Classes of Computers









Source: internet

Classes of Computers

- Personal computers
 - General purpose, variety of software
 - Subject to cost/performance trade-off

- Embedded computers
 - Hidden as components of systems
 - Stringent power/performance/cost constraints




Classes of Computers

- Server computers
 - Network based
 - High capacity, performance, reliability
 - Range from small servers to building sized
- Supercomputers
 - High end scientific and engineering calculations
 - Highest capability but represent a small fraction of the overall computer market



The PostPC Era has arrived

Your next computer is not a computer (apple)



The PostPC Era

- Cloud computing
 - Warehouse Scale Computers (WSC)
 - Software as a Service (SaaS)
 - Portion of software run on a PMD and a portion run in the Cloud
 - Amazon and Google
- Personal Mobile Device (PMD)
 - Battery operated
 - Connects to the Internet
 - Hundreds of dollars
 - Smart phones, tablets, electronic glasses




Understanding Performance

- Algorithm
 - Determines number of operations executed
- Programming language, compiler, architecture
 - Determine number of machine instructions executed per operation
- Processor and memory system
 - Determine how fast instructions are executed
- I/O system (including OS)
 - Determines how fast I/O operations are executed



Below Your Program



- Application software
 - Written in high-level language
- System software
 - Compiler: translates HLL code to machine code
 - Operating System: service code
 - Handling input/output
 - Managing memory and storage
 - Scheduling tasks & sharing resources
- Hardware
 - Processor, memory, I/O controllers



2-Jan-23

Levels of Program Code

- High-level language
 - Level of abstraction closer to problem domain
 - Provides for productivity and portability
- Assembly language
 - Textual representation of instructions
- Hardware representation
 - Binary digits (bits)
 - Encoded instructions and data
- Which layer represents for program.exe/.asm/.c?


```
swap(int v[], int k){
               int temp;
               temp = v[k];
               v[k] = v[k+1];
               v[k+1] = |temp|
High-level
 Language
                     Compiler
 program
  (in C)
          swap: multi $2,
                            $5, 4
                add
                            $4, $2
                       $15, 0($2)
  Assembly
                       $16, 4($2)
  Language
                       $16, 0($2)
   Program
                       $15, 4($2)
                SW
 (for MIPS)
                       $31
                 jr
                    Assembler
```


Binary Machine Language (for MIPS)



2-Jan-23

Components of a Computer





- Same components for all kinds of computer
 - Desktop, server, embedded
- Input/output includes
 - User-interface devices
 - Display, keyboard, mouse
 - Storage devices
 - Hard disk, CD/DVD, flash
 - Network adapters
 - For communicating with other computers



Inside the Processor (CPU)

- Datapath: performs operations on data
- Control: sequences Datapath, memory, ...
- Cache memory
 - Small fast SRAM memory for immediate access to data



Eight Great Ideas

- Design for Moore's Law
- Use abstraction to simplify design
- Make the common case fast
- Performance via parallelism
- Performance via pipelining
- Performance via prediction
- Hierarchy of memories
- Dependability via redundancy









COMMON CASE FAST










2-Jan-23

Opening the Box






2-Jan-23

Through the Looking Glass

- LCD screen: picture elements (pixels)
 - Mirrors content of frame buffer memory






Touchscreen

- PostPC device
- Supersedes keyboard and mouse
- Resistive and Capacitive types
 - Most tablets, smart phones use capacitive
 - Capacitive allows multiple touches simultaneously



Inside the Processor

Apple A14



Abstractions

- Abstraction helps us deal with complexity
 - Hide lower-level detail
- Instruction set architecture (ISA)
 - The hardware/software interface
- Application binary interface
 - The ISA plus system software interface
- Implementation
 - The details underlying and interface



A Safe Place for Data

- Volatile main memory
 - Loses instructions and data when power off
- Non-volatile secondary memory
 - SSD, Magnetic disk
 - Flash memory
 - Optical disk (CDROM, DVD)







Networks

- Communication, resource sharing, nonlocal access
- Local area network (LAN): Ethernet
- Wide area network (WAN): the Internet
- Wireless network: WiFi, Bluetooth





Technology Trends

- Electronics technology continues to evolve
 - Increased capacity and performance
 - Reduced cost

Year	Technology	Relative performance/cost
1951	Vacuum tube	1
1965	Transistor	35
1975	Integrated circuit (IC)	900
1995	Very large scale IC (VLSI)	2,400,000
2013	Ultra large scale IC	250,000,000,000




Semiconductor Technology

- Silicon: semiconductor
- Add materials to transform properties:
 - Conductors
 - Insulators
 - Switch



Manufacturing ICs

Yield: proportion of working dies per wafer






Intel Core i7 Wafer

300mm wafer, 280 chips, 32nm technology

Each chip is 20.7 x 10.5 mm





Integrated Circuit Cost

- Nonlinear relation to area and defect rate
 - Wafer cost and area are fixed
 - Defect rate determined by manufacturing process
 - Die area determined by architecture and circuit design

Cost per die =
$$\frac{\text{Cost per wafer}}{\text{Dies per wafer} \times \text{Yield}}$$


Diesper wafer ≈ Wafer area/Die area


Yield =
$$\frac{1}{(1+(Defects per area \times Die area/2))^2}$$





Defining Performance

Which airplane has the best performance?











Faculty of Computer Science and Engineering

Response Time and Throughput

- Response time
 - How long it takes to do a task
- Throughput
 - Total work done per unit time
 - e.g., tasks/transactions/... per hour
- How are response time and throughput affected by
 - Replacing the processor with a faster version?
 - Adding more processors?
- We'll focus on response time for now...



Relative Performance

- Define: Performance = 1/Execution Time
- "X is n time faster than Y"

```
Performance<sub>x</sub>/Performance<sub>y</sub>
```

- = Execution time $_{Y}$ /Execution time $_{X} = n$
- Example: time taken to run a program
 - 10s on A, 15s on B
 - Execution TimeB / Execution TimeA= 15s / 10s = 1.5
 - So, A is 1.5 times faster than B




Measuring Execution Time

- Elapsed time
 - Total response time, including all aspects
 - Processing, I/O, OS overhead, idle time
 - Determines system performance
- CPU time
 - Time spent processing a given job
 - Discounts I/O time, other jobs' shares
 - Comprises user CPU time and system CPU time
 - Different programs are affected differently by CPU and system performance



CPU Clocking

 Operation of digital hardware governed by a constantrate clock



- Clock period: duration of a clock cycle
 - e.g., $250ps = 0.25ns = 250 \times 10^{-12}s$
- Clock frequency (rate): cycles per second
 - e.g., $4.0GHz = 4000MHz = 4.0 \times 10^9Hz$



2-Jan-23

CPU Time

- Performance improved by
 - Reducing number of clock cycles
 - Increasing clock rate
 - Hardware designer must often trade off clock rate against cycle count

```
CPUTime = CPUClock Cycles \times Clock Cycle Time
= \frac{CPUClock Cycles}{Clock Rate}
```



CPU Time Example

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
 - Aim for 6s CPU time
 - Can do faster clock, but causes 1.2 × clock cycles
- How fast must Computer B clock be?

$$Clock Rate_{B} = \frac{Clock Cycles_{B}}{CPUTime_{B}} = \frac{1.2 \times Clock Cycles_{A}}{6s}$$

Clock Cycles_A = CPU Time_A
$$\times$$
 Clock Rate_A

$$=10s\times2GHz = 20\times10^{9}$$

Clock Rate_B =
$$\frac{1.2 \times 20 \times 10^9}{6s} = \frac{24 \times 10^9}{6s} = 4$$
GHz



Instruction Count and CPI

- Instruction Count for a program
 - Determined by program, ISA and compiler
- Average cycles per instruction
 - Determined by CPU hardware
 - If different instructions have different CPI
 - Average CPI affected by instruction mix

```
Clock Cycles = Instructio n Count \times Cycles per Instructio n
```

CPU Time = Instructio n Count \times CPI \times Clock Cycle Time

$$_{_}$$
 Instructio n Count $imes$ CPI

Clock Rate



CPI Example

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?

$$\begin{aligned} \text{CPU Time}_{A} &= \text{Instructio n Count} \times \text{CPI}_{A} \times \text{Cycle Time}_{A} \\ &= I \times 2.0 \times 250 \text{ps} = I \times 500 \text{ps} \\ \text{CPU Time}_{B} &= \text{Instructio n Count} \times \text{CPI}_{B} \times \text{Cycle Time}_{B} \\ &= I \times 1.2 \times 500 \text{ps} = I \times 600 \text{ps} \\ \hline \text{CPU Time}_{A} &= \frac{I \times 600 \text{ps}}{I \times 500 \text{ps}} = 1.2 \end{aligned}$$



...by this much

A is faster...

CPI in More Detail

 If different instruction classes take different numbers of cycles

Clock Cycles =
$$\sum_{i=1}^{n} (CPI_i \times Instructio \ n \ Count_i)$$

Weighted average CPI

$$CPI = \frac{Clock Cycles}{Instructio n Count} = \sum_{i=1}^{n} \left(CPI_i \times \frac{Instructio n Count_i}{Instructio n Count} \right)$$

Relative frequency



CPI Example

 Alternative compiled code sequences using instructions in classes A, B, C

Class	А	В	С
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

- Sequence 1: IC = 5
 - Clock Cycles= 2×1 + 1×2 + 2×3= 10
 - Avg. CPI = 10/5 = 2.0

- Sequence 2: IC = 6
 - Clock Cycles= 4×1 + 1×2 + 1×3= 9
 - Avg. CPI = 9/6 = 1.5

Performance Summary

- Performance depends on
 - Algorithm: affects IC, possibly CPI
 - Programming language: affects IC, CPI
 - Compiler: affects IC, CPI
 - Instruction set architecture: affects IC, CPI, Tc


$$CPUTime = \frac{Instructio \ ns}{Program} \times \frac{Clock \ cycles}{Instructio \ n} \times \frac{Seconds}{Clock \ cycle}$$



Power Trends

In CMOS IC technology

×30



Power = Capacitive load \times Voltage $^2 \times$ Frequency



5V → 1V

×1000


Multiprocessors

- Multicore microprocessors
 - More than one processor per chip
- Requires explicitly parallel programming
 - Compare with instruction level parallelism
 - Hardware executes multiple instructions at once
 - Hidden from the programmer
 - Hard to do
 - Programming for performance
 - Load balancing
 - Optimizing communication and synchronization



SPEC CPU Benchmark

- Programs used to measure performance
 - Supposedly typical of actual workload
- Standard Performance Evaluation Corp (SPEC)
 - Develops benchmarks for CPU, I/O, Web, ...
- SPEC CPU2006
 - Elapsed time to execute a selection of programs
 - Negligible I/O, so focuses on CPU performance
 - Normalize relative to reference machine
 - Summarize as geometric mean of performance ratios
 - CINT2006 (integer) and CFP2006 (floating-point)





SPEC Power Benchmark

- Power consumption of server at different workload levels
 - Performance: ssj_ops/sec
 - Power: Watts (Joules/sec)

Overall ssj_ops per Watt =
$$\left(\sum_{i=0}^{10} ssj_ops_i\right) / \left(\sum_{i=0}^{10} power_i\right)$$



Pitfall: Amdahl's Law

 Improving an aspect of a computer and expecting a proportional improvement in overall performance

$$T_{\text{improved}} = \frac{T_{\text{affected}}}{\text{improvement factor}} + T_{\text{unaffected}}$$

- Example: multiply accounts for 80s/100s
 - How much improvement in multiply performance to get 5× overall?

$$20 = \frac{80}{n} + 20$$
 • Can't be done!

Corollary: make the common case fast



Pitfall: MIPS as a Performance Metric

- MIPS: Millions of Instructions Per Second
 - Doesn't account for
 - Differences in ISAs between computers
 - Differences in complexity between instructions

$$\begin{aligned} \text{MIPS} &= \frac{\text{Instructio n count}}{\text{Execution time} \times 10^6} \\ &= \frac{\text{Instructio n count}}{\frac{\text{Instructio n count} \times \text{CPI}}{\text{Clock rate}}} \times 10^6 \\ &= \frac{\text{Clock rate}}{\text{Clock rate}} \end{aligned}$$

CPI varies between programs on a given CPU



Reducing Power

- Suppose a new CPU has
 - 85% of capacitive load of old CPU
 - 15% voltage and 15% frequency reduction

$$\frac{P_{\text{new}}}{P_{\text{old}}} = \frac{C_{\text{old}} \times 0.85 \times (V_{\text{old}} \times 0.85)^2 \times F_{\text{old}} \times 0.85}{C_{\text{old}} \times V_{\text{old}}^2 \times F_{\text{old}}} = 0.85^4 = 0.52$$

- The power wall
 - We can't reduce voltage further
 - We can't remove more heat
- How else can we improve performance?



Concluding Remarks

- Cost/performance is improving
 - Due to underlying technology development
- Hierarchical layers of abstraction
 - In both hardware and software
- Instruction set architecture
 - The hardware/software interface
- Execution time: the best performance measure
- Power is a limiting factor
 - Use parallelism to improve performance



Exercise

Given a program X in detail as below.

	Instruction class	A	В	C	D
	CPI	2	4	3	2.5
•	# instruction	1000	2000	3000	4000

- What is CPU time of X where it is run at 2Ghz?
- Improving performance by reducing #instruction of B by a half. What is the speed up?
- To improve performance by changing only 1 class of instruction. What is the limitation of speed up?



Exercise

Given a program X in detail as below.

_	Instruction class	A	В	C	D
	CPI	2	4	3	2.5
	# instruction	1000	2000	3000	4000

- What is CPU time of X where it is run at 2Ghz? (14.5 µsec)
- Improving performance by reducing #instruction of B by a half. What is the speed up? (1.16)
- To improve performance by changing only 1 class of instruction. What is the limitation of speed up? (1.53)



Question?