

# AMCREST HTTP API FOR IP CAMERAS Version 1.51



#### 1.Preface

This document details the API of Amcrest video products. Programmers can access and configure Amcrest video products using this API.

# 2. Catalog

Document History	Error! Bookmark not defined.
1.Preface	3
2.Catalog	3
3.HTTP API Transaction	9
3.1Transaction	9
3.2Authentication	10
4.Camera	11
4.1Stream	11
4.1.1 GetStream	11
4.1.2 GetMaxExtraStreamCounts	11
4.1.3 GetSnapshot	11
4.1.4 GetVideo	12
4.1.5 PlayBack	12
4.1.6 LoadFile	12
4.1.7 GetStream By Http	13
4.1.8 Playback By Http	13
4.2VideoColor	14
4.2.1 GetVideoColorConfig	14
4.2.2 SetVideoColorConfig	14
4.3VideoInOptions	15
4.3.1 GetVideoInputCaps	15
4.3.2 GetVideoInOptionsConfig	17
4.3.3 SetVideoInOptionsConfig	19
4.4VideoEncode	24
4.4.1 GetVideoConfigCaps	24
4.4.2 Resolution	25
4.4.3 GetVideoEncodeConfig	26
4.4.4 SetVideoEncodeConfig	27
4.5AudioEncode	28
4.5.1 GetAudioConfigCaps	28
4.5.2 GetAudioEncodeConfig	28
4.5.3 SetAudioEncodeConfig	29
4.6. SpanEproado	20



4.6.1 GetSnapConfigCaps	30
4.6.2 GetSnapEncodeConfig	30
4.6.3 SetSnapEncodeConfig	31
4.7ChannelTitle	32
4.7.1 GetChannelTitleConfig	32
4.7.2 SetChannelTitleConfig	32
4.8VideoStandard	32
4.8.1 GetVideoStandardConfig	32
4.8.2 SetVideoStandardConfig	33
4.9VideoWidget	33
4.9.1 GetVideoWidgetConfig	33
4.9.2 SetVideoWidgetConfig	34
4.10VideoIn	36
4.10.1 getCollect	36
4.11VideoOut	36
4.11.1 GetVideoOutConfig	36
4.11.2 SetVideoOutConfig	37
4.12FlashLight	37
4.12.1 GetFlashLightConfig	37
4.12.2 SetFlashLightConfig	
5.NetWork	38
5.1NetInterfaces	38
5.1.1 GetInterfaces	38
5.2BasicConfig	39
5.2.1 GetBasicConfig	39
5.2.2 SetBasicConfig	
5.3PPPoE	40
5.3.1 GetPPPoEConfig	40
5.3.2 SetPPPoEConfig	40
5.4DDNS	41
5.4.1 GetDDNSConfig	
5.4.2 SetDDNSConfig	
5.5Email	
5.5.1 GetEmailConfig	42
5.5.2 SetEmailConfig	42
5.6Wlan	
5.6.1 GetWlanConfig	
5.6.2 SetWlanConfig	
5.6.3 ScanWlanDevices	44
5.7UPnP	45
5.7.1 GetUPnPConfig	
5.7.2 SetUPnPConfig	
5.7.3 GetUPnPStatus	
5.8NTP	46



5.8.1 GetNTPConfig	46
5.8.2 SetNTPConfig	46
5.9RTSP	47
5.9.1 GetRTSPConfig	47
5.9.2 SetRTSPConfig	48
6.Events	49
6.1EventHandler	49
6.1.1 GetEventHandler	49
6.1.2 SetEventHandler	50
6.2Alarm	52
6.2.1 GetAlarmConfig	52
6.2.2 SetAlarmConfig	52
6.2.3 GetAlarmOutConfig	52
6.2.4 SetAlarmOutConfig	53
6.2.5 GetInSlots	53
6.2.6 GetOutSlots	53
6.2.7 GetInState	53
6.2.8 GetOutState	54
6.2.9 GetChannelInState	54
6.2.10 GetChannelOutState	54
6.3MotionDetect	54
6.3.1 GetMotionDetectConfig	54
6.3.2 SetMotionDetectConfig	55
6.4BlindDetect	56
6.4.1 GetBlindDetectConfig	56
6.4.2 SetBlindDetectConfig	56
6.5LossDetect	57
6.5.1 GetLossDetectConfig	57
6.5.2 SetLossDetectConfig	57
6.6LoginFailureAlarm	57
6.6.1 GetLoginFailureAlarmConfig	57
6.6.2 SetLoginFailureAlarmConfig	57
6.7 StorageAbnormal	58
6.7.1 GetStorageNotExistConfig	58
6.7.2 SetStorageNotExistConfig	58
6.7.3 Get StorageFailureConfig	58
6.7.4 Set StorageFailureConfig	58
6.7.5 GetStorageLowSpaceConfig	59
6.7.6 SetStorageLowSpaceConfig	59
6.8 NetAbnormal	59
6.8.1 GetNetAbortConfig	59
6.8.2 SetNetAbortConfig	59
6.8.3 GetIPConflictConfig	60
6.8.4 SetIPConflictConfig	60



6.9 GetEventIndexes	60
6.10 Attach	61
7.PTZ	62
7.1PTZConfig	62
7.1.1 GetPTZConfig	
7.1.2 SetPTZConfig	63
7.2PTZControl	64
7.2.1 GetProtocolList	64
7.2.2 GetCurrentProtocolCaps	64
7.2.3 PTZ control commands	65
7.3PTZStatus	68
7.3.1 PTZ GetStatus	68
8.Record Snap	68
8.1Record	68
8.1.1 GetRecordConfig	
8.1.2 SetRecordConfig	69
8.1.3 GetRecordModeConfig	69
8.1.4 SetRecordModeConfig	69
8.2Snap	70
8.2.1 GetSnapConfig	70
8.2.2 SetSnapConfig	70
8.3MediaGlobal	71
8.3.1 GetMediaGlobalConfig	71
8.3.2 SetMediaGlobalConfig	71
8.4Holiday	72
8.4.1 GetHolidayConfig	72
8.4.2 SetHolidayConfig	72
9.System	73
9.1General	73
9.1.1 GetGeneralConfig	73
9.1.2 SetGeneralConfig	73
9.2SystemTime	74
9.2.1 GetCurrentTime	74
9.2.2 SetCurrentTime	74
9.3Locales	74
9.3.1 GetLocalesConfig	74
9.3.2 SetLocalesConfig	
9.4Language	76
9.4.1 GetLanguageCaps	76
9.4.2 GetLanguageConfig	76
9.4.3 SetLanguageConfig	76
9.5AccessFilter	77
9.5.1 GetAccessFilterConfig	77
9.5.2 SetAccessFilterConfig	77



9.6AutoMaintain	77
9.6.1 GetAutoMaintainConfig	77
9.6.2 SetAutoMaintainConfig	78
9.7UserManager	79
9.7.1 Group	79
9.7.2 GetGroupInfo	79
9.7.3 GetGroupInfoAll	79
9.7.4 AddUser	79
9.7.5 DeleteUser	80
9.7.6 ModifyUser	80
9.7.7 ModifyPassword	80
9.7.8 GetUserInfo	8
9.7.9 GetUserInfoAll	8
9.7.10 GetActiveUserInfoAll	8
9.8System Operation	82
9.8.1 Reboot	82
9.8.2 Shutdown	82
9.8.3 GetDeviceType	82
9.8.4 GetHardwareVersion	82
9.8.5 GetSerialNo	82
9.8.6 GetMachineName	82
9.8.7 GetSystemInfo	83
9.8.8 GetVendor	83
9.8.9 GetSoftwareVersion	83
9.8.10 GetOnvifVersion	83
9.9 Log	83
9.9.1 StartFind	83
9.9.2 DoFind	84
9.9.3 StopFind	84
9.9.4 Clear	85
9.10 UserGlobal	85
9.10.1 GetUserGlobalConfig	85
9.10.2 SetUserGlobalConfig	85
9.11 IntervideoManager	85
9.11.1 GetCGIVersion	85
).Storage	86
10.1 File Finding	86
10.1.1 Create	86
10.1.2 StartFind	86
10.1.3 FindNextFile	8
10.1.4 Close	8
10.1.5 Destroy	88
10.2 Storage Device	88
10.2.1 GetStorageDeviceCollect	88



10.2.2 getDeviceAllInfo	88
10.2.3 setStorageDevice	88
10.2.4 getCaps	89
10.3 Work Group	89
10.3.1 GetWorkGroupCollect	89
10.4 Work Directory	89
10.4.1 GetWorkDirectoryCollect	89
10.5 NAS	90
10.5.1 GetNASConfig	90
10.5.2 SetNASConfig	90
10.6 Storage Point	91
10.6.1 GetRecordStoragePointConfig	91
10.6.2 SetRecordStoragePointConfig	91
10.6.3 GetStorageGroupConfig	92
10.6.4 SetStorageGroupConfig	92
11.Audio	92
11.1 Audio MIME type	92
11.2 Post Audio	93
11.2.1 Example for singlepart	93
11.2.2 Example for multipart	93
11.3 Get Audio	94
11.3.1 Example for singlepart	94
11.3.2 Example for multipart	94
11.4 Audio Input	95
11.4.1 getCollect	95
11.5 Audio Output	95
11.5.1 getCollect	
12.Appendix	95
12.1 Stream Format	95
13.VedioInput	
13.1 AdjustFocus	98
13.2 AdjustFocusContinuously	98
13.3 AutoFocus	
13.4 GetFocusStatus	
14. SD Camera	
14.1 VideoInWhiteBalance	
14.1.1 GetVideoInWhiteBalance	
14.2.2 SetVideoInWhiteBalance	
14.2 VideoInExposure	
14.2.1 GetVideoInExposure	
14.2.2 SetVideoInExposure	
14.3 VideoInDenoise	
14.3.1 GetVideoInDenoise	
14.3.2 SetVideoInDenoise	



14.4 VideoInDayNight	104
14.4.1 GetVideoInDayNight	104
14.4.2 SetVideoInDayNight	105
14.5 VideoInFocus	105
14.5.1 GetVideoInFocus	105
14.5.2 SetVideoInFocus	106
14.6 VideoInZoom	106
14.6.1 GetVideoInZoom	106
14.6.2 SetVideoInZoom	107
14.7 VideoInSharpness	107
14.7.1 GetVideoInSharpness	107
14.7.2 SetVideoInSharpness	107
14.8 VideoInColor	108
14.8.1 GetVideoInColor	108
14.8.2 SetVideoInColor	109
14.9 VideoInRotate	109
14.9.1 GetVideoInRotate	109
14.9.2 SetVideoInRotate	110
14.10 VideoInMode	110
14.10.1 GetVideoInMode	110
14.10.2 SetVideoInMode	111
15. VideoAnalyse	112
15.1 VideoAnalyseRule	112
15.1.1 GetVideoAnalyseRule	112
15.1.2 SetVideoAnalyseRule	112
16 TrafficSnap	116
16.1 getParkingSpaceStatus	116

#### 3. HTTP API Transaction

#### 3.1 Transaction

The HTTP API Transaction starts from a request from a client Application, usually a web browser. The request is processed by the web server on the Amcrest product, then sends the response back to the client application. The HTTP request is taken in GET form. If the request is successful, the Amcrest product will return a HTTP header contains 200 OK. The HTTP Body will contain actual data or error message if an error occurs.

For convenience, we use some short words to instead the long expressions. The follows are several regulations:

- 1. The italics and bold will be replaced by the value behind the symbol "=".
- 2. The URL must follow the standard way of writing a URL.(RFC\_3986:Uniform Resource Identifiers (URI) Generic Syntax);that is ,spaces and other reserved characters (";", "/", "?", ":", "@", "=", "+", "," and "\$") within a <paramName> or a <paramValue> must be replaced



with %<ASCII hex>.For example ,the blank must be instead with %20.

- 3. To describe the range of the configuration, we use some symbols such as "[]", "{}" and so on. For example: "[0-100]" denotes a integer not less than 0 and not larger than 100. "{0,1,2,3}" denotes the valid value of a integer among 0,1,2 and 3.
- 4. In the request and response, we use "[]" to denote an array. The index is usually a integer and start form 0.
- 5. The parameter value has several types: string, integer, bool and float. Integer is 32 bits. The range of bool is "true" and "false".

The below is an example of a transaction:

Request	GET http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoColor</ip>
Description	Get VideoColor configuration.
Response	HTTP/1.1 200 OK
	Content-Type:text/plain
	<i>head</i> .Brightness=50
	head.Contrast=50
	<b>head</b> .Hue=50
	head.Saturation=50
	<b>head</b> .TimeSection=1 00:00:00-24:00:00
Comment	In above table, <i>head</i> = table.VideoColor[ <i>ChannelNo</i> ][ <i>ColorConfigNo</i> ]
	ChannelNo = video channel index,
	colorConfigNo = color config index.
	0 = Color Config 1
	1 = Color Config 2
	We can also request the single config.
	For example:
	Request:
	GET http://10.7.2.4/cgi-bin/configManager.cgi?action=getConfig&name=VideoColor[0][0].Brightness
	Response:
	HTTP/1.1 200 OK
	Content-Type:text/plain
	table.VideoColor[0][0].Brightness=50

#### 3.2 Authentication

The Amcrest video product supplies two authentication ways: basic authentication and digest authentication. If the http request does not have "Authorization", the Amcrest video product returns a 401, utill the http request has a legal authentication.

For example:

1. When basic authentication, the Amcrest video product response:

401 Unauthorized

WWW-Authenticate: Basic realm=" XXXXXXX"

Then the client encode the username and password with base64, send the following request:

 $\hbox{Authorization: Basic VXZVXZ.}$ 

2. When digest authentication, the Amcrest video product response:

WWW-Authenticate: Digest realm="DH\_00408CA5EA04", nonce="000562fdY631973ef04f77a3ede7c1832ff48720ef95ad",



stale=FALSE, qop="auth";

The client calculates the digest using username, password, nonce, realm and URI with MD5, then send the following request:

 $\label{login} Authorization: \ Digest \ username="admin", \ realm="DH_00408CA5EA04", \ nc=00000001, cnonce="0a4f113b", qop="auth" \\ nonce="000562fdY631973ef04f77a3ede7c1832ff48720ef95ad", uri="cgi-bin/global.login?userName=admin", \\ response="65002de02df697e946b750590b44f8bf" \\ \\$ 

#### 4. Camera

Camera API allows application to configure and view Amcrest video product settings.

#### 4.1 Stream

#### 4.1.1 GetStream

URL Syntax	rtsp:// <username>:<password>@<ip>:<port>/cam/realmonitor?channel=<channelno>&amp;subtype=<typeno></typeno></channelno></port></ip></password></username>
Comment	<username>: a valid user's username.</username>
	<pre><password> :user's password.</password></pre>
	<ip>:the IP address of the Amcrest video product.</ip>
	<pre><port>: the default port is 554. It can be omitted. It can be obtained in 5.10.1 GetRTSPConfig.</port></pre>
	<pre><channelno> :the channel number. It starts from 1.</channelno></pre>
	<typeno> :the stream type. The <typeno> of main stream is 0, extra stream 1 is 1, extra stream 2 is 2.The extra stream</typeno></typeno>
	counts can be obtained in 4.1.2 GetMaxStreamCounts. The stream must be enabled by setting head. Video Enable to
	true in 4.4.4 SetVideoEncodeConfig.
	For example, we request the extra stream 1 of channel 1, the URL is:
	rtsp://admin:admin@10.7.6.67:554/cam/realmonitor?channel=1&subtype=1.
	The IP Camera supports both TCP and UDP transmission forms.
	It also supplies basic authentication and digest authentication ways. The authentication process is similar with 3.2
	Authentication.

#### 4.1.2 GetMaxExtraStreamCounts

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=getProductDefinition&amp;name=<b>MaxExtraStream</b></ip>
Response	table.MaxExtraStream=1
Comment	In above table, the range of table.MaxExtraStream is {1,2,3}

#### 4.1.3 GetSnapshot

URL Syntax	http:// <ip>/cgi-bin/snapshot.cgi? [channel=<channelno>]</channelno></ip>
------------	---



Response	A picture encoded by jpg
Comment	The channel number is default 0 if the request is not carried the param.

#### 4.1.4 GetVideo

URL Syntax	http:// <ip>/cgi-bin/mjpg/video.cgi?[channel=&lt;<i>channelNo</i>&gt;]&amp;subtype=<typeno></typeno></ip>
Response	video stream encoded by mjpg
	Return:
	HTTP Code:200 OK
	Content-Type:multipart/x-mixed-replace;boundary= <boundary></boundary>
	Body:
	<boundary></boundary>
	Content-Type:image/jpeg
	Content-Length: <image size=""/>
	<jpeg data="" image=""></jpeg>
	<boundary></boundary>
Comment	The channel number is default 0 if the request is not carried the param.
	subtype : Definition in 4.1.1 GetStream

# 4.1.5 PlayBack

URL Syntax	rtsp:// <username>:<password>@<ip>:<port>/<filename></filename></port></ip></password></username>
Response	It's similar with 4.1.1 GetStream.
	For example:
	rtsp://admin:admin@10.7.6.67:554//mnt/sd/2012-07-13/001/dav/09/09.30.37-09.30.47[R][0@0][0].dav

#### 4.1.6 LoadFile

URL Syntax	http:// <ip>/cgi-bin/RPC_Loadfile/<filename></filename></ip>
Response	HTTP Code: 200 OK
	Content-Type: Application/octet-stream
	Content-Length: <filelength></filelength>
	Body:
	<data></data>
	<data></data>
	For example:
	http://10.61.5.117/cgi-bin/RPC_Loadfile/mnt/sd/2012-07-13/001/dav/09/09.30.37-09.30.47[R][0@0][0].dav



# 4.1.7 GetStream By Http

URL Syntax	http:// <ip>/cgi-bin/realmonitor.cgi?action=getStream&amp;channel=<channelno>&amp;subtype=<typeno></typeno></channelno></ip>
Response	HTTP Code: 200 OK
	Content-Type: Application/octet-stream
	Body:
	<data></data>
	<data></data>
Comment	Compared to 4.1.1 GetStream using RTSP, it is another way of get stream. This is a way to use http
	protocol to get realmonitor stream. The data format is shown in appendix.

# 4.1.8 Playback By Http

URL Syntax	http:// <ip>/cgi-bin/playBack.cgi?action=getStream&amp;channel=<channelno>&amp;subtype=<typeno>&amp;startTime=<starttime>8</starttime></typeno></channelno></ip>
	endTime= <endtime></endtime>
Response	HTTP Code: 200 OK
	Content-Type: Application/octet-stream
	Body:
	streamId= <streamid>\r\n</streamid>
	<data></data>
	<data></data>
Comment	Compared to 4.1.5 Playback using RTSP, it is another way of get playback stream. This is a way to use
	http protocol to get playback stream. The data format is shown in appendix.

URL Syntax	http:// <ip>/cgi-bin/playBack.cgi?action=control&amp;streamId=<streamid>&amp;cmd=<cmd>&amp;<paramname>=<paramvalue>[&amp;&lt;</paramvalue></paramname></cmd></streamid></ip>	
	paramName>= <paramvalue>]</paramvalue>	
Response	OK or ERROR	
Comment	Control the playback stream	
	Cmd=play	
	Speed= <speed> optional, default speed=1,if speed &gt; 0, play back forward, else if speed &lt; 0, playback</speed>	
	backward(param iframe is ignored, only support iframe playback backward);	
	Iframe= <iframe> optional, default iframe=0, if iframe=1, playback I frame only;</iframe>	
	seekTime= <seektime> seek time, optional, default playback from the stream current point;</seektime>	
	cmd=pause	
	pause the playback stream;	
	cmd=cancel	



	cancel the playback stream, and destroy the streamed;
	This is the cgi to control playback stream, used to control the stream which built by "action=getStream".

#### 4.2 VideoColor

#### 4.2.1 GetVideoColorConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>VideoColo</b>r</ip>	
Response	<i>head</i> .Brightness=50	
	head.Contrast=50	
	<b>head</b> .Hue=50	
	head.Saturation=50	
	<b>head</b> .TimeSection=1 00:00:00-24:00:00	
Comment	In above table, <i>head</i> = table.VideoColor[ <i>ChannelNo</i> ][ <i>ColorConfigNo</i> ]	
	ChannelNo = video channel index,	
	colorConfigNo = color config index.	
	0 = Color Config 1	
	1 = Color Config 2	

#### 4.2.2 SetVideoColorConfig

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]	
Response	OK or ERROR	
Comment	In below table, <i>head</i> =VideoColor[ <i>ChannelNo</i> ][ <i>ColorConfigNo</i> ]	
	ChannelNo = video channel index,	
	colorConfigNo = color config index,	
	0 = Color Config 1	
	1 = Color Config 2	

ParamName	ParamValue type	Description
<i>head</i> .Brightness	integer	Brightness, range is [0-100]
<i>head</i> .Contrast	integer	Contrast, range is [0-100]
<i>head</i> .Hue	integer	Hue
<i>head</i> .Saturation	integer	Saturation
<i>head</i> .TimeSection	string	Effective time for this video color config.
		Format is: mask starttime endtime
		<b>Mask</b> range is {0, 1}.



Mask 0 – this video config is not effective
Mask 1 - this config is effective
Starttime/Endtime format like 11:00:00.
Example:
0 01:00:00-02:00:00, means this config is not effective.
1 01:00:00-02:00:00, means this config is effective between 01:00:00 and 02:00:00

# 4.3 VideoInOptions

# 4.3.1 GetVideoInputCaps

URL Syntax	http:// <ip>/cgi-bin/devVideoInput.cgi?action=getCaps&amp;channel=<channelno></channelno></ip>
Description	Get video input capabilities, <i>channelNo</i> is video in channel index.
Response	caps.Backlight=true
	caps.ChipID=0
	caps.CoverCount=0
	caps.CoverType=0
	caps.CustomManualExposure=true
	caps.DayNightColor=true
	caps.DownScaling=true
	caps.Exposure=9
	caps.ExternalSyncInput=true
	caps.FlashAdjust=true
	caps.Flip=true
	caps.Gain=true
	caps.GainAuto=true
	caps.HorizontalBinning=1
	caps.InfraRed=false
	caps.lris=false
	caps.lrisAuto=false
	caps.LadenBitrate=750000
	caps.LimitedAutoExposure=true
	caps.MaxHeight=1200
	caps.MaxWidth=1600
	caps.Mirror=false
	caps.NightOptions=false
	caps.ReferenceLevel=false
	caps.Rotate90=false
	caps.SetColor=true
	caps.SignalFormats=Inside,720p,1080p



caps.SyncChipChannels=false
caps.TitleCount=0
caps.UpScaling=false
caps.VerticalBinning=1
caps.WhiteBalance=2

Field in response	Value type	Description	
Backlight	bool	True: support backlight	
ChipID	String	ID of chips in this channel	
CoverCount	integer	The maximum cover region count.	
CoverType	integer	0: don't support cover	
		1: support realtime cover	
		2: support non-realtime cover	
CustomManualExposure	bool,	true: support use defined manual exposure time	
DayNightColor	bool	true: support color alternate between day and night.	
DownScaling	bool	true: support down scaling, binning mode not included.	
Exposure	integer	Exposure grade. 0 – don't support exposure control.	
ExternalSyncInput	bool	true: support HD signal external synchronization.	
FlashAdjust	bool	true: support flash adjust	
Flip	bool	true: support picture flip.	
Gain	bool	true: support gain control.	
GainAuto	bool	true: support auto gain.	
HorizontalBinning	integer	Horizontal/Vertical pixel binning mask,	
VerticalBinning	integer	1 – support 2 pixel binning,	
		2 – support 3 pixel binning	
		4 - support 4 pixel binning	
		2^n – support n+2 pixel binning	
InfraRed	bool	true: support Infra compensation	
Iris	bool	true: support Iris adjust	
IrisAuto	bool	true: support auto Iris adjust	
LadenBitrate	integer	Unit is Kbps.	
		Maximum value of video stream bitrate, 16bpp, not in binning mode.	
LimitedAutoExposure	bool	true: support auto exposure with time limit.	
MaxHeight	integer	Maximum video height	
MaxWidth	integer	Maximum video width	
Mirror	bool	true: support picture mirror.	
NightOptions	bool	true: support night options.	
ReferenceLevel	bool	true: support reference level.	
Rotate90	bool	true: support clockwise/anticlockwise 90° rotate	
SetColor	bool	true: support color set.	
SignalFormats	string	It's a string contains supported video input signal formats for this channel. Signal formats	
	*	•	



		are separated by comma.	
		Range is {Inside, BT656, 720p,1080p, 1080i, 1080sF, 1_3M}	
		Inside – inside input.	
		1_3M - 1280*960	
SyncChipChannels	bool	True: channels in same chip should be synchronized. Synchronized means video resolution	
		of these channels should be the same.	
TitleCount	integer	Maximum count of blending titles.	
UpScaling	bool	true: support up scaling.	
WhiteBalance	integer	Range is {0, 1, 2, 3}	
		0 – don't support white balance.	
		1 – support auto white balance	
		2 - support auto and pre defined white balance.	
		3 - support auto, pre defined and user defined white balance	

# 4.3.2 GetVideoInOptionsConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInOptions</ip>		
Description	Video in options contain Backlight, ExposureSpeed, DayNightColor. DayOptions, NightOptions, NormalOptions and so on		
Response	head.Backlight=0		
	head.DayNightColor=false		
	<pre>head.ExposureSpeed=0</pre>		
	head. Exposure Value 1=0.100000		
	head. Exposure Value 2=80.000000		
	<i>head</i> .ExternalSync=0		
	<i>head</i> .ExternalSyncPhase=0		
	head.FlashControl.Mode=0		
	head.FlashControl.Pole=0		
	head.FlashControl.Value=0		
	head.FlashControl.PreValue=0		
	<i>head</i> .Flip=false		
	head.Gain=50		
	head.GainAuto=true		
	<i>head</i> .lrisAuto=false		
	<i>head</i> .Mirror=false		
	head.NightOptions.AntiFlicker=0		
	head.NightOptions.Backlight=0		
	head. Night Options. Backlight Region [0] = 3096		
	head.NightOptions.BacklightRegion[1]=3096		
	head. Night Options. Backlight Region [2] = 5096		
	head. Night Options. Backlight Region [3] = 5096		



head. Night Options. Brightness Threshold = 50

head.NightOptions.DayNightColor=2

head.NightOptions.ExposureMode=0

head. Night Options. Exposure Speed = 0

head. Night Options. Exposure Value 1=0

*head*.NightOptions.ExposureValue2=40

head. Night Options. External Sync Phase = 125

*head*.NightOptions.Flip=false

head.NightOptions.Gain=50

*head*.NightOptions.GainAuto=true

head. Night Options. Gain Blue = 50

head. Night Options. Gain Green = 50

head.NightOptions.GainMax=50

head.NightOptions.GainMin=0

*head*.NightOptions.GainRed=50

**head**. Night Options. Glare Inhibition = 0

*head*.NightOptions.IrisAuto=true

*head*.NightOptions.Mirror=false

head.NightOptions.Profile=3

head. Night Options. Reference Level = 50

head. Night Options. Rotate 90=0

head.NightOptions.SunriseHour=0

head. Night Options. Sunrise Minute=0

head. Night Options. Sunrise Second=0

head. Night Options. Sunset Hour = 23

head. Night Options. Sunset Minute = 59

head. Night Options. Sunset Second = 59

head. Night Options. Switch Mode=4

head. Night Options. White Balance = Auto

**head**.NightOptions.WideDynamicRange=0

head. Night Options. Wide Dynamic Range Mode = 0

head.NormalOptions.AntiFlicker=0

*head*.NormalOptions.Backlight=0

 $\textbf{\textit{head}}. Normal Options. Backlight Region [0] = 3096$ 

head. Normal Options. Backlight Region [1] = 3096

head.NormalOptions.BacklightRegion[2]=5096

 $\textbf{\textit{head}}. Normal Options. Backlight Region [3] = 5096$ 

 $\textbf{\textit{head}}. Normal Options. Brightness Threshold = 50$ 

 $\textbf{\textit{head}}. \textbf{Normal Options. Day Night Color=1}$ 

head. Normal Options. Exposure Mode=0

head.NormalOptions.ExposureSpeed=0

head. Normal Options. Exposure Value 1=0

head. Normal Options. Exposure Value 2=40

head.NormalOptions.ExternalSyncPhase=125



	<i>head</i> . Normal Options. Flip=false
	<i>head</i> .NormalOptions.Gain=50
	<i>head</i> .NormalOptions.GainAuto=true
	<i>head</i> .NormalOptions.GainBlue=50
	<i>head</i> . Normal Options. Gain Green = 50
	<i>head</i> .NormalOptions.GainMax=50
	<pre>head.NormalOptions.GainMin=0</pre>
	<i>head</i> . Normal Options. Gain Red = 50
	head.NormalOptions.GlareInhibition=0
	<i>head</i> . Normal Options. Iris Auto=true
	<i>head</i> . Normal Options. Mirror=false
	<i>head</i> . Normal Options. Profile=0
	<i>head</i> . Normal Options. Reference Level = 50
	<i>head</i> . Normal Options. Rotate 90 = 0
	<i>head</i> . Normal Options. Sunrise Hour=0
	<i>head</i> . Normal Options. Sunrise Minute = 0
	<i>head</i> . Normal Options. Sunrise Second = 0
	<i>head</i> . Normal Options. Sunset Hour=23
	<i>head</i> . Normal Options. Sunset Minute = 59
	<i>head</i> . Normal Options. Sunset Second = 59
	<i>head</i> . Normal Options. Switch Mode = 0
	<i>head</i> .ReferenceLevel=50
	<i>head</i> .ReferenceLevelEnable=false
	<i>head</i> .Rotate90=0
	<i>head</i> .SignalFormat=BT656
	<i>head</i> .WhiteBalance=Disable
Comment	In above table, <i>head</i> = table.VideoInOptions[ <i>ChannelNo</i> ]
	ChannelNo = video channel index.
-	

# 4.3.3 SetVideoInOptionsConfig

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]				
Comment	In below table, <i>head</i> =VideoInOptions[ <i>ChannelNo</i> ]				
	ChannelNo = video channel index.				
	For example:				
	Auto Exposure:				
	http://172.29.2.33/cgi-bin/configManager.cgi?action=setConfig&VideoInOptions[0].ExposureMode=0				
	&VideoInOptions[0].ExposureSpeed=0				
	Low Noice:				
	http://172.29.2.33/cgi-bin/configManager.cgi?action=setConfig&VideoInOptions[0].ExposureMode=1				
	&VideoInOptions[0].ExposureSpeed=0&VideoInOptions[0].GainMin=0				
	& VideoInOptions[0].GainMax=60				



	Low Motion Blur:
	http://172.29.2.33/cgi-bin/configManager.cgi?action=setConfig&VideoInOptions[0].ExposureMode=2
	&VideoInOptions[0].ExposureSpeed=0&VideoInOptions[0].GainMin=0
	& VideoInOptions[0].GainMax=50&VideoInOptions[0].ExposureValue1=0
	& VideoInOptions[0].ExposureValue2=20
	Manual:
	http://172.29.2.33/cgi-bin/configManager.cgi?action=setConfig&VideoInOptions[0].ExposureMode=4
	&VideoInOptions[0].ExposureSpeed=32&VideoInOptions[0].GainMin=0
	& VideoInOptions[0].GainMax=50&VideoInOptions[0].ExposureValue1=40
	& VideoInOptions[0].ExposureValue2=40
Response	OK or ERROR

ParamName	ParamValue	Description
	type	
<b>head</b> .Backlight	integer	Range is [0-n]
		n depends on capability in 4.3.1 GetVideoInputCaps
		0 – backlight closed.
		1 – backlight grade 1
		n – backlight grade n
<i>head</i> .DayNightColor	integer	Range is {0,1,2}
		0: always multicolor
		1: autoswitch along with brightness,
		2: always monochrome
<i>head</i> .ExposureMode	integer	Range is {0,1,2, 4}
		0: AutoExposure
		1: Gain first
		2: Exposure first
		4:Manual.
<i>head</i> .ExposureSpeed	integer	Range is [0-n+1]
		n depends on capability in 4.3.1 GetVideoInputCaps
		0: AutoExposure
		1-n-1: manual Exposure grade
		n: AutoExposure with time limit.
		n+1:manualExposure with user-defined time
		(n is supported maximum exposure grade )
<i>head</i> .ExposureValue1	float	Range is [0.1-80], unit is millisecond
		If ExposureSpeed is O(AutoExposure enable), it's lower limit of AutoExposure
		time, otherwise it's time of manualExposure
head.ExposureValue2	float	Range is [0.1-80], unit is millisecond
		Upper limit of AutoExposure time, should be bigger than ExposureValue1
<i>head</i> .ExternalSync	integer	Range is {0,1}
		External Synchronous



		Or Internal Conchronization
		0: Internal Synchronization
		1: External Synchronous
<i>head</i> .ExternalSyncPhase	integer	Range is [0°-360°]
		External Synchronous Signal Phase
<i>head</i> .FlashControl.Mode	integer	Range is {0,1,2}
		0:forbid flash
		1:always flash
		2:auto flash
<i>head</i> .FlashControl.Pole	integer	Range is {0,1, 2, 3}
		Trigger mode:
		0:low level
		1:high level
		2: rising-edge
		3:falling-edge
<i>head</i> . Flash Control. Value	integer	Range is [0-15]
		Flashlight time-unit:
		0 - 0us,
		1 - 64us,
		2 - 128us,
		3 – 192us
		15 - 960us
<i>head</i> .FlashControl.PreValue	integer	Range is [0-100]
		It's threshold of brightness value, if brightness is less than this value, flash light
		begin to work.
<b>head</b> .Flip	bool	true: enable video flip function
		false: disable video flip function
<i>head</i> .Gain	integer	Range is [0-100]
		If GainAuto is true, it's upper limit of auto gain, else it's the fixed gain adjust
		value.
<i>head</i> .GainBlue	integer	Range is [0-100]
		Gain for blue value, Value is effective when WhiteBalance is "Custom."
<i>head</i> .GainRed	integer	Range is [0-100]
		Gain for red value, Value is effective when WhiteBalance is "Custom."
<i>head</i> .GainGreen	integer	Range is [0-100]
		Gain for green value, Value is effective when WhiteBalance is "Custom."
<i>head</i> .GainAuto	bool	true: GainAuto
		false: No GainAuto
<i>head</i> .IrisAuto	bool	true: IrisAuto
		false: No IrisAuto
<i>head</i> .Mirror	bool	true: enable video mirror function
neuu.iviii10i	5001	false: disable video mirror function
hand Whita Palanca	Ctuin -	
<i>head</i> .WhiteBalance	String	Range is {Disable, Auto, Custom, Sunny, Cloudy, Home, Office, Night}



		White balance Mode
<i>head</i> .ReferenceLevel	integer	Range is [0-100]
		The expected average brightness level of video frames.
<i>head</i> .Rotate90	integer	Range is {0,1,2}
		Video rotation:
		0: No rotate
		1: clockwise rotate 90°
		2: anticlockwise rotate 90°
<i>head</i> .SignalFormat	String	Range is {Inside, BT656, 720p, 1080p, 1080i, 1080sF}
		Input Signal Mode
<i>head</i> .AntiFlicker	integer	Range is {0,1,2}
		AntiFlicker mode:
		0: Outdoor
		1: 50 Hz AntiFlicker
		2: 60 Hz AntiFlicker
<i>head</i> . GlareInhibition	integer	Range is [0-100]
		GlareInhibition:
		0: Close GlareInhibition.
<i>head</i> .NightOptions.BrightnessThreshold	integer	NightOptions contain a set of parameters used when brightness is not enough.
		Range is [0-100]
		when brightness is less than the BrightnessThreshold, parameters change to
		Nightoptions.
head. Night Options. Iris Auto	bool	true: IrisAuto
		false: No IrisAuto
<b>head</b> . Night Options. Sunrise Hour	integer	Range is [00-23]
		Sunrise hour.
<i>head</i> . Night Options. Sunrise Minute	integer	Range is [00-59]
		Sunrise minute
<b>head</b> . Night Options. Sunrise Second	integer	Range is [00-59]
		Sunrise second
<i>head</i> . Night Options. Sunset Hour	integer	Sunset time. Its range is same with sunrise time, and it should be after sunrise
head. Night Options. Sunset Minute	integer	time.
<i>head</i> .NightOptions.SunsetSecond	integer	NightOptions are used if time is after sunset time and before sunrise time.
<i>head</i> .NightOptions.SwitchMode	integer	Range is {0,1,2}
		0: NoSwitch,always use day options;
		1: Switch depends on brightness;
		2: Switch depends on time, switch to NightOptions when time is after sunset
		time and before sunrise.
		3: NoSwitch,always use NightOptions;
		4:No switch,always use NormalOptions.
<i>head</i> .NightOptions.Profile	integer	Range is {0,1,2,3}
		0: use temporary day options;
		1: use temporary NightOptions;



		2: use temporary NormalOptions;
		3:depends on <i>head</i> .NightOptions.SwitchMode.
head. Night Options. Exposure Speed	integer	Range is the same as relevant items of day options in this table.
head.NightOptions.ExposureValue1	float	Example:
head.NightOptions.ExposureValue2	float	Value range of <i>head</i> .NightOptions.ExposureSpeed is the same with
head. Night Options. Gain	integer	<i>head</i> . ExposureSpeed
head. Night Options. Gain Auto	bool	
head.NightOptions.GainBlue	integer	
head. Night Options. Gain Green	integer	
head.NightOptions.GainRed	integer	
head.NightOptions.WhiteBalance	String	
head.NightOptions.ReferenceLevel	integer	
head.NightOptions.ExternalSyncPhase	integer	
<i>head</i> .NightOptions.AntiFlicker	integer	
<i>head</i> .NightOptions.Backlight	integer	
head.NightOptions.DayNightColor	integer	
<i>head</i> .NightOptions.ExposureMode	integer	
head. Night Options. Glare Inhibition	integer	
<i>head</i> .NightOptions.Mirror	integer	
<i>head</i> .NightOptions.Flip	integer	
head.NightOptions.Rotate90	integer	
<b>head</b> . Nomal Options. Brightness Threshold	integer	NomalOptions contain a set of parameters similar with NightOptions.
<i>head</i> . Normal Options. Iris Auto	bool	Range is the same as relevant items of <b>NightOptions</b> in this table.
<i>head</i> . Normal Options. Sunrise Hour	integer	
<i>head</i> . Normal Options. Sunrise Minute	integer	
<i>head</i> . Normal Options. Sunrise Second	integer	
<i>head</i> . Normal Options. Sunset Hour	integer	
<i>head</i> . Normal Options. Sunset Minute	integer	
<i>head</i> .NormalOptions.SunsetSecond	integer	
<i>head</i> .NormalOptions.ExposureSpeed	integer	
<i>Head</i> .NormalOptions.ExposureValue1	float	
<i>head</i> .NormalOptions.ExposureValue2	float	
<i>head</i> .NormalOptions.Gain	integer	
<i>head</i> . Normal Options. Gain Auto	bool	
<i>head</i> . Normal Options. Gain Blue	integer	
<i>head</i> .NormalOptions.GainGreen	integer	
<i>head</i> .NormalOptions.GainRed	integer	
<i>head</i> .NormalOptions.WhiteBalance	String	
<i>head</i> .NormalOptions.ReferenceLevel	integer	
<b>head</b> .NormalOptions.ExternalSyncPhase	integer	
<i>head</i> .NormalOptions.AntiFlicker	integer	
<i>head</i> .NormalOptions.Backlight	integer	



head.NormalOptions.DayNightColor	integer
<i>head</i> . Normal Options. Exposure Mode	integer
head. Normal Options. Glare Inhibition	integer
head.NormalOptions.Mirror	integer
head. Normal Options. Flip	integer
head.NormalOptions.Rotate90	integer

#### 4.4 VideoEncode

# 4.4.1 GetVideoConfigCaps

URL Syntax	http:// <ip>/cgi-bin/encode.cgi?action=getConfigCaps&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>						
Description	Get video config capibilities. The description of <pre>caparamName</pre> and <pre>caparamValue</pre> is the same as <pre>4.4.4</pre>						
	SetVideoEncodeConfig.						
	For example:						
	http://192.168.1.108/cgi-bin/encode.cgi?action=getConfigCaps&						
	Encode[0].MainFormat[0].Video.Width=1920&Encode[0].MainFormat[0].Video.Height=1080						
Response	<i>headMain</i> .Video.BitRateOptions=448,2560						
	<i>headMain</i> .Video.CompressionTypes=H.264,MJPG						
	<i>headMain</i> .Video.FPSMax=25						
	<i>headMain</i> .Video.ResolutionTypes=2048 x 1536,1080,SXGA, 1280 x 960,720,D1,CIF						
	<i>headExtra</i> .Video.BitRateOptions=80,448						
	<i>headExtra</i> .Video.CompressionTypes=H.264,MJPG						
	headExtra.Video.FPSMax=25						
	headExtra.Video.ResolutionTypes=D1,CIF						
	<i>headSnap</i> .Video.CompressionTypes=H.264,MJPG						
	<i>headSnap</i> .Video.ResolutionTypes=2048 x 1536,1080,SXGA, 1280 x 960,720,D1,CIF						
Comment	In above table:						
	Channel: video channel index						
	RecordType:						
	0 = regular record						
	1 = motion detection record						
	2 = alarm record						
	ExtraStream:						
	0 = extra stream 1						
	1 = extra stream 2						
	2 = extra stream 3						
	SnapType:						
	0 = regular snapshot						
	1 = motion detection snapshot						
	2 = alarm snapshot						



Abbreviations in below table:

headMain= caps[Channel].MainFormat[RecordType]
headExtra = caps[Channel].ExtraFormat[ExtraStream]
headSnap = caps[Channel].SnapFormat[SnapType]

Field in respons	Value range	Description
BitRateOptions	string	Before comma is minimum bit rate. (kbps), after comma is maximum bit rate.(kbps)
		BitRateOptions=80,448
		80 is minimum bitrate, 448 is maximum.
CompressionTypes	string	It contains all supported video compression types separated by comma.
		Range is {MPEG4, MPEG2, MPEG1, MJPG, H.263, H.264}
FPSMax	integer	Maximum FPS.
ResolutionTypes	ResolutionTypes string	It contains all supported video resolutions.
		Range is in 4.4.2 Resolution.

#### 4.4.2 Resolution

Fixed Resolution Name	Size in PAL	Size in NTSC
"D1"	704 x 576	704 x 480
"HD1"	352 x 576	352 x 480
"BCIF"	704 x 288	704 x 240
"CIF"	352 x 288	352 x 240
"QCIF"	176 x 144	176 x 120
"VGA"	640 x 480	
"QVGA"	320 x 240	
"SVCD"	480 x 480	
"QQVGA"	160 x 128	
"SVGA"	800 x 592	
"XVGA"	1024 x 768	
"WXGA"	1280 x 800	
"SXGA"	1280 x 1024	
"WSXGA"	1600 x 1024	
"UXGA"	1600 x 1200	
"WUXGA"	1920 x 1200	
"ND1"	240 x 192	
"720"	1280 x 720	
"1080"	1920 x 1080	
"1280x960"	1280 x 960 (1.3 Mega Pixels)	
"1872x1408"	1872 x 1408 (2.5 Mega Pixels)	
"3744x1408"	3744 x 1408 (5 Mega Pixels)	



"2048x1536"	2048 x 1536 (3 Mega Pixels)		
"2432x2048"	2432 x 2048 (5 Mega Pixels)		
"1216x1024"	1216 x 1024 (1.2 Mega Pixels)		
"1408x1024"	1408 x 1024 (1.5 Mega Pixels)		
"3296x2472"	3296 x 2472 (8 Mega Pixels)		
"2560x1920"	2560 x 1920 (5 Mega Pixels)		
"960H",	960 x 576 960 x 480		
"DV720P"	960 x 720		

# 4.4.3 GetVideoEncodeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Encode</b></ip>
Response	<i>headMain</i> .Video.BitRate=8192
	<i>headMain</i> .Video.BitRateControl=CBR
	headMain.Video.Compression=H.264
	<i>headMain</i> .Video.FPS=25
	<i>headMain</i> .Video.GOP=50
	<i>headMain</i> .Video.Height=1200
	<i>headMain</i> .Video.Profile=Main
	<i>headMain</i> .Video.Quality=4
	<i>headMain</i> .Video.Width=1600
	<i>headMain</i> .VideoEnable=true
	<i>headExtra</i> .Video.BitRate=8192
	<i>headExtra</i> .Video.BitRateControl=CBR
	headExtra.Video.Compression=H.264
	<i>headExtra</i> .Video.FPS=25
	<i>headExtra</i> .Video.GOP=50
	<i>headExtra</i> .Video.Height=1200
	headExtra.Video.Profile=Main
	<pre>headExtra.Video.Quality=4</pre>
	headExtra.Video.Width=1600
	<i>headExtra</i> .VideoEnable=true
Comment	Channel: video channel index
	RecordType:
	0 = regular record
	1 = motion detection record
	2 = alarm record
	ExtraStream:
	0 = extra stream 1
	1 = extra stream 2
	2 = extra stream 3



Abbreviations in above table:
<pre>headMain= table.Encode[Channel].MainFormat[RecordType]</pre>
<pre>headExtra =table.Encode[Channel].ExtraFormat[ExtraStream]</pre>

# 4.4.4 SetVideoEncodeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Channel: video channel index	
	RecordType:	
	0 = regular record	
	1 = motion detection record	
	2 = alarm record	
	ExtraStream:	
	0 = extra stream 1	
	1 = extra stream 2	
	2 = extra stream 3	
	Abbreviation in below table:	
	head=Encode[Channel].MainFormat[RecordType] (or)	
	Encode[Channel].ExtraFormat[ExtraStream]	
Response	OK or ERROR	

ParamName	ParamValue type	Description
<i>head</i> .Video.BitRate	integer	Unit is Kbps
		Range depends on capability in 4.4.1 GetVideoConfigCaps
<i>head</i> .Video.BitRateControl	string	Range is {CBR,VBR}
		CBR: constant bitrate
		VBR: variable bitrate, available when Video.Compression=H264
<i>head</i> .Video.Compression	String	Range is {MPEG4,MPEG2, MPEG1,MJPG,H.263,H.264}
		Depends on capacity in 4.4.1 GetVideoConfigCaps
<i>head</i> .Video.FPS	float	Range is [0.2-30]. Frames per second.
		< 1.0: several seconds/frame, FPS=0.3333: 3 seconds per frame.
		>1.0: several frames/second. FPS=3: 3 frames per second.
<i>head</i> .Video.GOP	integer	Range is [1-100].
		Group of picture, it's the interval of I Frame,
		Example: GOP=50, means there is one I frame every 49 P or B frames
<i>head</i> .Video.Height	integer	Video height
<i>head</i> .Video.Width	integer	Video Width
<i>head</i> .Video.Profile	String	Range is { Baseline, Main , Extended , High }
		Only when video compression is H.264, it's effective.
<i>head</i> .Video.Quality	integer	Range is [1-6].



		Image Quality, available when Video.BitRateControl=VBR
		1: worst quality
		6: best quality
<i>head</i> .VideoEnable	bool	True: enable video

#### 4.5 AudioEncode

# 4.5.1 GetAudioConfigCaps

URL Syntax	http:// <ip>/cgi-bin/encode.cgi?action=getConfigCaps</ip>
Comment	The angle brackets below denotes a array
Response	caps[0].ExtraFormat[0].Audio.CompressionTypes=PCM,G.711A,G.711Mu
	caps[0].ExtraFormat[1]
	caps[0].MainFormat[0].Audio.CompressionTypes=PCM,G.711A,G.711Mu
	caps[0].MainFormat[1]

Field in respons	Value range	Description
CompressionTypes		It contains all supported audio compression types, separated by comma.
	string	Range is {PCM, ADPCM, G.711A, G.711Mu, G.726, G.729, MPEG2, AMR}

#### 4.5.2 GetAudioEncodeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Encode</b></ip>
Response	<i>headMain</i> .Audio.Bitrate=64
	headMain. Audio. Compression=G.711A
	<i>headMain</i> .Audio.Depth=16
	<i>headMain</i> .Audio.Frequency=44000
	<i>headMain</i> .Audio.Mode=0
	<i>headMain</i> .AudioEnable=false
	<i>headExtra</i> .Audio.Bitrate=64
	headExtra.Audio.Compression=G.711A
	headExtra.Audio.Depth=16
	<i>headExtra</i> .Audio.Frequency=44000
	headExtra.Audio.Mode=0
	headExtra.AudioEnable=false
Comment	Channel: video channel index
	RecordType:



0 = regular record
1 = motion detection record
2 = alarm record

ExtraStream:
0 = extra stream 1
1 = extra stream 2
2 = extra stream 3

Abbreviations in above table:
headMain=table.Encode[Channel].MainFormat[RecordType]
headExtra=table.Encode[Channel].ExtraFormat[ExtraStream]

#### 4.5.3 SetAudioEncodeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Channel: video channel index	
	RecordType:	
	0 = regular record	
	1 = motion detection record	
	2 = alarm record	
	ExtraStream:	
	0 = extra stream 1	
	1 = extra stream 2	
	2 = extra stream 3	
	Abbreviations in below table:	
	head=Encode[Channel].MainFormat[RecordType] (or)	
	Encode[Channel].ExtraFormat[ExtraStream]	
Response	OK or ERROR	

ParamName	ParamValue type	Description
<i>head</i> .Audio.Bitrate	integer	Unit is kbps
		Range depends on capacity in 4.5.1 GetAudioConfigCaps
<i>head</i> .Audio.Compression	string	Range depends on capacity in 4.5.1 GetAudioConfigCaps
<i>head</i> .Audio.Depth	integer	Audio sampling depth
<i>head</i> .Audio.Frequency	integer	Audio sampling frequency
<i>head</i> .Audio.Mode	integer	Range is {0,1,2,3,4,5,6,7}
		Audio encode mode.
		0: 4.75kbps,
		1: 5.15 kbps,



		2: 5.9 kbps,
		3: 6.7 kbps,
		4: 7.4 kbps,
		5: 7.95 kbps,
		6: 10.2 kbps,
		7: 12.2 kbps,
<i>head</i> . Audio Enable	bool	Enable/Disable audio

# 4.6 SnapEncode

# 4.6.1 GetSnapConfigCaps

URL Syntax	http:// <ip>/cgi-bin/encode.cgi?action=<b>getConfigCaps</b></ip>			
Comment	Channel: video channel index			
	SnapType:			
	0 = regular snapshot			
	1 = motion detection snapshot			
	2 = alarm snapshot			
Response	caps[ <i>Channel</i> ].SnapFormat[ <i>SnapType</i> ].Video.CompressionTypes=H.264,MJPG			
	caps[Channel]. SnapFormat[SnapType]. Video. ResolutionTypes=3M, 1080, SXGA, 1_3M, 720, D1, CIF			

Field in respons	Value range	Description
CompressionTypes	ctring	It contains all supported video compression types separated by comma.
	string	Range is {MPEG4, MPEG2, MPEG1, MJPG, H.263, H.264}
ResolutionTypes		It contains all supported video resolutions, separated by comma.
	string	Range is {D1, HD1, BCIF, CIF, QCIF, VGA, QVGA, SVGA, XVGA, WXGA, SXGA, WSXGA, UXGA,
		WUXGA, ND1,720, 1080, 1_3M, 2_5M, 3M, 5M}.

#### 4.6.2 GetSnapEncodeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=<b>getConfig</b>&amp;name=Encode [<i>Channel</i>].SnapFormat</ip>
Response	headSnap.Video.BitRate=384
	<i>headSnap</i> .Video.BitRateControl=VBR
	headSnap.Video.Compression=H.264
	headSnap.Video.FPS=1
	headSnap.Video.GOP=50



	<i>headSnap</i> .Video.Height=576	
	headSnap.Video.Quality=4	
	<i>headSnap</i> .Video.Width=704	
	<i>headSnap</i> .VideoEnable=true	
Comment	Channel: video channel index	
	SnapType:	
	0 = regular snapshot	
	1 = motion detection snapshot	
	2 = alarm snapshot	
	Abbreviations in above table:	
	<pre>headSnap = table.Encode[Channel].SnapFormat[SnapType]</pre>	

# 4.6.3 SetSnapEncodeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	Channel: video channel index
	SnapType:
	0 = regular snapshot
	1 = motion detection snapshot
	2 = alarm snapshot
	Abbreviation in below table:
	<pre>head= Encode[Channel].SnapFormat[SnapType]</pre>
Response	OK or ERROR

ParamName	ParamValue type	Description	
<i>head</i> .Video.BitRate	integer	Unit is Kbps	
		Range depends on capability in 4.3.1 GetVideoInputCaps	
<i>head</i> .Video.BitRateControl	string	Range is {CBR,VBR}	
		CBR: constant bitrate	
		VBR: variable bitrate	
<i>head</i> .Video.Compression	String	Range is {MPEG4,MPEG2, MPEG1,MJPG,H.263,H.264}	
		Depends on capacity in 4.3.1 GetVideoInputCaps	
<i>head</i> .Video.FPS	float	Range is [0.2-30]. The lower limit can be reached 0.00002 with firmware 2.4 and	
		above.	
		Frames per second.	
		< 1.0: several seconds/frame, FPS=0.3333: 3 seconds per frame.	
		>1.0: several frames/second. FPS=3: 3 frames per second.	
<i>head</i> .Video.GOP	integer	Range is [1-100].	
		Group of picture, it's the interval of I Frame,	



		Example: GOP=50, means there is one I frame every 49 P or B frames	
<i>head</i> .Video.Height	integer	Video height	
<i>head</i> .Video.Width	integer	Video Width	
<i>head</i> .Video.Quality	integer	Range is [1-6].	
		Image Quality, available when Video.BitRateControl=VBR	
		1: worst quality	
		6: best quality	
<i>head</i> .VideoEnable	bool	True: enable video	

#### 4.7 ChannelTitle

#### 4.7.1 GetChannelTitleConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>ChannelTitle</b></ip>	
Comment	Get the title of the channel.	
	In below table, <i>Channel</i> = video channel index	
Response	table.ChannelTitle[ <i>Channel</i> ].Name=CAM1	

#### 4.7.2 SetChannelTitleConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue></paramvalue></paramname></ip>	
Comment	Set the title of the channel.	
	If VideoWidget[ <i>Channel</i> ]. ChannelTitle. EncodeBlend is true, this title is blended to the video frames.	
	Please refer to 4.8.2 SetVideoWidget	
	In below table, <i>Channel</i> : video channel index	
Response	OK or ERROR	

ParamName	ParamValue type	Description
ChannelTitle[ <i>Channel</i> ].Name	String	Channel Name

#### 4.8 VideoStandard

#### 4.8.1 GetVideoStandardConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoStandard</ip>
------------	---



Comment	
Response	table.VideoStandard=PAL

# 4.8.2 SetVideoStandardConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue></paramvalue></paramname></ip>	
Comment		
Response	OK or ERROR	

ParamName	ParamValue type	Description
VideoStandard	string	Range is {PAL, NTSC}
		Video Standard

# 4.9 VideoWidget

# 4.9.1 GetVideoWidgetConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoWidget</ip>		
Description	VideoWidget config contains ChannelTitle, Covers and TimeTitle parameters, defines the background color, front color and		
	positions of channel title and time title, and defines the regions which are not visible (cover).		
Response	head.BackColor[0]=0		
	head.BackColor[1]=0		
	head.BackColor[2]=0		
	head.BackColor[3]=128		
	<i>head</i> .EncodeBlend=true		
	head.FrontColor[0]=255		
	head.FrontColor[1]=255		
	head.FrontColor[2]=255		
	head.FrontColor[3]=0		
	<b>head</b> .Rect[0]=0		
	<b>head</b> .Rect[1]=8191		
	<b>head</b> .Rect[2]=0		
	<b>head</b> .Rect[3]=8191		
Comment	Channel: video channel index		
	CoReg: Cover Region		
	Covers is an array which sustains multi- Cover regions		
	0 = region 1		
	1 = region 2		



2 = region 3
3 = region 4
head=table.VideoWidget[Channel].ChannelTitle (or)
table.VideoWidget[Channel].Covers[CoReg] (or)
table.VideoWidget[ <i>Channel</i> ].TimeTitle
table.VideoWidget[ <i>Channel</i> ].CustomTitle[index]

# 4.9.2 SetVideoWidgetConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>			
Comment	Channel: video channel index			
	CoReg :Cover region index			
	Covers is an array which contains multiple cover regions			
	0 = region 1			
	1 = region 2			
	2 = region 3			
	3 = region 4			
	<pre>headChannelTitle = VideoWidget[Channel].ChannelTitle</pre>			
	<pre>headCover = VideoWidget[Channel].Covers[CoReg]</pre>			
	<pre>headTimeTitle = VideoWidget[Channel].TimeTitle</pre>			
	<pre>headCustomTitle = VideoWidget[Channel].CustomTitle</pre>			
	VideoWidgetConfig contains cover region settings, channel title settings and time title settings.			
	The italics below will be replaced by the above abbreviations.			
Response	OK or ERROR			

ParamName	ParamValue type	Description
headCover.BackColor[0]	integer	Range is [0-255].
headCover.BackColor[1]		BackColor[0]:red value
headCover.BackColor[2]		BackColor[1]:green value
headCover.BackColor[3]		BackColor[2]:blue value
		BackColor[3]: alpha value
<i>headCover</i> .EncodeBlend	bool	false - widget blend is disabled.
headCover.FrontColor[0]	integer	Range is [0-255].
headCover.FrontColor[1]		FrontColor[0]:red value
headCover.FrontColor[2]		FrontColor[1]:green value
headCover.FrontColor[3]		FrontColor[2]:blue value
		FrontColor[3]: alpha value
headCover.Rect[0]	integer	Range is [0-8191].
headCover.Rect[1]		Rect[0]: top left corner x coordinate (left)
headCover.Rect[2]		Rect[1]: top left corner y coordinate (top)



headCover.Rect[3]		Rect[2]: bottom right x coordinate (right)
		Rect[3]: bottom right y coordinate (bottom)
headChannelTitle.BackColor[0]	integer	Range is the same with <i>headCover</i>
headChannelTitle.BackColor[1]		
headChannelTitle.BackColor[2]		
headChannelTitle.BackColor[3]		
<i>headChannelTitle</i> .EncodeBlend	bool	
headChannelTitle.FrontColor[0]	integer	
headChannelTitle.FrontColor[1]		
headChannelTitle.FrontColor[2]		
headChannelTitle.FrontColor[3]		
headChannelTitle.Rect[0]	integer	Only use the value of (left,top),the value of (right,bottom) is the same
headChannelTitle.Rect[1]		as (left,top)
headChannelTitle.Rect[2]		Rect[0], Rect[1] are used, and Rect[2] must be same with Rect[0],
headChannelTitle.Rect[3]		Rect[3] must be same with Rect[1].
headTimeTitle.BackColor[0]	integer	Range is the same with <i>headChannelTitle</i>
headTimeTitle.BackColor[1]		These are configs about time title.
headTimeTitle.BackColor[2]		
headTimeTitle.BackColor[3]		
headTimeTitle.EncodeBlend	bool	
headTimeTitle.FrontColor[0]	integer	
headTimeTitle.FrontColor[1]		
headTimeTitle.FrontColor[2]		
headTimeTitle.FrontColor[3]		
headTimeTitle.Rect[0]	integer	
headTimeTitle.Rect[1]		
headTimeTitle.Rect[2]		
headTimeTitle.Rect[3]		
headTimeTitle.ShowWeek	bool	True: Display week within the time title.
headCustomTitle.BackColor[0]	integer	Range is the same with <i>headCover</i>
headCustomTitle.BackColor[1]		
headCustomTitle.BackColor[2]		
headCustomTitle.BackColor[3]		
headCustomTitle.EncodeBlend	bool	
headCustomTitle.FrontColor[0]	integer	
headCustomTitle.FrontColor[1]		
headCustomTitle.FrontColor[2]		
headCustomTitle.FrontColor[3]		
headCustomTitle.Rect[0]	integer	Range is [0-8191].
headCustomTitle.Rect[1]		Rect[0]: top left corner x coordinate (left)
headCustomTitle.Rect[2]		Rect[1]: top left corner y coordinate (top)
headCustomTitle.Rect[3]		Rect[2]: bottom right x coordinate (right)
		Rect[3]: bottom right y coordinate (bottom).



PTZPreset.BackColor[0]	integer	Range is the same with headCover
PTZPreset.BackColor[1]		
PTZPreset.BackColor[2]		
PTZPreset.BackColor[3]		
<b>PTZPreset</b> .EncodeBlend	bool	
PTZPreset.FrontColor[0]	integer	
PTZPreset.FrontColor[1]		
PTZPreset.FrontColor[2]		
PTZPreset.FrontColor[3]		
<b>PTZPreset</b> .Rect[0]	integer	Range is [0-8191].
PTZPreset.Rect[1]		Rect[0]: top left corner x coordinate (left)
PTZPreset.Rect[2]		Rect[1]: top left corner y coordinate (top)
PTZPreset.Rect[3]		Rect[2]: bottom right x coordinate (right)
		Rect[3]: bottom right y coordinate (bottom).

#### 4.10 VideoIn

#### 4.10.1 getCollect

URL Syntax	http:// <ip>/cgi-bin/devVideoInput.cgi?action=<b>getCollect</b></ip>	
Description	Get video input <i>channels</i>	
Response	result=1	

#### 4.11 VideoOut

# 4.11.1 GetVideoOutConfig

<b>URL Syntax</b>	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoOut</ip>
Description	
Response	head.Margin[0]=0
	<pre>head.Margin[1]=0</pre>
	head.Margin[2]=0
	head.Margin[3]=0
	<i>head</i> .Color.Brightness=50
	head.Color. Contrast =50
	head.Color. Satuation =50
	<i>head</i> .Color. Hue =50
	<i>head</i> .Mode. Width =800



	<i>head</i> .Mode. Height=600	
head.Mode. BPP =16		
head.Mode. Format ="Auto"		
	<i>head</i> .Mode. RefreshRate =60	
Comment	head = table.VideoOut[channel].	

## 4.11.2 SetVideoOutConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
head.Margin[0]	integer	Margin
head.Margin[1]		
head.Margin[2]		
head.Margin[3]		
<i>head</i> .Color.Brightness	integer	Brightness
head.Color.Contrast =50	integer	Contrast
head.Color.Satuation =50	integer	Satuation
<i>head</i> .Color.Hue =50	integer	Hue
<i>head</i> .Mode.Width =800	integer	Resolution
<i>head</i> .Mode.Height=600		
<b>head</b> .Mode.BPP =16	integer	
head.Mode.Format ="Auto"	string	The range is {"Auto", "TV", "VGA", "DVI"}
head. Mode. Refresh Rate = 60	integer	Refresh rate.

# 4.12 FlashLight

# 4.12.1 GetFlashLightConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>FlashLight</b></ip>	
Description		
Response	head .Brightness=50	
	<i>head</i> .Enable=false	
	<b>head</b> .TimeSection[0][0]=1 00:00:00-23:59:59	
	<b>head</b> .TimeSection[0][1]=0 00:00:00-23:59:59	
	<b>head</b> .TimeSection[6][5]=0 00:00:00-23:59:59	



Comment	head = table.FlashLight
---------	-------------------------

# 4.12.2 SetFlashLightConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>		
Comment			
Response	OK or ERROR		

ParamName	ParamValue type	Description
FlashLight.Enable	bool	Enable
FlashLight.Brightness	integer	Brightness
FlashLight.TimeSection[wd][ts]	string	It's table contains effective time period for flash light everyday.
		wd (week day) range is [0-6] (Sunday-Staurday)
		ts (time section) range is [0-23], it's index of timesection table.
		Format: mask hh:mm:ss-hh:mm:ss
		Mask: {0,1}, hh: [0-24], mm: [00-59], ss: [00-59]
		Mask 0: this time section is not used.
		Mask 1: this time section is used.
		Example:
		TimeSection[1][0]=1 12:00:00-18:00:00
		Means flash light is effective between 12:00:00 and 18:00:00 at
		Monday.

# 5. Network

### **5.1 NetInterfaces**

### **5.1.1 GetInterfaces**

URL Syntax	http:// <ip>/cgi-bin/netApp.cgi?action=getInterfaces</ip>	
Comment	Get all of the system network interfaces.	
	Description for items In below table	
	Name: network interface name.	
	"eth0" - wired network interface	
	"eth2" - wireless network interface	



	"3G" - 3G network interface
	Type: "Normal" – wired network  "Wireless" – wireless network  "Auto", "TD-SCDMA", "WCDMA", "CDMA1x", "EDGE", "EVDO" – 3G network types.
	Valid: network interface is valid if netInterface[n].Valid is true.
Response	netInterface[0].Name=eth0
	netInterface[0].Type=Normal
	netInterface[0].Valid=true
	netInterface[1]

## 5.2 BasicConfig

## 5.2.1 GetBasicConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Network</b></ip>		
Comment	Basic config contains basic network parameters (Default interface, domain name, host name), and configuration of each		
	network interface.		
	interface in below table is network interface name, such as eth0, eth2		
Response	table.Network.DefaultInterface=eth0		
	table.Network.Domain=Amcrest		
	table.Network.Hostname=badak		
	table.Network. interface. Default Gateway = 10.7.0.1		
	table.Network. <i>interface</i> .DhcpEnable=false		
	table.Network. interface.DnsServers[0]=221.123.33.228		
	table.Network. interface. DnsServers[1]=221.12.1.228		
	table.Network. <i>interface</i> .IPAddress=10.7.2.3		
	table.Network. <i>interface</i> .MTU=1500		
	table.Network. <i>interface</i> .PhysicalAddress=00:10:5c:f2:1c:b4		
	table.Network. <i>interface</i> .SubnetMask=255.255.0.0		

### 5.2.2 SetBasicConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	interface in below table is network interface name, such as eth0, eth1	
Response	OK or ERROR	

ParamName	ParamValue type	Description
-----------	-----------------	-------------



NetWork.DefaultInterface	string	Set default network interface when multiple interfaces exist.
		Range of interfaces is depends on <b>5.1.1 GetInterfaces</b>
NetWork.Domain	string	Domain name.
NetWork.Hostname	string	Hostname and Domain compose a network address.
Network. interface. Default Gateway	string	IP address
Network. interface. DhcpEnable	bool	Enable/Disable DHCP.
Network. interface. DnsServers[0]	string	IP address of first DNS server.
Network. interface. Dns Servers [1]	string	IP address of second DNS server.
Network. interface. IPAddress	string	Interface IP address.
Network. <i>interface</i> .MTU	integer	Interface MTU.
Network. <i>interface</i> . Physical Address	string	MAC address of interface.
		HEX string in the form of:
		xx:xx:xx:xx:xx.
		Range of x is [0-9,a-f,A-F]
		Example:
		00:10:5c:f2:1c:b4
		00:10:5C:F2:1C:B5
Network. interface. Subnet Mask	string	Network mask string:
		In the form of x.x.x.x, range of x is [0-255]
		Example:
		255.255.255.0

### **5.3 PPPoE**

### 5.3.1 GetPPPoEConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>PPPoE</b></ip>	
Comment		
Response	table.PPPoE.Enable=false	
	table.PPPoE.Password=123456	
	table.PPPoE.UserName=123456	

### **5.3.2 SetPPPoEConfig**

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>		
Comment			
Response	OK or ERROR		

40



ParamName	ParamValue type	Description
PPPoE.Enable	bool	Enable/Disable PPPoE.
PPPoE.UserName	string	PPPoE user name.
PPPoE.Password	string	PPPoE user password.

### **5.4 DDNS**

## 5.4.1 GetDDNSConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>DDNS</b></ip>	
Comment	<i>Index</i> below is the DDNS protocol table index, start from 0.	
Response	table.DDNS[ <i>index</i> ].Address=www.Amcresttech.com	
	table.DDNS[ <i>index</i> ].Enable=true	
	table.DDNS[ <i>index</i> ].HostName=www.Amcresttech.com	
	table.DDNS[ <i>index</i> ].KeepAlive=10	
	table.DDNS[index].Password=none	
	table.DDNS[ <i>index</i> ].Port=5050	
	table.DDNS[ <i>index</i> ].Protocol=AMCREST	
	table.DDNS[index].UserName=user1	

### 5.4.2 SetDDNSConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Index below is the DDNS protocol table index, start from 0.	
Response	OK or ERROR	

ParamName	ParamValue type	Description
DDNS[ <i>index</i> ].Address	string	DDNS server IP address or name.
DDNS[ <i>index</i> ].Enable	bool	Multiple DDNS hostname can be configured, but Only one
		hostname can be enabled, others should be disabled.
DDNS[ <i>index</i> ].HostName	String	Host name of this device.
DDNS[ <i>index</i> ].KeepAlive	integer	Range is [1-65535].
		Unit is minutes.
DDNS[ <i>index</i> ].Password	string	DDNS user password
DDNS[ <i>index</i> ].Port	integer	Range is [1-65535].
		Port of DDSN server
DDNS[ <i>index</i> ].Protocol	string	Range is {NO-IP DDNS, Dyndns DDNS, AMCREST}.



		DDSN protocol type
DDNS[ <i>index</i> ].UserName	string	DDNS user name

### 5.5 Email

## 5.5.1 GetEmailConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Email</b></ip>	
Comment		
Response	table.Email.Address=www.Amcresttech.com	
	table.Email.Anonymous=true	
	table.Email.AttachEnable=true	
	table.Email.AttachmentEnable=true	
	table.Email.Enable=true	
	table.Email.HealthReport.Enable=false	
	table.Email.HealthReport.Interval=61	
	table.Email.Password=123456	
	table.Email.Port=26	
	table.Email.Receivers[0]=x@Amcresttech.com	
	table.Email.Receivers[1]=y@Amcresttech.com	
	table.Email.Receivers[2]=z@Amcresttech.com	
	table.Email.SendAddress=x@Amcresttech.com	
	table.Email.SslEnable=false	
	table.Email.Title=DVRMessage	
	table.Email.UserName=anonymitty	

## 5.5.2 SetEmailConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
Email.Address	string	SMTP server IP address or name.
Email.Anonymous	bool	Enable/Disable anonymous email.
Email.AttachEnable	bool	Enable/Disable email attachment



		1
Email.AttachmentEnable	bool	Enable/Disable email attachment
Email.Enable	bool	Enable/Disable email function
Email.HealthReport.Enable	bool	Enable/Disable report device status by email.
Email.HealthReport.Interval	integer	Range is [30-1440].
		Unit is minutes
Email.Password	string	User password of email account.
Email.Port	integer	Range is [1-65535]
Email.Receivers[0]	string	Email addresses of 3 receivers.
Email.Receivers[1]	string	
Email.Receivers[2]	string	
Email.SendAddress	string	Sender email address.
Email.SslEnable	bool	True: enable SSL email.
Email.Title	string	Title of email.
Email.UserName	string	User name of email account.

### **5.6 Wlan**

# 5.6.1 GetWlanConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>WLan</b></ip>
Comment	
Response	table.WLan.eth2.Enable=true
	table.WLan.eth2.Encryption=off
	table.WLan.eth2.KeyFlag=false
	table.WLan.eth2.KeyID=0
	table.WLan.eth2.KeyType=Hex
	table.WLan.eth2.Keys[0]=password1
	table.WLan.eth2.Keys[1]=password2
	table.WLan.eth2.Keys[2]=password3
	table.WLan.eth2.Keys[3]=password4
	table.WLan.eth2.LinkMode=Auto
	table.WLan.eth2.SSID=Amcrest

# 5.6.2 SetWlanConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
OILE SYIILUA	Tittp:// vips/egi bii/comigivanager.egi.action=seccomiga vparamitames=



Comment	interface is name of wireless interface, to get all the network interfaces and their properties, refer to 5.1:NetInterfaces.
Response	OK or ERROR

ParamName	ParamValue type	Description
WLan. interface. Enable	bool	True: Enable WLan on this interface.
WLan. interface. Encryption	string	Range is {Off, On, WEP64Bits, WEP128Bits,
		WPA-PSK-TKIP, WPA-PSK-CCMP}
		Encryption mode.
WLan. <i>interface</i> .KeyFlag	bool	true: key is configured.
WLan. <i>interface</i> .KeyID	integer	Range is [0-3]
		Indicates which key is used.
		0 : WLan. <i>interface</i> . Keys[0] is used.
WLan. <i>interface</i> .KeyType	string	Range is {Hex, ASCII]
WLan. <i>interface</i> .Keys[0]	string	For ASCII key type: 64bits encryption key length is 5,
WLan. <i>interface</i> .Keys[1]	string	128bits encryption key length is 13, consists of [0-9,
WLan. <i>interface</i> .Keys[2]	string	a-z, A-Z]
WLan. <i>interface</i> .Keys[3]	string	
		For HEX key type: 64bits encryption key length is 10,
		128bits encryption key length is 26, consists of [0-9,
		a-z, A-Z]
WLan. interface. Link Mode	string	Range is {Auto, Ad-hoc, Infrastructure}.
		Auto – select suitable mode automatically.
		Ad-hoc – Device with wireless network adapter can
		connect to each other without Access Point.
		Infrastructure – Integrate wire and wireless LAN
		together to share network resource, access point is
		need in this mode.
WLan. interface. SSID	string	

### 5.6.3 ScanWlanDevices

URL Syntax	http:// <ip>/cgi-bin/wlan.cgi?action=scanWlanDevices&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Search wifi information	
Response	Available wifi num and detailed information, for example:	
	found=1	
	wlanDevice[0].ApConnected=0	
	wlanDevice[0].ApMaxBitRate=54000000	
	wlanDevice[0].ApNetWorkType=255	
	wlanDevice[0].AuthMode=7	
	wlanDevice[0].BSSID=28:2c:b2:5c:de:36	
	wlanDevice[0].EncrAlgr=3	



wlanDevice[0].LinkMode=0
wlanDevice[0].LinkQuality=31
wlanDevice[0].RSSIQuality=0
wlanDevice[0].SSID=xia_yuguo 13098 Internet

ParamName	ParamValue type	Description
SSID	string	Specified SSID, if not include any SSID, all wifi
		information will be searched and displayed.

### 5.7 UPnP

## 5.7.1 GetUPnPConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>UPnP</b></ip>	
Comment	<i>Index</i> in below is the UPNP map table index, start from 0.	
Response	table.UPnP.Enable=true	
	table.UPnP.MapTable[index].Enable=true	
	table.UPnP.MapTable[index].InnerPort=80	
	table.UPnP.MapTable[index].OuterPort=8080	
	table.UPnP.MapTable[index].Protocol=TCP	
	table.UPnP.MapTable[index].ServiceName=HTTP	

## 5.7.2 SetUPnPConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Index in below table is UPNP map table index, range is [0-255]	
Response	OK or ERROR	

ParamName	ParamValue type	Description
UPnP.Enable	bool	Enable/Disable UPNP feature.
UPnP.MapTable[ <i>index</i> ].Enable	bool	Enable/Disable this UPNP map.
UPnP.MapTable[ <i>index</i> ].InnerPort	integer	Range is [1-65535].
		Inner port number
UPnP.MapTable[ <i>index</i> ].OuterPort	integer	Range is [1-65535].
		Outer port number.
UPnP.MapTable[ <i>index</i> ].Protocol	string	Range is {TCP, UDP]
UPnP.MapTable[ <i>index</i> ].ServiceName	string	User defined UPnP service name.



### 5.7.3 GetUPnPStatus

URL Syntax	http:// <ip>/cgi-bin/netApp.cgi?action=getUPnPStatus</ip>	
Comment	Get UPNP mapping result:	
	result=1: mapping succeed.	
	result=0: mapping failed.	
Response	rsult=1	

### **5.8 NTP**

## 5.8.1 GetNTPConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=NTP</ip>
Comment	
Response	table.NTP.Address=clock.isc.org
	table.NTP.Enable=false
	table.NTP.Port=38
	table.NTP.TimeZone=9
	table.NTP.UpdatePeriod=31

# 5.8.2 SetNTPConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
NTP.Address	string	NTP server IP address or name.
NTP.Enable	bool	Enable/Disable NTP server.
NTP.Port	integer	Range is [1-65535].
		Port of NTP server.
NTP.TimeZone	integer	Range is [0-32].
		0: "GMT+00:00"



		1. "CNAT.01.00"
		1: "GMT+01:00"
		2: "GMT+02:00"
		3: "GMT+03:00"
		4: "GMT+03:30"
		5: "GMT+04:00"
		6: "GMT+04:30"
		7: "GMT+05:00"
		8: "GMT+05:30"
		9: "GMT+05:45"
		10: "GMT+06:00"
		11: "GMT+06:30"
		12: "GMT+07:00"
		13: "GMT+08:00"
		14: "GMT+09:00"
		15: "GMT+09:30"
		16: "GMT+10:00"
		17: "GMT+11:00"
		18: "GMT+12:00"
		19: "GMT+13:00"
		20: "GMT-01:00"
		21: "GMT-02:00"
		22: "GMT-03:00"
		23: "GMT-03:30"
		24: "GMT-04:00"
		25: "GMT-05:00"
		26: "GMT-06:00"
		27: "GMT-07:00"
		28: "GMT-08:00"
		29: "GMT-09:00"
		30: "GMT-10:00"
		31: "GMT-11:00"
		32: "GMT-12:00"
NTP.UpdatePeriod	integer	Range is [0-65535], unit is minutes
1411.Opdater eriod	пперег	Transe is to ossess, and is infinites

## **5.9 RTSP**

# 5.9.1 GetRTSPConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=RTSP</ip>
Comment	



Response	table.RTSP.Enable=true
	table.RTSP.Port=554
	table.RTSP.RTP.EndPort=40000
	table.RTSP.RTP.StartPort=20000

### 5.9.2 SetRTSPConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
RTSP.Enable	bool	Enable/Disable RTSP.
RTSP.Port	integer	RTSP port.
RTSP.RTP.StartPort	integer	RTP start port.
RTSP.RTP.EndPort	integer	RTP end port.

### **5.10 Telnet**

## 5.10.1 GetTelnetConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Telnet</b></ip>
Comment	
Response	table.Telnet.Enable=true

## 5.10.2 SetTelnetConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
Telnet.Enable	bool	Enable/Disable Telnet.



## 6.Events

#### 6.1 EventHandler

EventHandler is used in alarm and event config in following sections. It contains settings for actions linked with alarm and events. Actions include record, snapshot, PTZ action, log, mail, alarm out and so on. When alarm or event happen, actions defined in alarm EventHandler and event EventHandler are executed.

#### 6.1.1 GetEventHandler

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<handlername></handlername></ip>
Comment	< handlerName> can be one of below four formats
	Alarm[alarm channel]. Event Handler
	MotionDetect[video channel]. EventHandler
	BlindDetect[ <i>video channel</i> ]. EventHandler
	LossDetect[video channel]. EventHandler
	LoginFailureAlarm.EventHandler
	Example URL:
	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=Alarm[0].EventHandler</ip>
	can get EventHandler settings of alarm channel 0.
Response	
	handlerName. EventHandler. AlarmOutChannels [0] = 1
	handler Name. Event Handler. Alarm Out Channels [1] = 1
	handler Name. Event Handler. Alarm Out Enable = false
	handlerName. EventHandler. AlarmOutLatch=10
	handlerName. EventHandler. BeepEnable=true
	handlerName. EventHandler. Dejitter=0
	handlerName. EventHandler. Delay=30
	handlerName. EventHandler. LogEnable=true
	handlerName. EventHandler. MailEnable=true
	handlerName. EventHandler. PtzLink[0][0]=None
	handlerName. EventHandler. PtzLink[0][1]=0
	handlerName. EventHandler. PtzLink[1][0]=None
	handlerName. EventHandler. PtzLink[1][1]=0
	handlerName. EventHandler. PtzLinkEnable = false
	handlerName. EventHandler. RecordChannels [0] = 1



 $\textbf{\textit{handlerName}}. Event Handler. Record Channels [1] = 1$ 

•••

handlerName.EventHandler.RecordEnable=true
handlerName.EventHandler.RecordLatch=10

handlerName.EventHandler.SnapshotChannels[0]=1
handlerName.EventHandler.SnapshotChannels[1]=1

...

 $\textbf{\textit{handlerName}}. Event Handler. Snapshot Enable = false$ 

handlerName.EventHandler.SnapshotPeriod=3
handlerName.EventHandler.SnapshotTimes=0

 $\label{lem:handlerName} \textbf{handlerName}. \textbf{EventHandler.TimeSection[0][0]=1 01:00:00-24:00:00} \\ \textbf{handlerName}. \textbf{EventHandler.TimeSection[0][1]=1 01:00:00-24:00:00} \\ \textbf{handler.TimeSection[0][1]=1 01:00:00-24:00:00-24:00:00} \\ \textbf{handler.TimeSection[0][1]=1 01:00:00-24:00-24:0$ 

•••

...

 $\textbf{\textit{handlerName}}. Event Handler. Time Section [6] [5] = 1\ 01:00:00-24:00:00$ 

**handlerName**. Event Handler. Tip Enable = true

handlerName. EventHandler. ExAlarmOutEnable=true

handlerName. ExAlarmOutChannels[0] =2
handlerName.ExAlarmOutChannels[1]=3

...

#### 6.1.2 SetEventHandler

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	Meaning of <i>handlerName</i> is the same with <u>6.1.1 GetEventHandler</u>
Response	OK or ERROR

paramName	paramValue	Description
	type	
handler Name. Event Handler. Alarm Out Channels [ch]	integer	Range is {0, 1}, <i>ch</i> is alarm out channel index.
		0 – do not output alarm at alarm out channel <i>ch</i>
		1 – output alarm at alarm out channel <i>ch</i>
handler Name. Event Handler. Alarm Out Enable	bool	Enable/Disable alarm out function.
handler Name. Event Handler. Alarm Out Latch	Integer	Range is [10-300].
		Unit is seconds, indicates the time to output alarm after input alarm is
		cleared.
handler Name. Event Handler. Beep Enable	bool	Enable/Disable beep.
handler Name. Event Handler. Dejitter	integer	Range is [0-255].
		Alarm signal dejitter seconds. Alarm signal change during this period is



		ignored.
handlerName. EventHandler. Delay	integer	Range is [0-300].
		Delay seconds before setting take effect.
handlerName.EventHandler.LogEnable	bool	Enable/Disable log for alarm.
handlerName. EventHandler. Mail Enable	bool	Enable/Disable mail send for alarm.
handlerName.EventHandler.PtzLink[ch][0]	string	Range is {None, Preset, Tour, Pattern}
		This is PTZ action linked with events. <i>ch</i> is PTZ channel index.
handlerName. Event Handler. Ptz Link [ch][1]	integer	This is the parameter of PtzLink[ <i>ch</i> ][0],
		If PtzLink[ <i>ch</i> ]][0] is
		Preset: this is preset point.
		Tour: this is tour path number.
		Pattern: this is pattern number.
handler Name. Event Handler. Ptz Link Enable	Bool	Enable/Disable PTZ link.
handler Name. Event Handler. Record Channels [ch]	Integer	Range is {0, 1}
		0 – do not record on video channel <i>ch</i>
		1 – record. on video channel <i>ch</i>
<i>handler Name</i> . Event Handler. Record Enable	bool	Enable/Disable record function.
handler Name. Event Handler. Record Latch	integer	Range is [10-300].
		Unit is seconds, indicates the time to record after input alarm is cleared
<b>handler Name</b> . Event Handler. Snapshot Channels [ch]	integer	Range is {0, 1}
		0 – do not snapshot on video channel <i>ch</i>
		1 – snapshot on video channel <i>ch</i>
<i>handlerName</i> . Event Handler. Snapshot Enable	bool	Enable/Disable snapshot function.
<i>handlerName</i> . Event Handler. Snapshot Period	integer	Range is [0-255].
		Frames between snapshot.
		0 means continuously snapshot for every frame.
<b>handler Name</b> . Event Handler. Snapshot Times	integer	Range is [0-65535]
		Snapshot times before stop, 0 means don't stop snapshot.
handlerName. EventHandler.TimeSection[wd][ts]	String	It's table contains effective time period for eventHanlder everyday.
		wd (week day) range is [0-6] (Sunday-Staurday)
		ts (time section) range is [0-23], it's index of timesection table.
		Format: mask hh:mm:ss-hh:mm:ss
		Mask: {0,1}, hh: [0-24], mm: [00-59], ss: [00-59]
		Mask 0: this time section is not used.
		Mask 1: this time section is used.
		Framala
		Example:
		TimeSection[1][0]=1 12:00:00-18:00:00
		Means EventHandler is effective between 12:00:00 and 18:00:00 at
handlarNama Eventlandlar TipErrela	hool	Monday.
handlerName.EventHandler.TipEnable	bool	Enable/Disable local message box tip.
handlerName.EventHandler. ExAlarmOutEnable	bool	



#### 6.2 Alarm

### 6.2.1 GetAlarmConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=Alarm</ip>
Comment	
Response	table.Alarm[0].Enable=false
	table.Alarm[0].EventHandler(output of EventHandler is described in 6.1.1 GetEventHandler)
	table.Alarm[0].Name=Door1
	table.Alarm[0].SensorType=NC
	table.Alarm[1]

### 6.2.2 SetAlarmConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	In below table, <b>input</b> is external alarm input channel, <b>ch</b> is channel number, <b>wd</b> is weekday index, <b>ts</b> is timesection index.
	EventHandler defines parameter of relevant actions when alarm or event happens. It's also used in following sections about
	events.
Response	OK or ERROR

ParamName	ParamValue type	Description	
Alarm[input].Enable	bool	Enable/Disable alarm from a input channel	
Alarm[input]. Event Handler		Setting of EventHandler is described in <b>6.1.2 SetEventHandler</b>	
Alarm[input].Name	string	Name of alarm input channel.	
Alarm[input].SensorType	string	Range is {NC, NO].	
		NC: normal close	
		NO: normal open	

## 6.2.3 GetAlarmOutConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>AlarmOut</b></ip>	
Comment	alarmOutChannel below is the alarm out channel index.	
Response	table.AlarmOut[alarmOutChannel].Mode=0	



table.AlarmOut	[alarmOutChannel]	.Name=Bee	o

## 6.2.4 SetAlarmOutConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Port in below table is alarm out port index, start form 0.	
Response	OK or ERROR	

ParamName	ParamValue type	Description
AlarmOut[ <i>port</i> ].Mode	integer	Range is {0, 1, 2}
		0: automatically alarm
		1: force alarm
		2: close alarm
AlarmOut[ <i>port</i> ].Name	string	Alarm out port name.

### 6.2.5 GetInSlots

URL Syntax	http:// <ip>/cgi-bin/alarm.cgi?action=<b>getInSlots</b></ip>
Comment	Get alarm input channel number.
	Below response means there are 2 alarm input channels.
Response	result=2

#### 6.2.6 GetOutSlots

URL Syntax	http:// <ip>/cgi-bin/alarm.cgi?action=getOutSlots</ip>	
Comment	Get alarm output channel number.	
Response	result=1	

#### 6.2.7 GetInState

URL Syntax	http:// <ip>/cgi-bin/alarm.cgi?action=<b>getInStates</b></ip>	
Comment	Get alarm input state for all channels.	
	A bit in the response result indicates a channel alarm states, below result 3 means alarm channel 1 and channel 2 have	
	alarm now.	



_		<del></del>
_		
Response	result=3	
response	result-5	

#### 6.2.8 GetOutState

URL Syntax	http:// <ip>/cgi-bin/alarm.cgi?action=getOutStates</ip>	
Comment	Get alarm output state for all channels.	
	A bit in the response result indicates a channel. 1 means alarm is present.	
Response	result=0	

### 6.2.9 GetChannelInState

URL Syntax	http:// <ip>/cgi-bin/alarm.cgi?action=getInStates&amp;channel=<channelno></channelno></ip>	
Comment	Get alarm input state for <i>channelNo</i> . <i>channelNo</i> starts from 0, and must be less than alarm input channels obtained from	
	6.2.5 GetInSlots.	
	Result 1 means alarm is present. Result 0 means alarm is not present.	
Response	result=1	

#### 6.2.10 GetChannelOutState

URL Syntax	http:// <ip>/cgi-bin/alarm.cgi?action=getOutStates&amp;channel=<channelno></channelno></ip>	
Comment	Get alarm output state for <i>channelNo</i> . <i>channelNo</i> starts from 0, and must be less than alarm output channels obtained	
	from 6.2.6 GetOutSlots .	
	Result 1 means alarm is present. Result 0 means alarm is not present.	
Response	result=0	

#### 6.3 MotionDetect

### **6.3.1 GetMotionDetectConfig**

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>MotionDetect</b></ip>	
Comment	MotionDetect config of a video channel contains Enable, Level, Region and EventHandler.	
Response	table.MotionDetect[0].Enable=false	
	table.MotionDetect[0].EventHandler (output of EventHandler is described in 6.1.1 GetEventHandler)	
	table.MotionDetect[0].Level=3	
	table.MotionDetect[0].Region[0]=3932160	
	table.MotionDetect[0].Region[1]=3932160	



table.MotionDetect[0].MotionDetectWindow[0].Id=0
table.MotionDetect[0].MotionDetectWindow[0].Name=Region0
table.MotionDetect[0].MotionDetectWindow[0].Sensitive=58
table.MotionDetect[0].MotionDetectWindow[0].Threshold=4
table.MotionDetect[0].MotionDetectWindow[0].Region[0]=3932160
table.MotionDetect[0].MotionDetectWindow[0].Region[1]=3932160
...
...
table.MotionDetect[1]...
...

## **6.3.2 SetMotionDetectConfig**

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>			
Comment	Channel: video channel index			
	LineNum			
	Index of region, region is divided into lines and each line has several blocks, a line is described by a 32 bit integer, a bit for			
	a block			
	0=Line 1			
	1=Line 2			
	···			
	WinNum			
Index of detect window, there are 4 detect windows at present. Each window is divided into 18 lines				
	MotionDetectWindow is available with firmware 2.212 and above.			
	RegionIndex			
	It is similar with <i>LineNum</i> , but is beyond to a detect window.			
	Head = MotionDetect[Channel]			
	The italics below will be replaced by the above abbreviations.			
Response	OK or ERROR			

ParamName	ParamValue type	Description
<i>head</i> .Enable	bool	Enable/Disable motion detect feature in a channel.
<i>head</i> . Event Handler		Setting of EventHandler is described in 6.1.2 SetEventHandler
<i>head</i> .Level	integer	Range is [1-6].
		Sensitivity of motion detection.
		1: lowest sensitivity.
		6: highest sensitivity.
head.Region[LineNum]	integer	Currently, region is divided into 18 lines and 22 blocks/line.
		A bit describes a block in the line.
		Bit = 1: motion in this block is monitored
		This filed is used to compatible with the previous firmware. It can be instead by



		head. MotionDetectWindow[WinNum].
		Example:
		MotionDetect[0].Region[0] = 4194303 (0x3FFFFF):: motion in channel 0 line 0's
		22 blocks is monitored.
		MotionDetect[0].Region[1] =0: motion in line 1's 22 blocks is not monitored.
		MotionDetect[0].Region[17] = 3: in the last line of channel 0, motion in the left
		two blocks is monitored.
<i>head</i> .MotionDetectWindow	integer	It is the Id of a detect window.
[ <i>WinNum</i> ].Id		
<i>head</i> .MotionDetectWindow	string	It is the name of a detect window.
[ <i>WinNum</i> ].Name		
<i>head</i> .MotionDetectWindow	integer	Range is [0-100].
[ <i>WinNum</i> ].Sensitive		It presents more sensitive if the value is larger.
<i>head</i> .MotionDetectWindow	integer	Range is [0-100].
[ <i>WinNum</i> ]. Threshold		It presents the threshold value when trigger motion detect.
<i>head</i> .MotionDetectWindow	integer	It is similar with <i>head</i> .Region[ <i>LineNum</i> ].
[WinNum]. Region[RegionIndex]		

### 6.4 BlindDetect

# 6.4.1 GetBlindDetectConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=BlindDetect</ip>	
Comment	Channel: video channel number	
	<pre>head= table.BlindDetect[Channel]</pre>	
Response	head.Enable=false	
	head. EventHandler = (output of EventHandler is described in 6.1.1 GetEventHandler)	
	<i>head</i> .Level=3	

### 6.4.2 SetBlindDetectConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Channel: video channel number	
	<i>head</i> =BlindDetect[ <i>Channel</i> ]	
Response	OK or ERROR	

ParamName	ParamValue type	Description
<i>head</i> .Enable	bool	Enable/Disable blind detect feature.
<i>head</i> .EventHandler		Setting of EventHandler is described in 6.1.2 SetEventHandler



<i>head</i> .Level	integer	Range is [1-6].
		Sensitivity of blind detection.
		1: lowest sensitivity.
		6: highest sensitivity.

### 6.5 LossDetect

### 6.5.1 GetLossDetectConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=LossDetect</ip>	
Comment	Channel: video channel number	
	head=table.BlindDetect[Channel]	
Response	head.Enable=false	
	<i>head</i> .EventHandler= (output of EventHandler is described in <u>6.1.1 GetEventHandler</u> )	

### 6.5.2 SetLossDetectConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>		
Comment	Channel: video channel number		
	<pre>Head = BlindDetect[Channel]</pre>		
Response	OK or ERROR		

ParamName	ParamValue type	Description
<i>head</i> .Enable	bool	Enable/Disable loss detect feature.
<i>head</i> . Event Handler		Setting of EventHandler is described in 6.1.2 SetEventHandler

### 6.6 LoginFailureAlarm

## **6.6.1 GetLoginFailureAlarmConfig**

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=LoginFailureAlarm</ip>	
Comment	Channel: video channel number	
	<i>head</i> =table.LoginFailureAlarm	
Response	head.Enable=false	
	<i>head</i> .EventHandler= (output of EventHandler is described in 6.1.1 GetEventHandler)	

### 6.6.2 SetLoginFailureAlarmConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
------------	--



Comment	<i>Head</i> =LoginFailureAlarm
Response	OK or ERROR

ParamName	ParamValue type	Description
<i>head</i> .Enable	bool	Enable/Disable notify LoginFailure event. Now this event can be linked
		with send email and alarm out.The max try login times can be configured
		in chapter 9.1.2 SetGeneralConfig.
<i>head</i> . Event Handler		Setting of EventHandler is described in 6.1.2 SetEventHandler

### 6.7 StorageAbnormal

### **6.7.1 GetStorageNotExistConfig**

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=StorageNotExist</ip>	
Comment		
Response	StorageNotExist.Enable=false	
	StorageNotExist.EventHandler= (output of EventHandler is described in 6.1.1 GetEventHandler)	

### **6.7.2 SetStorageNotExistConfig**

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
StorageNotExist.Enable	bool	Enable/Disable loss detect feature.
StorageNotExist.EventHandler		Setting of EventHandler is described in 6.1.2 SetEventHandler

## 6.7.3 Get StorageFailureConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name= StorageFailure</ip>	
Comment		
Response	StorageFailure.Enable=false	
	StorageFailure.EventHandler= (output of EventHandler is described in 6.1.1 GetEventHandler)	

### 6.7.4 Set StorageFailureConfig

URL S	Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
-------	--------	--

58



Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
StorageFailure.Enable	bool	Enable/Disable loss detect feature.
StorageFailure.EventHandler		Setting of EventHandler is described in 6.1.2 SetEventHandler

### 6.7.5 GetStorageLowSpaceConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name= StorageLowSpace</ip>	
Comment		
Response	StorageLowSpace.Enable=false	
	StorageLowSpace.EventHandler= (output of EventHandler is described in <b>6.1.1 GetEventHandler</b> )	

### 6.7.6 SetStorageLowSpaceConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
StorageLowSpace.Enable	bool	Enable/Disable loss detect feature.
StorageLowSpace.EventHandler		Setting of EventHandler is described in 6.1.2 SetEventHandler

### 6.8 NetAbnormal

### 6.8.1 GetNetAbortConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name= NetAbort</ip>	
Comment		
Response	NetAbort.Enable=false	
	NetAbort.EventHandler= (output of EventHandler is described in 6.1.1 GetEventHandler)	

### 6.8.2 SetNetAbortConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
------------	--

59



Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
NetAbort.Enable	bool	Enable/Disable loss detect feature.
NetAbort.EventHandler		Setting of EventHandler is described in 6.1.2 SetEventHandler

## 6.8.3 GetIPConflictConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name= IPConflict</ip>	
Comment		
Response	IPConflict.Enable=false	
	IPConflict.EventHandler= (output of EventHandler is described in <u>6.1.1 GetEventHandler</u> )	

## 6.8.4 SetIPConflictConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	
Response	OK or ERROR

ParamName	ParamValue type	Description
IPConflict.Enable	bool	Enable/Disable loss detect feature.
IPConflict.EventHandler		Setting of EventHandler is described in <u>6.1.2 SetEventHandler</u>

### 6.9 GetEventIndexes

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/eventManager.cgi?action=getEventIndexes&code=< <i>eventCode</i> >	
Comment	Get channels indexes that event of code <i>eventCode</i> happens.	
	eventCode includes:	
	VideoMotion: motion detection event	
	VideoLoss: video loss detection event	
	VideoBlind: video blind detection event.	
	AlarmLocal: alarm detection event.	
Response	channels[0]=0	
	channels[1]=2	
	channels[2]=3	



...
(This response means event happened on channel 0, channel 2, and channel 3.)

### 6.10 Attach

URL Syntax	http:// <ip>/cgi-bin/eventManager.cgi?action=attach&amp;codes=[<eventcode>,<eventcode>,]</eventcode></eventcode></ip>
Comment	Get channels indexes that event of code <i>eventCode</i> happens.
	eventCode includes:
	VideoMotion: motion detection event
	VideoLoss: video loss detection event
	VideoBlind: video blind detection event.
	AlarmLocal: alarm detection event.
	CrossLineDetection: tripwire event
	CrossRegionDetection: intrusion event
	LeftDetection: abandoned object detection
	TakenAwayDetection: missing object detection
	VideoAbnormalDetection: scene change event
	FaceDetection: face detect event
	AudioMutation: intensity change
	AudioAnomaly: input abnormal
	VideoUnFocus: defocus detect event
	WanderDetection: loitering detection event
	RioterDetection: People Gathering event
	ParkingDetection: parking detection event
	MoveDetection: fast moving event
	MDResult: motion detection data reporting event. The motion detect window contains 18 rows and 22 columns. The
	event info contains motion detect data with mask of every row.
Response	HTTP Code: 200 OK\r\n
	Cache-Control: no-cache\r\n
	Pragma: no-cache\r\n
	Expires: Thu, 01 Dec 2099 16:00:00 GMT\r\n
	Connection: close\r\n
	Content-Type: multipart/x-mixed-replace; boundary=< <b>bondary</b> >\r\n
	Body:
	< <b>bondary&gt;</b> \r\n
	Content-Type: text/plain\r\n
	Content-Length: <data length="">\r\n</data>
	<eventinfo>\r\n\r\n</eventinfo>
	< <b>bondary&gt;</b> \r\n
	Content-Type: text/plain\r\n
	Content-Length: <data length="">\r\n</data>
	<eventinfo>\r\n\r\n</eventinfo>



For example:

HTTP Code: 200 OK\r\n
Cache-Control: no-cache\r\n
Pragma: no-cache\r\n

Expires: Thu, 01 Dec 2099 16:00:00 GMT\r\n

Connection: close\r\n

Body:

-- myboundary \r\n

Content-Type: text/plain\r\n
Content-Length: 39\r\n

 $Code=VideoMotion; action=Start; index=0 \\ \\ r\\ \\ n\\ \\ r\\ \\ n$ 

-- myboundary  $r\n$ 

Content-Type: text/plain\r\n
Content-Length: 38\r\n

 $Code=VideoBlind; action=Start; index=0\r\n\r\n$ 

-- myboundary  $r\n$ 

Content-Type: text/plain\r\n
Content-Length: 38\r\n

Code= AlarmLocal;action=Start;index=0\r\n\r\n

-- myboundary  $r\n$ 

Content-Type: text/plain\r\n
Content-Length: 38\r\n

-- myboundary  $r\n$ 

...

### **7. PTZ**

### 7.1 PTZConfig

### 7.1.1 GetPTZConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Ptz</b></ip>
Comment	Port in below table is PTZ port index, start form 0.
Response	table.Ptz[ <i>port</i> ].Address=8
	table.Ptz[port].Attribute[0]=115200
	table.Ptz[port].Attribute[1]=8
	table.Ptz[ <i>port</i> ].Attribute[2]=Even



table.Ptz[ <b>port</b> ].Attribute[3]=1
table.Ptz[ <b>port</b> ].Homing[0]=0
table.Ptz[ <b>port</b> ].Homing[1]=30
table.Ptz[ <b>port</b> ].NumberInMatrixs=0
table.Ptz[ <i>port</i> ].ProtocolName=NONE

# 7.1.2 SetPTZConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Port in below table is PTZ port index, start form 0.	
Response	OK or ERROR	

ParamName	ParamValue type	Description
Ptz[ <b>port</b> ].Address	integer	Range is [0-255].
		Device address, if there are more than one device connected to
		this port, distinguish them by this address.
Ptz[ <b>port</b> ].Attribute[0]	integer	Range is {1200, 2400 ,4800, 9600, 19200, 38400, 57600,
		115200}.
		Baudrate
Ptz[ <i>port</i> ].Attribute[1]	integer	Range is {4, 5, 6, 7, 8}.
		Data bit.
Ptz[ <i>port</i> ].Attribute[2]	string	Range is {Even, Mark, None, Odd, Space}.
		Parity verification mode.
Ptz[ <i>port</i> ].Attribute[3]	float	Range is {1, 1.5, 2}.
		Stop bit.
Ptz[ <i>port</i> ].Homing[0]	integer	Range is {-1,0-255}
		-1: homing is disabled.
		[0-255]: preset point number
Ptz[ <i>port</i> ].Homing[1]	integer	Range is [0-65535].
		No operation timeout, unit is seconds.
		After no operation timeout, PTZ go to preset point set in
		Ptz[port].Homing[0].
Ptz[ <i>port</i> ].ProtocolName	string	PTZ protocol name, depends on PTZ capability,
		refer to <b>7.2.1 GetProtocolList</b> to get the protocol list.



### 7.2 PTZControl

### 7.2.1 GetProtocolList

URL Syntax	http:// <ip>/cgi-bin/ptz.cgi?action=<b>getProtocolList</b></ip>
Comment	Get PTZ protocol list.
	Response contains all support PTZ protocols separated by comma.
Response	result=NONE,AD1641M,ADMATRIX,BANKNOTE,DH-CC440,DH-MATRIX,DH-SD1,DH-SD2,HAIYU,HY,LILIN,PANASONIC

## 7.2.2 GetCurrentProtocolCaps

URL Syntax	http:// <ip>/cgi-bin/ptz.cgi?action=getCurrentProtocolCaps&amp;channel=<channelno></channelno></ip>	
Comment	Get PTZ protocol list, <i>channelNo</i> is PTZ channel index.	
Response	caps.AlarmLen=0	
	caps.AuxMax=8	
	caps.AuxMin=1	
	caps.CamAddrMax=255	
	caps.CamAddrMin=1	
	caps.Interval=200	
	caps.Menu=false	
	caps.MonAddrMax=255	
	caps.MonAddrMin=0	
	caps.Name=DH-SD1	
	caps.PanSpeedMax=255	
	caps.PanSpeedMin=1	
	caps.PatternMax=5	
	caps.PatternMin=1	
	caps.PresetMax=80	
	caps.PresetMin=1	
	caps.TileSpeedMax=255	
	caps.TileSpeedMin=1	
	caps.TourMax=7	
	caps.TourMin=0	
	caps.Type=1	

Field in response	Description
AlarmLen	Alarm length in protocol
AuxMax	Maximum/Minimum number for auxiliary functions



AuxMin	
CamAddrMax	Maximum/Minimum channel address
CamAddrMin	
Menu	True or false, support internal menu of the PTZ or not,
MonAddrMax	Maximum/Minimum monitor address
MonAddrMin	
Name	Name of the operation protocol
PanSpeedMax	Maximum/Minimum pan speed.
PanSpeedMin	
PatternMax	Maximum/Minimum pattern path number.
PatternMin	
PresetMax	Maximum/Minimum preset point number.
PresetMin	
TileSpeedMax	Maximum/Minimum tile speed.
TileSpeedMin	
TourMax	Maximum/Minimum tour path number.
TourMin	
Туре	Type of PTZ protocol.

### 7.2.3 PTZ control commands

URL Syntax	http:// <ip>/cgi-bin/ptz.cgi?action=[action]&amp;channel=[ch]&amp;code=[code]&amp;arg1=[argstr]&amp;arg2=[argstr]&amp;arg3=[argstr]</ip>
Comment	This URL is used to start/stop PTZ control command.
	action is PTZ control command, it can be start or stop.
	ch is PTZ channel range is [0 - n-1], code is PTZ operation, and arg1, arg2, arg3 is the arguments of operation.
	Code and argstr values are listed in below table.
Response	OK or ERROR

Code	Code description	arg1	arg2	arg3	arg4
Up	Tile up	0	Vertical speed,	0	0
			range is [1-8]		
Down	Tile down	0	Vertical speed,	0	0
			range is [1-8]		
Left	Pan left	0	Vertical speed,	0	0
			range is [1-8]		
Right	Pan right	0	Vertical speed,	0	0
			range is [1-8]		
ZoomWide	Zoom out	0	multiple	0	0
ZoomTele	Zoom in	0	multiple	0	0
FocusNear	Focus near	0	multiple	0	0
FocusFar	Focus far	0	multiple	0	0



IrisLarge	Aperture larger	0	multiple	0	0
IrisSmall	Aperture smaller	0	multiple	0	0
GotoPreset	Go to PTZ preset point	0	Preset point	0	0
			number		
SetPreset	Set PTZ preset point	0	Preset point	0	0
			number		
ClearPreset	Clear PTZ preset point	0	Preset point	0	0
			number		
LampWaterClear		1: open	0	0	0
		2: close			
StartTour	Start PTZ tour	Tour path	0	1: start	0
		number		2: automatically	
				3: stop	
LeftUp	Pan left and tile up	Vertical speed,	Horizontal speed,	0	0
		range is [1-8]	range is [1-8]		
RightUp	Pan right and tile up	Vertical speed,	Horizontal speed,	0	0
		range is [1-8]	range is [1-8]		
LeftDown	Pan left and tile down	Vertical speed,	Horizontal speed,	0	0
		range is [1-8]	range is [1-8]		
RightDown	Pan right and tile down	Vertical speed,	Horizontal speed,	0	0
		range is [1-8]	range is [1-8]		
AddTour	Add preset point to tour path	Tour path	Preset point	0	0
		number	number		
DelTour	Delete preset point from tour	Tour path	Preset point	0	0
	path	number	number		
ClearTour	Clear tour path	Tour path	0	0	0
		number			
AutoPanOn	Start pan rotate	0	0	0	0
AutoPanOff	Stop pan rotate	0	0	0	0
SetLeftLimit	Set left limit.	0	0	0	0
SetRightLimit	Set right limit.	0	0	0	0
AutoScanOn	Start auto scan.	0	0	0	0
AutoScanOff	Stop auto scan.	0	0	0	0
SetPatternBegin	Begin pattern path set.	Pattern number	0	0	0
SetPatternEnd	End pattern path set.	Pattern number	0	0	0
StartPattern	Run pattern path	Pattern number	0	0	0
StopPattern	Stop pattern path	Pattern number	0	0	0
ClearPattern	Clear pattern path	Pattern number	0	0	0
AlarmSearch	Search alarm.	0	0	0	0
Position	Go to position	Horizontal	Vertical position	Zoom change	0
		position			
AuxOn	Auxiliary function on, auxiliary	0	0	0	0
	function is defined in product				



_	definition document.				<u> </u>
AuxOff	Auxiliary function off	0	0	0	0
Menu	Transmary remediation	0	0	0	0
Exit		0	0	0	0
Enter		0	0	0	0
Esc		0	0	0	0
MenuUp		0	0	0	0
MenuDown		0	0	0	0
MenuLeft		0	0	0	0
MenuRight		0	0	0	0
Reset	Restore default configuration.	0	0	0	0
SetPresetName	Nestore default configuration.	Preset point	Preset point title.	0	0
Setriesetivanie		number (1 byte)	rreset point title.		o o
AlarmPtz	Alarm linked PTZ.	External alarm	Link type:	Argument of link	0
,	7 Martin Minked 1 12.	input channel.	1: go to preset	type:	
		input chamien	point	Link type = 1,	
			2: auto scan	this is preset point	
			3: tour	number	
				Link type = 2,	
				this is auto scan	
				path	
				Link type = 3,	
				this is tour path	
LightController	Control the light on/off.	Address of light	Light number	switch	0
		controller			
PositionABS	Go to ABS position	Horizontal angle:	Vertical	Zoom in mutiple	Speed[1-8], not
		0°-360°	angle :0°-90°		must
PositionReset	Use current direction as	0	0	0	0
	reference.				
UpTele	up + TELE	Speed [1-8]	0	0	0
DownTele	down + TELE	Speed [1-8]	0	0	0
LeftTele	left + TELE	Speed [1-8]	0	0	0
RightTele	right + TELE	Speed [1-8]	0	0	0
LeftUpTele	leftup + TELE	Speed [1-8]	0	0	0
LeftDownTele	leftdown + TELE	Speed [1-8]	0	0	0
RigjtUpTele	rightup + TELE	Speed [1-8]	0	0	0
RightDownTele	rightdown + TELE	Speed [1-8]	0	0	0
UpWide	up + WIDE	Speed [1-8]	0	0	0
DownWide	down + WIDE	Speed [1-8]	0	0	0
LeftWide	left + WIDE	Speed [1-8]	0	0	0
RightWide	right + WIDE	Speed [1-8]	0	0	0
LeftUpWide	leftup + WIDE	Speed [1-8]	0	0	0
LeftDownWide	leftdown + WIDE	Speed [1-8]	0	0	0



RightUpWide	rightup + WIDE	Speed [1-8]	0	0	0
RightDownWide	rightdown + WIDE	Speed [1-8]	0	0	0
Continuously	Maya Cantinyayah	Horizontal Speed	Vertical Speed	Zoom Speed [-8-8]	Timeout
	Move Continuously	[-8-8]	[-8-8]		
Relatively	Maria Dalatirah	Relatively angle:	Relatively	Relatively Zoom	
	Move Relatively	0°-360°	angle :0°-90°		

### 7.3 PTZStatus

#### 7.3.1 PTZ GetStatus

URL Syntax	http:// <ip>/cgi-bin/ptz.cgi?action=getStatus</ip>	
Comment	This URL is used to get PTZStatus.	
Response	status.UTC=6538920	
	status.MoveStatus=Idle	
	status.ZoomStatus=Idle	
	status.PresetID=10	
	status.Position=120,12,2	

# 8. RecordSnap

### 8.1 Record

# 8.1.1 GetRecordConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Record</b></ip>	
Comment	Channel in below table is video channel number, weekday range is [0-6] (Sunday - Saturday).	
	Record config contains pre record time and record time sections of every day.	
Response	table.Record[ <i>channel</i> ].PreRecord=6	
	table.Record[ <i>channel</i> ].HolidayEnable=true	
	table.Record[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][0]=1 00:00:00-24:00:00	
	table.Record[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][1]=0 02:00:00-24:00:00	
	table.Record[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][2]=0 03:00:00-24:00:00	
	table.Record[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][3]=0 04:00:00-24:00:00	
	table.Record[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][4]=0 05:00:00-24:00:00	
	table.Record[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][5]=0 06:00:00-24:00:00	



### 8.1.2 SetRecordConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table: <i>ch</i> = channel index, <i>wd</i> = week day index, <i>ts</i> = time section index	
Response	OK or ERROR	

ParamName	ParamValue type	Description
Record[ <i>ch</i> ].PreRecord	integer	Range is [0-300].
		Prerecord seconds, 0 means no prerecord.
		ch (Channel number) starts form 0
Record[ <i>ch</i> ]. HolidayEnable	bool	Record or not when a day is a holiday setted is chapter <b>8.4 Holiday</b> .
Record[ <i>ch</i> ].TimeSection[ <i>wd</i> ][ <i>ts</i> ]	string	wd (week day) range is [0-6] (Sunday - Staurday)
		ts (time section) range is [0-23], timesection table index.
		Format: mask hh:mm:ss-hh:mm:ss
		Mask: [0-65535], hh: [0-24], mm: [0-59], ss: [0-59]
		Mask indicates record type by bits:
		Bit0: regular record
		Bit1: motion detection record
		Bit2: alarm record
		Bit3: card record

#### Example:

Set record time to every Sunday all day. Record type is motion detection and alarm.

URL should be:

http://<ip>/ cgi-bin/configManager.cgi?action=setConfig&name=Record[0]. TimeSection[0][0]&table=6.00:00:00-24:00-24

In this example, "6 00:00:00-24:00:00" means motion detection and alarm record all day (6 = 4 & 2, alarm is 4, motion detection is 2.).

### 8.1.3 GetRecordModeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>RecordMode</b></ip>	
Comment	Get record mode for video channels. <i>channel</i> in below table is video channel number.	
Response	table.RecordMode[ <i>channel</i> ].Mode=0	

### 8.1.4 SetRecordModeConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	channel in below table is video channel index, start form 0.

69



D.	ocnonco	OK or FRROR
I IN	esponse	OK OF EKROK

ParamName	ParamValue type	Description
RecordMode[ <i>channel</i> ].Mode	integer	Range is {0, 1, 2}.
		0: automatically record
		1: manually record
		2: stop record.

## **8.2 Snap**

## 8.2.1 GetSnapConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Snap</b></ip>	
Comment	<i>Channel</i> in below table is video channel number, <i>weekday</i> range is [0-6] (Sunday - Saturday).	
Response	table.Snap [ <i>channel</i> ].HolidayEnable=true	
	table.Snap[channel].TimeSection[weekday][0]=1 00:00:00-24:00:00	
	table.Snap[channel].TimeSection[weekday][1]=0 02:00:00-24:00:00	
	table.Snap[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][2]=0 03:00:00-24:00:00	
	table.Snap[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][3]=0 04:00:00-24:00:00	
	table.Snap[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][4]=0 05:00:00-24:00:00	
	table.Snap[ <i>channel</i> ].TimeSection[ <i>weekday</i> ][5]=0 06:00:00-24:00:00	

# 8.2.2 SetSnapConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table: <i>ch</i> = channel index, <i>wd</i> = week day index, <i>ts</i> = time section index	
Response	OK or ERROR	

ParamName	ParamValue type	Description
Snap [ch].HolidayEnable	bool	Snap or not when a day is a holiday setted is chapter <b>8.4 Holiday</b> .
Snap[ch].TimeSection[wd][ts] string		wd (week day) range is [0-6] (Sunday- Staurday)
		ts (time section) range is [0-23], it's timesection table index.
		Format: mask hh:mm:ss-hh:mm:ss
		Mask: [0-65535], hh: [0-24], mm: [0-59], ss: [0-59]
		Mask indicates record type by bits:
		Bit0: regular snapshot



	Bit1: motion detection snapshot
	Bit2: alarm snapshot
	Bit3: card snapshot

### 8.2.3 attachFileProc

URL Syntax	http:// <ip>/cgi-bin/snapManager.cgi?action=attachFileProc&amp;Flags[0]=Event&amp;Events=[<eventcode>,<eventcode>,]</eventcode></eventcode></ip>		
Comment	Get channels indexes that event of code <i>eventCode</i> happens.		
	Flag[0]:Event		
	eventCode includes:		
	All: all event.		
	VideoMotion: motion detection event		
	VideoLoss: video loss detection event		
	VideoBlind: video blind detection event.		
	AlarmLocal: alarm detection event.		
	All intelligent event include CrossLineDetection,eg		
Response	<jpeg data=""></jpeg>		

### 8.3 MediaGlobal

### 8.3.1 GetMediaGlobalConfig

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=getConfig&name= <b>MediaGlobal</b>	
Description		
Response	table.MediaGlobal.SnapFormatAs=MainFormat	

# 8.3.2 SetMediaGlobalConfig

URL Syntax	$\verb http:///cgi-bin/configManager.cgi?action=setConfig&=[&=] $	
Comment	It presents obtaining snap stream from Main stream or extra stream.	
Response	OK or ERROR	

ParamName	ParamValue type	Description
Media Global. Snap Format As	string	The range is {"MainFormat", "ExtraFormat"}



# 8.4 Holiday

# 8.4.1 GetHolidayConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Holiday</b></ip>
Description	Get holiday config for record or snap.
Response	table.Holiday.MonthMask[0]=3
	table.Holiday.MonthMask[1]=0
	table.Holiday.MonthMask[2]=0
	table.Holiday.MonthMask[3]=0
	table.Holiday.MonthMask[4]=0
	table.Holiday.MonthMask[5]=0
	table.Holiday.MonthMask[6]=0
	table.Holiday.MonthMask[7]=0
	table.Holiday.MonthMask[8]=0
	table.Holiday.MonthMask[9]= 1610612739
	table.Holiday.MonthMask[10]=0
	table.Holiday.MonthMask[11]=0

# 8.4.2 SetHolidayConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	monthindex presents the index of a month. 0 presents January, 1 presents February, 11 presents December.	
Response	OK or ERROR	

ParamName	ParamValue type	Description
Holiday. Month Mask [month Index]	integer	It is the mask of a month. Every bit present a day. For example, 0x0001
		presents the first day of a month is holiday.0x0002 presents the second
		day of a month is holiday, 0x0003 presents the first day and second day
		of a month is holiday.



# 9. System

### 9.1 General

# 9.1.1 GetGeneralConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>General</b></ip>
Comment	
Response	table.General.MachineName=Amcrest001
	table.General. LocalNo=8
	table.General. MachineAddress="binjiangqv jiangnandadao weiyelu"
	table.General. MachineGroup="jiaojing yidui
	table.General.LockLoginEnable=true
	table.General.LockLoginTimes=3
	table.General.LoginFailLockTime=1800

# 9.1.2 SetGeneralConfig

URL Syntax	URL Syntax http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue></paramvalue></paramname></paramvalue></paramname></ip>	
Comment		
Response	OK or ERROR	

ParamName	ParamValue type	Description
General.MachineName	string	Device name or serial number.
General. LocalNo	integer	
General. MachineAddress	string	
General. MachineGroup	string	
General. LockLoginEnable	bool	Whether support lock login times setting.
General. LockLoginTimes	integer	Max try times of login failed, when exceeding the
		times the device will be locked and alarm.
General. LoginFailLockTime	integer	Lock login seconds.

73



# 9.2 SystemTime

### 9.2.1 GetCurrentTime

URL Syntax http:// <ip>/cgi-bin/global.cgi?action=getCurrentTime</ip>	
Comment	The time format is "Y-M-D H-m-S". It's not be effected by Locales. Time Format in <b>9.3.2 SetLocales Config.</b>
Response	result = 2011-7-3 21:02:32

### 9.2.2 SetCurrentTime

URL Syntax	http:// <ip>/cgi-bin/global.cgi?action=setCurrentTime&amp;time=2011-7-3%2021:02:32</ip>
Comment	The time format is "Y-M-D H-m-S". It's not be effected by Locales. TimeFormat in 9.3.2 SetLocales Config.
Response	OK or ERROR

## 9.3 Locales

# 9.3.1 GetLocalesConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>Locales</b></ip>
Comment	
Response	table.Locales.DSTEnable=false
	table.Locales.DSTEnd.Day=1
	table.Locales.DSTEnd.Hour=0
	table.Locales.DSTEnd.Minute=0
	table.Locales.DSTEnd.Month=1
	table.Locales.DSTEnd.Week=2
	table.Locales.DSTEnd.Year=2011
	table.Locales.DSTStart.Day=0
	table.Locales.DSTStart.Hour=0
	table.Locales.DSTStart.Minute=0
	table.Locales.DSTStart.Month=1
	table.Locales.DSTStart.Week=1
	table.Locales.DSTStart.Year=2011
	table.Locales.TimeFormat=yyyy-MM-dd HH:mm:ss



# 9.3.2 SetLocalesConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment		
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
Locales.DSTEnable	bool	Enable/Disable DST (daylight saving time)
Locales.DSTEnd.Day	integer	Range is [0-6] or [1-31]
		[0-6]: week day, 0 = Sunday, 6 = Saturday
		[1-31]: month day
		If Locales.DSTEnd.Week is 0, use month day, otherwise, use week day.
Locales.DSTEnd.Hour	integer	Range is [0-23]
Locales.DSTEnd.Minute	integer	Range is [0-59]
Locales.DSTEnd.Month	integer	Range is [1-12]
Locales.DSTEnd.Week	Integer	Range is {1,2,3,4,-1,0}.
		0 = Use month day
		[1,2,3,4,-1]: use week day.
		1 = first week, 2 = second, 3 = third, 4 = fourth, -1 = last.
Locales.DSTEnd.Year	Integer	Range is [2000-2038]
Locales.DSTStart.Day		Range is the same with items in Locales.DSTEnd
Locales.DSTStart.Hour		Locales.DSTStart table and Locales.DSTEnd table together defines the
Locales.DSTStart.Minute		time range of DST.
Locales.DSTStart.Month		
Locales.DSTStart.Week		
Locales.DSTStart.Year		
Locales.TimeFormat	string	Defines time format displayed in video time title.
		String form is: year-month-day hour:mm:ss.
		Position of <i>year</i> , <i>month</i> and <i>day</i> can be exchanged.
		Range of <i>year</i> is {yy, yyyy}
		yy = year without century, yyyy = year with century.
		Range of <i>month</i> is {M, MM, MMMM}
		M = 1 for January, MM = 01 for January, MMMM = Jan for January
		Range of <i>day</i> is {d, dd}
		d = 1 for first day, dd = 01 for first day
		Range of <i>hour</i> is {H, HH, h, hh}
		H = 1 for 1:00, HH = 01 for 1:00, range is 0-23
		h = 1 for 1:00, hh = 01 for 1:00, time range is 1-12



	Example:
	уууу-MM-dd HH:mm:ss or
	MM-dd-yyyy HH:mm:ss or
	dd-M-yy hh:mm:ss

# 9.4 Language

# 9.4.1 GetLanguageCaps

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=getLanguageCaps</ip>	
Comment	Get the list of supported languages, response is a string contains languages with comma separated.	
	Languages include	
	{English, SimpChinese, TradChinese, Italian, Spanish, Japanese, Russian, French, German]	
Response	Languages=SimpChinese,English,French	

# 9.4.2 GetLanguageConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=Language</ip>
Comment	Get current system language cofnig.
Response	table.Language=SimpChinese

# 9.4.3 SetLanguageConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<paramvalue>[&amp;<para< th=""></para<></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></paramvalue></paramname></ip>	
Comment	NOTE: After changing language setting, system will automatically reboot!	
Response	OK or ERROR	

ParamName	ParamValue type	Description
Language	string	The language range is get from interface in <b>9.3.1 GetLanguageCaps</b>



## 9.5 AccessFilter

# 9.5.1 GetAccessFilterConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=AccessFilter</ip>	
Comment	bannedIndex below is the banned IP list index,	
	trustIndex below is the trust IP list index.	
Response	table. Access Filter. Banned List [banned Index] = 10.6.10.1	
	table.AccessFilter. TrustList[trustIndex]=1.2.3.4	
	table.AccessFilter.Enable=false	
	table.AccessFilter.Type=BannedList	

## 9.5.2 SetAccessFilterConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	Range of <i>index</i> in below table is [0-255]	
Response	OK or ERROR	

ParamName	ParamValue type	Description
AccessFilter.BannedList[ <i>index</i> ]	string	Banned IP address list
AccessFilter.TrustList[ <i>index</i> ]	string	Trusted IP address list
AccessFilter.Enable	bool	Enable/Disable access filter function
AccessFilter.Type	string	Range is {TrustList, BannedList},
		TrustList: Turst list is used, banned list is not used.
		BannedList: Banned list is used, turst list is not used.

### 9.6 AutoMaintain

## 9.6.1 GetAutoMaintainConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>AutoMaintain</b></ip>	
Comment		
Response	table.AutoMaintain. AutoRebootDay=3	
	table.AutoMaintain. AutoRebootHour=0	



table.AutoMaintain. AutoRebootMinute=0
table.AutoMaintain. AutoShutdownDay=1
table.AutoMaintain. AutoShutdownHour=0
table.AutoMaintain. AutoShutdownMinute=0
table.AutoMaintain. AutoStartUpDay=1
table.AutoMaintain. AutoStartUpHour=2
table.AutoMaintain. AutoStartUpMinute=0

# 9.6.2 SetAutoMaintainConfig

URL Syntax	ntax http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment		
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
AutoMaintain. AutoRebootDay	integer	Range is [-1-7].
		Auto restart day.
		-1 = never auto restart
		0- 6 = Sunday-Saturday
		7 = restart every day
AutoMaintain. AutoRebootHour	integer	Range is [0-23].
		Auto restart hour
AutoMaintain. AutoRebootMinute	integer	Range is [0-59].
		Auto restart minute
AutoMaintain. AutoShutdownDay	integer	Auto reboot time.
AutoMaintain. AutoShutdownHour		Range is same with AutoOpenDay, AutoOpenHour, AutoOpenMinute.
AutoMaintain. AutoShutdownMinute		
AutoMaintain. AutoStartUpDay	integer	Auto shutdown time.
AutoMaintain. AutoStartUpHour		Range is same with AutoOpenDay, AutoOpenHour, AutoOpenMinute.
AutoMaintain. AutoStartUpMinute		



# 9.7 UserManager

## 9.7.1 Group

There are two user groups: "admin" and "user". The "admin" group has all the authorities of operating the IP Camera. The "user" group only has monitor and replay authorities.

## 9.7.2 GetGroupInfo

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=getGroupInfo&amp;name=<groupname></groupname></ip>	
Comment	Get group setting with name <i>groupName</i> .	
	The range of <i>groupName</i> is: "admin" and "user".	
Response	group.Name=admin	
	group.Memo=administrator group	
	goup. AuthorityList= <authlist></authlist>	

## 9.7.3 GetGroupInfoAll

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=<b>getGroupInfoAll</b></ip>	
Comment	Get information of all groups.	
Response	group[0].Name=admin	
	group[0].Memo=administrator group	
	group[0]. AuthorityList=< <b>authList</b> >	
	group[1].Name=user	
	group[1].Memo=user group	
	group[1]. AuthorityList=< <b>authList&gt;</b>	
	group[2]	

### 9.7.4 AddUser

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=addUser&amp;</ip>	
	user.Name=< <i>userName</i> >&	
	user.Password=< <i>userPassword</i> >&	
	user.Memo=< <i>userMemo</i> >&	
	user.Group=< <i>userGroup</i> >&	
	user.Reserved=< <i>userReserved</i> >&	
	user.Sharable=< <i>userSharable</i> >	



	user.AuthList=< <b>authList&gt;</b>
Comment	user.Group: string, the range is "admin" and "user". In different group, the user has different authorities.
	user.Sharable: bool, true means allow multi-point login.
	User.Reserved: bool, true means this user can't be deleted.
	User.AuthList;.
	For example:
	Add a user of name operator, password 123456, belongs to group user, and allow multi-point login.
	http:// <i><ip< i="">&gt;/cgi-bin/userManager.cgi?action=addUser&amp;user.Name=operator&amp;user.Password=123456&amp;user.Group=user&amp;us</ip<></i>
	er.Sharable=true&user.Reserved=false&user.AuthList= CtrlPanel,ShutDown, Record,Backup
Response	OK or ERROR

## 9.7.5 DeleteUser

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=deleteUser&amp;name=&lt;<i>userName</i>&gt;</ip>
Comment	Delete user with name <i>username</i> .
Response	OK or ERROR

# 9.7.6 ModifyUser

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/userManager.cgi?action= <b>modifyUser</b> &
	name=< <b>oldUserName</b> >&
	user.Name=< <i>userName</i> >&
	user.Password=< <i>userPassword</i> >&
	user.Memo=< <i>userMemo</i> >&
	user.Group=< <i>userGroup</i> >&
	user.Reserved=< <i>userReserved</i> >&
	user.Sharable=< <i>userSharable</i> >
	user.AuthList=< <i>authList</i> >
Comment	Value range of parameters in <> is the same with <u>9.7.4 AddUser</u>
Response	OK or ERROR

# 9.7.7 ModifyPassword

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=modifyPassword&amp;name=<username>&amp;pwd=<newpwd>&amp;pwdOld=<oldpwd></oldpwd></newpwd></username></ip>
Comment	Modify user password, old password <i>oldPwd</i> should be supplied, new password is <i>newPwd</i> .
Response	OK or ERROR



### 9.7.8 GetUserInfo

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=getUserInfo&amp;name=<username></username></ip>
Comment	Get use information with name <i>userName</i>
Response	user.Name=admin
	user.Memo=admin 's account
	user.Group=admin
	user.Reserved=true
	user.Sharable=true
	user. AuthList= <authlist></authlist>

### 9.7.9 GetUserInfoAll

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=getUserInfoAll</ip>
Comment	Get information of all users.
Response	users[0].Group=admin
	users[0].Id=1
	users[0].Memo=admin 's account
	users[0].Name=admin
	users[0].Reserved=true
	users[0].Sharable=true
	users[0]. AuthList=< <i>authList</i> >
	users[1].Group=admin

### 9.7.10 GetActiveUserInfoAll

URL Syntax	http:// <ip>/cgi-bin/userManager.cgi?action=getActiveUserInfoAll</ip>
Comment	Get active users.
Response	users[0].name=admin
	users[0].ip=10.43.2.16
	users[0].group=admin
	users[0].clienttype=web3.0
	users[0].logintime=2011-11-08 09:51:03

81



# 9.8 System Operation

### **9.8.1** Reboot

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=<b>reboot</b></ip>
Comment	Reboot the device. If successful, response OK. If fail, response ERROR.
Response	OK or ERROR

### 9.8.2 Shutdown

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=<b>shutdown</b></ip>
Comment	Shutdown the device. If successful, response OK. If fail, response ERROR.
Response	OK or ERROR

## 9.8.3 GetDeviceType

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=<b>getDeviceType</b></ip>
Comment	Get the device type.
Response	type=IPC-HF3300

### 9.8.4 GetHardwareVersion

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=<b>getHardwareVersion</b></ip>
Comment	Get the device hardware version
Response	version=1.00

### 9.8.5 GetSerialNo

URL Syntax	http:// <ip> /cgi-bin/magicBox.cgi?action=<b>getSerialNo</b></ip>
Comment	Get the device serial number
Response	sn=YZC0GZ05100020

### 9.8.6 GetMachineName

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=<b>getMachineName</b></ip>
Comment	Get the device machine name.



Response	name=YZC0GZ05100020
----------	---------------------

## 9.8.7 GetSystemInfo

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=getSystemInfo</ip>
Comment	Get the system information.
Response	serialNumber=YZC0GZ05100020
	deviceType=IPC-HF3300
	hardwareVersion=1.00

### 9.8.8 GetVendor

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=getVendor</ip>
Comment	Get the vendor information.
Response	vendor=Amcrest

### 9.8.9 GetSoftwareVersion

URL Syntax	http:// <ip>/cgi-bin/magicBox.cgi?action=getSoftwareVersion</ip>
Comment	Get software information.
Response	version=2.212.0000.0.R,build:2013-11-14

### 9.8.10 GetOnvifVersion

URL Syntax	http:// <ip>/cgi-bin/intervideoManager.cgi?action=getOnvifVersion</ip>
Comment	Get onvif version information.
Response	version=2.4.1

# 9.9 Log

### 9.9.1 StartFind

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/log.cgi?action= <b>startFind</b> &condition.StartTime=< <b>start</b> >&condition.EndTime=< <b>end</b> >
Comment	Start to find log, in response, there is a token for further log finding process.
	start/end: the start/end time of log. Format is: yyyy-mm-dd hh:mm:ss.
	Example:
	Find log between 2011-1-1 12:00:00 and 2011-1-10 12:00:00, URL is:
	http:// <ip>/cgi-bin/log.cgi?action=startFind&amp;condition.StartTime=2011-1-1 12:00:00</ip>



	&condition.EndTime=2011-1-10 12:00:00
Response	token=1

## **9.9.2 DoFind**

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/log.cgi?action= <b>doFind</b> &token=< <b>tokenValue</b> >&count=< <b>logCount</b> >
Comment	Find log with token tokenValue and count logCount
	tokenValue is get by startFind in above section, logCount is the count of logs for this query.
	The maximum value of <i>logCount</i> is 100.
Response	found=2
	items[0].RecNo=789
	items[0].Time=2011-05-20 11:59:10
	items[0].Type=ClearLog
	items[0].User=admin
	items[1].Detail.Compression=H.264->MJPG
	items[1].Detail.Data=Encode
	items[1].RecNo=790
	items[1].Time=2011-05-20 11:59:21
	items[1].Type=SaveConfig
	items[1].User=System
	···

Field in Response	Description
found	Count of found log, found is 0 if no log is found.
User	User name
Туре	Log type
Time	Time of this log
RecNo	Log number.
Detail	Log details.

# 9.9.3 StopFind

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/log.cgi?action= <b>stopFind</b> &token=< <b>tokenValue</b> >
Comment	Stop query log by token <i>tokenValue</i>
Response	OK or ERROR

84



### 9.9.4 Clear

URL Syntax	http:// <ip>/cgi-bin/log.cgi?action=clear</ip>
Comment	Clear all the logs.
Response	OK or ERROR

### 9.10 UserGlobal

## 9.10.1 GetUserGlobalConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>UserGlobal</b></ip>
Comment	
Response	table.UserGlobal.OnvifLoginCheck=false

## 9.10.2 SetUserGlobalConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;UserGlobal.OnvifLoginCheck=<flag></flag></ip>
Comment	Enable Onvif login check or not, < <b>flag&gt;</b> range is {true, false}
Response	OK or ERROR

# 9.11 IntervideoManager

### 9.11.1 GetCGIVersion

URL Syntax	http:// <ip>/cgi-bin/ IntervideoManager.cgi?action=getVersion&amp;Name=CGI</ip>
Comment	Get CGI version
Response	version=1.40



# 10. Storage

# 10.1 File Finding

### **10.1.1** Create

URL Syntax	http:// <ip>/cgi-bin/mediaFileFind.cgi?action=factory.create</ip>
Comment	Create a media file finder
Response	result=08137

## 10.1.2 StartFind

<b>URL Syntax</b>	http:// <ip>/cgi-bin/mediaFileFind.cgi?action=findFile&amp;object=&lt;<b>objectId</b>&gt;&amp;condition.Channel=&lt;<b>channel</b>&gt;&amp;condition.StartTime=</ip>
	$<\!$
	vents[0]=< <b>event&gt;</b>
Comment	Start to find file wth the above condition. If start successfully, return true, else return false.
	object : The object Id is got from interface in <b>10.1.1 Create</b>
	condition.Channel: in which channel you want to find the file .
	condition.StartTime/condition.EndTime: the start/end time when recording.
	condition.Dirs: in which directories you want to find the file. It is an array. The index starts from 0. The range of dir is
	{"/mnt/dvr/sda0", "/mnt/dvr/sda1"}. This condition can be omitted. If omitted, find files in all the directories.
	condition. Types: which types of the file you want to find. It is an array. The index starts from 0. The range of type is {"dav",
	"jpg", "mp4"}. If omitted, find files with all the types.
	condition.Flags: which flags of the file you want to find. It is an array. The index starts from 0. The range of flag is {"Timing",
	"Manual", "Marker", "Event", "Mosaic", "Cutout"}. If omitted, find files with all the flags.
	condition. Event: by which event the record file is triggered. It is an array. The index starts from 0. The range of <i>event</i> is
	{"AlarmLocal", "VideoMotion", "VideoLoss", "VideoBlind", "Traffic*"}. This condition can be omitted. If omitted, find files of all
	the events.
	Example:
	Find file in channel 1, in directory "/mnt/dvr/sda0", event type is "AlarmLocal" or "VideoMotion", file type is "dav", and time
	between 2011-1-1 12:00:00 and 2011-1-10 12:00:00 , URL is:
	http:// <ip>/cgi-bin/mediaFileFind.cgi?action=findFile&amp;object=08137&amp;condition.Channel=1&amp;conditon.Dir[0]="/mnt/dvr/sda0"&amp;</ip>
	conditon.Event[0]=AlarmLocal&conditon.Event[1]=VideoMotion&condition.StartTime=2011-1-1%2012:00:00&condition.EndTi
	me=2011-1-10%2012:00:00
Response	OK or Error



## 10.1.3 FindNextFile

URL Syntax	http:// <ip>/cgi-bin/mediaFileFind.cgi?action=findNextFile&amp;object=&lt;<b>objectId</b>&gt;&amp;count=&lt;<b>fileCount</b>&gt;</ip>
Comment	Find the next <i>fileCount</i> files.
	The maximum value of <i>fileCount</i> is 100.
Response	found=1
	items[0]. Channel =1
	items[0]. StartTime =2011-1-1 12:00:00
	items[0]. EndTime =2011-1-1 13:00:00
	items[0]. Type =dav
	items[0]. Events[0]=AlarmLocal
	items[0]. FilePath =/mnt/dvr/sda0/2010/8/11/dav/15:40:50.jpg
	items[0]. Length =790
	items[0]. Duration = 3600
	items[0].SummaryOffset=2354
	tems[0].Repeat=0
	items[0].WorkDir="/mnt/dvr/sda0"
	items[0]. Overwrites=5
	items[0]. WorkDirSN=0

Field in Response	Description
found	Count of found file, found is 0 if no file is found.
Channel	Channel
StartTime	Start Time
EndTime	End time
Туре	File type
Events	Event type.
FilePath	filepath.
Length	File length
Duration	Duration time
SummaryOffset	Summary offset
Repeat	Repeat file number
WorkDir	The file's directory
Overwrites	Overwrite times of the work directory
WorkDirSN	Workdir No

### **10.1.4 Close**

URL Syntax	http:// <ip>/cgi-bin/mediaFileFind.cgi?action=close&amp;object=&lt;<b>objectId</b>&gt;</ip>
Comment	Stop find.

87



Response
----------

## **10.1.5 Destroy**

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/mediaFileFind.cgi?action=destroy&object=< <i>objectId</i> >
Comment	Destroy the media file finder.
Response	OK or ERROR

## **10.2 Storage Device**

## 10.2.1 GetStorageDeviceCollect

URL Syntax	http:// <ip>/cgi-bin/storageDevice.cgi?action=factory.getCollect</ip>
Comment	Get all the storage device names
Response	A list of all device names
	list[0]="/dev/sda0"
	list[1]="/dev/sda1"
	list[2]="/dev/sg1"

## 10.2.2 getDeviceAllInfo

URL Syntax	http:// <ip>/cgi-bin/storageDevice.cgi?action=getDeviceAllInfo</ip>
Comment	Get all the storage device infos
Response	list[0].Detail[0].lsError=false
	list[0].Detail[0].Pointer=27023434
	list[0].Detail[0].TotalBytes=0
	list[0].Detail[0].Type=ReadWrite
	list[0].Detail[0].UsedBytes=0
	list[0].Pointer=22347602
	list[0].State=Success

## 10.2.3 setStorageDevice

URL Syntax	http:// <ip>/cgi-bin/storageDevice.cgi?action=setDevice&amp;pointer=xxx&amp;type=xxx</ip>
Comment	Set to storage device wth the above condition. If set successfully, return true, else return false. type: Range is {Lock, UnLock,
	FormatPatition, UnMount }. pointer: The object Id is got from cgi API(cgi-bin/storageDevice.cgi?action=getDeviceAllInfo).If
	type is Lock or UnLock, pointer is list[0]. Detail[0]. Pointer, If If type is FormatPatition or UnMount, pointer is list[0]. Pointer.



Response	OK or Error:No SD Card
----------	------------------------

<sup>\*</sup>After formation operation, the device would reboot.

## **10.2.4** getCaps

URL Syntax	http:// <ip>/cgi-bin/storage.cgi?action=<b>getCaps</b></ip>	
Description	Get storage caps	
Response	caps.lsLocalStore= true	
	caps.IsRemoteStore=true	
	capsSupportRemoteLimit=false	
	see Storage Capabilities	

# 10.3 Work Group

## 10.3.1 GetWorkGroupCollect

URL Syntax	http:// <ip>/cgi-bin/workGroup.cgi?action=factory.getCollect</ip>
Comment	Get all the work group names
Response	A list of all device names
	list [0]="group1"
	list [1]="group2"
	list [2]="group3"

## 10.4 Work Directory

## 10.4.1 GetWorkDirectoryCollect

URL Syntax	http:// <ip>/cgi-bin/workDirectory.cgi?action=factory.getCollect</ip>
Comment	Get the all work derictory names
Response	A list of all work directory names
	list [0]="dir1"
	list [1]="dir2"
	list [2]="dir3"



## 10.5 NAS

# 10.5.1 GetNASConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=NAS</ip>
Comment	Return all the directories on the NAS server.
Response	table.NAS[0].Name=" FTP1"
	table.NAS[0].Enable = true
	table.NAS[0].Protocol ="FTP"
	table.NAS[0].Address ="www.Amcresttech.com"
	table.NAS[0].Port =21
	table.NAS[0].UserName ="anonymity"
	table.NAS[0].Password ="none"
	table.NAS[0].Directory ="share"

# 10.5.2 SetNASConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	below table:	
	Head =NAS[index]	
	Index: The index of the NAS Server	
Response	OK or ERROR	

ParamName	ParamValue type Description		
<i>Head</i> .Name	string	NAS name.	
<b>Head</b> .Enable	bool	Enable/Disable the NAS.	
<b>Head</b> . Protocol	string The range is {"FTP", "SMB"}		
<b>Head</b> . Address	string The IP address or host name.		
<b>Head</b> .Port	integer NAS port.		
<b>Head</b> .UserName	string NAS username.		
Head .Password	string	NAS password.	
Head .Directory	string Directory name.		



# **10.6 Storage Point**

# 10.6.1 GetRecordStoragePointConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=<b>RecordStoragePoint</b></ip>
Comment	
Response	table.RecordStoragePoint [0].TimingRecord.Local ="local"
	table.RecordStoragePoint [0].TimingRecord. Redundant =" Redundant"
	table.RecordStoragePoint [0].TimingRecord. Remote =" FTP"
	table.RecordStoragePoint [0].TimingRecord. AutoSync = false
	table.RecordStoragePoint [0].TimingRecord. AutoSyncRange =0
	table.RecordStoragePoint [0].TimingRecord. LocalForEmergency =false
	table.RecordStoragePoint [0].TimingRecord. CompressBefore =15

# 10.6.2 SetRecordStoragePointConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table:	
	ch = channel index,	
	recType :The range is {"TimingRecord"," VideoDetectRecord"," AlarmRecord"," EventRecord"," TimingSnapShot","	
	VideoDetectSnapShot"," AlarmSnapShot"," EventSnapShot"}	
Response	OK or Error	

ParamName	ParamValue type	Description
RecordStoragePoint [ch].[recType].Local	string	Local directory name.
RecordStoragePoint [ch].[recType]. Redundant	string	Redundant directory name.
RecordStoragePoint [ch].[recType]. Remote	string	Remote directory name.
RecordStoragePoint [ch].[recType]. AutoSync	bool	When remote directory recovers, auto synchronize local
		directory to remote directory or not.
RecordStoragePoint [ch].[recType]. AutoSyncRange	integer	From the remote directory recovering time, how long the
		data needs to be synchronized. The unit is hour. If it is 0, all
		the data needs to be synchronized.
RecordStoragePoint [ch].[recType]. LocalForEmergency	bool	When the remote directory is unusable, save the data the
		local directory or not.
RecordStoragePoint [ch].[recType]. CompressBefore	integer	How many days data will be compressed.



# 10.6.3 GetStorageGroupConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=StorageGroup</ip>
Comment	
Response	table.StorageGroup[0]. Name="ReadWrite"
	table.StorageGroup[0]. Memo =" For Reading & Writing Files"
	table.StorageGroup[0]. FileHoldTime =0
	table.StorageGroup[0]. OverWrite =true
	table.StorageGroup[0]. Channels[0]. MaxPictures =1000
	table.StorageGroup[0]. Channels[0]. Path ="/mnt/dvr/sda0"

## 10.6.4 SetStorageGroupConfig

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table:	
	Index = StorageGroup index	
	ch = channel index	
Response	OK or Error	

ParamName	ParamValue type	Description
StorageGroup[ <i>Index</i> ]. Name	string	Storage group name.
StorageGroup[ <i>Index</i> ]. Memo	string	Storage group memo.
StorageGroup[ <i>Index</i> ]. FileHoldTime	integer	How many days the file will be hold.
StorageGroup[ <i>Index</i> ]. OverWrite	bool	Over write or not when there is not enough storage.
StorageGroup[ <i>Index</i> ]. Channels[ <i>ch</i> ]. MaxPictures	Integer	The max pictures beyond which the old pictures will be over written. If it is 0, the old pictures will be not over written.
StorageGroup[ <i>Index</i> ]. Channels[ <i>ch</i> ]. Path	string	The channel path.

# 11. Audio

# 11.1 Audio MIME type

MIME	Description
Audio/PCM	
Audio/ADPCM	
Audio/G.711A	
Audio/G.711Mu	
Audio/G.726	
Audio/G.729	



Audio/MPEG2	
Audio/AMR	
Audio/AAC	

### 11.2 Post Audio

URL Syntax	http:// <ip>/cgi-bin/audio.cgi?action=postAudio&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>				
Comment	paramValue as below table.				
Response	OK or ERROR				

ParamName	ParamValue type	Description				
httptype	string	singlepart:HTTP content is a continuous flow of audi				
		packets				
		multipart:HTTP content type is				
		multipart/x-mixed-replace,and each audio packet ends				
		with a boundary string				
channel	integer	The audio channel				

### 11.2.1 Example for singlepart

The RUL of transmit a singlepart、channel 1 audio stream(encoded with G.711 A-law) is: http://<ip>/cgi-bin/audio.cgi?action=postAudio&httptype=singlepart&channel=1

example:

POST /cgi-bin/audio.cgi?action=postAudio&httptype=singlepart&channel=1 HTTP/1.1

Content-Type: Audio/G.711A Content-Length:9999999

<Audio data>

### 11.2.2 Example for multipart

The RUL of transmit a multipart channel 1 audio stream(encoded with G.711 A-law) is: http://<ip>/cgi-bin/audio.cgi?action=postAudio&httptype= multipart &channel=1

example:

POST /cgi-bin/audio.cgi?action=postAudio&httptype= multipart &channel=1 HTTP/1.1

Content-Type: multipart/x-mixed-replace; boundary=<boundary>

--<boundary>

Content-Type: Audio/G.711A



Content-Length: 800

<Audio data>

--<boundary>

#### 11.3 Get Audio

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/audio.cgi?action=getAudio& <paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname>					
Comment	paramValue as below table.					
Response	OK or ERROR					

ParamName	ParamValue type	Description				
httptype	string	singlepart:HTTP content is a continuous flow of audi				
		packets				
		multipart:HTTP content type is				
		multipart/x-mixed-replace,and each audio packet ends				
		with a boundary string				
channel	integer	The audio channel				

### 11.3.1 Example for singlepart

The RUL of Request a singlepart channel 1 audio stream(encoded with G.711 A-law) is:

http://<ip>/cgi-bin/audio.cgi?action=getAudio&httptype=singlepart&channel=1

If the request was successful, the server returns a continuous flow of audio packets. The content type is only set at the beginning of the connection.

Return:

HTTP Code: 200 OK

Content-Type: Audio/G.711A

Body:

<Audio data>

### 11.3.2 Example for multipart

The RUL of Request a multipart、channel 1 audio stream(encoded with G.711 A-law) is:

http://<ip>/cgi-bin/audio.cgi?action=getAudio&httptype=multipart&channel=1

If the request was successful, the server returns a continuous flow of audio packets. The content type is "multipart/x-mixed-replace" and each audio packet ends with a boundary string.



Return:

HTTP Code: 200 OK

Content-Type: multipart/x-mixed-replace; boundary=<boundary>

--<boundary>

Content-Type: Audio/G.711A

Content-Length: 800

<Audio data>

--<boundary>

## 11.4 Audio Input

### 11.4.1 getCollect

URL Syntax	http:// <ip>/cgi-bin/devAudioInput.cgi?action=<b>getCollect</b></ip>			
Comment	Get Audio input channel number.			
	Below response means there are 2 audio input channels.			
Response	result=2			

## 11.5 Audio Output

## 11.5.1 getCollect

URL Syntax	http:// <ip>/cgi-bin/devAudioOutput.cgi?action=<b>getCollect</b></ip>				
Comment	Get Audio output channel number.				
	Below response means there are 2 audio output channels.				
Response	result=2				

# 12. Appendix

### 12.1 Stream Format

The Stream format is used by 4.1.7 GetStream By Http and 4.1.8 Playback By Http, describes the format of the data stream. Stream Header:



Byte Order	0	1	2	3	4	5	6	7
Key	Fla	ag	Туре	reserved		packet	length	
Byte Order	8	9	10	11	12	13	14	15
Key	channel		Extend header length		Sequence			
			ien	gtn				
			ien	gtn				
Byte Order	16	17	18	<b>gtn</b> 19	20	21	22	23

Flag="DH";

Type=0x10 means the audio packet;

Type=0x20 means the video packet;

Packet length means the packet total length, contains the packet header, maybe one or more extend header, and the media data;

#### Extend Header Format

Key	Туре	len	gth	reserved		da	ıta	
Byte Order	0	1	2	3	4	5	6	

Extend header length must be multiple of 4 bytes;

#### Audio extend header:

Byte Order	0	1	2	3	4	5	6	7
Key	0x11	8	3	reserved	Audio Type	Tracks	Sample Freq	reserved

A audio packet must contain the audio extend header;

Audio Type:1 - PCM8;2 - G729;3 - IMA\_ADPCM;4 - G711U;5 - G721;6 - PCM8\_VWIS;7 - MS\_ADPCM;8 - G711A;9 - AMR-NB;10 - PCM16;11- G723.1;12 - AAC;13 - G726\_40;14 - G726\_32;15 - G726\_24;16 - G726\_16

Tracks: Tracks number, support 1 and 2;

Sample Freq: audio sample frequence, 1 - 4000; 2 - 8000; 3 - 11025; 4 - 16000; 5 - 20000; 6 - 22050; 7 - 32000; 8 - 44100; 9 - 48000;



#### Video Extend Header:

Byte Order	0	1	2	3	4	5	6	7
Key	0x21	16		reserved	Video Type	Frame Type	Wid	dth
Byte Order	8	9	10	11	12	13	14	15
Key	Hei	aht	I Frame Interval			rese	rved	

A video packet must contain the video extend header; Video Type means the video codec type, 1-MPEG4; 2-H.264; Frame Type: 1-I frame; 2-P frame; Width and Height describe the frame width and height by pixel;

#### Channel Title Extend Header:

Order Key	0 0x22	1 le	2	3 reserved	4	5	6 e ···	
Byte		4		0	4	-	•	

When a stream begin, or the device channel title changes, the video packet must contain the channel title extend header; If the channel title is Chinese, it only supports utf8 format.

#### TimeZone Extend Header:

Byte Order	0	1	2	3	4	5	6	7
Key	0x31	8	3	reserved	Time		Daylight saving time	reserved

When a stream begin, or the TimeZone changes, the video packet must contain the TimeZone extend header; Time Zone[0]: [-12,12](west time zone 12 to east time zone 12), Time Zone[1] modify the time by minutes; Daylight saving time: 1/0, yes or not in daylight saving time;

#### Event Flag Extend Header:

Key	0x23	le	en	reserved		Even	t Flag	
Byte Orde	. 0	1	2	3	4	5	6	

If the video frame contain one or more event flags, the video packet should contain the Event Flag Extend Header. The event flag means



what event had happened by set the bit as 1;

Event Flag: bit0-exterior alarm; bit1-move detect; bit2-video lost.

# 13. VideoInput

# 13.1 AdjustFocus

URL Syntax	http:// <ip>/cgi-bin/devVideoInput.cgi?action= adjustFocus&amp;focus=<focus>&amp;zoom=<zoom></zoom></focus></ip>			
Comment	ocus: float, the range is between 0 and 1; -1 means reset to position 0.			
	zoom: float, the range is between 0 and 1; -1 means reset to position 0.			
Response	OK or ERROR			

# 13.2 AdjustFocusContinuously

URL Syntax	http:// <ip>/cgi-bin/devVideoInput.cgi?action= adjustFocusContinuously&amp;focus=<focus>&amp;zoom=<zoom></zoom></focus></ip>
Comment	focus: float, the range is -1 < focus < 1; 0 means stop.
	zoom: float, the range is -1 < zoom< 1; 0 means stop.
	The value means the moving speed of motor lens, positive value means move forwards, negative value means move
	backwards. This command is used to drive the lens move continuously, until it reaches end. When motor is moving, and you
	send this command again with <i>focus</i> or <i>zoom</i> parameter as 0, the motor will stop immediately. In this command when you
	adjust the <b>focus</b> parameter, the <b>zoom</b> parameter should be -1, and the <b>focus</b> parameter should be -1 when adjust the <b>zoom</b>
	parameter.
Example	If we want to adjust focus, the API like this:
	http://172.30.1.100/cgi-bin/devVideoInput.cgi?action=adjustFocusContinuously&focus=0.02&zoom=-1
	and when the motor is moving, we send below command to let it stop:
	http://172.30.1.100/cgi-bin/devVideoInput.cgi?action=adjustFocusContinuously&focus=0&zoom=-1
Response	OK or ERROR

### 13.3 AutoFocus

URL Syntax	http:// <ip>/cgi-bin/devVideoInput.cgi?action= autoFocus</ip>
Comment	
Response	OK or ERROR



### 13.4 GetFocusStatus

URL Syntax	http:// <ip>/cgi-bin/devVideoInput.cgi?action= getFocusStatus</ip>
Comment	The range of status. Status is "Normal" and "Autofocus". This command must be continual executed until status. Status is
	"Normal".
Response	status.Focus=0.5
	status.Zoom=0.5
	status.Status=Normal

# 14. SD Camera

This chapter is only effective with SD Camera.

### 14.1 VideoInWhiteBalance

### 14.1.1 GetVideoInWhiteBalance

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInWhiteBalance</ip>
Description	Get VideoInWhiteBalance capabilities, channelNo is video in channel index.
Response	table.VideoInWhiteBalance[0][0].ColorTemperatureLevel=50
	table.VideoInWhiteBalance[0][0].GainBlue=50
	table.VideoInWhiteBalance[0][0].GainGreen=50
	table.VideoInWhiteBalance[0][0].GainRed=50
	table.VideoInWhiteBalance[0][0].Mode=ATW
	table.VideoInWhiteBalance[0][1].ColorTemperatureLevel=50
	table.VideoInWhiteBalance[0][1].GainBlue=50
	table.VideoInWhiteBalance[0][1].GainGreen=50
	table.VideoInWhiteBalance[0][1].GainRed=50
	table.VideoInWhiteBalance[0][1].Mode=Auto
	table.VideoInWhiteBalance[0][2].ColorTemperatureLevel=50
	table.VideoInWhiteBalance[0][2].GainBlue=50
	table.VideoInWhiteBalance[0][2].GainGreen=50
	table.VideoInWhiteBalance[0][2].GainRed=50
	table.VideoInWhiteBalance[0][2].Mode=Auto



## 14.2.2 SetVideoInWhiteBalance

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]
Comment	In below table, <i>head</i> =VideoInOptions[ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]
	ChannelNo = video channel index.
	ConfigNo=0,1,2; normal,day,night
Response	OK or ERROR

ParamName	ParamValue	Description
	type	
<i>head</i> . Mode	integer	"Auto", "Indoor", "Outdoor", "ATW", "Manual", "AutoOutdoor"
<i>head</i> . GainRed	integer	Range is 0-100
<i>head</i> . GainBlue	integer	Range is 0-100

# 14.2 VideoInExposure

# 14.2.1 GetVideoInExposure

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name= VideoInExposure</ip>
Description	
Response	table.VideoInExposure[0][0].AutoGainMax=2
	table.VideoInExposure[0][0].Backlight=0
	table.VideoInExposure[0][0].Compensation=7
	table.VideoInExposure[0][0].DoubleExposure=0
	table.VideoInExposure[0][0].Gain=1
	table.VideoInExposure[0][0].GlareInhibition=0
	table.VideoInExposure[0][0].Iris=10
	table.VideoInExposure[0][0].Mode=0
	table.VideoInExposure[0][0].RecoveryTime=900
	table.VideoInExposure[0][0].Rect[0]=0
	table.VideoInExposure[0][0].Rect[1]=0
	table.VideoInExposure[0][0].Rect[2]=0
	table.VideoInExposure[0][0].Rect[3]=0
	table.VideoInExposure[0][0].SlowAutoExposure=0
	table.VideoInExposure[0][0].SlowShutter=true
	table.VideoInExposure[0][0].SlowSpeed=25
	table.VideoInExposure[0][0].Speed=50

table.VideoInExposure[0][0].Value1=0.100000

table.VideoInExposure[0][0].Value2=80

table.VideoInExposure[0][0].WideDynamicRange=0

table.VideoInExposure[0][0].WideDynamicRangeMode=0

table.VideoInExposure[0][1].AutoGainMax=2

table.VideoInExposure[0][1].Backlight=0

table.VideoInExposure[0][1].Compensation=14

table.VideoInExposure[0][1].DoubleExposure=0

table.VideoInExposure[0][1].Gain=1

table.VideoInExposure[0][1].GlareInhibition=0

table.VideoInExposure[0][1].Iris=10

table.VideoInExposure[0][1].Mode=2

table. Video In Exposure [0] [1]. Recovery Time = 900

table.VideoInExposure[0][1].Rect[0]=0

table.VideoInExposure[0][1].Rect[1]=0

table.VideoInExposure[0][1].Rect[2]=0

table.VideoInExposure[0][1].Rect[3]=0

table.VideoInExposure[0][1].SlowAutoExposure=14

table. Video In Exposure [0] [1]. Slow Shutter = true

table.VideoInExposure[0][1].SlowSpeed=25

table.VideoInExposure[0][1].Speed=50

table.VideoInExposure[0][1].Value1=0.100000

table.VideoInExposure[0][1].Value2=80

table.VideoInExposure[0][1].WideDynamicRange=0

table. Video In Exposure [0] [1]. Wide Dynamic Range Mode = 0

table. Video In Exposure [0] [2]. Auto Gain Max = 2

table. Video In Exposure [0] [2]. Backlight = 0

table.VideoInExposure[0][2].Compensation=7

table.VideoInExposure[0][2].DoubleExposure=0

table.VideoInExposure[0][2].Gain=1

table. Video In Exposure [0] [2]. Glare Inhibition = 0

table.VideoInExposure[0][2].Iris=10

table. Video In Exposure [0] [2]. Mode = 0

table. Video In Exposure [0] [2]. Recovery Time = 900

table. VideoInExposure [0] [2]. Rect [0] = 0

table.VideoInExposure[0][2].Rect[1]=0

table.VideoInExposure[0][2].Rect[2]=0

table. Video In Exposure [0] [2]. Rect [3] = 0

table.VideoInExposure[0][2].SlowAutoExposure=0

table.VideoInExposure[0][2].SlowShutter=true

table.VideoInExposure[0][2].SlowSpeed=25

table. Video In Exposure [0] [2]. Speed = 50

table.VideoInExposure[0][2].Value1=0.100000

table.VideoInExposure[0][2].Value2=80



	table.VideoInExposure[0][2].WideDynamicRange=0 table.VideoInExposure[0][2].WideDynamicRangeMode=0	
Comment	In above table, <i>head</i> = table.VideoInOptions[ <i>ChannelNo</i> ]	
	ChannelNo = video channel index.	

## 14.2.2 SetVideoInExposure

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]	
Comment	In below table, <i>head</i> = VideoInExposure[ <i>ChannelNo</i> ][ConfigNo]	
	ChannelNo = video channel index.	
	ConfigNo=0,1,2; normal,day,night	
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
<i>head</i> .Mode	integer	Range is {0,2,3, 4}
		0: AutoExposure
		2: Gain first
		3: Exposure first
		4:Manual.
<i>head</i> .Gain	integer	Range is 0-15
<b>Head</b> .Iris	integer	Range is 0-17
<b>head</b> .Speed	integer	Range is [3,,3000]
<i>head</i> . Compensation	float	Range is [0-14],
<i>head</i> .SlowAutoExposure	float	Range is [0-15]
<b>head</b> .AutoGainMax	integer	Range is {0,1,2}
		0: low
		1: middle
		2: high
<i>head</i> .SlowShutter	integer	true: Enable SlowShutter
		false: Disable SlowShutter
<i>head</i> .SlowSpeed	integer	Range is {1,2,3,6,12,25}
		0:forbid flash
		1:always flash



		2:auto flash
<i>head</i> .RecoveryTime	integer	Range is {0,300,900, 3600, 7200}, Unit is second.
		0:close
<i>head</i> .WideDynamicRangeMode=1	integer	Range is [0,1]
		0 –disable,
		1 –enable
<i>head</i> .GlareInhibition	integer	Range is [0,1,2,3]
		0: disable
		1: low
		2: middle
		3: high
<b>head</b> .Backlight	bool	0: enable Backlight
		1: disable Backlight

# 14.3 VideoInDenoise

## 14.3.1 GetVideoInDenoise

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInDenoise</ip>
Description	
Response	table.VideoInDenoise[0][0].2DEnable=true
	table. VideoInDenoise [0] [0]. 2DLevel=8
	table. VideoInDenoise [0] [0]. 3DAutoType. AutoLevel=2
	table.VideoInDenoise[0][0].3DAutoType.Mod=8
	table.VideoInDenoise[0][0].3DManulType.SnfLevel=0
	table. VideoInDenoise [0] [0]. 3DM anul Type. Tnf Level = 0
	table.VideoInDenoise[0][0].3DType=Auto
	table.VideoInDenoise[0][1].2DEnable=true
	table.VideoInDenoise[0][1].2DLevel=8
	table.VideoInDenoise[0][1].3DAutoType.AutoLevel=2
	table.VideoInDenoise[0][1].3DAutoType.Mod=8
	table.VideoInDenoise[0][1].3DManulType.SnfLevel=0
	table.VideoInDenoise[0][1].3DManulType.TnfLevel=0
	table.VideoInDenoise[0][1].3DType=Auto
	table.VideoInDenoise[0][2].2DEnable=true
	table.VideoInDenoise[0][2].2DLevel=8
	table. VideoInDenoise [0] [2]. 3DAutoType. AutoLevel=2
	table.VideoInDenoise[0][2].3DAutoType.Mod=8
	table.VideoInDenoise[0][2].3DManulType.SnfLevel=0
	table. VideoInDenoise [0] [2]. 3DManul Type. Tnf Level = 0
	table.VideoInDenoise[0][2].3DType=Auto



### 14.3.2 SetVideoInDenoise

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table, <i>head</i> = VideoInDenoise [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]	
	ChannelNo = video channel index.	
	ConfigNo=0,1,2; normal,day,night	
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
head.2DEnable	integer	true: Enable 2D Denoise
		false: Disable 2D Denoise
head.2DLevel	integer	Range is 1-5
<i>head</i> .3DType	String	"Off"
		"Auto"
<b>head</b> .3DAutoType.Mode	integer	Range is 0-1

# 14.4 VideoInDayNight

# 14.4.1 GetVideoInDayNight

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInDayNight</ip>
Description	
Response	table.VideoInDayNight[0][0].BCRDelay=10
	table.VideoInDayNight[0][0].ICRDelay=10
	table.VideoInDayNight[0][0].Mode=Brightness
	table.VideoInDayNight[0][0].Sensitivity=4
	table.VideoInDayNight[0][0].Type=Electron
	table.VideoInDayNight[0][1].BCRDelay=10
	table.VideoInDayNight[0][1].ICRDelay=10
	table.VideoInDayNight[0][1].Mode=BlackWhite
	table.VideoInDayNight[0][1].Sensitivity=4
	table.VideoInDayNight[0][1].Type=Electron
	table.VideoInDayNight[0][2].BCRDelay=10
	table.VideoInDayNight[0][2].ICRDelay=10



table.VideoInDayNight[0][2].Mode=BlackWhite
table.VideoInDayNight[0][2].Sensitivity=4
table.VideoInDayNight[0][2].Type=Electron

# 14.4.2 SetVideoInDayNight

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]	
Comment	In below table, <i>head</i> = VideoInDayNight [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]	
	ChannelNo = video channel index.	
	ConfigNo=0,1,2; normal,day,night	
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
<b>head</b> . Type	integer	Electron:
		Mechanism:
<i>head</i> . Mode	integer	Auto、Color、BlackWhite
<i>head</i> . Sensitivity	integer	Range is 0-7

## 14.5 VideoInFocus

### 14.5.1 GetVideoInFocus

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInDayNight</ip>
Description	
Response	table.VideoInFocus[0][0].FocusLimit=100
	table.VideoInFocus[0][0].FocusLimitSelectMode=Manual
	table.VideoInFocus[0][0].IRCorrection=0
	table.VideoInFocus[0][0].Mode=3
	table.VideoInFocus[0][0].Sensitivity=1
	table.VideoInFocus[0][1].FocusLimit=100
	table.VideoInFocus[0][1].FocusLimitSelectMode=Manual
	table.VideoInFocus[0][1].IRCorrection=0
	table.VideoInFocus[0][1].Mode=3
	table.VideoInFocus[0][1].Sensitivity=1
	table.VideoInFocus[0][2].FocusLimit=100
	table.VideoInFocus[0][2].FocusLimitSelectMode=Manual



table.VideoInFocus[0][2].IRCorrection=0
table.VideoInFocus[0][2].Mode=3
table.VideoInFocus[0][2].Sensitivity=1

### 14.5.2 SetVideoInFocus

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>			
Comment	In below table, <i>head</i> = VideoInDayNight [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]			
	ChannelNo = video channel index.			
	ConfigNo=0,1,2; normal,day,night			
Response	OK or ERROR			

ParamName	ParamValue	Description
	type	
<i>head</i> . Mode	integer	2-Auto focus, 3-Half auto focus, 4-Manual focus
<i>head</i> . FocusLimit	integer	100、1000、2000、3000、5000、
<i>head</i> . Sensitivity	integer	Range is 0,1,2
		0-high,1-default,2-low
head. IRCorrection	integer	0 : No correcetion; 1: Correction; 2:Auto correction

## 14.6 VideoInZoom

### 14.6.1 GetVideoInZoom

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInZoom</ip>
Description	
Response	table.VideoInZoom[0][0].DigitalZoom=true
	table.VideoInZoom[0][0].Speed=7
	table.VideoInZoom[0][0].ZoomLimit=4
	table.VideoInZoom[0][1].DigitalZoom=true
	table.VideoInZoom[0][1].Speed=0
	table.VideoInZoom[0][1].ZoomLimit=4
	table.VideoInZoom[0][2].DigitalZoom=false
	table.VideoInZoom[0][2].Speed=7
	table.VideoInZoom[0][2].ZoomLimit=4



### 14.6.2 SetVideoInZoom

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table, <i>head</i> = VideoInZoom [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]	
	ChannelNo = video channel index.	
	ConfigNo=0,1,2; normal,day,night	
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
<i>head</i> . DigitalZoom	integer	true: Enable DigitalZoom
		false: Disable DigitalZoom
<i>head</i> . Speed	integer	Range is 0-7

# 14.7 VideoInSharpness

# 14.7.1 GetVideoInSharpness

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInSharpness</ip>		
Description			
Response	table.VideoInSharpness[0][0].Level=4		
	table.VideoInSharpness[0][0].Mode=1		
	table.VideoInSharpness[0][0].Sharpness=8		
	table.VideoInSharpness[0][1].Level=4		
	table.VideoInSharpness[0][1].Mode=1		
	table.VideoInSharpness[0][1].Sharpness=8		
	table.VideoInSharpness[0][2].Level=4		
	table.VideoInSharpness[0][2].Mode=1		
	table.VideoInSharpness[0][2].Sharpness=8		

# 14.7.2 SetVideoInSharpness

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>	
Comment	In below table, <i>head</i> = VideoInSharpness [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]	
	ChannelNo = video channel index.	



	ConfigNo=0,1,2; normal,day,night
Response	OK or ERROR

ParamName	ParamValue	Description
	type	
head. Sharpness	integer	Range is 0-15
<i>head</i> . Level	integer	Range is 0-15

## 14.8 VideoInColor

## 14.8.1 GetVideoInColor

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInColor</ip>	
Description		
Response	table.VideoInColor[0][0].Brightness=50	
	table.VideoInColor[0][0].ChromaSuppress=1	
	table.VideoInColor[0][0].Contrast=50	
	table.VideoInColor[0][0].Gamma=0	
	table.VideoInColor[0][0].Hue=50	
	table.VideoInColor[0][0].Saturation=50	
	table.VideoInColor[0][0].Style=Standard	
	table.VideoInColor[0][1].Brightness=50	
	table.VideoInColor[0][1].ChromaSuppress=1	
	table.VideoInColor[0][1].Contrast=50	
	table.VideoInColor[0][1].Gamma=0	
	table.VideoInColor[0][1].Hue=50	
	table.VideoInColor[0][1].Saturation=50	
	table.VideoInColor[0][1].Style=Standard	
	table.VideoInColor[0][2].Brightness=50	
	table.VideoInColor[0][2].ChromaSuppress=1	
	table.VideoInColor[0][2].Contrast=50	
	table.VideoInColor[0][2].Gamma=0	
	table.VideoInColor[0][2].Hue=50	
	table.VideoInColor[0][2].Saturation=50	
	table.VideoInColor[0][2].Style=Flamboyant	



## 14.8.2 SetVideoInColor

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]	
Comment	In below table, <i>head</i> = VideoInColor [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]	
	ChannelNo = video channel index.	
	ConfigNo=0,1,2; normal,day,night	
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
<i>head</i> . Style	integer	Gentle
		Standard
		Flamboyant
<i>head</i> . Hue	integer	Range is 0-100
<i>head</i> . Brightness	integer	Range is 0-100
head. Saturation		Range is 0-100
<i>head</i> . ChromaSuppress		Range is 0-3
<i>head</i> . Gamma		Range is 0-15

## 14.9 VideoInRotate

### 14.9.1 GetVideoInRotate

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInRotate</ip>
Description	
Response	table.VideoInRotate[0][0].Flip=false
	table.VideoInRotate[0][0].Freeze=false
	table.VideoInRotate[0][0].Mirror=false
	table.VideoInRotate[0][0].Rotate90=0
	table.VideoInRotate[0][0].Stable=false
	table.VideoInRotate[0][1].Flip=false
	table.VideoInRotate[0][1].Freeze=false
	table.VideoInRotate[0][1].Mirror=false
	table.VideoInRotate[0][1].Rotate90=0



_	
	table.VideoInRotate[0][1].Stable=false
	table.VideoInRotate[0][2].Flip=false
	table.VideoInRotate[0][2].Freeze=false
	table.VideoInRotate[0][2].Mirror=false
	table.VideoInRotate[0][2].Rotate90=0
	table.VideoInRotate[0][2].Stable=false

### 14.9.2 SetVideoInRotate

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]	
Comment	In below table, <i>head</i> = VideoInRotate [ <i>ChannelNo</i> ] [ <i>ConfigNo</i> ]	
	ChannelNo = video channel index.	
	ConfigNo=0,1,2; normal,day,night	
Response	OK or ERROR	

ParamName	ParamValue	Description
	type	
<i>head</i> . Flip	integer	true: Enable flip function
		false: Disable flip function

## 14.10 VideoInMode

### 14.10.1 GetVideoInMode

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoInMode</ip>
Description	
Response	table.VideoInMode[0].Config[0]=1
	table.VideoInMode[0].Mode=0
	table.VideoInMode[0].TimeSection[0][0]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[0][1]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[0][2]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[0][3]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[0][4]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[0][5]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[1][0]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[1][1]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[1][2]=0 00:00:00-23:59:59
	table.VideoInMode[0].TimeSection[1][3]=0 00:00:00-23:59:59



table.VideoInMode[0].TimeSection[1][4]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[1][5]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[2][0]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[2][1]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[2][2]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[2][3]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[2][4]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[2][5]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[3][0]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[3][1]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[3][2]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[3][3]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[3][4]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[3][5]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[4][0]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[4][1]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[4][2]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[4][3]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[4][4]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[4][5]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[5][0]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[5][1]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[5][2]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[5][3]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[5][4]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[5][5]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[6][0]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[6][1]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[6][2]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[6][3]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[6][4]=0 00:00:00-23:59:59 table.VideoInMode[0].TimeSection[6][5]=0 00:00:00-23:59:59

### 14.10.2 SetVideoInMode

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	In below table, <i>head</i> = VideoInMode [ <i>ChannelNo</i> ]  ChannelNo = video channel index.
Response	OK or ERROR

ParamName ParamValu	Description
---------------------	-------------



	type	
<i>head</i> . Mode	integer	Range is {0,1}
		0: NoSwitch;
		1: Switch depends on <i>head</i> .TimeSection.
<i>head</i> . Config	integer	Mode=0 Config[0]={0 \ 1/2}
		Mode=1 Config[1]={ 1 }
		Config[2]={ 2 }
head.TimeSection[0][0]	integer	The time format is "0 H:m: H:m:S "
		For example: 0 00:00:00-10:59:59

# 15. VideoAnalyse

This chapter is only effective with smart IP Camera.

# 15.1 VideoAnalyseRule

# 15.1.1 GetVideoAnalyseRule

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoAnalyseRule</ip>		
Description	Get VideoAnalyseRule.		
	In below table, <i>head</i> =table.VideoAnalyseRule[ <i>ChannelNo</i> ] [ <i>RuleNo</i> ]		
	ChannelNo = video channel index.		
	RuleNo =rule index.		
Response	head.Name= line1		
	<i>head.</i> Type=CrossLineDetection		
	head.VideoAnalyseRule[0][0].Enable =true		
	head. Video Analyse Rule [0] [0]. Event Handler = (output of Event Handler is described in 6.1.1 Get Event Handler)		
1			

## 15.1.2 SetVideoAnalyseRule

URL Syntax	http:// <i><ip></ip></i> /cgi-bin/configManager.cgi?action=setConfig&< <i>paramName</i> >=< <i>paramValue</i> >[&< <i>paramName</i> >=< <i>paramValue</i> >]	
Comment	In below table, <i>head</i> =VideoAnalyseRule[ <i>ChannelNo</i> ] [ <i>RuleNo</i> ]	
	ChannelNo = video channel index.	
	RuleNo =rule index.	
	ParamName starts with <i>head</i> .Config is only effective with {"CrossLineDetection", "CrossRegionDetection", "LeftDetection",	
	"TakenAwayDetection"}	
Response	OK or ERROR	



ParamName	ParamValue	Description
	type	
<i>head</i> .Name	string	Rule name, it must be unique.
<b>head.</b> Type	string	The range is {"CrossLineDetection", "CrossRegionDetection", "LeftDetection","
		"TakenAwayDetection","VideoAbnormalDetection","FaceDetection",
		,"AudioMutation","AudioAnomaly","VideoUnFocus","WanderDetection","
		RioterDetection"," ParkingDetection"," MoveDetection", "NumberStat"}"
<i>head</i> .Enable	bool	Enable/Disable this rule
<i>head</i> .EventHandler		Setting of EventHandler is described in <u>6.1.2 SetEventHandler</u>
head.Config.DetectLine[0][0]	integer	The start point of DetectLine 0;
<i>head</i> .Config.DetectLine[0][1]	integer	The end point of DetectLine 0;
head.Config.DetectLine[1][0]	integer	The start point of DetectLine 1;
head.Config.DetectLine[1][1]	integer	The end point of DetectLine 1;
<i>head</i> .Config.Direction	string	The range is {"LeftToRight", "RightToLeft", "Both"}
<b>head</b> .Config .SizeFilter.MaxSize[0]	integer	Maximum width. The width of the object must not be beyond maximum width.
		Adapt to {"CrossLineDetection", "CrossRegionDetection", "LeftDetection",
		"TakenAwayDetection", "FaceDetection", "WanderDetection", "RioterDetection",
		"ParkingDetection", "MoveDetection"}
<b>head</b> .Config .SizeFilter.MaxSize[1]	integer	Maximum height. The height of the object must not be beyond maximum height.
<b>head</b> .Config .SizeFilter.MinSize[0]	integer	Minimum width. The width of the object must not be less than minimum width.
<b>head</b> .Config .SizeFilter.MinSize[1]	integer	Minimum height. The height of the object must not be beyond minimum height.
<b>head</b> .Config.DetectRegion[0][0]	integer	The start point of DetectRegion 0;
		Adapt to {"CrossRegionDetection", "LeftDetection", "TakenAwayDetection",
		"WanderDetection", "RioterDetection", "ParkingDetection", "MoveDetection"}
head.Config.DetectRegion[0][1]	integer	The end point of DetectRegion 0;
<b>head</b> .Config.DetectRegion[1][0]	integer	The start point of DetectRegion 1;
head.Config.DetectRegion[1][1]	integer	The end point of DetectRegion 1;
head.Config.DetectRegion[2][0]	integer	The start point of DetectRegion 2;
head.Config.DetectRegion[2][1]	integer	The start point of DetectRegion 2;
head.Config. MinDuration	integer	Range is 1-600, adapt to {"LeftDetection", "TakenAwayDetection",
		"WanderDetection"}.
		Range is 10-300, adapt to {"RioterDetection"}.
		Range is 6-300, adapt to {"ParkingDetection"}.
<i>head</i> .Config. Sensitivity	integer	Range is 1-10, adapt to {"RioterDetection", "MoveDetection"}.
<i>Head</i> .Config. EnterThreshold	integer	Range is 0- 100000000, adapt to {"NumberStat"}.
<i>Head</i> .Config. ExitThreshold	integer	Range is 0- 100000000, adapt to {"NumberStat"}.
<i>Head</i> .Config. InsideThreshold	integer	Range is 0- 100000000, adapt to {"NumberStat"}.



# ${\bf 15.2\ VideoWidgetNumberStat}$

# 15.2.1 GetVideoWidgetNumberStat

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoWidgetNumberStat</ip>	
Description	Get VideoWidgetNumberStat.	
	In below table, <i>head</i> =table.VideoWidgetNumberStat[ <i>ChannelNo</i> ]	
	ChannelNo = video channel index.	
Response	<i>head</i> .EncodeBlend=true	
	<i>head.</i> ShowEnterNum=true	
	<i>head</i> .ShowExitNum=true	
	<i>head</i> .TextAlign=0	

## 15.2.2 SetVideoWidgetNumberStat

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	In below table, <i>head</i> =VideoWidgetNumberStat[ <i>ChannelNo</i> ]
	ChannelNo = video channel index.
Response	OK or ERROR

ParamName	ParamValue	Description
	type	
<i>head</i> .EncodeBlend	bool	Enable/Disable
<i>head.</i> ShowEnterNum	bool	Enable/Disable
<i>head</i> .ShowExitNum	bool	Enable/Disable
<i>head</i> .TextAlign	integer	0 for left, 2 for right

### 15.3 VideoEncodeROI

### 15.3.1 GetVideoEncodeROI

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=getConfig&amp;name=VideoEncodeROI</ip>	
Description	Get VideoEncodeROI.	
	In below table, <i>head</i> =table.VideoEncodeROI[ <i>ChannelNo</i> ]	
	ChannelNo = video channel index.	
Response	onse Head. DynamicTrack=false	



### 15.3.2 SetVideoEncodeROI

URL Syntax	http:// <ip>/cgi-bin/configManager.cgi?action=setConfig&amp;<paramname>=<paramvalue>[&amp;<paramname>=<paramvalue>]</paramvalue></paramname></paramvalue></paramname></ip>
Comment	In below table, <i>head</i> =VideoEncodeROI[ <i>ChannelNo</i> ]
	ChannelNo = video channel index.
Response	OK or ERROR

ParamName	ParamValue	Description
	type	
<i>head</i> .DynamicTrack	bool	Enable/Disable



# 16 TrafficSnap

# 16.1 getParkingSpaceStatus

URL	http:// <i><ip></ip></i> /cgi-bin/trafficSnap.cgi?action=getParkingSpaceStatus&channel=< <i>channelNo</i> >& <paramname>=<paramvalue>[&amp;<pa< th=""></pa<></paramvalue></paramname>	
Syntax	ramName>= <paramvalue>]</paramvalue>	
Descripti	Get specific parking space(s) status	
on	For example If want to get all parking space status, the url is	
	http:// <ip>/cgi-bin/trafficSnap.cgi?action=getParkingSpaceStatus&amp; condition.Lane[0]=0 &amp; condition.Lane[1]=255</ip>	
Response	A list of parking space status	
	status[0].Lane=0	
	status[0].PictureId=5	
	status[0]. TrafficCar. CountInGroup=1	
	<del></del>	
	status[1].Lane=1	
	status[1].PictureId=4	
	status[1]. <i>TrafficCar</i> . CountInGroup=1	
Comment	Param :	
	channelNo : the index of trafficSnap channel	
	<i>index</i> : The index of type array,start from 0	
	<i>TrafficCar</i> : the members refer to <u>TrafficCar</u>	

ParamName	ParamValue type	Description
condition.Lane[index]	int	The Lane value
condition. ResponseLevel	int	The Level value , refer to <u>conditon</u>

# 17 TrafficParking

# ${\bf 17.1\ get All Parking Space Status}$

URL	http:// <ip>/cgi-bin/ trafficParking.cgi?action= getAllParkingSpaceStatus</ip>
Syntax	
Descripti	Get all valid parking spaces status of one device
on	For example If want to get all parking space status, the url is
	http:// <ip>/cgi-bin/trafficParking.cgi?action=getAllParkingSpaceStatus</ip>



Response	A list of parking space status
	status[0].Lane=0
	status[0]. <i>Status</i> = Park
	status[1].Lane=1
	status[1]. <i>Status</i> = NoPark
Comment	Param :
	Status: Park or NoPark

# **17 VideoDetect**

# 17.1 getCaps

URL Syntax	http:// <ip>/cgi-bin/devVideoDetect.cgi?action=getCaps&amp;channel=<channelno></channelno></ip>
Response	caps.DetectVersion[0]=V1.0
	caps.DetectVersion[1]=V3.0
	caps.MotionColumns=22
	caps.MotionDetectWindow=4
	caps.MotionLinkPtzPattern=true
	caps.MotionLinkPtzPreset=true
	caps.MotionLinkPtzTour=true
	caps.MotionResult=1
	caps.MotionRows=18
	caps.SupportBlind=1
	caps.SupportLoss=0
	caps.SupportMotion=1
Comment	Get video detect capabilities, <i>channelNo</i> is video in channel index. Notice that When your device is using V1.0
	V2.0 Motion detection, you can not get any reply while excuting the command.