```
/* USER CODE BEGIN Header */
* @file
        : main.c
* @brief : Main program body
* @attention
* Copyright (c) 2023 STMicroelectronics.
* All rights reserved.
* This software is licensed under terms that can be found in the LICENSE file
* in the root directory of this software component.
* If no LICENSE file comes with this software, it is provided AS-IS.
/* USER CODE END Header */
/* Includes -----*/
#include "main.h"
/* Private includes -----*/
/* USER CODE BEGIN Includes */
#include <stdio.h>
#include "stm32f0xx.h"
#include <lcd stm32f0.c>
/* USER CODE END Includes */
/* Private typedef -----*/
/* USER CODE BEGIN PTD */
/* USER CODE END PTD */
/* Private define -----*/
/* USER CODE BEGIN PD */
// TODO: Add values for below variables
#define NS 128 // Number of samples in LUT
#define TIM2CLK 8000000 // STM Clock frequency
#define F_SIGNAL 50 // Frequency of output analog signal
/* USER CODE END PD */
/* Private macro -----*/
/* USER CODE BEGIN PM */
```

/* USER CODE END PM */

/* Private variables -----*/
TIM_HandleTypeDef htim2;
TIM_HandleTypeDef htim3;
DMA HandleTypeDef hdma tim2 ch1;

/* USER CODE BEGIN PV */

// TODO: Add code for global variables, including LUTs uint8_t waveForm = 0; uint32 t prevTick = 0;

//These are Time on for the PWM, this will become the CCR values of the PWM uint32_t Sin_LUT[NS] =

{512,486,461,436,412,387,363,339,316,293,270,249,227,207,187,168,150,133,116,101,86,73,6 0,49,39,30,22,15,10,6,2,1,0,1,2,6,10,15,22,30,39,49,60,73,86,101,116,133,150,168,187,207,22 7,249,270,293,316,339,363,387,412,436,461,486,512,537,562,587,611,636,660,684,707,730,7 53,774,796,816,836,855,873,890,907,922,937,950,963,974,984,993,1001,1008,1013,1017,102 1,1022,1023,1022,1021,1017,1013,1008,1001,993,984,974,963,950,937,922,907,890,873,855,836,816,796,774,753,730,707,684,660,636,611,587,562,537};

uint32 t saw LUT[NS] =

 $\{0,8,16,24,32,40,48,56,64,72,80,88,96,104,112,120,128,136,144,152,160,168,176,184,192,200,208,216,224,232,240,248,256,264,272,280,288,296,304,312,320,328,336,344,352,360,368,376,384,392,400,408,416,424,432,440,448,456,464,472,480,488,496,504,512,519,527,535,543,551,559,567,575,583,591,599,607,615,623,631,639,647,655,663,671,679,687,695,703,711,719,727,735,743,751,759,767,775,783,791,799,807,815,823,831,839,847,855,863,871,879,887,895,903,911,919,927,935,943,951,959,967,975,983,991,999,1007,1015\};$

uint32_t triangle_LUT[NS] =

 $\{0,16,32,48,64,80,96,112,128,144,160,176,192,208,224,240,256,272,288,304,320,336,352,368,384,400,416,432,448,464,480,496,512,527,543,559,575,591,607,623,639,655,671,687,703,719,735,751,767,783,799,815,831,847,863,879,895,911,927,943,959,975,991,1007,1023,943,927,911,895,879,863,847,831,815,799,783,767,751,735,719,703,687,671,655,639,623,607,591,575,559,543,527,511,495,479,463,447,431,416,400,384,368,352,336,320,304,288,272,256,240,224,208,192,176,160,144,128,112,96,80,64,48,32,16\};$

// TODO: Equation to calculate TIM2 Ticks

uint32_t TIM2_Ticks = (int)round(TIM2CLK/(F_SIGNAL*NS)); // How often to write new LUT value

uint32_t DestAddress = (uint32_t) &(TIM3->CCR3); // Write LUT TO TIM3->CCR3 to modify PWM duty cycle

```
/* USER CODE END PV */
/* Private function prototypes -----*/
void SystemClock_Config(void);
static void MX_GPIO_Init(void);
static void MX_DMA_Init(void);
static void MX_TIM2_Init(void);
static void MX_TIM3_Init(void);
/* USER CODE BEGIN PFP */
void EXTI0_1_IRQHandler(void);
/* USER CODE END PFP */
/* Private user code -----*/
/* USER CODE BEGIN 0 */
/* USER CODE END 0 */
 * @brief The application entry point.
 * @retval int
 */
int main(void)
 /* USER CODE BEGIN 1 */
/* USER CODE END 1 */
 /* MCU Configuration-----*/
 /* Reset of all peripherals, Initializes the Flash interface and the Systick. */
 HAL_Init();
 /* USER CODE BEGIN Init */
 init LCD();
 /* USER CODE END Init */
 /* Configure the system clock */
 SystemClock_Config();
 /* USER CODE BEGIN SysInit */
 /* USER CODE END SysInit */
 /* Initialize all configured peripherals */
 MX GPIO Init();
```

```
MX DMA Init();
 MX_TIM2_Init();
 MX TIM3 Init();
 /* USER CODE BEGIN 2 */
 // TODO: Start TIM3 in PWM mode on channel 3
 HAL TIM PWM Start(&htim3, TIM CHANNEL 3); // Start PWM on TIM3 Channel 3
 // TODO: Start TIM2 in Output Compare (OC) mode on channel 1.
 HAL TIM OC Start(&htim2, TIM CHANNEL 1);
 // TODO: Start DMA in IT mode on TIM2->CH1; Source is LUT and Dest is TIM3->CCR3; start
with Sine LUT
 HAL_DMA_Start_IT(&hdma_tim2_ch1,(uint32_t)Sin_LUT,DestAddress, NS);
 // TODO: Write current waveform to LCD ("Sine")
 lcd command(CLEAR);
 lcd putstring("Sine");
 delay(3000);
// TODO: Enable DMA (start transfer from LUT to CCR)
 __HAL_TIM_ENABLE_DMA(&htim2,TIM_DMA_CC1);
/* USER CODE END 2 */
/* Infinite loop */
/* USER CODE BEGIN WHILE */
 while (1)
  /* USER CODE END WHILE */
 /* USER CODE BEGIN 3 */
/* USER CODE END 3 */
 * @brief System Clock Configuration
 * @retval None
void SystemClock Config(void)
 LL FLASH SetLatency(LL FLASH LATENCY 0);
 while(LL_FLASH_GetLatency() != LL_FLASH_LATENCY_0)
```

```
{
 LL_RCC_HSI_Enable();
 /* Wait till HSI is ready */
 while(LL_RCC_HSI_IsReady() != 1)
 {
 LL RCC HSI SetCalibTrimming(16);
 LL_RCC_SetAHBPrescaler(LL_RCC_SYSCLK_DIV_1);
 LL_RCC_SetAPB1Prescaler(LL_RCC_APB1_DIV_1);
 LL_RCC_SetSysClkSource(LL_RCC_SYS_CLKSOURCE_HSI);
 /* Wait till System clock is ready */
 while(LL_RCC_GetSysClkSource() != LL_RCC_SYS_CLKSOURCE_STATUS_HSI)
 {
 LL_SetSystemCoreClock(8000000);
 /* Update the time base */
 if (HAL_InitTick (TICK_INT_PRIORITY) != HAL_OK)
  Error_Handler();
 }
}
 * @brief TIM2 Initialization Function
 * @param None
 * @retval None
static void MX_TIM2_Init(void)
{
/* USER CODE BEGIN TIM2_Init 0 */
 /* USER CODE END TIM2_Init 0 */
 TIM ClockConfigTypeDef sClockSourceConfig = {0};
 TIM_MasterConfigTypeDef sMasterConfig = {0};
 TIM_OC_InitTypeDef sConfigOC = {0};
```

```
/* USER CODE BEGIN TIM2 Init 1 */
 /* USER CODE END TIM2 Init 1 */
 htim2.Instance = TIM2;
 htim2.Init.Prescaler = 0;
 htim2.Init.CounterMode = TIM COUNTERMODE UP;
 htim2.Init.Period = TIM2 Ticks - 1;
 htim2.Init.ClockDivision = TIM CLOCKDIVISION DIV1;
 htim2.Init.AutoReloadPreload = TIM_AUTORELOAD_PRELOAD_ENABLE;
 if (HAL TIM Base Init(&htim2) != HAL OK)
  Error_Handler();
 sClockSourceConfig.ClockSource = TIM_CLOCKSOURCE_INTERNAL;
 if (HAL TIM ConfigClockSource(&htim2, &sClockSourceConfig) != HAL OK)
 {
  Error_Handler();
 if (HAL_TIM_OC_Init(&htim2) != HAL_OK)
  Error_Handler();
 sMasterConfig.MasterOutputTrigger = TIM TRGO RESET;
 sMasterConfig.MasterSlaveMode = TIM MASTERSLAVEMODE DISABLE;
 if (HAL_TIMEx_MasterConfigSynchronization(&htim2, &sMasterConfig) != HAL_OK)
  Error_Handler();
 sConfigOC.OCMode = TIM_OCMODE_TIMING;
 sConfigOC.Pulse = 0;
 sConfigOC.OCPolarity = TIM_OCPOLARITY_HIGH;
 sConfigOC.OCFastMode = TIM OCFAST DISABLE;
 if (HAL_TIM_OC_ConfigChannel(&htim2, &sConfigOC, TIM_CHANNEL_1) != HAL_OK)
  Error_Handler();
 /* USER CODE BEGIN TIM2_Init 2 */
/* USER CODE END TIM2_Init 2 */
}
 * @brief TIM3 Initialization Function
```

```
* @param None
 * @retval None
static void MX_TIM3_Init(void)
/* USER CODE BEGIN TIM3 Init 0 */
 /* USER CODE END TIM3 Init 0 */
 TIM ClockConfigTypeDef sClockSourceConfig = {0};
 TIM_MasterConfigTypeDef sMasterConfig = {0};
 TIM OC InitTypeDef sConfigOC = {0};
 /* USER CODE BEGIN TIM3 Init 1 */
/* USER CODE END TIM3_Init 1 */
 htim3.Instance = TIM3;
 htim3.Init.Prescaler = 0;
 htim3.Init.CounterMode = TIM_COUNTERMODE_UP;
 htim3.Init.Period = 1023;
 htim3.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
 htim3.Init.AutoReloadPreload = TIM AUTORELOAD PRELOAD ENABLE;
 if (HAL TIM Base Init(&htim3) != HAL OK)
 {
  Error_Handler();
 sClockSourceConfig.ClockSource = TIM CLOCKSOURCE INTERNAL;
 if (HAL_TIM_ConfigClockSource(&htim3, &sClockSourceConfig) != HAL_OK)
  Error_Handler();
 if (HAL_TIM_PWM_Init(&htim3) != HAL_OK)
  Error_Handler();
 sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;
 sMasterConfig.MasterSlaveMode = TIM MASTERSLAVEMODE DISABLE;
 if (HAL_TIMEx_MasterConfigSynchronization(&htim3, &sMasterConfig) != HAL_OK)
 {
  Error Handler();
 sConfigOC.OCMode = TIM OCMODE PWM1;
 sConfigOC.Pulse = 0;
```

```
sConfigOC.OCPolarity = TIM OCPOLARITY HIGH;
 sConfigOC.OCFastMode = TIM_OCFAST_DISABLE;
 if (HAL TIM PWM ConfigChannel(&htim3, &sConfigOC, TIM CHANNEL 3) != HAL OK)
 {
  Error_Handler();
 /* USER CODE BEGIN TIM3 Init 2 */
 /* USER CODE END TIM3 Init 2 */
 HAL TIM MspPostInit(&htim3);
}
/**
 * Enable DMA controller clock
static void MX_DMA_Init(void)
 /* DMA controller clock enable */
 __HAL_RCC_DMA1_CLK_ENABLE();
 /* DMA interrupt init */
 /* DMA1 Channel4 5 IRQn interrupt configuration */
 HAL_NVIC_SetPriority(DMA1_Channel4_5_IRQn, 0, 0);
 HAL NVIC EnableIRQ(DMA1 Channel4 5 IRQn);
}
 * @brief GPIO Initialization Function
 * @param None
 * @retval None
static void MX GPIO Init(void)
 LL_EXTI_InitTypeDef EXTI_InitStruct = {0};
/* USER CODE BEGIN MX GPIO Init 1 */
/* USER CODE END MX_GPIO_Init_1 */
 /* GPIO Ports Clock Enable */
 LL_AHB1_GRP1_EnableClock(LL_AHB1_GRP1_PERIPH_GPIOF);
 LL AHB1 GRP1 EnableClock(LL AHB1 GRP1 PERIPH GPIOA);
 LL_AHB1_GRP1_EnableClock(LL_AHB1_GRP1_PERIPH_GPIOB);
```

```
/**/
 LL_SYSCFG_SetEXTISource(LL_SYSCFG_EXTI_PORTA, LL_SYSCFG_EXTI_LINE0);
 /**/
 LL_GPIO_SetPinPull(Button0_GPIO_Port, Button0_Pin, LL_GPIO_PULL_UP);
 /**/
 LL_GPIO_SetPinMode(Button0_GPIO_Port, Button0_Pin, LL_GPIO_MODE_INPUT);
 /**/
 EXTI_InitStruct.Line_0_31 = LL_EXTI_LINE_0;
 EXTI InitStruct.LineCommand = ENABLE;
 EXTI_InitStruct.Mode = LL_EXTI_MODE_IT;
 EXTI InitStruct.Trigger = LL EXTI TRIGGER RISING;
 LL_EXTI_Init(&EXTI_InitStruct);
/* USER CODE BEGIN MX GPIO Init 2 */
 HAL_NVIC_SetPriority(EXTI0_1_IRQn, 0, 0);
 HAL NVIC EnableIRQ(EXTIO 1 IRQn);
/* USER CODE END MX_GPIO_Init_2 */
}
/* USER CODE BEGIN 4 */
void EXTI0_1_IRQHandler(void)
{
      // TODO: Debounce using HAL GetTick()
      if(HAL_GetTick()-prevTick >200)
               _HAL_TIM_DISABLE_DMA(&htim2,TIM_DMA_CC1);
            HAL DMA Abort IT(&hdma tim2 ch1);
            waveForm++;
            if(waveForm >=3)
                   waveForm =0;
            switch(waveForm)
            {
                   case 0:
                   {
                          HAL_DMA_Start_IT(&hdma_tim2_ch1,(uint32_t)Sin_LUT
,DestAddress, NS);
```

```
lcd_command(CLEAR);
                           lcd_putstring("Sine");
                           break;
                    }
                    case 1:
                    {
                           HAL_DMA_Start_IT(&hdma_tim2_ch1,(uint32_t)saw_LUT
,DestAddress, NS);
                           lcd_command(CLEAR);
                           lcd putstring("Sawtooth");
                           break;
                    }
                    case 2:
HAL_DMA_Start_IT(&hdma_tim2_ch1,(uint32_t)triangle_LUT,DestAddress, NS);
                           lcd_command(CLEAR);
                           lcd putstring("Triangle");
                           break;
                    }
             __HAL_TIM_ENABLE_DMA(&htim2,TIM_DMA_CC1);
      }
      // TODO: Disable DMA transfer and abort IT, then start DMA in IT mode with new LUT
and re-enable transfer
      // HINT: Consider using C's "switch" function to handle LUT changes
       HAL_GPIO_EXTI_IRQHandler(Button0_Pin); // Clear interrupt flags
/* USER CODE END 4 */
 * @brief This function is executed in case of error occurrence.
 * @retval None
void Error_Handler(void)
```

```
/* USER CODE BEGIN Error_Handler_Debug */
 /* User can add his own implementation to report the HAL error return state */
  _disable_irq();
 while (1)
 {
 /* USER CODE END Error_Handler_Debug */
#ifdef USE FULL ASSERT
 * @brief Reports the name of the source file and the source line number
       where the assert param error has occurred.
 * @param file: pointer to the source file name
 * @param line: assert param error line source number
 * @retval None
void assert_failed(uint8_t *file, uint32_t line)
 /* USER CODE BEGIN 6 */
/* User can add his own implementation to report the file name and line number,
  ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */
/* USER CODE END 6 */
#endif /* USE_FULL_ASSERT */
```