# Instructions to separate the build system image from the SDK

ID: RK-SM-YF-386

Release Version: V1.4.0

Release Date: 2020-09-15

Security Level: □Top-Secret □Secret □Internal ■Public

#### **DISCLAIMER**

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP") DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

#### **Trademark Statement**

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

#### All rights reserved. ©2020. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

#### **Preface**

#### Overview

The document presents the separate compiling kernel U-Boot or Rootfs of Rockchip RV1126/RV1109 Linux SDK, aiming to help engineers get started with RV1126/RV1109 Linux SDK faster.

#### **Product Version**

| Chipset       | Kernel Version |
|---------------|----------------|
| RV1126/RV1109 | Linux 4.19     |

#### **Intended Audience**

This document (this guide) is mainly intended for:

- Technical support engineers
- Software development engineers

#### **Revision History**

| Version    | Author | Date | Revision History   |
|------------|--------|------|--|
| 2020-08-10 | V1.0.0 | CWW  | alpha  |
| 2020-08-12 | V1.1.0 | CWW  | <ol> <li>Add idblock.bin compile instructions</li> <li>Add drivers insmod</li> </ol> |
| 2020-09-01 | V1.2.0 | CWW  | 1. Support eMMC compile instructions   |
| 2020-09-10 | V1.3.0 | CWW  | 1. Add Debug info chapter  |
| 2020-09-15 | V1.4.0 | CWW  | 1. Support AB system compilation   |

#### Instructions to separate the build system image from the SDK

- 1. U-Boot compilation
  - 1.1 Get U-Boot code from SDK
  - 1.2 For SPI NOR U-Boot compilation
  - 1.3 For eMMC U-Boot compilation
    - 1.3.1 Non-support AB system
    - 1.3.2 Support AB system
  - 1.4 Instructions to U-Boot images
- 2. Linux kernel compilation
  - 2.1 Get linux kernel code from SDK
  - 2.2 Build command explanation
  - 2.3 For SPI NOR linux kernel compilation
  - 2.4 For eMMC linux kernel compilation
    - 2.4.1 Build eMMC kernel without peripheral drivers
    - 2.4.2 Build eMMC kernel with peripheral drivers
  - 2.5 Package drivers (only for building without peripheral drivers into kernel)
  - 2.6 Instructions to linux kernel image
  - 2.7 Instructions to drivers insmod (only for building without peripheral drivers into kernel)
- 3. Root filesystem compilation
  - 3.1 Get tarball of build-busybox and compile
  - 3.2 Instructions to auto mount partition
- 4. Manufacture programmer firmware image for SPI NOR
- 5. Instructions to compile the libraries of BSP

```
5.1 Command to build BSP's libraries
5.2 BSP files
6. Debug info
6.1 CPU debug info
6.1.1 CPU frequency debug
6.1.1.1 Print CPU frequency
6.1.2 Set CPU fixed frequency
6.1.2 Print CPU thermal
6.1.3 Disable CPU thermal control
6.2 Encode debug info
6.2.1 Print encode frame rate
6.2.2 Print encode summary info
6.3 Print ISPP info
6.4 Print ISP info
```

# 1. U-Boot compilation

#### 1.1 Get U-Boot code from SDK

Get thses directories from root directory of SDK:

| Directory | Instructions                      |
|-----------|-----------------------------------|
| rkbin     | about DDR and prebuilt loader bin |
| u-boot    | U-Boot code                       |
| prebuilts | cross-compile tool                |

## 1.2 For SPI NOR U-Boot compilation

```
cd u-boot
./make.sh rv1126-spi-nor-tiny
./make.sh spl-s # or ./make.sh --spl
./make.sh --idblock --spl
```

# 1.3 For eMMC U-Boot compilation

## 1.3.1 Non-support AB system

```
cd u-boot
./make.sh rv1126
./make.sh spl-s # or ./make.sh --spl
# parameter e.g.
#
mtdparts=rk29xxnand:0x00002000@0x00004000(uboot),0x00010000@0x00006000(boot),0x00
010000@0x00016000(rootfs),-@0x00026000(data:grow)
```

#### 1.3.2 Support AB system

```
cd u-boot
./make.sh rv1126-ab
./make.sh spl-s # or ./make.sh --spl
# parameter e.g.
#
mtdparts=rk29xxnand:0x00002000@0x00004000(uboot_a),0x00002000@0x00006000(uboot_b)
,0x00001000@0x00008000(misc),0x00010000@0x00009000(boot_a),0x00010000@0x00019000(boot_b),0x00020000@0x00029000(system_a),0x00020000@0x00049000(system_b),-
@0x00069000(data:grow)
```

## 1.4 Instructions to U-Boot images

| the name of image         | comment   |
|---------------------------|---|
| rv1126_spl_loader_***.bin | loader file   |
| uboot.img                 | U-Boot image  |
| idblock.bin               | the IDBlock partition file for firmware_merger tool |

# 2. Linux kernel compilation

## 2.1 Get linux kernel code from SDK

Get thses directories from root directory of SDK:

| Directory | Instructions       |
|-----------|--------------------|
| kernel    | linux kernel code  |
| prebuilts | cross-compile tool |

## 2.2 Build command explanation

Build command format:

```
# configure linux kernel
# args1: chip architecture (e.g. arm)
# args2: linux kernel defconfig filename (e.g. xxx_defconfig)
# args3: linux kernel defconfig fragment filename (option)
make ARCH=args1 args2 args3
make menuconfig # this step is optinal

# make kernel image
# args1: chip architecture (e.g. arm)
# args2: linux kernel dts's filename (e.g. arch/arm/boot/dts/rv1126-38x38-v10-emmc.dts)
# -j12: allow 12 jobs compilation at once
make ARCH=args1 args2.img -j12
```

## 2.3 For SPI NOR linux kernel compilation

```
make ARCH=arm rv1126_defconfig rv1126-spi-nor.config
make ARCH=arm rv1126-38x38-v10-spi-nor.img -j12
```

## 2.4 For eMMC linux kernel compilation

#### 2.4.1 Build eMMC kernel without peripheral drivers

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-modules.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
```

## 2.4.2 Build eMMC kernel with peripheral drivers

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-builtin.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
```

# 2.5 Package drivers (only for building without peripheral drivers into kernel)

```
make modules_install ARCH=arm INSTALL_MOD_STRIP=1 INSTALL_MOD_PATH=./drivers-ko
# remove unused soft link
rm -f drivers-ko/lib/modules/4.19.111/build drivers-
ko/lib/modules/4.19.111/source
```

## 2.6 Instructions to linux kernel image

| the name of image | comment                               |
|-------------------|---------------------------------------|
| zboot.img         | linux kernel image                    |
| drivers-ko        | the directory of linux kernel drivers |

# 2.7 Instructions to drivers insmod (only for building without peripheral drivers into kernel)

```
# insmod videobuf2
insmod kernel/drivers/media/common/videobuf2/videobuf2-memops.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-dma-contig.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-common.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-v4l2.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-vmalloc.ko
# insmod drm
insmod kernel/drivers/gpu/drm/drm kms helper.ko
insmod kernel/drivers/gpu/drm/rockchip/rockchipdrm.ko
# insmod audio
insmod kernel/sound/soundcore.ko
insmod kernel/sound/core/snd.ko
insmod kernel/sound/core/snd-timer.ko
insmod kernel/sound/core/snd-pcm.ko
insmod kernel/sound/core/snd-pcm-dmaengine.ko
insmod kernel/sound/soc/snd-soc-core.ko
insmod kernel/sound/soc/codecs/snd-soc-dummy-codec.ko
insmod kernel/sound/soc/codecs/snd-soc-rk817.ko
insmod kernel/sound/soc/rockchip/snd-soc-rockchip-i2s-tdm.ko
insmod kernel/sound/soc/generic/snd-soc-simple-card-utils.ko
insmod kernel/sound/soc/generic/snd-soc-simple-card.ko
# insmod isp ispp cif rk ircut and sensor
insmod kernel/drivers/media/v412-core/v412-fwnode.ko
insmod kernel/drivers/media/i2c/os04a10.ko
insmod kernel/drivers/media/i2c/imx415.ko
insmod kernel/drivers/media/i2c/rk ircut.ko
insmod kernel/drivers/phy/rockchip/phy-rockchip-mipi-rx.ko
insmod kernel/drivers/media/platform/rockchip/cif/video rkcif.ko
insmod kernel/drivers/media/platform/rockchip/isp/video rkisp.ko
insmod kernel/drivers/media/platform/rockchip/ispp/video rkispp.ko
echo 1 > /sys/module/video_rkisp/parameters/clr_unready_dev
echo 1 > /sys/module/video rkispp/parameters/mode
# insmod vcodec
insmod kernel/drivers/video/rockchip/mpp/rk vcodec.ko
# insmod usb for adb
insmod kernel/drivers/phy/rockchip/phy-rockchip-naneng-usb2.ko
insmod kernel/drivers/usb/dwc3/dwc3-of-simple.ko
```

```
insmod kernel/drivers/usb/dwc3/dwc3.ko
# insmod for adc key
insmod kernel/drivers/input/keyboard/adc-keys.ko
# insmod for led flash
insmod kernel/drivers/leds/led-class-flash.ko
insmod kernel/drivers/leds/leds-rgb13h.ko
# insmod sdcard ko
insmod kernel/drivers/mmc/host/dw mmc.ko
insmod kernel/drivers/mmc/host/dw mmc-pltfm.ko
insmod kernel/drivers/mmc/host/dw_mmc-rockchip.ko
insmod kernel/drivers/mmc/host/rk_sdmmc_ops.ko
# audio codec
insmod kernel/sound/soc/codecs/snd-soc-es8311.ko
# rtc
insmod kernel/drivers/rtc/rtc-pcf8563.ko
# pwm fill light
insmod kernel/drivers/leds/leds-pwm.ko
```

## 3. Root filesystem compilation

# 3.1 Get tarball of build-busybox and compile

Get busybox tarball from path: device/rockchip/rv1126 rv1109/prebuilt-packages/build-busybox

```
# unpackage busybox tarball
tar xjf busybox-1.27.2-patch-reboot-arg.tar.bz2
# copy rockchip's busybox defconfig
# busybox spi nor defconfig used for spi nor
# busybox emmc defconfig used for eMMC (default)
cp busybox-1.27.2-patch/configs/busybox defconfig busybox-
1.27.2/configs/busybox defconfig
# change directory to busybox
cd busybox-1.27.2
# config defconfig
make busybox defconfig
# compile, Notice: the cross compile tool is in the prebuilts directory of SDK
make ARCH=arm install CROSS COMPILE=~/RV1109-SDK/prebuilts/qcc/linux-x86/arm/qcc-
arm-8.3-2019.03-x86 64-arm-linux-gnueabihf/bin/arm-linux-gnueabihf- -j32
# unpackage base root filesystem which is prebuilt bin, e.g. target-emmc-
v1.0.0.tar.bz2
tar xjf target-emmc-v1.0.0.tar.bz2
```

```
# copy busybox target bin and libs to target directory (option)
cp busybox-1.27.2/_install/* target/ -rfa

# package root filesystem with squashfs
mksquashfs target rootfs.squashfs -noappend -comp xz

# package root filesystem with ext4, e.g.
tar xjf tools.tar.bz2
./tools/mkfs-ext4/do-mkfs.ext4.sh target rootfs.ext4 64M

# the command of unpackage squashfs filesystem : unsquashfs ./rootfs.squashfs
```

NOTICE: The library named /usr/lib/libv4l/plugins/libv4l-mplane.so MUST be placed in the rootfs.

## 3.2 Instructions to auto mount partition

target-emmc-v1.0.0.tar.bz2 support auto mount the partitions which config in the file of /etc/fstab. Auto mount script: target/etc/init.d/S21mountall.sh

Refer to the partition of userdata

# 4. Manufacture programmer firmware image for SPI NOR

Get firmware\_merger from path: device/rockchip/rv1126\_rv1109/prebuilt-packages/firmware\_merger

# 5. Instructions to compile the libraries of BSP

Get thses directories from root directory of SDK:

| Directory | Instructions       |
|-----------|--------------------|
| buildroot | buildroot's source |
| external  | rockchip BSP codes |
| prebuilts | cross-compile tool |

## 5.1 Command to build BSP's libraries

```
source envsetup.sh rockchip_rv1126_rv1109_libs

make -j12
```

## 5.2 BSP files

```
tree buildroot/output/rockchip rv1126 rv1109 libs/BSP/
buildroot/output/rockchip_rv1126_rv1109_libs/BSP/
- example
   - CMakeLists.txt
     - common
       - sample_common.h
     L sample_common_isp.c
     — iqfiles
     FEC_mesh_2688_1520_imx347_4IR
        - meshxf_level0.bin
  meshxf_level1.bin
  meshxf_level2.bin
   meshxf_level3.bin
         - meshxf_level4.bin
         - meshxi_level0.bin
          - meshxi level1.bin
```

```
- meshxi level2.bin
 - meshxi_level3.bin
 - meshxi_level4.bin
 - meshyf_level0.bin
 - meshyf_level1.bin
 - meshyf_level2.bin
 - meshyf level3.bin
 - meshyf_level4.bin
 - meshyi_level0.bin
 - meshyi_level1.bin
 meshyi level2.bin
 - meshyi level3.bin
 └─ meshyi_level4.bin
- FEC_mesh_2688_1520_os04a10_4IR
 - meshxf_level0.bin
 meshxf level1.bin
 - meshxf level2.bin
 - meshxf_level3.bin
 - meshxf_level4.bin
 - meshxi_level0.bin
 meshxi level1.bin
 - meshxi_level2.bin
 - meshxi_level3.bin
 - meshxi level4.bin
 meshyf level0.bin
 meshyf level1.bin
 meshyf_level2.bin
 meshyf level3.bin
 - meshyf_level4.bin
 - meshyi level0.bin
 meshyi level1.bin
 - meshyi_level2.bin
 - meshyi level3.bin
 └─ meshyi_level4.bin
- FEC_mesh_2688_1520_os04a10_6IR
 - meshxf level0.bin
 - meshxf level1.bin
 - meshxf level2.bin
 - meshxf_level3.bin
 - meshxf_level4.bin
 - meshxi level0.bin
 - meshxi_level1.bin
 - meshxi level2.bin
 - meshxi_level3.bin
 - meshxi level4.bin
 - meshyf_level0.bin
 - meshyf_level1.bin
 meshyf level2.bin
 - meshyf level3.bin
 - meshyf level4.bin
 - meshyi_level0.bin
 meshyi_level1.bin
 - meshyi level2.bin
 - meshyi level3.bin
 └─ meshyi_level4.bin
- FEC_mesh_3840_2160_imx415_3.6mm
 meshxf level0.bin
 - meshxf level1.bin
```

```
- meshxf level2.bin
   - meshxf level3.bin
   meshxf level4.bin
   - meshxi_level0.bin
   - meshxi_level1.bin
   - meshxi level2.bin
   - meshxi level3.bin
   - meshxi level4.bin
   - meshyf_level0.bin
   - meshyf_level1.bin
   - meshyf level2.bin
   - meshyf level3.bin
   - meshyf_level4.bin
   - meshyi_level0.bin
   - meshyi_level1.bin
   - meshyi level2.bin
   - meshyi level3.bin
   └─ meshyi_level4.bin
___ gc2053_CMK-OT1726-PG1_29IR-2MP-F25.xml
- gc2053 YT-RV1109-2-V1 40IR-2MP-F20.xml
gc2093 YT-RV1109-2-V1 40IR-2MP-F20.xml
- gc4c33_PCORW0009A_40IRC-4M.xml
- imx307_CMK-OT0837-PT2_YT-2929_UNV-40IRC-2M-F20.xml
- imx334_CMK-OT1522-FG3_CS-P1150-IRC-8M-FAU.xml
- imx347_JSD3425-C1 40IRC.xml
- imx378 A12N01B 48IRC-12M-F18.xml
- imx415 YT10092 IR0147-28IRC-8M-F20-hdr3.xml
- imx415 YT10092 IR0147-28IRC-8M-F20.xml
- imx415_YT10092_IR0147-36IRC-8M-F20-hdr3.xml
- imx415 YT10092 IR0147-36IRC-8M-F20.xml
- imx415 YT10092 IR0147-60IRC-8M-F20-hdr3.xml
- imx415_YT10092_IR0147-60IRC-8M-F20.xml
- LDCH mesh 2688 1520 imx347 4IR
  - mesh_level0.bin
   - mesh level1.bin
   - mesh level2.bin
   - mesh_level3.bin
   └─ mesh_level4.bin
 - LDCH mesh 2688 1520 os04a10 4IR
   - mesh_level0.bin
   - mesh level1.bin
   - mesh_level2.bin
   - mesh level3.bin
  └─ mesh level4.bin
 - LDCH mesh 2688 1520 os04a10 6IR
   - mesh level0.bin
   - mesh_level1.bin
   - mesh_level2.bin
   - mesh_level3.bin
   └─ mesh_level4.bin
 - LDCH_mesh_3840_2160_imx415_3.6mm
   - mesh level0.bin
   - mesh level1.bin
   - mesh_level2.bin
    - mesh level3.bin
   └─ mesh_level4.bin
 — os04a10 CMK-OT1607-FV1 M12-40IRC-4MP-F16.xml
 — os04a10 CMK-OT1607-FV1 M12-60IRC-4MP-F16.xml
```

```
- ov02k10 O2F0068 2D2A-40IRC-2M-F18.xml
   - ov02k10_ORCF-0249-00-PD-V1_xuye.xml
    -- ov2718 YT-RV1109-3-V1 M43-4IR-2MP-F2.xml
   - ov4689_JSD3425-C1_JSD3425-C1-36IRC-4M-F20.xml
   - s5kgm1sp_PCORW0009A_4mm-4M.xml
   - s5kgm1sp_S5KGM1ST03_40IR-12M-F20.xml
   └── sc200ai CMK-OT1607-FV1 M12-40IRC-4MP-F16 tmp2 addnr3.xml
- Makefile
- rkmedia_audio_test.c
- rkmedia_isp_test.c
- rkmedia main stream with jpeg test.c
- rkmedia_venc_avbr_test.c
- rkmedia_venc_cover_test.c
- rkmedia_venc_jpeg_test.c
- rkmedia_venc_mjpeg_test.c
- rkmedia venc offline test.c
- rkmedia_venc_osd_test.c
- rkmedia_venc_roi_osd_test.c
- rkmedia_venc_smartp_test.c
- rkmedia_vi_double_cameras test.c
- rkmedia vi get frame test.c
- rkmedia_vi_md_test.c
- rkmedia_vi_multi_bind_test.c
- rkmedia_vi_od_test.c
- rkmedia_vi_rga_test.c
- rkmedia vi venc change resolution test.c
- rkmedia_vi_venc_test.c
- rkmedia vi vo test.c
- rkmedia_vi_work_mode_test.c
 uintTest
   - buffer
       buffer_pool_test.cc
      └─ CMakeLists.txt
   - CMakeLists.txt
     - ffmpeg
       - CMakeLists.txt
       ffmpeg_enc_mux_test.cc
     flow
       audio_decoder_flow_test.cc
       - audio_encoder_flow_test.cc
       — audio loop test.cc
       - audio_process_test.cc
       - CMakeLists.txt
       flow_event_test.cc
       flow stress test.cc
       - FlowTest.cc
       - link_flow_test.cc
       move_detection_flow_test.cc
       - muxer_flow_test.cc
       - occlusion detection flow test.cc
       - rga_filter_flow_test.cc
       through_guard_jpeg_test.cc
       - video encoder bps test.cc
       video_encoder_flow_test.cc
       - video encoder osd test.cc
         - video_encoder_roi_test.cc
       video_smart_encoder_test.cc
     - live555
```

```
- CMakeLists.txt
           - h264_frames
             - 0.h264 frame
             - 10.h264_frame
             -- 1.h264_frame
             - 2.h264_frame
            - 3.h264 frame
           -- 4.h264 frame
           - 5.h264 frame
           - 6.h264_frame
           - 7.h264 frame
             -- 8.h264_frame
             ___ 9.h264_frame
         - rtsp_multi_server_test.cc
         rtsp_server_test.cc
         - CMakeLists.txt
          ogg_decode_test.cc
         _ ogg_encode_test.cc
       - rkmpp
         - CMakeLists.txt
         mpp_dec_test_320_240.jpg
         - mpp_dec_test.cc
         mpp_dec_test.h264
         mpp_dec_test.hevc
         mpp_enc_test_320_240.nv12
         __ mpp_enc_test.cc
       — stream
        - camera_capture_test.cc
         - CMakeLists.txt
        — drm display_test.cc
     L_ uvc
         - CMakeLists.txt
         └─ uvc_flow_test.cc
   - vgefiles
     - 16k
        └─ RKAP_AecPara.bin
     L--- 8k
        └─ RKAP_AecPara.bin
- include
  - rga
    - drmrga.h
   --- RgaApi.h
     - rga.h
      - RockchipRga.h
     └─ RockchipRgaMacro.h
   - rkaiq
     - algos
        — a3dlut
             - rk_aiq_types_a3dlut_algo.h
             - rk_aiq_types_a3dlut_algo_int.h
             - rk_aiq_types_a3dlut_hw.h
         | L— rk_aiq_uapi_a3dlut_int.h
         - ablc
           - rk_aiq_types_ablc_algo.h
             - rk_aiq_types_ablc_algo_int.h
             - rk_aiq_types_ablc_hw.h
             - rk_aiq_uapi_ablc_int.h
```

```
- rk_aiq_types_accm_algo.h
   - rk_aiq_types_accm_algo_int.h
   - rk_aiq_types_accm_hw.h
  - rk_aiq_uapi_accm_int.h
— acp
  - rk_aiq_types_acp_algo.h
   - rk_aiq_types_acp_algo_int.h
   - rk_aiq_uapi_acp_int.h
- adebayer
  - rk aiq types algo adebayer.h
     — rk_aiq_types_algo_adebayer_int.h
   - rk_aiq_uapi_adebayer_int.h
- adehaze
  - rk_aiq_types_adehaze_algo.h
  - rk aiq types adehaze algo int.h
     — rk_aiq_types_adehaze_hw.h
   L— rk_aiq_uapi_adehaze_int.h
- adpcc
  - rk_aiq_types_adpcc_algo.h
  - rk_aiq_types_adpcc_algo_int.h
   - rk_aiq_types_adpcc_hw.h
   - rk_aiq_uapi_adpcc_int.h
   - rk_aiq_types_ae_algo.h
  - rk_aiq_types_ae_algo_int.h
   - rk_aiq_types_ae_hw.h
   - rk_aiq_uapi_ae_int.h
   - rk_aiq_uapi_ae_int_types.h
 — af
  --- rk_aiq_af_hw_v200.h
   - rk_aiq_types_af_algo.h
   - rk_aiq_types_af_algo_int.h
  - rk_aiq_uapi_af_int.h
 — afec
  - fec_algo.h
  - rk aiq types afec algo.h
   - rk aiq types afec algo int.h
  L- rk_aiq_uapi_afec_int.h
agamma
  - rk_aiq_types_agamma_algo.h
  - rk_aiq_types_agamma_algo_int.h
   - rk_aiq_types_agamma_hw.h
  L- rk_aiq_uapi_agamma_int.h
- agic
  - rk_aiq_types_algo_agic.h
   - rk_aiq_types_algo_agic_int.h
   L- rk_aiq_uapi_agic_int.h
- ahdr
  - rk_aiq_types_ahdr_algo.h
  - rk_aiq_types_ahdr_algo_int.h
   - rk_aiq_types_ahdr_stat_v200.h
   L- rk_aiq_uapi_ahdr_int.h
 — aie
   - rk_aiq_types_aie_algo.h
   L— rk_aiq_types_aie_algo_int.h
 — aldch
   - rk aiq types aldch algo.h
```

```
rk_aiq_types_aldch_algo_int.h
     rk_aiq_uapi_aldch_int.h
   - alsc
     - rk_aiq_types_alsc_algo.h
    - rk_aiq_types_alsc_algo_int.h
     - rk_aiq_types_alsc_hw.h
    - rk aiq uapi alsc int.h
   — anr
   - rk_aiq_types_anr_algo.h
   - rk_aiq_types_anr_algo_int.h
     - rk aiq types anr hw.h
    - rk_aiq_uapi_anr_int.h
   — aorb
     - rk_aiq_orb_hw.h
    - rk_aiq_types_orb_algo.h
     - rk_aiq_types_asd_algo.h
    - rk_aiq_uapi_asd_int.h
 - asharp
   - rk_aiq_types_asharp algo.h
    - rk aiq types asharp algo int.h
     - rk_aiq_types_asharp_hw.h
    - rk_aiq_uapi_asharp_int.h
 - awb
     - rk_aiq_types_awb_algo.h
     - rk_aiq_types_awb_algo_int.h
     - rk_aiq_types_awb_stat_v200.h
     - rk_aiq_types_awb_stat_v201.h
     - rk_aiq_types_awb_stat_v2xx.h
     L— rk_aiq_uapi_awb_int.h
 └─ rk aiq algo des.h
- common
 - gen mesh
   - genMesh.h
     - genMesh_static 32bit
    └─ genMesh static_64bit
 linux
   - compiler.h
     -- rk-camera-module.h
     - rk-led-flash.h
     - v412-controls.h
    - videodev2.h
  mediactl
   -- mediactl.h
     - mediactl-priv.h
     - tools.h
    v412subdev.h
  — opencv2
     -- calib3d
     └── calib3d c.h
      - core
       - core c.h
        - cuda
        | L— detail
     - cv_cpu_dispatch.h
         - cv_cpu_helper.h
         - cvdef.h
```

```
- hal
     - interface.h
     msa_macros.h
   - opencl
    L- runtime
     L— autogenerated
   - types_c.h
  └─ utils
- cvconfig.h
 L__ utils
- features2d
 L- hal
    interface.h
- flann
 - all indices.h
 - allocator.h
  - any.h
  - autotuned_index.h
  - composite_index.h
  — config.h
 - defines.h
  - dist.h
  - dummy.h
  — dynamic_bitset.h
  - general.h
  - ground_truth.h
  - hdf5.h
  - heap.h
  hierarchical_clustering_index.h
  - index_testing.h
  - kdtree_index.h
  - kdtree_single_index.h
  - kmeans_index.h
  linear_index.h
  - logger.h
  - lsh_index.h
  - lsh_table.h
  - matrix.h
  - nn_index.h
  - object factory.h
 - params.h
  - random.h
  - result_set.h
  - sampling.h
  - saving.h
  - simplex_downhill.h
  L timer.h
– gapi
  - cpu
  - fluid
  - gpu
  - infer
  - ocl
   -- own
  - plaidml
  - render
  - streaming
```

```
L- util
        highgui
         └─ highgui c.h
         imgcodecs
         imgcodecs c.h
         - ios.h
         L- legacy
           L constants_c.h
       - imgproc
         - detail
         - hal
         interface.h
         - imgproc_c.h
         L types_c.h
       - lib
         L- 3rdparty
       — ml
     - objdetect
       — photo
         L legacy
           - constants_c.h
       - stitching
         └─ detail
       — video
         └─ legacy
           └─ constants_c.h
     └── videoio
         - cap ios.h
         - legacy
           L constants_c.h
         └─ videoio_c.h
 - rk_aiq_comm.h
 - rk aiq.h
 - rk_aiq_pool.h
   — rk_aiq_types.h
 └─ shared_item_pool.h
— iq parser
 ☐ RkAiqCalibDbTypes.h
- rkisp api.h
- uAPI
 rk aiq user api a3dlut.h
 - rk_aiq_user_api_ablc.h
 rk aiq user api accm.h
 - rk_aiq_user_api_acp.h
 - rk aiq user api adebayer.h
 - rk_aiq_user_api_adehaze.h
 - rk_aiq_user_api_adpcc.h
 rk_aiq_user_api_ae.h
 - rk_aiq_user_api_afec.h
 - rk_aiq_user_api_af.h
 - rk_aiq_user_api_agamma.h
 - rk_aiq_user_api_agic.h
 - rk_aiq_user_api_ahdr.h
 - rk_aiq_user_api_aldch.h
  rk_aiq_user_api_alsc.h
 - rk_aiq_user_api_anr.h
 - rk_aiq_user_api_asd.h
 - rk aiq user api asharp.h
```

```
rk_aiq_user_api_awb.h
         - rk_aiq_user_api_debug.h
         - rk aiq user api imgproc.h
         └─ rk_aiq_user_api_sysctl.h
     L xcore
         L— base
             - xcam_common.h
             L- xcam_defs.h
   — rkmedia
     - rkmedia_adec.h
     - rkmedia aenc.h
     - rkmedia ai.h
     - rkmedia_ao.h
     - rkmedia_api.h
     - rkmedia_buffer.h
     - rkmedia common.h
     - rkmedia event.h
     - rkmedia_move_detection.h
     - rkmedia_occlusion_detection.h
     - rkmedia_rga.h
     - rkmedia venc.h
     - rkmedia_vi.h
     - rkmedia_vo.h
- lib
  libasound.so -> libasound.so.2.0.0
  - libasound.so.2 -> libasound.so.2.0.0
  libasound.so.2.0.0
  libavcodec.so -> libavcodec.so.58.35.100
  - libavcodec.so.58 -> libavcodec.so.58.35.100
  |-- libavcodec.so.58.35.100
  - libavformat.so -> libavformat.so.58.20.100
  libavformat.so.58 -> libavformat.so.58.20.100
  ├─ libavformat.so.58.20.100
  libavutil.so -> libavutil.so.56.22.100
  |-- libavutil.so.56 -> libavutil.so.56.22.100
  - libavutil.so.56.22.100
  - libdrm.so -> libdrm.so.2.4.0
  - libdrm.so.2 -> libdrm.so.2.4.0
  ├─ libdrm.so.2.4.0
  libeasymedia.so -> libeasymedia.so.1
  libeasymedia.so.1 -> libeasymedia.so.1.0.1
    - libeasymedia.so.1.0.1
  - libmd share.so
  libod share.so
  - librga.so -> librga.so.2
  librga.so.2 -> librga.so.2.0.0
  ├─ librga.so.2.0.0
  - librkaiq.so
  - libRKAP_AEC.so
  - librkap ANR.so
  libRKAP Common.so
  librockchip_mpp.so -> librockchip_mpp.so.1
  librockchip mpp.so.0
  - librockchip mpp.so.1 -> librockchip mpp.so.0
  - libswresample.so -> libswresample.so.3.3.100
  - libswresample.so.3 -> libswresample.so.3.3.100
  - libswresample.so.3.3.100
  - libv412.so -> libv412.so.0.0.0
```

# 6. Debug info

## 6.1 CPU debug info

#### 6.1.1 CPU frequency debug

#### 6.1.1.1 Print CPU frequency

```
# print current cpu frequency
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_cur_freq
1008000

# print cpu available frequencies
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_available_frequencies
408000 600000 816000 1008000 1200000 1296000
```

#### 6.1.1.2 Set CPU fixed frequency

```
# set CPU 600MHz fixed frequency
echo userspace > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
echo 600000 > /sys/devices/system/cpu/cpu0/cpufreq/scaling_setspeed
```

#### 6.1.2 Print CPU thermal

cat /sys/class/thermal/thermal\_zone0/temp

#### 6.1.3 Disable CPU thermal control

```
# diable thermal control
echo user_space > /sys/class/thermal/thermal_zone0/policy
# disable frequency limit
echo 0 > /sys/class/thermal/thermal_zone0/cdev0/cur_state
echo 0 > /sys/class/thermal/thermal_zone0/cdev1/cur_state
```

## 6.2 Encode debug info

#### 6.2.1 Print encode frame rate

```
# enable print fps log
echo 0x100 > /sys/module/rk_vcodec/parameters/mpp_dev_debug

# disable print fps log
echo 0 > /sys/module/rk_vcodec/parameters/mpp_dev_debug
```

### 6.2.2 Print encode summary info

```
cat /proc/mpp_service/session_summary
```

## 6.3 Print ISPP info

cat /proc/rkispp0

```
cat /proc/rkispp0
rkispp0 Version:v00.01.05
        rkisp0 Format:FBC420 Size:3840x2160 (frame:15441 rate:41ms delay:20ms)
         rkispp m bypass Format:FBC0 Size:3840x2160 (frame:15440 rate:41ms
delay:45ms)
Output rkispp_scale0 Format:NV12 Size:1280x720 (frame:15440 rate:41ms
delay:45ms)
Output rkispp scale1 Format:NV12 Size:720x480 (frame:15440 rate:41ms
Output rkispp_scale2 Format:NV12 Size:1280x720 (frame:15440 rate:41ms
delay:45ms)
TNR ON(0xd00000d) (mode: 2to1) (global gain: disable) (frame:15441
time:12ms) CNT:0x0 STATE:0x1e000000
NR ON(0x47) (external gain: enable) (frame:15441 time:12ms) 0x5f0:0x0
0x5f4:0x0
SHARP
        ON(0x1b) (YNR input filter: ON) (local ratio: ON) 0x630:0x0
         OFF(0x2) (frame:0 time:0ms) 0xc90:0x0
FEC
ORB OFF(0x0)
Interrupt Cnt:46278 ErrCnt:0
clk_ispp 500000000
aclk ispp 500000000
hclk_ispp 250000000
```

### 6.4 Print ISP info

```
cat /proc/rkisp0
```

```
cat /proc/rkisp0
rkisp0 Version:v00.01.05
```

```
Input rkcif mipi lvds Format:SGBRG10 1X10 Size:3840x2160@30fps Offset(0,0) |
RDBK X1(frame:15584 rate:40ms)
       rkispp0 Format:FBC420 Size:3840x2160 (frame:15583 rate:39ms)
Output
Interrupt Cnt:62011 ErrCnt:0
clk isp 594000000
aclk_isp 500000000
hclk_isp 250000000
       ON(0x40000005)
DPCC0
        ON(0x40000005)
DPCC1
DPCC2
BLS
        ON(0x4000005)
        ON(0x4000001)
SDG
        OFF(0x80446197)
        ON(0x1)
LSC
AWBGAIN ON(0x80446197) (gain: 0x010d010d, 0x02260227)
DEBAYER ON (0xf000111)
        ON(0xc0000001)
CCM
GAMMA OUT ON (0xc000001)
CPROC
       ON(0xf)
ΙE
        OFF(0x0) (effect: BLACKWHITE)
WDR
        OFF(0x30cf0)
HDRTMO
        ON(0xc8505a25)
HDRMGE
        OFF(0x0)
        ON(0xc0100001)
RAWNR
GIC
        OFF (0x0)
DHAZ
        ON(0xc0001009)
3DLUT
        OFF (0x2)
GAIN
        ON(0xc0010010)
LDCH
        OFF(0x0)
CSM
        FULL(0x80446197)
SIAF
        OFF(0x0)
SIAWB
        OFF(0x0)
YUVAE
        ON(0x400100f3)
        ON(0x38000107)
SIHST
RAWAF
        ON(0x7)
RAWAWB
        ON(0x4037e887)
RAWAE0 ON (0x40000003)
RAWAE1
        ON(0x400000f5)
RAWAE2
        ON(0x400000f5)
        ON(0x400000f5)
RAWAE3
RAWHISTO ON (0x40000501)
RAWHIST1 ON (0x60000501)
RAWHIST2 ON (0x60000501)
RAWHIST3 ON (0x60000501)
```