# Hide sidebar nav and TOC on the home page

Welcome to the **Cinemate** documentation.

Edit docs/index.md and hit save - the site updates automatically when running mkdocs serve.

**(**) July 7, 2025

### Overview

#### Overview

CineMate scripts is a way for users to implement and customize manual controls for their cinepi-raw build.

Project aims at offering an easy way to build a custom camera. For basic operation and experimentation, Raspberry Pi, camera board and monitor is needed. For practical use, buttons and switches can easily be added.

A ready made disk image can be found here.

Join the CinePi Discord here.

### Hardware requirements

- Rasberry Pi 4/5 or CM4 module
- · Official HQ or GS camera
- · HDMI monitor or device (phone or tablet) for monitoring

For recording, use a high speed NVME drive or CFE Hat by Will Whang. Drive needs to be formatted as ext4 and named "RAW".

CineMate is also compatible with OneInchEye (Sony IMX 283) and StarlightEye (Sony IMX 585) by Will Whang. Works with CM4 module and Pi 5B.

## Quickstart guide

- 1) Burn image to ssd card. 16 GB or larger.
- 2) Connect Pi and camera sensor board

• When connecting the camera module to the Pi, make sure it is the Pi is not powered. It is not advised to hot-swap the camera cable.

3) Boot up the Pi. CineMate should autostart.

### 7.3 CineMate "Pseudo-CLI"

CineMate doesn't use a real command-line parser or shell. Instead, it implements a "pseudo-CLI" inside the running Python process to let you type or send simple, human-readable commands over and SSH session and USB/serial Here's how it works:

#### **Available Commands**

Command	Argument(s)	What it does
rec / stop	none	Toggle recording on/off
set iso <100-3200>	int	Set ISO (clamps to nearest valid step)
inc iso / dec iso	none	Step ISO up/down
set shutter a <float></float>	float	Set shutter angle (snaps unless in free/sync mode)
inc shutter a / dec shutter a	none	Step shutter angle through dynamic list
set shutter a nom <float></float>	float	Set nominal shutter (motion-blur target)
inc shutter a nom / dec shutter a nom	none	Step nominal shutter angle
set fps <float></float>	float	Set frames-per-second (snaps or free)
inc fps / dec fps	none	Step FPS up/down
set wb [ <kelvin>]</kelvin>	int or none	Set or cycle white balance
inc wb / dec wb	none	Cycle WB up/down
set resolution [ <mode>]</mode>	int or none	

# How "inverse" (1-0-1) buttons are auto-detected

Many latching push-buttons are wired closed = logic 1 at rest and open = 0 when pressed. At start-up each SmartButton performs:

```
if self.button.is_pressed: # high at rest → treat as "inverse"
    self.inverse = True
```

If so, the framework swaps the handlers:

```
when_pressed ← on_release
when_released ← on_press
```

**(**) July 7, 2025

## settings.json Cheat Sheet

A quick-reference table of every setting in settings.json, what it does, and its allowed values.

```
{
    "pin": 27,
    "state_on_action": {"method": "set_all_lock", "args": [1]},
    "state_off_action": {"method": "set_all_lock", "args": [0]}
},

if self.button.is_pressed: # high at rest → treat as "inverse"
```

## Geometry

self.inverse = True

JSON Path	Description	Values
<pre>geometry.camX.rotate_180</pre>	Rotate image 180° on startup	true / false
<pre>geometry.camX.horizontal_flip</pre>	Flip image horizontally on startup	true / false
<pre>geometry.camX.vertical_flip</pre>	Flip image vertically on startup	true / false

## Output

JSON Path	Description	Values
output.camX.hdmi_port	Select DRM connector for HDMI output (cinepi-rawhdmi-port)	0, 1, or -1 (auto)