

# **Storage limits for Cloud Volumes ONTAP 9.8 in Azure**

**Cloud Volumes ONTAP** 

Ben Cammett December 21, 2020

# **Table of Contents**

Storage limits for Cloud Volumes ONTAP 9.8 in Azure	 	1
Maximum system capacity by license	 	1
Disk and tiering limits by VM size	 	1
Aggregate limits	 	4
Logical storage limits	 	4
iSCSI storage limits	 	5

# Storage limits for Cloud Volumes ONTAP 9.8 in Azure

Cloud Volumes ONTAP has storage configuration limits to provide reliable operations. For best performance, do not configure your system at the maximum values.

## Maximum system capacity by license

The maximum system capacity for a Cloud Volumes ONTAP system is determined by its license. The maximum system capacity includes disk-based storage plus object storage used for data tiering. NetApp doesn't support exceeding this limit.

License	Maximum system capacity (disks + object storage)
Explore	2 TB (data tiering is not supported with Explore)
Standard	10 TB
Premium	368 TB
BYOL	368 TB per license

For HA, is the license capacity limit per node or for the entire HA pair?

The capacity limit is for the entire HA pair. It is not per node. For example, if you use the Premium license, you can have up to 368 TB of capacity between both nodes.

## Disk and tiering limits by VM size

The disk limits below are specific to disks that contain user data. The limits do not include the root disk, core disk, and VNVRAM.

The tables below show the maximum system capacity by VM size with disks alone, and with disks and cold data tiering to object storage.

Disk limits are shown by VM size for Premium and BYOL licenses only because disk limits can't be reached with Explore or Standard licenses due to system capacity limits.

- Single node systems can use Standard HDD Managed Disks, Standard SSD Managed Disks, and Premium SSD Managed Disks, with up to 32 TB per disk. The number of supported disks varies by VM size.
- HA systems use Premium page blobs as disks, with up to 8 TB per page blob. The number of supported disks varies by VM size.



You can now purchase multiple licenses for a Cloud Volumes ONTAP BYOL system to allocate more than 368 TB of capacity. The number of licenses that you can purchase for a single node system or HA pair is unlimited. Be aware that disk limits can prevent you from reaching the capacity limit by using disks alone. You can go beyond the disk limit by tiering inactive data to object storage. Learn how to add additional system licenses to Cloud Volumes ONTAP.

### Single node with a Premium license

VM size	Max data disks per node	Max system capacity with disks alone	Max system capacity with disks and data tiering
DS3_v2	13	368 TB	Tiering not supported
DS4_v2	29	368 TB	368 TB
DS5_v2	61	368 TB	368 TB
DS13_v2	29	368 TB	368 TB
DS14_v2	61	368 TB	368 TB
DS15_v2	61	368 TB	368 TB
E32s_v3	29	368 TB	368 TB
E48s_v3	29	368 TB	368 TB
L8s_v2	13	368 TB	368 TB

#### Single node with one or more BYOL licenses



For some VM types, you'll need several BYOL licenses to reach the max system capacity listed below. For example, you'd need 6 BYOL licenses to reach 1.95 PB with DS5 v2.

VM size	Max data disks per node	Max system capacity with one license		Max system capacilicenses	city with multiple
		Disks alone	Disks + data tiering	Disks alone	Disks + data tiering
DS3_v2	13	368 TB	Tiering not supported	416 TB	Tiering not supported
DS4_v2	29	368 TB	368 TB	928 TB	368 TB x each license
DS5_v2	61	368 TB	368 TB	1.95 PB	368 TB x each license
DS13_v2	29	368 TB	368 TB	928 TB	368 TB x each license
DS14_v2	61	368 TB	368 TB	1.95 PB	368 TB x each license

VM size	Max data disks per node	Max system capacity with one license		Max system capa	city with multiple
DS15_v2	61	368 TB	368 TB	1.95 PB	368 TB x each license
E32s_v3	29	368 TB	368 TB	928 TB	368 TB x each license
E48s_v3	29	368 TB	368 TB	928 TB	368 TB x each license
L8s_v2	13	368 TB	368 TB	416 TB	368 TB x each license

### **HA** pairs with a Premium license

VM size	Max data disks per node	Max system capacity with disks alone	Max system capacity with disks and data tiering
DS4_v2	29	368 TB	368 TB
DS5_v2	61	368 TB	368 TB
DS13_v2	29	368 TB	368 TB
DS14_v2	61	368 TB	368 TB
DS15_v2	61	368 TB	368 TB
E48s_v3	29	368 TB	368 TB

## **HA** pairs with one or more BYOL licenses



For some VM types, you'll need several BYOL licenses to reach the max system capacity listed below. For example, you'd need 3 BYOL licenses to reach 976 TB with DS5\_v2.

VM size	Max data disks per node	Max system capacity with one license				pacity with multiple
		Disks alone	Disks + data tiering	Disks alone	Disks + data tiering	
DS4_v2	29	368 TB	368 TB	464 TB	368 TB x each license	
DS5_v2	61	368 TB	368 TB	976 TB	368 TB x each license	
DS13_v2	29	368 TB	368 TB	464 TB	368 TB x each license	
DS14_v2	61	368 TB	368 TB	976 TB	368 TB x each license	
DS15_v2	61	368 TB	368 TB	976 TB	368 TB x each license	

VM size	Max data disks per node					city with multiple
E48s_v3	29	368 TB	368 TB	464 TB	368 TB x each license	

# **Aggregate limits**

Cloud Volumes ONTAP uses Azure storage as disks and groups them into aggregates. Aggregates provide storage to volumes.

Parameter	Limit
Maximum number of aggregates	Same as the disk limit
Maximum aggregate size	352 TB of raw capacity for single node <sup>1, 2</sup> 96 TB of raw capacity for HA pairs <sup>1</sup>
Disks per aggregate	1-12 <sup>3</sup>
Maximum number of RAID groups per aggregate	1

#### Notes:

- 1. The aggregate capacity limit is based on the disks that comprise the aggregate. The limit does not include object storage used for data tiering.
- 2. The 352 TB limit is supported starting with 9.6 P3. Releases prior to 9.6 P3 support up to 200 TB of raw capacity in an aggregate on a single node system.
- 3. All disks in an aggregate must be the same size.

# **Logical storage limits**

Logical storage	Parameter	Limit
Storage virtual machines (SVMs)	Maximum number for Cloud Volumes ONTAP (HA pair or single node)	One data-serving SVM and one destination SVM used for disaster recovery. You can activate the destination SVM for data access if there's an outage on the source SVM.   The one data-serving SVM spans the entire Cloud Volumes ONTAP system (HA pair or single node).
Files	Maximum size	16 TB
	Maximum per volume	Volume size dependent, up to 2 billion
FlexClone volumes	Hierarchical clone depth <sup>2</sup>	499
FlexVol volumes	Maximum per node	500
	Minimum size	20 MB
	Maximum size	Azure HA: Dependent on the size of the aggregate <sup>3</sup> Azure single node: 100 TB

Logical storage	Parameter	Limit
Qtrees	Maximum per FlexVol volume	4,995
Snapshot copies	Maximum per FlexVol volume	1,023

#### Notes:

- Cloud Manager does not provide any setup or orchestration support for SVM disaster recovery. It also does
  not support storage-related tasks on an additional SVM. You must use System Manager or the CLI for SVM
  disaster recovery.
  - SVM Disaster Recovery Preparation Express Guide
  - SVM Disaster Recovery Express Guide
- 2. Hierarchical clone depth is the maximum depth of a nested hierarchy of FlexClone volumes that can be created from a single FlexVol volume.
- 3. Less than 100 TB is supported for this configuration because aggregates on HA pairs are limited to 96 TB of *raw* capacity.

# iSCSI storage limits

iSCSI storage	Parameter	Limit
LUNs	Maximum per node	1,024
	Maximum number of LUN maps	1,024
	Maximum size	16 TB
	Maximum per volume	512
igroups	Maximum per node	256
Initiators	Maximum per node	512
	Maximum per igroup	128
iSCSI sessions	Maximum per node	1,024
LIFs	Maximum per port	32
	Maximum per portset	32
Portsets	Maximum per node	256

#### **Copyright Information**

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

#### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.