



Future Technology Devices International Ltd.

Application Note AN_118 Migrating Vinculum Designs From VNC1L to VNC2-48L1A

Document Reference No.: FT_000159

Version 1.2

Issue Date: 2010-04-22

The purpose of this document is to provide guidelines for migrating VNC1L designs to VNC2.








TABLE OF CONTENTS

1	ln ⁻	troduction	2			
2	١٧	NC1L vs VNC2	3			
3	Re	eference Schematics	4			
	3.1	VNC1L schematic	4			
	3.2	VNC2-48L1A Equivalent of VNC1L VDIP2 Reference Schematic	5			
4	В	OM Change required to convert from VNC1L to VNC2-48L1A	6			
5	Fi	rmware	7			
6	Lo	oading Firmware	8			
7	Summary12					
8	Co	Contact Information13				
Α	ppei	ndix A – Revision History	15			

Migrating Vinculum Designs From VNC1L to VNC2-48L1A Application Note AN_118

Version 1.2

Clearance No.: FTDI# 139

Introduction 1

The Vinculum VNC2 is FTDI's 2^{nd} generation USB host controller solution and it expands on the capabilities of the VNC1L. VNC2 is supplied in 6 different packages. These are 32 pin QFN and LQFP packages, 48 pin QFN and LQFP packages and 64 pin QFN and LQFP packages.

The smaller packages reduce the number of IO by 16 pins to allow for more compact designs where space limitations are a consideration.

The larger packages provide additional 16 I/O to allow for increased functionality. In addition to the increased number of VNC2 package options, there is also a new software development tool suite developed by FTDI to enable users to create their own customised firmware.

The main focus of this document will be on how to migrate from a design using the VNC1L to a VNC2-48L1A device.



Clearance No.: FTDI# 139

2 VNC1L vs VNC2

The main features of the two generations of devices are shown below. All features are available in the 64 pin packages. The 48 pin and 32 pin packages have the same memory and internal functions but less I/O. The 48 pin package matches the VNC1L device. For full details see the VNC2 Datasheet at www.ftdichip.com


FEATURE	VNC1L	VNC2
MECHANICAL	12 1 12 2	
Package	48 pin LQFP	64, 48,32 pin QFN or LQFP
Temperature	-40 to +85C	-40 to +85C
ELECTRICAL		
VCC	3V3	3V3
VCCIO	5V tolerant 3V3	5V tolerant 3V3
CLK source	12MHz (external)	12MHz (external)
СРИ	8-bit Harvard architecture	16-bit Harvard architecture
INTERFACING		
USB ports	2	2
UART port	1	1
SPI slave port	1	2
SPI master port	0	1
FIFO monitor port option	1	1
Debug port	0	1
FIRMWARE		
Precompiled firmware	YES	YES
Tools for creating own firmware	NO	YES
MEMORY		
DATA RAM	4k x 8 (4kbytes)	4k x 32 (16kbytes)
E-FLASH	64k x 8 (64kbytes)	128k x 16 (256kByte)
USB MODES		
Speed	Full / low	Full / low
Transfer modes	Bulk / Interrupt	Bulk, interrupt, isochronous
CONFIGURATION PORTS		
UART	YES	YES
USB	YES (after initial programming)	YES
SPI	NO	YES
FIFO	NO	YES
DEBUG PORT	N/A	YES

Clearance No.: FTDI# 139

3 Reference Schematics


3.1 VNC1L schematic

This schematic is for the VDIP2 based on the VNC1L.



Clearance No.: FTDI# 139

3.2 VNC2-48L1A Equivalent of VNC1L VDIP2 Reference Schematic



Document Reference No.: FT_000159

Version 1.2 Clearance No.: FTDI# 139

BOM Change required to convert from VNC1L to VNC2-48L1A

VNC1L Schematic Component	VNC2-48L1A Schematic Component	Description
U1 - VNC1L	U1 -VNC2-48L1A	Controller IC
C8, C9 – 68pF Capacitor	C10, C11 – 27pF Capacitor	Load capacitor on crystal
R9, 10k resistor	Do not fit pull down on U1 pin 48	PLL enable
R7, 180R	Replace with 0R link or simply track over if redesigning PCB	VNC1L PLL Filter / VNC2 VREGOUT
C10, 10nF	C12, 4.7uF	VNC1L PLL Filter / VNC2 VREGOUT
C11, 1nF	C13, 100nF	VNC1L PLL Filter / VNC2 VREGOUT
R8, 0R to 3V3		Remove

The pull up resistors, shown on the VNC1L schematic R12-R36, are optional even on the VNC1L schematic.

Clearance No.: FTDI# 139

5 Firmware

As the internals of the two devices is different, the firmware that runs on the devices is different. However to maintain backward compatibility there is equivalent firmware available for download.

VNC1L Firmware	VNC2 Firmware
VDAP	V2DAP
VMSC	V2MSC
VDPS	V2DPS
VCDC	V2CDC
VDIF	V2DIF2

These builds may be downloaded from www.ftdichip.com (at the time of writing this application note, these builds were not available, but were scheduled to be put onto the website soon).

In addition to using these pre-compiled libraries, VNC2 is supplied with a software development tool chain to allow customers to customise the pre-compiled firmware or create their own firmware for greater flexibility in design.

Clearance No.: FTDI# 139

Loading Firmware

VNC1L was limited to using the UART to load firmware onto a blank device. The VNC2 may be programmed via the debug port or via the UART interface. Although FTDI will provide utilities for this, there may be situations where users prefer to develop their own programmer over the UART and there are some significant differences between VNC1L and VNC2.

Key differences between VNC1L and VNC2:

- Each block of the flash on the VNC2 is 128 bytes compared with 64 bytes on the VNC1L.
- The endianess of the VNC2 is different from that of the VNC1L meaning that data must be reversed before it can be sent to the device.
- The size of the ROM files on VNC1L were all 64k, the ROM files on the VNC2 can be anything up to the size of the flash.

To program the VNC2 firmware over the UART the device must be reset in prog mode; this is achieved by driving the prog# pin low and then driving the reset# pin low then high. When the device is in prog mode it is ready be programmed over the UART using the following command / response standard.

Command Name	Command(s):	Response	Comment
Echo	0xFF	0xFF	
Echo	0xFB	0xFB	VNC1L used the 0xFA command to echo, VNC2 uses 0xFB to distinguish between the devices.
Set Baud Rate	0x01 BaudRate(1, 2 or 3)	0x02	(9600 Baud == 1, 115200 Baud == 2 and 1MBaud == 3)
Read Address	0x02 FlashAddrLow FlashAddrHigh	0x02 Data to Read	
Write Address	0x02 FlashAddrLow FlashAddrHigh Data to Write	0x02	The 0x02 response will be sent after FlashAddrHigh has been received by the device.

Below is a snippet of the test code that has been used to write and verify the flash of the VNC2....

```
// Sample code for writing flash of VNC2 written in C/C++.
// Function: sendData - writes the data read from the ROM file to the VNC2 and verifies it.
// Parameters: romfile - a handle to the ROM file obtained from the open(....) function.
            filename - a char array containing the name of the rom file that we have opened.
//
            ftHandle - handle to the TTL cable that we are communicating over.
//
// Return:
             returns 1 on successful completion, !1 otherwise.
char sendData(int romfile, char *filename, FT_HANDLE ftHandle)
{
       unsigned long filesize;
       unsigned long pageSegCount;
                                              // The amount of pages needed to store the ROM file.
       unsigned long pageRem = 0;
                                              // Portion of a ROM file left over that doesn't fill a full
       unsigned long numwrit;
                                              // Not required to be used....
       unsigned long padByteCnt = 0;
       unsigned long padSegRem = 0;
       unsigned long padSegSize = (1 * 128);
       unsigned char databuf[PAGESIZE];
                                              // Data read from the ROM file.
```



Clearance No.: FTDI# 139

```
// Data read from the ROM file reversed to accommodate
unsigned char endianBuf[PAGESIZE];
                                      // VNC2 endianess
unsigned char receiveBuf[PAGESIZE]; // Data received from the VNC2
unsigned char j = 0;
unsigned char cmd;
unsigned char dataread = 0x00;
unsigned char baudbuf[6];
FT_STATUS ftStatus;
unsigned long i;
                                      // Index used as the location within the device flash.
struct stat stbuf;
stat(filename, &stbuf);
// FILE SIZE CALCULATIONS
filesize = stbuf.st size;
pageSegCount = filesize / PAGESIZE;
pageRem = filesize % PAGESIZE;
//echo from the device...
cmd = 0xFF;
ftStatus = FT_Write(ftHandle, &cmd, 1, &numwrit);
numwrit = 0;
ftStatus = FT Read(ftHandle, &dataread, 1, &numwrit);
cmd = 0xFB;
ftStatus = FT Write(ftHandle, &cmd, 1, &numwrit);
numwrit = 0;
ftStatus = FT_Read(ftHandle, &dataread, 1, &numwrit);
// Set the baud rate of the chip...
cmd = 0x01;
baudbuf[0] = cmd;
                              // 1, 2 or 3
baudbuf[1] = 0x03;
ftStatus = FT_Write(ftHandle, baudbuf, 2, &numwrit);
// Allow some time for the baud rate to settle...
Sleep(100);
// Set the baud rate of the TTL cable.
FT_SetBaudRate(ftHandle, 1000000);
numwrit = 0:
ftStatus = FT_Read(ftHandle, &dataread, 1, &numwrit);
if(dataread != 0x02)
       printf("The baud rates aren't synced, exiting.\n");
       return -1;
}
//echo from the device...
cmd = 0xFB:
FT_Write(ftHandle, &cmd, 1, &numwrit);
numwrit = 0;
FT Read(ftHandle, &dataread, 1, &numwrit);
cmd = 0xFF;
FT_Write(ftHandle, &cmd, 1, &numwrit);
numwrit = 0;
FT_Read(ftHandle, &dataread, 1, &numwrit);
printf("Writing File");
// Increment by one to accommodate the fractional page, the fractional page will be memset with
// 0xFF...
```



Clearance No.: FTDI# 139



pageSegCount++;

```
for(i = 0; i < pageSegCount; i++)</pre>
       unsigned char transdata[2];
       int numread = 0;
       // Memset the data buffer...
       memset(databuf, 0xFF, PAGESIZE);
       numread = read(romfile, databuf, PAGESIZE);
       // Change the data to little? endian for VNC2.
       for (j=0; j < PAGESIZE; j += 2)
               endianBuf[j] = databuf[j+1];
               endianBuf[j+1] = databuf[j];
       }
       WRITE FORMAT
       0x03
       FlashAddressLow
       FlashAddressHigh
       Data block to write.
       cmd = 0x03;
       FT_Write(ftHandle, &cmd, 1, &numwrit);
       transdata[0] = (i \& 0xFF);
       transdata[1] = ((i >> 8) \& 0xFF);
       // Send the data address....
       FT_Write(ftHandle, transdata, 2, &numwrit);
       // Check for a response from this....
       FT Read(ftHandle, &dataread, 1, &numwrit);
       if(dataread != 0x02)
       {
               printf("!");
               return -1;
       }
       // Send the data.
       // Send the data address....
       FT Write(ftHandle, endianBuf, PAGESIZE, &numwrit);
       // Check for a response again....
       FT_Read(ftHandle, &dataread, 1, &numwrit);
       if(dataread == 0x02)
       {
               printf(".");
       }
       else
               printf("!");
               return -1;
       }
       READ FORMAT
       0x02
       FlashAddressLow
       FlashAddressHigh
       // Read the data back to make sure that it has been programmed correctly.
```



Clearance No.: FTDI# 139



```
cmd = 0x02;
               transdata[0] = (i \& 0xFF);
               transdata[1] = ((i >> 8) \& 0xFF);
               // Send the command
               FT Write(ftHandle, &cmd, 1, &numwrit);
               // Send the data address....
               FT_Write(ftHandle, transdata, 2, &numwrit);
               // Check for a response from this....
               FT_Read(ftHandle, &dataread, 1, &numwrit);
               Sleep(10);
               // Make sure that we have 128 bytes to read from the chip!!!
               FT GetQueueStatus(ftHandle, &numwrit);
               if(numwrit < PAGESIZE)</pre>
               {
                       printf("Not enough data to read");
                       return -1;
               }
               // Read 128 bytes back from the chip...
               FT_Read(ftHandle, receiveBuf, PAGESIZE, &numwrit);
// Compare the data read back from the flash with the data sent....
// NOTE: The data that is returned is reversed due to the endianess of the VNC2,
// compare the returned data with the data that we reversed to send to the chip.
               for(j = 0 ; j < PAGESIZE; j++)
                       if(endianBuf[j] != receiveBuf[j])
                               printf("The data returned is not the same!");
                               return -1;
                       }
               }
       return 1;
}
```

Migrating Vinculum Designs From VNC1L to VNC2-48L1A Application Note AN_118

Version 1.2

Clearance No.: FTDI# 139

7 Summary

In summary VNC2 will allow for existing PCBs to be upgraded to the more powerful device without needing to change the PCB, but will also allow for greater customisation of the firmware and hence a better product and user experience.

New designs, requiring new PCBs may also opt for different device packages. The 32 pin option will allow for smaller designs where space is a consideration. The 64 pin package will allow for additional functionality to be added via the extra pin count.



Clearance No.: FTDI# 139

8 Contact Information

Head Office - Glasgow, UK

Future Technology Devices International Limited Unit 1, 2 Seaward Place, Centurion Business Park Glasgow G41 1HH United Kingdom

Tel: +44 (0) 141 429 2777 Fax: +44 (0) 141 429 2758

E-mail (Sales) sales1@ftdichip.com
E-mail (Support) support1@ftdichip.com
E-mail (General Enquiries) admin1@ftdichip.com

Web Site URL http://www.ftdichip.com Web Shop URL http://www.ftdichip.com

Branch Office - Taipei, Taiwan

Future Technology Devices International Limited (Taiwan)

2F, No 516, Sec. 1 NeiHu Road

Taipei 114 Taiwan, R.O.C.

Tel: +886 (0) 2 8797 1330 Fax: +886 (0) 2 8751 9737

E-mail (Sales) <u>tw.sales1@ftdichip.com</u>

E-mail (Support) <u>tw.support1@ftdichip.com</u> E-mail (General Enquiries) <u>tw.admin1@ftdichip.com</u>

Web Site URL http://www.ftdichip.com

Branch Office - Hillsboro, Oregon, USA

Future Technology Devices International Limited (USA) 7235 NW Evergreen Parkway, Suite 600 Hillsboro, OR 97123-5803 USA

Tel: +1 (503) 547 0988 Fax: +1 (503) 547 0987

E-Mail (Sales)

E-Mail (Support)

E-Mail (General Enquiries)

Web Site URL

us.sales@ftdichip.com
us.support@ftdichip.com
us.admin@ftdichip.com
http://www.ftdichip.com

Branch Office - Shanghai, China

Future Technology Devices International Limited (China) Room 408, 317 Xianxia Road, ChangNing District, ShangHai, China

Tel: +86 (21) 62351596 Fax: +86(21) 62351595

E-Mail (Sales): cn.sales@ftdichip.com E-Mail (Support): cn.support@ftdichip.com

E-Mail (General Enquiries): cn.admin1@ftdichip.com

Web Site URL: http://www.ftdichip.com



Document Reference No.: FT_000159

Migrating Vinculum Designs From VNC1L to VNC2-48L1A Application Note AN_118


Version 1.2

Clearance No.: FTDI# 139

Distributor and Sales Representatives

Please visit the Sales Network page of the FTDI Web site for the contact details of our distributor(s) and sales representative(s) in your country.

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. Future Technology Devices International Ltd will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH United Kingdom. Scotland Registered Number: SC136640



Clearance No.: FTDI# 139



Appendix A - Revision History

Version PreliminaryFirst Preliminary version available1st Feb 2010Version 1.0First release Rev 1.0 available19th Feb 2010Version 1.1Added new chapter 6 for loading firmware over UART22nd March 2010Version 1.2Modified chapter 622nd April 2010