```
0279
        32
              BZ
                         ; Branch to exit - no conversion needed
  7A
        8F
  7B
        FO
              LDX
                         Get the same instruction from stack
  7C
        FB
              XRI
  7D
        70
                         ; If = 70 (7N type)
        32
  7E
              BZ
                         ; Branch to exit
        8F
  7F
0280
        FO
             LDX
  81
        FB
              XRI
  82
        CO
                         ; If = CO (CN type)
  83
        32
              BZ
                         ; Branch to exit
  84
        8F
  85
86
        FO
             LDX
        FB
             XRI
  87
88
        FO
                         ; If = FO (FN type)
        32
              BZ
                         ; Branch to exit
  89
        8F
  8A
        OA
             LDN
                   RA
                         ;Else get the instruction
  8B
        F9
             ORI
  8C
        OF
                         ; "OR" to convert to XF for look up table
  8D
        B7
             PHI
                         :Store in R7.1
        D5
  8E
             SEP
                   R5
                         :Return
  8F
        OA
             LDN
                   RA
                         Some tests branch to here, loading R7.1
0290
        B7
             STR
                   R7
                         ; With the unconverted instruction
  91
             SEP
        D5
                   R5
                         :And returning
                           TEST FOR ARGUMENTS
0292
        F8
             LDI
  93
94
        01
        AB
             PLO
                   RB
                         ;Initialize RB.O = O1 -Argument count
  95
96
        F8
             LDI
        02
  97
98
             PLO
                         ;RF.0 = Loop count - 2 part table
        AF
                   RF
        OA
             LDN
                   RA
                         ;Get instruction for disassembly
  99
        E2
             SEX
                         X = 2
  9Å
9B
        52
             STR
                   R2
                         ; Push value for comparison test
       F8
             LDI
  90
       09
  9D
        BE
             PHI
                   RE
                         ;Set RE = beginning
  9E
        F8
             LDI
  9F
        CO
                         Of argument table @ 0900
02A0
        AE
             PLO
                   RE
        4E
  A1
             LDA
                   RE
                         ;Get entry from table - advance pointer
                         ; If 00 (null) found (end of part "N" table)
  A2
        32
             BZ
        A8
                         ; Branch to done test
  A3
  A4
        F3
             XOR
                         ;Else compare with stacked instruction
  A5
A6
        3A
             BNZ
                         :If not equal, loop till equality or
                         ; End of table part "N" found
        A1
```