# Contents

1	Cor	Configurations, Forces, Moments, Equilibrium (Compact Sheet)				
	1.1	Geometry of a planar curve (arclength $s$ )	1			
	1.2	Forces and moments (Cosserat rod view)	1			
	1.3	Worked examples	2			
	1.4	At-a-glance checklist	3			
	1.5	Minimal 3D $\rightarrow$ 1D link (why the equations look like this)	3			
2	Def	ormation and Elasticity	4			
	2.1	Kinematics: reference vs. deformed configurations	4			
	2.2	Examples (kinematics only)	4			
	2.3	Statics recap in Lagrangian form (per reference length)	5			
	2.4	Virtual work and elastic energy	5			
	2.5	Linear elasticity (Hooke-type rod)	5			
	2.6	Special limiting models	6			
	2.7	Checklist for problems	6			
3	_	uilibrium Boundary-Value Problems	7			
	3.1	Overview	7			
	3.2	Typical boundary conditions	7			
	3.3	Summary of governing equations (Lagrangian form)	7			
	3.4	Rigid-body model	8			
	3.5	Rigid ring under uniform pressure $p$	8			
	3.6	Elastic ring	9			
	3.7	Strings	9			
4	Mo	del Comparison in Statics	10			
	4.1	Introduction	10			
	4.2	Galileo's beam setup	10			
	4.3	Load regimes	10			
	4.4	Small load regime	11			
	4.5	Moderate loads: nonlinear elastic rod	11			
	4.6	Large load regime	11			
	4.7	Model validity summary	12			
5	Lin	ear Elasticity	13			
	5.1	Prelude: Galileo's beam in the small-load regime	13			
	5.2	Assumptions of linear elasticity	13			
	5.3	Linearized kinematics	13			
	5.4	Linearized equilibrium equations	14			
	5.5	Linearized constitutive relations	14			
	5.6	Linearized boundary conditions	14			

2 Contents

	5.7 5.8	Solving the linearized BVP	
6	Sta	bility of Conservative Systems with $N$ Degrees of Freedom (Part 1)	16
	6.1	Conservative forces	16
	6.2	Conservative elastic systems	16
	6.3	Kinematically admissible configurations	17
	6.4	Stability criterion	17
	6.5	Example 1: Rotating rigid bar	18
	6.6	Example 2: Rotating rigid beam on a roller	18
	6.7	General conclusions	19

# Configurations, Forces, Moments, Equilibrium (Compact Sheet)

# Geometry of a planar curve (arclength s)

Let the centerline be  $\mathbf{r}(s) \in \mathbb{R}^2$ , with unit tangent  $\mathbf{t} = \mathbf{r}'(s)$ ,  $|\mathbf{t}| = 1$ , and unit normal  $\mathbf{n}$  obtained by a  $+90^{\circ}$  rotation of  $\mathbf{t}$ . The tangent angle  $\alpha(s)$  satisfies  $\mathbf{t} = (\cos \alpha, \sin \alpha)$  and the signed curvature is  $\kappa(s) = \alpha'(s)$ .

# Frenet relations

$$t' = \kappa n$$
,

$$n' = -\kappa t$$
,

$$\kappa = \alpha'(s).$$

# Orientation and curvature sign

Reversing the parametrization (clockwise vs. counterclockwise) flips the sign of  $\kappa$ .

# Forces and moments (Cosserat rod view)

# Decomposition in n and t

$$N' - \kappa T + f_n = 0,$$

$$T' + \kappa N + f_t = 0,$$

$$M' + T + m_b = 0,$$

**Internal resultants:** contact force F(s) (decomposed as F = Nn + Tt) and bending moment M(s) (out of plane, scalar).

**Distributed loads:** body force per unit length f(s) and body couple per unit length  $m_b(s)$ . Concentrated loads at  $s = s_0$ : force P and couple  $M_0$ .

# Local equilibrium (no concentrated loads in the open interval)

# Vector form

$$F'(s) + f(s) = 0$$
,  $M'(s) + r'(s) \times F(s) + m_b(s) = 0$ 

In 2D ( $\mathbf{r}' = \mathbf{t}$ ; the cross product is out-of-plane): where  $f_n = \mathbf{f} \cdot \mathbf{n}$  and  $f_t = \mathbf{f} \cdot \mathbf{t}$ .

# Action-reaction and jump conditions

Across a point  $s_0$  with no concentrated load:

$$F(s_0^-) = F(s_0^+), \quad M(s_0^-) = M(s_0^+).$$

If a concentrated force P and/or couple  $M_0$  act at  $s_0$ :

# Jump conditions at $s_0$

$$M(s_0^+) - M(s_0^-) + \underbrace{(\mathbf{r}'(s_0) \times 0)}_{=0 \text{ for point load on centerline}} + M_0 = 0.$$

(If P acts off the centerline, include the appropriate moment of P about the section.)

# **Endpoint conditions**

At the right end s = L with applied  $\mathbf{F}^{\text{ext}}, M^{\text{ext}}$ :

$$F(L) + F^{\text{ext}} = 0,$$
  $M(L) + M^{\text{ext}} = 0.$ 

At the left end s = 0 with applied  $F_0, M_0$  (note sign due to orientation):

$$F(0) - F_0 = 0,$$
  $M(0) - M_0 = 0.$ 

A free end has  $\mathbf{F} = \mathbf{0}$ , M = 0.

# Worked examples

# Circular vault / arch of radius R

Parametrize counterclockwise by angle  $\theta$ ; arclength  $s = R\theta$ . Then

$$t = (-\sin \theta, \cos \theta), \quad \alpha = \theta, \quad \kappa = \alpha' = \frac{1}{R}.$$

Clockwise parametrization gives  $\kappa = -1/R$ .

# Cantilever of length L with a tip load $P \hat{y}$ at s = L (weightless beam)

No distributed loads:  $\mathbf{f} = \mathbf{0}$ ,  $m_b = 0$ .

$${m F}'=0 \ \Rightarrow \ {m F}(s)\equiv (0,P) \quad \mbox{(constant shear, no axial)},$$
  $M'+T=0 \ \Rightarrow \ M'(s)+P=0 \ \Rightarrow \ M(s)=-P(L-s).$ 

Reactions at the wall (s = 0):  $\mathbf{F}(0) = (0, P)$  and M(0) = PL.

# Body couple from eccentric reinforcement (reinforced concrete column)

Concrete matrix area  $A_c$ , density  $\rho_c$ ; steel area  $A_m$ , density  $\rho_m$ ; gravitational  $\mathbf{g} = g \hat{\mathbf{y}}$ ; steel centroid offset h from the centerline.

Body force per length:  $\mathbf{f} = (\rho_c A_c + \rho_m A_m) \mathbf{g}$ , Body couple per length:  $m_b = \rho_m A_m \mathbf{g} \mathbf{h}$ .

If h = 0 (reinforcement on centerline), then  $m_b = 0$ .

# At-a-glance checklist

- Pick orientation and note  $\kappa$  sign.
- Resolve loads along (n, t); write N', T', M' equations.
- Apply jump/endpoint conditions (free, clamped, loaded).
- Integrate from boundary where reactions are known.

# Minimal 3D→1D link (why the equations look like this)

Balancing 3D tractions and body forces over a thin control volume around a section and taking the slender limit yields the 1D balance:  $\mathbf{F}' + \mathbf{f} = 0$  and  $M' + \mathbf{t} \times \mathbf{F} + m_b = 0$ . The action–reaction and jump conditions follow from the same control-volume argument.

# Deformation and Elasticity

# Kinematics: reference vs. deformed configurations

Let S denote the arclength in the reference configuration and s the arclength in the deformed configuration. A material point is labeled by  $S \in [0, L_0]$  and maps to a current position r(S) in the equilibrium configuration. Let  $\alpha_0(S)$  be the tangent angle of the reference centerline and  $\alpha(S)$  that of the deformed centerline. Define

$$\text{stretch} \quad E(S) := \frac{\mathrm{d}s}{\mathrm{d}S} - 1 = \| \boldsymbol{r}'(S) \| - 1, \qquad \text{flexural strain} \quad K(S) := \omega'(S), \ \ \omega(S) := \alpha(S) - \alpha_0(S).$$

# Idea (measures of deformation).

E captures in-plane stretching (change of length); K captures bending (change of orientation relative to the reference). For a pure rigid motion:  $E \equiv 0$  and  $K \equiv 0$ .

# Useful relations.

$$t_0 = (\cos \alpha_0, \sin \alpha_0), \ t = (\cos \alpha, \sin \alpha), \ \kappa_0 = \frac{d\alpha_0}{ds_0}, \ \kappa = \frac{d\alpha}{ds}, \ \text{and} \ K = \frac{d\alpha}{dS} - \frac{d\alpha_0}{dS}.$$

# Change of curvature vs. K

The geometric change of curvature  $\bar{\kappa} := \kappa - \kappa_0$  is *not* the same as K in general (they coincide when  $E \equiv 0$ ). This justifies using E and K as independent strain measures.

# Examples (kinematics only)

# Uniform stretching of a straight wire.

If  $s' = ds/dS = 1 + \varepsilon$  (constant), then  $E = \varepsilon$  (constant) and K = 0.

# Uniform coiling of an unstretched string on a circle of radius R.

If s'=1 (no stretch), the string winds into a circle:  $\alpha'(S)=1/R$  so K=1/R and E=0.

# Uniform dilation of a circular ring from $R_0$ to R.

The ring expands uniformly with no additional rotation relative to the reference centerline, giving  $E = \frac{R - R_0}{R_0}$  and K = 0 (even though  $\kappa$  changes from  $1/R_0$  to 1/R).

# Statics recap in Lagrangian form (per reference length)

Let  $\mathbf{F}(S) = N \, \mathbf{n} + T \, \mathbf{t}$  be the internal force resultant and M(S) the internal bending moment (out of plane). With body force  $\mathbf{f}(S)$  and body couple  $m_b(S)$  per unit reference length, the local balances read

# Local equilibrium (no point loads in the open interval).

$$F'(S) + f(S) = 0,$$
  $M'(S) + t(S) \times F(S) + m_b(S) = 0.$ 

# Jumps and endpoints.

Across  $S_0$  with a concentrated force  $\mathbf{P}$  and couple  $M_0$ :  $\mathbf{F}^+ - \mathbf{F}^- + \mathbf{P} = 0$ ,  $M^+ - M^- + M_0 = 0$ . At a free end:  $\mathbf{F} = \mathbf{0}$ , M = 0.

# Virtual work and elastic energy

Consider a quasi-static adjacent equilibrium  $\delta r(S)$ . The external virtual work equals the internal one:

# Power-conjugate pairs.

$$\delta W = \int_0^{L_0} (N \, \delta E + M \, \delta K) \, \mathrm{d}S.$$

In an elastic rod, this derives from a lineal strain-energy density  $W_e(E, K)$ :

# Constitutive in energetic form.

$$N = \frac{\partial W_e}{\partial E}, \qquad M = \frac{\partial W_e}{\partial K}.$$

# Linear elasticity (Hooke-type rod)

For small strains and small curvature changes, a standard quadratic density is

$$W_e(E, K) = \frac{1}{2} EA E^2 + \frac{1}{2} EI K^2,$$

where EA is the axial stiffness and EI the bending stiffness (both possibly varying with S for inhomogeneous rods).

# Linear constitutive laws.

$$N = EAE$$
,  $M = EIK$ .

# Section properties.

For homogeneous isotropic material with Young's modulus  $E_Y$ :  $EA = E_YA$ ,  $EI = E_YI$ , where A is the cross-sectional area and I the (geometric) second moment of area about the out-of-plane axis of bending.

# Order-of-magnitude (steel).

 $E_Y \approx 200\,\mathrm{GPa}$ . A 1 m steel rod with  $A=1\,\mathrm{cm^2}$  under  $P=1000\,\mathrm{N}$  in uniform tension stretches by  $\Delta L \approx \frac{PL}{EA} \sim 5 \times 10^{-6}\,\mathrm{m}$ .

# Special limiting models

# Summary of idealizations.

- Inextensible rod:  $E \equiv 0$  (constraint). N becomes a reaction (not constitutively prescribed). Bending elastic with M = EIK.
- Inflexible rod (rigid bar):  $K \equiv 0$  (constraint). M becomes a reaction. Axial elastic with N = EAE.
- String (perfectly flexible):  $M \equiv 0$ ; only axial response N = EAE (or inextensible string:  $E \equiv 0$ , N reactive).

# Checklist for problems

- 1. Choose reference  $\rightarrow$  current orientation; note whether E or K are constrained (idealizations).
- 2. Write local equilibrium in S; decompose along (t, n) if needed.
- 3. Use constitutive laws (N = EAE, M = EIK) or constraints (inextensible/inflexible).
- 4. Apply jumps/endpoint conditions; integrate from a boundary with known reactions.

# Equilibrium Boundary-Value Problems

# Overview

A static boundary-value problem (BVP) combines:

- 1. geometric relations (kinematics),
- 2. equilibrium equations (force and moment balance),
- 3. constitutive relations (N(E,K), M(E,K)),
- 4. and boundary conditions (BCs) at endpoints.

At each endpoint we impose either **position** or **force**, and either **orientation** or **moment**, but not both.  $\Rightarrow$  Three BCs total: two translational, one rotational.

# Typical boundary conditions

# Common boundary conditions

Clamped (built-in): both position and tangent angle  $\alpha$  prescribed.

**Pinned (hinged):** position prescribed, rotation free  $\Rightarrow M = 0$ .

**Roller:** point slides on a known curve  $y_c(x)$  (one geometric constraint), rotation free  $\Rightarrow M = 0$ .

**Loaded end:** applied resultant F and/or moment M specified.

**Periodic:** for a closed ring, r(0) = r(L),  $\alpha(0) = \alpha(L)$ , N(0) = N(L), M(0) = M(L).

# Heuristic rule for endpoints

At each end: impose (either E or r) and (either M or  $\alpha$ ).

Summary of governing equations (Lagrangian form)

# Governing equations

Geometry:  $\mathbf{r}' = \mathbf{t} = (\cos \alpha, \sin \alpha), \qquad \alpha' = K,$ 

Force balance:  $\mathbf{F}' + \mathbf{f} = 0$ ,  $\mathbf{F} = N\mathbf{n} + T\mathbf{t}$ ,

Moment balance:  $M' + t \times F + m_b = 0$ ,

Constitutive: N = EAE, M = EIK (or degenerate models),

BCs: as above (position/force + angle/moment).

# Rigid-body model

Rigid E = 0, K = 0. Only reactions are determined by equilibrium.

# Rigid cantilever with uniform weight

Length L, uniform load qg per length, clamped at S=0, free at S=L.

Force balance:  $T'(S) + qg = 0 \Rightarrow T(S) = qg(L - S), N(S) = 0.$ 

Moment balance:  $M'(S) + T(S) = 0 \Rightarrow M(S) = \frac{1}{2}qg(L-S)^2$ .

At wall (S = 0): T(0) = qgL,  $M(0) = \frac{1}{2}qgL^2$ .

# Roller at free end

Replacing the free condition by a roller removes one reaction: M(L) = 0, but the tangential reaction remains unknown—consistent with one less BC.

# Rigid ring under uniform pressure p

# Equilibrium of a rigid ring

Normal force:  $N(S) = pR \cos(\theta - \theta_0)$ ,

Shear force:  $T(S) = pR \sin(\theta - \theta_0)$ ,

Bending moment:  $M(S) = pR^2 \sin(\theta - \theta_0)$ .

# Interpretation

The rigid model leaves three arbitrary constants (global translation and rotation). Elasticity removes this indeterminacy.

3.6 Elastic ring

# Elastic ring

# Uniform contraction under pressure

With N=EAE, M=EIK, assume uniform contraction so K=0, E=0 constant. Equilibrium  $\Rightarrow N=pR=EAE$   $\Rightarrow E=\frac{pR}{EA}$ .

# Remarks

For p > 0 (compression), large enough p produces buckling (critical  $p_{\rm cr} \sim 3EI/R^3$ ). For p < 0, expansion is uniform.

# Strings

For a string,  $EI = 0 \Rightarrow M = 0$ .

# String equilibrium

$$N' + f_t = 0,$$
  $T \equiv 0,$   $\mathbf{F} = N\mathbf{t}.$ 

# Tangent discontinuities

When EI=0, bending energy vanishes and  $\alpha$  may be discontinuous. Therefore  $\alpha$  cannot be prescribed at endpoints.

# Extensible string pulled by a tip force F

Weightless, pinned at S=0, tension N(L)=F. Force balance  $\Rightarrow N(S)=F$ . From N=EAE we get  $E=\frac{F}{EA}$  constant. For an inextensible string (E=0), N is not given constitutively but adjusts to satisfy geometry and BCs.

# Summary of models

Model	Assumptions	Constitutive laws	Remarks
Rigid bar	E = 0, K = 0	none (reactions only)	No deformation
Elastic rod	small $E, K$	N = EAE, M = EIK	Standard elastic
Inextensible rod	E = 0	M = EIK	N reactive
String	EI = 0	N = EAE, M = 0	No bending
Inextensible string	E=0,EI=0	none $(N \text{ reactive})$	Perfectly flexible

# Model Comparison in Statics

## Introduction

We now compare the various models introduced so far — from the **rigid body** (no deformation) to the **extensible string** (perfectly flexible). The central one is the **elastic rod**, characterized by both axial and bending stiffnesses (EA, EI). While the elastic model is the most accurate, it can be mathematically demanding; simpler models may reproduce its behavior accurately under specific load regimes.

## Goal

Find which simplified model best approximates the full elastic model for a given structure, material, and load magnitude.

# Galileo's beam setup

A beam of stiffness (EA, EI), length L, clamped at S=0, and loaded by a vertical force F at its tip.

# Dimensionless form

Introducing  $\xi = S/L$  and the critical Euler load  $F_c = \pi^2 EI/L^2$ , we obtain:

$$\alpha'' + \lambda^2 \sin \alpha = 0, \qquad \alpha(0) = 0, \ \alpha(1) = 0,$$

where  $\lambda^2 = \frac{FL^2}{EI}$  measures load magnitude relative to bending stiffness.

# Load regimes

### 

# Small load regime

For  $F/EI \ll 1$ ,  $\sin \alpha \approx \alpha$  and the problem linearizes:

$$EI \alpha'' + F \alpha = 0,$$
  $\alpha(0) = \alpha(L) = 0.$ 

## Linearized solution

$$\alpha(S) = \frac{FL^2}{2EI} \left( \frac{S}{L} \right) \left( 1 - \frac{S}{L} \right), \quad M(S) = EI \, \alpha'(S) = F(L-S), \quad T(S) = F, \quad N(S) \approx 0.$$

# Interpretation

The linearized beam behaves almost rigidly — internal forces and moments match those of the rigid model to first order. Deformations, though small, can be computed analytically.

# Moderate loads: nonlinear elastic rod

For  $F/EI = \mathcal{O}(1)$ , extensibility remains negligible  $(E \simeq 0)$ , but the sine term must be retained.

# Phase-space formulation

Multiplying by  $\alpha'$ , integrate once:

$$\frac{1}{2}EI(\alpha')^2 = F(1 - \cos \alpha) + C.$$

This defines trajectories in  $(\alpha, \alpha')$  phase space corresponding to different load levels and boundary angles.

# Bifurcation and branches

When F exceeds the Euler critical value  $F_c$ , multiple equilibrium shapes (buckled branches) appear. These are symmetric, periodic solutions  $\alpha(S)$  corresponding to arcs AB, CD, etc. in phase space.

# Large load regime

For  $F/EI \gg 1$ , bending stiffness becomes negligible except near the clamped end. The rod behaves as a **string** almost everywhere.

# Asymptotic behavior

Outer region:  $EI\alpha'' \approx 0 \Rightarrow \cos \alpha \approx 0 \Rightarrow \text{string-like}$ .

Inner region:  $EI\alpha''$  balances  $F\cos\alpha$ , forming a narrow **boundary layer** near S=0.

# Boundary layer correction

Let  $x = S/\delta$ , with  $\delta \sim (EI/F)^{1/2}$  the thickness where bending and tension balance. The boundary-layer equation reads:

$$\alpha'' = \cos \alpha, \quad \alpha(0) = 0, \quad \alpha(+\infty) = \alpha_{\text{string}}.$$

Its unique smooth solution connects the clamped boundary to the outer (string) region.

# Boundary-layer solution

$$\alpha(x) = 4 \arctan[\tanh(x/2)],$$

with rotation rapidly changing over  $x = \mathcal{O}(1)$  then matching the string angle  $\alpha \to \alpha_{\text{string}}$ .

# Model validity summary

# Summary diagram

Load range	Dominant physics	Best model
$F \ll 0.25 F_c$	small deflection	Linearized beam
$0.25F_c \lesssim F \lesssim 5F_c$	finite deflection	Nonlinear elastic rod
$F \gg 5F_c$	near-string behavior	String + boundary layer

# Takeaway

The most appropriate model depends not only on material and geometry (EA, EI), but also on the magnitude of the applied load:

$$\frac{FL^2}{EI} \ll 1 \Rightarrow \text{linear}, \quad \frac{FL^2}{EI} \sim 1 \Rightarrow \text{elastic}, \quad \frac{FL^2}{EI} \gg 1 \Rightarrow \text{string with boundary layer}.$$

# Linear Elasticity

# Prelude: Galileo's beam in the small-load regime

For small Euler number  $F/F_c \ll 1$ , the nonlinear elastica reduces to a linear theory. The equilibrium configuration coincides (to first order) with the reference configuration predicted by the rigid-body model.

# Observation

Internal forces (N, T, M) are the same as in the rigid-body model, but now the small deformation field (u, w) can be explicitly computed.

# Apparent paradox

Inextensibility implies u = 0, yet a transverse displacement w(S) changes the length. Resolution: going to higher order in the asymptotic expansion introduces a small longitudinal correction  $u \neq 0$ .

# Assumptions of linear elasticity

We assume:

- Small external loads ⇒ small internal forces and moments;
- Small displacements and rotations:  $|u'|, |w'| \ll 1$ ;
- Small strain and curvature:  $|E|, |K| \ll 1$ .

# Physical meaning

"Small" means relative to the **critical buckling load**, which measures the intrinsic bending stiffness EI of the structure. For such small loads, nonlinear geometric effects are negligible.

## Linearized kinematics

Let the reference and deformed configurations be parameterized by S and

$$\boldsymbol{r}(S) = \boldsymbol{r}_0(S) + u(S)\,\boldsymbol{t}_0 + w(S)\,\boldsymbol{n}_0.$$

# Compatibility relation

Differentiating  $\mathbf{r}' = (1 + E)\mathbf{t}$  and projecting along  $\mathbf{n}$  yields:

$$w''(S) = K(S), \qquad u'(S) = E(S).$$

Thus smallness of E and K follows directly from the smallness of the displacement gradients.

# Linearized equilibrium equations

Starting from  $\mathbf{F}' + \mathbf{f} = 0$  and  $M' + \mathbf{t} \times \mathbf{F} + m_b = 0$ :

# Simplification

These equations are evaluated on the reference configuration (undeformed geometry). Body forces and couples are also taken with respect to this configuration, making the system linear.

## Linearized constitutive relations

# Hooke-type constitutive laws

$$N = EAE$$
,  $M = EIK$ ,

derived from the quadratic strain-energy density:

$$W_e(E, K) = \frac{1}{2}EAE^2 + \frac{1}{2}EIK^2.$$

# Remarks

For a homogeneous material,  $EA = E_Y A$  and  $EI = E_Y I$ , where  $E_Y$  is Young's modulus. Linearization is valid about the natural (unstressed) configuration where N = M = 0.

# Linearized boundary conditions

# Boundary conditions summary

- Clamped end: u = w = w' = 0 (both position and rotation fixed).
- Pinned end: u = w = 0, M = 0 (rotation free).
- Roller: u constrained along tangent of support, M=0.
- Free end: N = T = M = 0.
- Loaded end:  $N=N_{\rm ext},\, T=T_{\rm ext},\, M=M_{\rm ext}$  prescribed.

# Solving the linearized BVP

Integrate successively:

- 1. From force balance  $N' + f_t = 0$ , obtain N(S);
- 2. Then T(S) from  $T' + f_n = 0$ ;
- 3. From M' + T = 0 and BCs, compute M(S);
- 4. Use M = EI w'' to integrate for w(S) (and E = u' for u(S)).

# Example: clamped-roller beam under uniform weight

Weight qg per length, clamped at S = 0, roller at S = L.

$$qg = f_n, \quad f_t = 0.$$

Then:

$$N = 0$$
,  $T(S) = qg(L - S)$ ,  $M(S) = \frac{1}{2}qg(L - S)^2$ .

Deflection:

$$EI w'''' = qg, \quad w(0) = w'(0) = 0, \ w''(L) = w'''(L) = 0.$$

Solution:

$$w(S) = \frac{qg}{24EI} S^2 (6L^2 - 4LS + S^2).$$

# Validation of assumptions

The linear theory is consistent if  $|w'| \ll 1$  and  $|M|/(EI/L) \ll 1$ , which translates to small load-to-stiffness ratio  $qgL^3/(EI) \ll 1$ .

# Relation with Galileo's asymptotic expansion

# Comparison with asymptotic expansion

- Both yield identical internal force and moment distributions as the rigid model (to first order).
- Linear elasticity allows explicit computation of u, w and checks of smallness assumptions.
- Validity breaks when rotations are no longer small, i.e.  $F/F_c \gtrsim 0.25$ .

# Key takeaway

Linear elasticity is the simplest, self-consistent model for small displacements and rotations. It bridges the gap between rigid-body statics and nonlinear elasticity, forming the analytical foundation for most engineering beam and frame analyses.

# Stability of Conservative Systems with N Degrees of Freedom (Part 1)

## Conservative forces

A force F(x) is conservative if it derives from a potential U(x) such that

$$F(x) = -\nabla U(x).$$

# Key property

The work done by a conservative force is path-independent:

$$W_{A\to B} = -\int_A^B \nabla U \cdot d\mathbf{x} = U(A) - U(B).$$

# Examples and counterexamples

- Gravity:  $\mathbf{F} = m\mathbf{g}$ , U = mgz.
- Spring: F = -kx,  $U = \frac{1}{2}k|x|^2$ .
- Inertial (centrifugal) force in rotating frame:  $\mathbf{F} = m\omega^2 \mathbf{r}$ ,  $U = -\frac{1}{2}m\omega^2 r^2$ .
- Non-conservative: a velocity-dependent or non-curl-free field (e.g.  $\mathbf{F} = (k\,y,0)$ ) for which  $\nabla \times \mathbf{F} \neq 0$ .

# Conservative elastic systems

A conservative system has no dissipation; its total potential energy is

$$\Pi[\boldsymbol{r}] = \Pi_{\mathrm{int}} + \Pi_{\mathrm{ext}},$$

where

$$\Pi_{\mathrm{int}} = \int W_e(E, K) \, \mathrm{d}S, \qquad \Pi_{\mathrm{ext}} = -\int \boldsymbol{f} \cdot \boldsymbol{r} \, \mathrm{d}S - \boldsymbol{F} \cdot \boldsymbol{r}_{\mathrm{end}}.$$

# Typical internal energies

- Rigid body:  $\Pi_{int} = 0$ .
- Inextensible string:  $\Pi_{int} = 0$ .
- Elastic string:  $\Pi_{\text{int}} = \frac{1}{2} E A \int E^2 dS$ .

• Elastic rod:  $\Pi_{\text{int}} = \frac{1}{2} EI \int K^2 dS$ .

• Linear elastic rod:  $\Pi_{\text{int}}^2 = \frac{1}{2} \int (EAE^2 + EIK^2) dS$ .

# Examples

**Elastic string:** pinned at one end, force F at the other:  $\Pi = \frac{1}{2}EA\int_0^L (s'-1)^2 dS - Fy(L)$ .

Elastic rod: clamped at one end, tip load  $F: \Pi = \frac{1}{2} \int_0^L (EAE^2 + EIK^2) dS - Fy(L)$ .

# Kinematically admissible configurations

A configuration C is **kinematically admissible** (K.A.) if:

- It satisfies all kinematic BCs and constraints (e.g. rigidity, inextensibility);
- It yields a finite total potential energy  $\Pi[\mathcal{C}]$ .

# Example: inextensible string

$$C_{KA} = \{ r(S) : |r'(S)| = 1, \ r(0) = r_0 \}.$$

If bending rigidity vanishes (EI = 0),  $\alpha(S)$  may jump, but r remains continuous.

# Stability criterion

# Definition of stability

An equilibrium configuration  $r_e$  is **stable** if every nearby admissible configuration  $r_e + \delta r$  yields higher (or equal) potential energy:

$$\Pi[\boldsymbol{r}_e + \delta \boldsymbol{r}] \ge \Pi[\boldsymbol{r}_e].$$

Equivalently,  $r_e$  is a local minimum of  $\Pi$ .

## Finite-dimensional form

For N generalized coordinates  $\mathbf{q} = (q_1, \dots, q_N)$ ,

$$\Pi = \Pi(\boldsymbol{q}),$$
 equilibrium:  $\frac{\partial \Pi}{\partial a_i} = 0.$ 

Stability test: analyze the Hessian matrix

$$H_{ij} = \frac{\partial^2 \Pi}{\partial q_i \partial q_j}.$$

# Stability conditions

- Necessary:  $\frac{\partial \Pi}{\partial q_i} = 0$  at equilibrium.
- Sufficient for stability: Hessian H positive definite  $(\lambda_i > 0)$ .
- Sufficient for instability: at least one negative eigenvalue ( $\lambda_i < 0$ ).

# Example 1: Rotating rigid bar

# Equilibrium and stability

$$\frac{\mathrm{d}\Pi}{\mathrm{d}\alpha} = 0 \ \Rightarrow \ mg\sin\alpha = I\omega^2\sin\alpha\cos\alpha.$$

Solutions:

$$\sin \alpha = 0 \quad (\alpha = 0, \pi), \qquad \cos \alpha = \frac{mg}{I\omega^2}.$$

**Stability:**  $\Pi''(\alpha) > 0$  stable. Thus the downward configuration  $(\alpha = 0)$  is stable if  $\omega$  is small; beyond a critical  $\omega_c$ , instability (bifurcation) occurs.

# Interpretation

At equilibrium, the stationarity of  $\Pi$  coincides with the force and moment balances. A loss of stability (change of sign in  $\Pi''$ ) signals buckling or dynamic reversal.

# Example 2: Rotating rigid beam on a roller

The beam can slide freely along the horizontal axis while rotating about a roller at its lower end.

# Result

The equilibrium manifold includes  $\beta=0$  and  $\sin\alpha=0$  (vertical) or  $\cos\alpha=\frac{mg}{I\omega^2}$  (tilted). The Hessian has one zero eigenvalue (due to free translation), implying that every equilibrium is marginally unstable.

# **Energy interpretation**

For the pinned bar,  $\alpha = 0$  is a minimum of  $\Pi$  (stable). For the roller-supported bar, the same configuration is a saddle point — potential energy is stationary but not minimal.

6.7 General conclusions 19

# General conclusions

# Summary

- Stability of a conservative system  $\Pi$  has a local minimum.
- Equilibrium configurations satisfy  $\nabla \Pi = 0$ .
- Positive definite Hessian stable; indefinite unstable.
- The energy criterion is equivalent to the force–moment balance laws.

# Takeaway

In conservative mechanics, equilibrium and stationarity of total potential energy coincide. The **nature of equilibrium** (minimum, maximum, saddle) dictates **stability**.

Minimum Stable, Maximum/Saddle Unstable.