# TCC892X STB Android SDK Quick Start Guide

TCC892X-STB- Android 4.4.2(Kitkat-mr1.1)-V1.00E-Quick Start Guide

Mar 31, 2014



#### **DISCLAIMER**

All information and data contained in this material are without any commitment, are not to be considered as an offer for conclusion of a contract, nor shall they be construed as to create any liability. Any new issue of this material invalidates previous issues. Product availability and delivery are exclusively subject to our respective order confirmation form; the same applies to orders based on development samples delivered. By this publication, Telechips, Inc. does not assume responsibility for patent infringements or other rights of third parties that may result from its use.

Further, Telechips, Inc. reserves the right to revise this publication and to make changes to its content, at any time, without obligation to notify any person or entity of such revisions or changes.

No part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the express written consent of Telechips, Inc.

This product is designed for general purpose, and accordingly customer is responsible for all or any of intellectual property licenses required for actual application. Telechips, Inc. does not provide any indemnification for any intellectual properties owned by third party.

Telechips, Inc. cannot ensure that this application is the proper and sufficient one for any other purposes but the one explicitly expressed herein. Telechips, Inc. is not responsible for any special, indirect, incidental or consequential damage or loss whatsoever resulting from the use of this application for other purposes.

# COPYRIGHT STATEMENT

Copyright in the material provided by Telechips, Inc. is owned by Telechips unless otherwise noted.

For reproduction or use of Telechips' copyright material, permission should be sought from Telechips. That permission, if given, will be subject to conditions that Telechips' name should be included and interest in the material should be acknowledged when the material is reproduced or quoted, either in whole or in part. You must not copy, adapt, publish, distribute or commercialize any contents contained in the material in any manner without the written permission of Telechips. Trademarks used in Telechips' copyright material are the property of Telechips.

# **Important Notice**

#### For customers who use licensed Codec ICs and/or licensed codec firmware of mp3:

"Supply of this product does not convey a license nor imply any right to distribute content created with this product in revenue-generating broadcast systems (terrestrial, satellite, cable and/or other distribution channels), streaming applications(via internet, intranets and/or other networks), other content distribution systems(pay-audio or audio-on-demand applications and the like) or on physical media(compact discs, digital versatile discs, semiconductor chips, hard drives, memory cards and the like). An independent license for such use is required. For details, please visit http://mp3licensing.com".

#### For customers who use other firmware of mp3:

"Supply of this product does not convey a license under the relevant intellectual property of Thomson and/or Fraunhofer Gesellschaft nor imply any right to use this product in any finished end user or ready-to-use final product. An independent license for such use is required. For details, please visit http://mp3licensing.com".

#### For customers who use Digital Wave DRA solution:

"Supply of this implementation of DRA technology does not convey a license nor imply any right to this implementation in any finished end-user or ready-to-use terminal product. An independent license for such use is required."

# For customers who use DTS technology:

"This product made under license to certain U.S. patents and/or foreign counterparts."

"© 1996 - 2011 DTS, Inc. All rights reserved."

#### For customers who use Dolby technology:

"Supply of this Implementation of Dolby technology does not convey a license nor imply a right under any patent, or any other industrial or intellectual property right of Dolby Laboratories, to use this Implementation in any finished end-user or ready-to-use final product. It is hereby notified that a license for such use is required from Dolby Laboratories."

#### For customers who use MS technology:

"This product is subject to certain intellectual property rights of Microsoft and cannot be used or distributed further without the appropriate license(s) from Microsoft."

# **Revision History**

Date	Version	Description
2014-02-13	0.01	Initial Release
2014-03-31	1.00	Android 4.4.2(Kitkat-mr1.1) Official version release – v14.04_tcc-android-4.4.2

# **TABLE OF CONTENTS**

# Contents

Revision HistoryTABLE OF CONTENTS	
Contents	4
Figures	
1 Introduction	
2 Download Android Kitkat SDK	5
3 Setup compile environment	(
4 Compile Bootloader	
4.1 Select board configuration	
4.1.1 Set HW_REW for TCC892x	
4.1.2 Set HW_REW for TCC893x	
4.2 Compile	
4.3 TCC8925 HDMI Dongle T-Flash Board	
4.4 TCC8925 HDMI Dongle eMMC Board	9
4.5 TCC8925S HDMI Dongle Board	10
4.6 TCC8935 HDMI Dongle T-Flash Board	10
4.7 TCC8935(S) HDMI Dongle eMMC Board	10
4.8 TCC8935S HDMI Dongle Board	10
5 Compile Linux Kernel	1′
5.1 eMMC/T-Flash Board	1′
5.2 Compile	
6 Compile Android Framework	
6.1 Compile Environment	
6.1.1 TCC892x Board	
6.1.2 TCC893x Board	
6.1.3 TCC8925S HDMI Dongle Board	
6.1.4 TCC8935S HDMI Dongle Board	
6.2 Compile Frameworks	
6.3 Choose Wi-Fi Module	
7 Download Images	
7.1 Change Boot Mode	
7.1.1 YJ8925/30/33/35T Board	
7.1.2 HDMI Dongle Board	14
7.2 Install VTC driver	
7.3 Partition Layout	
7.3.1 Introduction	
7.3.2 GPT Partition Layout	
7.3.3 MBR Partition Layout	
7.4 Download images with FWDN V7	16
8 Download Images by using fastboot	19
8.1 Enter fastboot mode	
8.2 Install Android USB Driver	19
8.3 Download	20
9 Summary of Compile command	2′
9.1 TCC892x Board	
9.2 TCC893x Board	23
Figures	
Figure 1. FWDN program in Windows PC	16
Figure 2. Low format option in FWDN	16
Figure 3. GPT Partition information for FWDN	
Figure 4. MBR Partition information for FWDN	
Figure 5. Install Android USB driver	

#### 1 Introduction

This document provides guideline for users to start Android platform v4.4 (Kitkat) for TCC892x and TCC893x STB (Set-Top-Box) solution more quickly.

There are four types of target boards for STB solution.

- STBM
- YJ8925T, YJ8935T
- uPC
- HDMI Dongle

You must setup compile environment according to target board differently.

You must compile Bootloader, Kernel and Frameworks respectively. Bootloader and Kernel must be compiled prior to compile Android Frameworks.

#### 2 Download Android Kitkat SDK

Download SDK from Telechips Android git server (ssh://android.telechips.com/androidce/). Please contact agent to get information about accessing Telechips Android git server. You must to use "-b kitkat" option to download Android kitkat SDK.

```
$ repo init -u
ssh://android.telechips.com/androidce/android/platform/manifest.git -b kitkat
$ repo sync
```

After download SDK, you can see many folders and files from working folder. This document assumes working folder as "mydroid".

#### 3 Setup compile environment

Before you compile, TARGET\_PRODUCT must be setup for proper board configuration by executing "build/envsetup.sh" shell-script. To execute shell-script, there is space between dot ('.') and other ("build/envsetup.sh").

```
$ cd ~/mydroid
$ . build/envsetup.sh
including device/asus/deb/vendorsetup.sh
including device/asus/flo/vendorsetup.sh
including device/asus/grouper/vendorsetup.sh
including device/asus/tilapia/vendorsetup.sh
including device/generic/armv7-a-neon/vendorsetup.sh
including device/generic/mips/vendorsetup.sh
including device/generic/x86/vendorsetup.sh
including device/lge/hammerhead/vendorsetup.sh
including device/lge/mako/vendorsetup.sh
including device/samsung/manta/vendorsetup.sh
including device/telechips/m805_892x/vendorsetup.sh
including device/telechips/m805 893x/vendorsetup.sh
including device/telechips/tcc8920st/vendorsetup.sh
including device/telechips/tcc8920/vendorsetup.sh
including device/telechips/tcc8930st/vendorsetup.sh
including device/telechips/tcc893x/vendorsetup.sh
including sdk/bash completion/adb.bash
```

Please execute "lunch" and then you can see board lists.

```
$ lunch
You're building on Linux
Lunch menu... pick a combo:
1. aosp arm-eng
    2. aosp x86-eng
    3. aosp mips-eng
    4. vbox x86-eng
    5. aosp deb-userdebug
    6. aosp_flo-userdebug
    7. aosp grouper-userdebug
    8. aosp tilapia-userdebug
    9. mini armv7a neon-userdebug
    10. mini mips-userdebug
    11. mini x86-userdebug
    12. aosp hammerhead-userdebug
    13. aosp mako-userdebug
    14. aosp manta-userdebug
    15. full m805 892x-eng
    16. full m805 893x-eng
    17. full_tcc8920st-eng
    18. full_tcc8920-eng
    19. full_tcc8930st-eng
    20. full_tcc893x-eng
```

If you want to compile TCC892x STB solution, please select 'full\_tcc8920st-eng' and want to compile TCC893x STB solution, please select 'full tcc8930st-eng'.

Please execute 'choosevariant' and select 'user' or 'userdebug' for mass production.

```
$ choosevariant
Variant choices are:
    1. user
    2. userdebug
    3. eng
Which would you like? [eng]
```

# 4 Compile Bootloader

# 4.1 Select board configuration

Before compile bootloader, you must select proper board configuration.

# 4.1.1 Set HW\_REW for TCC892x

You can see below from 'bootable/bootloader/lk/target/tcc8920st evm/rules.mk'.

```
# Define board revision
# 0x6000 : STB /TCC8920 /DDR3 512MB (16BIT) /None
# 0x6020 : STB /TCC8920 /DDR3 512MB (32BIT) /None
# 0x6030 : STB /TCC8920 /DDR3 1024MB(32BIT) /None
# 0x6040 : STB /TCC8920 /DDR2 512MB (32BIT) /None
# 0x6050 : STB /TCC8920 /DDR2 1024MB(32BIT) /None
# 0x7100 : YAOJIN /TCC8925 /DDR3 512MB (16BIT) /None(1CS)
# 0x7110 : YAOJIN /TCC8925 /DDR3 1024MB(16BIT) /None(2CS)
# 0x8100 : UPC /TCC8925 /DDR3 512MB (16BIT) /None
# 0x8110 : UPC
                 /TCC8925 /DDR3 1024MB(16BIT) /None
# 0x9100 : DONGLE /TCC8925 /DDR3 512MB (16BIT) /None
# 0x9101 : DONGLE /TCC8925 /DDR3 512MB (16BIT) /'S' version
# 0x9110 : DONGLE /TCC8925 /DDR3 1024MB(16BIT) /None
# 0x9111 : DONGLE /TCC8925 /DDR3 1024MB (16BIT) /'S' version
# 0x9112 : DONGLE /TCC8925 /DDR3 1024MB (16BIT) /eMMC(BROADCOM)
HW REV=0x6030
#HW REV=0x7100
#HW REV=0x8110
#HW REV=0x9100
#HW REV=0x9112
```

You must select HW\_REV for proper board.

STBM	HW_REV=0x6030
YJ8925T	HW_REV=0x7100
uPC	HW_REV=0x8110
HDMI Dongle	HW REV=0x9100, 0x9112

#### 4.1.2 Set HW REW for TCC893x

You can see below from 'bootable/bootloader/lk/target/tcc8930st evm/rules.mk'.

```
# 0x9311 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /'S' version
# 0x9312 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /eMMC(BROADCOM)
# 0x9313 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /'S' version + eMMC
HW_REV=0x6230
#HW_REV=0x7230
#HW_REV=0x7231
#HW_REV=0x7430
#HW_REV=0x7310
#HW_REV=0x7310
#HW_REV=0x8310
#HW_REV=0x9310
#HW_REV=0x9310
#HW_REV=0x9312
#HW_REV=0x9313
```

You must select HW\_REV for proper board.

STBM	HW_REV=0x6230
YJ893xT	HW_REV=0x7230, 0x7231, 0x7430, 0x7300, 0x7310
uPC	HW_REV=0x8310
HDMI Dongle	HW_REV=0x9300, 0x9310, 0x9312, 0x9313

#### 4.2 Compile

Move in "bootable/bootloader/lk" folder. Execute "make tcc8920st\_evm" for TCC892x STB solution and execute "make tcc8930st\_evm" for TCC893x STB solution. If you want to use eMMC(T-Flash/SD) boot, please add " emmc" suffix.

Board	Command	Output folder which include 1k.rom	
TCC892x NAND	make tcc8920st_evm	build-tcc8920st_evm	
TCC892x eMMC (T-Flash)	make tcc8920st_evm_emmc	build-tcc8920st_evm_emmc	
TCC893x NAND	make tcc8930st_evm	build-tcc8930st_evm	
TCC893x eMMC (T-Flash)	make tcc8930st evm emmc	build-tcc8930st evm emmc	

If you want to clean the compiled result, you can execute the command like "make tcc8920st\_evm clean" or "make tcc8930st evm clean".

# 4.3 TCC8925 HDMI Dongle T-Flash Board

```
# 0x9100 : DONGLE /TCC8925 /DDR3 512MB (16BIT) /None
HW_REV=0x9100

# 0x9110 : DONGLE /TCC8925 /DDR3 1024MB(16BIT) /None
HW_REV=0x9110

$ make tcc8920st_evm_emmc
```

# 4.4 TCC8925 HDMI Dongle eMMC Board

```
# 0x9112 : DONGLE /TCC8925 /DDR3 1024MB (16BIT) /eMMC(BROADCOM)
HW_REV=0x9112

$ make tcc8920st_evm_emmc
```

# 4.5 TCC8925S HDMI Dongle Board

```
# 0x9101 : DONGLE /TCC8925 /DDR3 512MB (16BIT) /'S' version

HW_REV=0x9101

# 0x9111 : DONGLE /TCC8925 /DDR3 1024MB (16BIT) /'S' version

HW_REV=0x9111

$ make tcc8920st_evm
```

# 4.6 TCC8935 HDMI Dongle T-Flash Board

```
# 0x9300 : DONGLE /TCC8935 /DDR3 512MB (16BIT) /None

HW_REV=0x9300

# 0x9310 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /None

HW_REV=0x9310

$ make tcc8930st_evm_emmc
```

#### 4.7 TCC8935(S) HDMI Dongle eMMC Board

```
# 0x9312 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /eMMC(BROADCOM)

HW_REV=0x9312

# 0x9313 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /'S' version + eMMC

HW_REV=0x9313

$ make tcc8930st_evm_emmc
```

# 4.8 TCC8935S HDMI Dongle Board

```
# 0x9301 : DONGLE /TCC8935 /DDR3 512MB (16BIT) /'S' version

HW_REV=0x9301

# 0x9311 : DONGLE /TCC8935 /DDR3 1024MB(16BIT) /'S' version

HW_REV=0x9311

$ make tcc8930st_evm
```

# 5 Compile Linux Kernel

Kernel must be compiled prior to compile Android Frameworks and lunch menu must be selected before compiling Kernel because lunch menu affect Linux Kernel Configuration.

You must select defconfig according to proper board.

TCC892x Board	command
TCC8920 STBM	make tcc8920st_defconfig
TCC8925 YJ8925T	make tcc8925st_yj8925t_defconfig
TCC8925 uPC	<pre>make tcc8925st_upc_defconfig</pre>
TCC8925 HDMI Dongle	<pre>make tcc8925st_dongle_defconfig</pre>
TCC8925S HDMI Dongle	make dongle tcc8925s defconfig

TCC893x Board	command
TCC8930 STBM	make tcc8930st_defconfig
TCC8930 YJ8930T	<pre>make tcc8930st_yj8930t_defconfig</pre>
TCC8933 YJ8933T	<pre>make tcc8933st_yj8933t_defconfig</pre>
TCC8935 YJ8935T	make tcc8935st_yj8935t_defconfig
TCC8935 uPC	<pre>make tcc8935st_upc_defconfig</pre>
TCC8935 HDMI Dongle	make tcc8935st_dongle_defconfig
TCC8935S HDMI Dongle	make dongle tcc8935s defconfig

#### 5.1 eMMC/T-Flash Board

If target board uses eMMC boot, you should change kernel configuration.

```
$ make menuconfig
Device Drivers --> MMC/SD/SDIO card support --> [*] Support an eMMC
```

You should change kernel configuration according to WIFI chipset that you use. (Please refer chapter6.1)

# 5.2 Compile

To compile Linux Kernel, just execute "make".

```
$ cd ~/mydroid/kernel
$ make
```

# 6 Compile Android Framework

# 6.1 Compile Environment

Please refer chapter 4.1 to setup  ${\tt TARGET\_PRODUCT}$ . Except STBM board, you need to change some configurations.

#### 6.1.1 TCC892x Board

Define the name of target board in "device/telechips/tcc8920st/full tcc8920st.mk".

```
# Define the name of target board
TARGET_BOARD_8920_EV := true
#TARGET_BOARD_8925_YJ8925T := true
#TARGET_BOARD_8925_UPC := true
#TARGET_BOARD_8925_DONGLE := true
```

You should select the below define according to target board.

Target Board	Define	
TCC8920 STBM Board	TARGET_BOARD_8920_EV	
TCC8925 YJ8925T Board	TARGET_BOARD_8925_YJ8925T	
TCC8925 uPC Board	TARGET_BOARD_8925_UPC	
TCC8925 HDMI Dongle Board	TARGET_BOARD_8925_DONGLE	

#### 6.1.2 TCC893x Board

Define the name of target board in "device/telechips/tcc8930st/full tcc8930st.mk".

```
# Define the name of target board
TARGET_BOARD_8930_EV := true
#TARGET_BOARD_8930_YJ8930T := true
#TARGET_BOARD_8933_YJ8933T := true
#TARGET_BOARD_8935_YJ8935T := true
#TARGET_BOARD_8935_UPC := true
#TARGET_BOARD_8935_DONGLE := true
```

You should select the below define according to target board.

Target Board	Define		
TCC8930 STBM Board	TARGET_BOARD_8930_EV		
TCC8930 YJ8930T Board	TARGET_BOARD_8930_YJ8930T		
TCC8933 YJ8933T Board	TARGET_BOARD_8933_YJ8933T		
TCC8935 YJ8935T Board	TARGET_BOARD_8935_YJ8935T		
TCC8935 uPC Board	TARGET_BOARD_8935_UPC		
TCC8935 HDMI Dongle Board	TARGET_BOARD_8935_DONGLE		

# 6.1.3 TCC8925S HDMI Dongle Board

Define chipset feature in "device/telechips/tcc8920st/device.mk".

```
#TARGET_BOARD_SOC := tcc892x
```

```
TARGET_BOARD_SOC := tcc892xS
```

# 6.1.4 TCC8935S HDMI Dongle Board

Define chipset feature in "device/telechips/tcc8930st/device.mk".

```
#TARGET_BOARD_SOC := tcc893x
TARGET_BOARD_SOC := tcc893xS
```

# 6.2 Compile Frameworks

Just execute "make" command. You can build Android Frameworks.

```
$ cd ~/mydroid
$ make
```

#### 6.3 Choose Wi-Fi Module

You can select Wi-Fi module by using the below command after finishing compiling kernel and frameworks.

```
$ choosewifi "vendor" "chipset"

Ex)
$ choosewifi atheros
$ choosewifi realtek rt8188cu
$ choosewifi realtek rt8189es
$ choosewifi realtek rt8188eus
$ choosewifi broadcom bcm4330
$ choosewifi broadcom bcm4334
$ choosewifi broadcom bcm4335
```

# 7 Download Images

You must use FWDN\_V7 program to download images to target board. FWDN\_V7 can be found in "vendor/telechips/tools/FWDN" folder. Please refer the description below to know how to download images by using FWDN\_V7. The version of FWDN\_V7 must be higher than v2.44.

#### 7.1 Change Boot Mode

You must change boot mode of target board to "Boot from USB device - Firmware Download Mode" to download firmware. It is different to change boot mode according to target board. You can enter "Firmware Download Mode", if you power off/on or reboot target board after changing boot mode.

#### 7.1.1 YJ8925/30/33/35T Board

You can see "USB" and "NAND" from JSW1 and connect the jumper to "USB" direction for changing boot mode to "Firmware Download Mode" (TCC8925/35T) or press push button and don't release it before power on (TCC8933/35T).

# 7.1.2 HDMI Dongle Board

Before power on HDMI Dongle, press the button and don't release it. Then HDMI Dongle will enter "Firmware Download Mode".

#### 7.2 Install VTC driver

You need to install VTC driver to recognize target board on your PC with FWDN\_V7 program. Please execute "VTC Driver Installer....EXE" file in "vendor/telechips/tools/FWDN/vtcdrv" folder. The version of VTC driver must be higher than v5.0.0.5 for TCC892x/3x STB solution.

#### 7.3 Partition Layout

#### 7.3.1 Introduction

Default partition layout scheme is GPT. MBR partition layout scheme can be also supported and it is used only for user firmware upgrade from old version (JellyBean) which use MBR scheme. So if you want to upgrade firmware from JellyBean to Kitkat, you should use MBR scheme. It is not compatible between GPT and MBR. You should understand how to configure GPT/MBR partition layout for Android System, before you download images

# 7.3.2 GPT Partition Layout

Please refer to the following table to check default GPT partition layout.

Area	Name	Purpose	File System	Required
Boot	Boot Area	Kernel / Ram Disk	RAW	Mandatory
System	Android System	Android System Area	EXT4	Mandatory
Cache	Android Cache	Android Cache Area	EXT4	Mandatory
Recovery	Android Recovery	Recovery Mode Boot Area Recovery Mode Kernel / Ram Disk	RAW	Mandatory
Kpanic	Kpanic	Kernel Panic Log	RAW	Mandatory
Splash	Splash	Boot Screen Image	RAW	Mandatory
Misc	Miscellaneous	Firmware Update Bootloader Flag	RAW	Mandatory
TCC	Telechips Only	Set-top Flag write	RAW	Optional
UserData	Android UserData	Android User Data Application / Database	EXT4	Mandatory



Please refer to the following table to set the size of each partition. The size of some partitions can't be changeable.

Area	Size	Partition	FileSystem
Boot	15MB	ndda1 / mmcblk0p1	RAW
System	650MB	ndda2 <i>l</i> mmcblk0p2	EXT4
Cache	150MB	ndda3/mmcblk0p3	EXT4
Recovery	15MB	ndda4/mmcblk0p4	RAW
Kpanic	5MB	ndda5/mmcblk0p5	RAW
Splash	4MB	ndda6/mmcblk0p6	RAW
Misc	1MB	ndda7/mmcblk0p7	RAW
тсс	1MB	ndda8/mmcblk0p8	RAW
UserData	Available Size	ndda9/mmcblk0p9	EXT4

The additional partitions are not need for Android system. But you can add them for special purpose and source codes should be also changed to do it.

# 7.3.3 MBR Partition Layout

Please refer to the following table to check default MBR partition layout.

Area	Name	Purpose	FileSystem	Required
Boot	Boot Area	Kernel / Ram Disk	RAW	Mandatory
System	Android System	Android System Area	EXT4	Mandatory
UserData	Android UserData	Android User Data Application / Database	EXT4	Mandatory
Cache	Android Cache	Android Cache Area	EXT4	Mandatory
Recovery	Android Recovery	Recovery Mode Boot Area Recovery Mode Kernel / Ram Disk	RAW	Mandatory
Kpanic	Kpanic	Kernel Panic Log	RAW	Mandatory
Splash	Splash	Boot Screen Image	RAW	Mandatory
Misc	Miscellaneous	Firmware Update Bootloader Flag	RAW	Mandatory
тсс	Telechips Only	Set-top Flash write	RAW	Optional

Please refer to the following table to set the size of each partition. The size of some partitions can't be changeable.

Area	Size	Partition	FileSystem
Boot	15MB	Ndda1	RAW
System	650MB	Ndda2	EXT4
UserData	Available Size	Ndda3	EXT4
Extended	Extended	Ndda4	Extended
Cache	150MB	Ndda5	EXT4
Recovery	15MB	Ndda6	RAW
Kpanic	5MB	Ndda7	RAW
Splash	4MB	Ndda8	RAW
Misc	1MB	Ndda9	RAW
тсс	1MB	ndda10	RAW

Linux System can only support 4 primary partitions but we need more partitions. So we set an

Telectips Preliminary 15

extended partition (the forth partition) and it includes other logical partitions (6 ea). The additional partitions are not need for Android system. But you can add them for special purpose and source codes should be also changed to do it.

# 7.4 Download images with FWDN V7

Below steps can be used for not only NAND but also eMMC (T-Flash) boot.

**[Step1]** Load a bootloader image on FWDN and then connect target device (USB boot mode) with USB port of PC. If it succeeds in connection with FWDN, click "NAND Data" Button




Figure 1. FWDN program in Windows PC

If you want to do low-level format before downloading, select "Low format" option.



Figure 2. Low format option in FWDN

[Step2] Prepare the following images to download.

boot.img system.img recovery.img

The order of partitions should be same with the order of partition layout (section 7.3). Click "Create Image" button.

#### In case of GPT Partition Layout,




Figure 3. GPT Partition information for FWDN

**Notice:** To use GPT partition layout, you should select "Use GPT" like above image. You can see "Partition Label" is filled with the name of each partition. This name is very important because it is used to mount file system. So you should write correct name of partition to "Partition Label".

The difference of MBR and GPT partition is the number of partitions. MBR has extended partition but GPT don't have it.

#### In case of MBR Partition Layout,




Figure 4. MBR Partition information for FWDN

**Notice:** To use MBR partition layout, you should select "Use MBR" like above image. You can see that "Image File Path" of partition 3 (usderdata) and 4 (cache) is empty. From Android 4.1 (JellyBean), system will format these partitions and reboot automatically if they were not formatted during booting-up. So you don't need to write any file path for these partitions.

Partition 3 (usderdata) is used for the shared storage through MTP. So the size of this partition should be the remaining size of NAND. If you set size of partition 3 to 1024, the size of partition 9 is automatically calculated as the remaining size of NAND. Then you can switch the size of partition 3 and 9 like above image.

**[Step3]** If it succeeds in creating an image, Click "Start" button to start downloading images to target board

# 8 Download Images by using fastboot

*Kernel* and *Framework* image can be downloaded with "fastboot" command. Generally "fastboot" is used for development.

#### 8.1 Enter fastboot mode

If bootloader image was written to target board, you can enter "fastboot mode" by inputting 'f' character of keyboard on UART console window during booting-up. You can see messages below on console window if you entered "fastboot mode" normally.

```
[2720] fastboot_init()
[2720] udc_start()
```

#### 8.2 Install Android USB Driver

Connect target board with PC by using USB cable after entering "fastboot mode". If target board is firstly connected with PC, you should install "Android USB driver" to use "fastboot" command.




Figure 5. Install Android USB driver

If target board is normally connected with PC, you can see messages below on console window

```
[44040] USB Reset
[44050] Connect Done[44050] : High Speed
[44080] USB Reset
[44090] Connect Done[44090] : High Speed
[44180] fastboot: processing commands
```

To use "fastboot" command, you must have "fastboot.exe" which can be obtained from Android SDK. Android SDK can be downloaded from Google's site. If you can use "adb.exe", you can also use "fastboot.exe". Please search and refer to various information about "adb" and "fastboot" from internet sites.

#### 8.3 Download

Execute "cmd.exe" in your PC and move to folder which includes "fastboot.exe" and "adb.exe".

```
- - X
명령 프롬프트
 :\Android\tool>dir
     라이브의 볼륨에는
      일련 번호: 5C96-7804
 D:₩Android₩tool 디렉터리
            오후 06:00
오후 06:00
오후 05:47
2012-01-27
2012-01-27
                           <DIR>
2009-06-30
                               2,258,137 adb.exe
              후 05:47
2개 파일
2009-06-30
                                  994,250 fastboot.exe
               2개 파일 3,252,387 바이트
2개 디렉터리 39,548,002,304 바이트 남음
D:₩Android₩tool>
```

If you execute "fastboot devices" command, you can check list all connected devices. If there is no device, no messages will be shown.



If images exist in "z:\android\out\target\product\tcc8930st", you can set the path of images by using ANDROID\_PRODUCT\_OUT parameter like below in advance. So you don't need to write full path when you use "fastboot" commands.



You can use the below commands to download images.

Image	fastboot command
boot.img	fastboot flash boot
recovery.img	fastboot flash recovery
system.img	fastboot flash system

# 9 Summary of Compile command

# 9.1 TCC892x Board

Board	Build Item	Command
TCC8925 HDMI Dongle	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "17. full_tcc8920st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8920st_evm/rules.mk&gt; HW_REV=0x9100 \$ make tcc8920st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8925st_dongle_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8920st/full_tcc8920st.mk&gt; TARGET_BOARD_8925_DONGLE := true \$ make</pre>
TCC8925 uPC	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "17. full_tcc8920st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8920st_evm/rules.mk&gt; HW_REV=0x8100 \$ make tcc8920st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8925st_upc_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8920st/full_tcc8920st.mk&gt; TARGET_BOARD_8925_UPC := true \$ make</pre>
TCC8925 YJ8925T	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "17. full_tcc8920st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8920st_evm/rules.mk&gt; HW_REV=0x7100 \$ make tcc8920st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8925st_yj8925t_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8920st/full_tcc8920st.mk&gt; TARGET_BOARD_8925_YJ8925T := true \$ make</pre>

Board	Build Item	Command
TCC8925S HDMI Dongle	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "17. full_tcc8920st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8920st_evm/rules.mk&gt; HW_REV=0x9101 \$ make tcc8920st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make dongle_tcc8925s_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8920st/full_tcc8920st.mk&gt; TARGET_BOARD_8925_DONGLE := true \$ vi device/telechips/tcc8920st/device.mk&gt; TARGET_BOARD_SOC := tcc892xS \$ make</pre>
TCC8920 STBM	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "17. full_tcc8920st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8920st_evm/rules.mk&gt; HW_REV=0x6030 \$ make tcc8920st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8920st_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8920st/full_tcc8920st.mk&gt; TARGET_BOARD_8920_EV := true \$ make</pre>

# 9.2 TCC893x Board

Board	Build Item	Command
TCC8935 HDMI Dongle (512MB)	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x9300 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8935st_dongle_defconfig \$ make menuconfig \$ystem Type -&gt; DRAM Memory Size -&gt; 512MB System Type -&gt; DDR settings -&gt; Hynix DDR3_H5TQ2G83BFR_PBC \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_DONGLE := true \$ make</pre>
	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
TCC8935	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x9310 \$ make tcc8930st_evm</pre>
HDMI Dongle (1024MB)	Kernel	<pre>\$ cd kernel \$ make tcc8935st_dongle_defconfig \$ make menuconfig System Type -&gt; DRAM Memory Size -&gt; 1024MB System Type -&gt; DDR settings -&gt; Hynix DDR3_H5TQ4G83AFR_PBC \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_DONGLE := true \$ make</pre>
	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
TCC8935S HDMI Dongle eMMC (1024MB)	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x9312 \$ make tcc8930st_evm_emmc</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8935st_dongle_defconfig \$ make menuconfig \$ ystem Type -&gt; DRAM Memory Size -&gt; 1024MB System Type -&gt; DDR settings -&gt; Hynix DDR3_H5TQ4G83AFR_PBC Device Drivers -&gt; MMC/SD/SDIO card support -&gt; [*] Support an eMMC \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_DONGLE := true \$ make</pre>

Board	Build Item	Command
TCC8935S HDMI Dongle	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x9311 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make dongle_tcc8935s_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_DONGLE := true \$ vi device/telechips/tcc8930st/device.mk&gt; TARGET_BOARD_SOC := tcc893xS \$ make</pre>
TCC8935S HDMI Dongle eMMC	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x9313 \$ make tcc8930st_evm_emmc</pre>
	Kernel	<pre>\$ cd kernel \$ make dongle_tcc8935s_defconfig \$ make menuconfig Device Drivers -&gt; MMC/SD/SDIO card support -&gt; [*] Support an eMMC \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_DONGLE := true \$ vi device/telechips/tcc8930st/device.mk&gt; TARGET_BOARD_SOC := tcc893xS \$ make</pre>
TCC8935 uPC	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x8310 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8935st_upc_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_UPC := true \$ make</pre>

Board	Build Item	Command
TCC8935 YJ8935T	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x7310 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8935st_yj8935t_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8935_YJ8935T := true \$ make</pre>
TCC8933 YJ8933T	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x7430 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8933st_yj8933t_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8933_YJ8933T := true \$ make</pre>
TCC8930 YJ8930T	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x7231 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8930st_yj8930t_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8930_YJ8930T := true \$ make</pre>

Board	Build Item	Command
TCC8930 STBM	Compile Environment	<pre>\$ . build/envsetup.sh \$ lunch&gt; Select "19. full_tcc8930st-eng"</pre>
	Bootloader	<pre>\$ cd bootable/bootloader/lk \$ vi target/tcc8930st_evm/rules.mk&gt; HW_REV=0x6230 \$ make tcc8930st_evm</pre>
	Kernel	<pre>\$ cd kernel \$ make tcc8930st_defconfig \$ make</pre>
	Frameworks	<pre>\$ vi device/telechips/tcc8930st/full_tcc8930st.mk&gt; TARGET_BOARD_8930_EV := true \$ make</pre>