# CSE3666 — Lab 2

#### Mike Medved

#### January 29th, 2022

## 1 Prompt

In this lab, we write a program in RISC-V assembly language that prints 32 bits in a register. The program reads a signed integer from the console and prints the 32 bits in the integer, twice.

Skeleton code in 'lab2.s' already has the following steps. Study the code.

- 1. Read an integer using a system call and save it in 's1'.
- 2. Use a system call to print 's1' in binary.

Implement the following steps with RISC-V instructions.

- 1. Use system call to print a newline character (ASCII value 10). Find the system call number in the document. Use system call to print a newline character (ASCII value 10). Find the system call number in the document. We can use n as the immediate in instructions.
- 2. Write a loop to print the bits in 's1', from bit 31 to bit 0. The printed bits should be the same as the ones printed by the system call. Think about the strategy/algorithm first. One method is provided in pseudocode at the bottom of this page.
- 3. Use system call to print a newline character.

Here are some example inputs/outputs of the program.

-1	
111111111111111111111111111111111111111	
11111111111111111111111111111111111	
3666	
0000000000000000000111001010010	
000000000000000000111001010010	
20220201	
0000001001101001000100100101001	
00000001001101001000100100101001	
-3666	
11111111111111111111000110101110	
11111111111111111111000110101110	

### 2 Deliverables

```
# CSE 3666 Lab 2
.data
newline: .string "\n"
.globl main
.text
main:
    # use system call 5 to read integer
           a7, x0, 5
    ecall
    addi
            s1, a0, 0 # int in s1
    # use system call 35 to print a0 in binary
    # a0 has the integer we want to print
         a7, x0, 35
    ecall
    # print newline
            aO, newline # load the address of the newline string
    li
            a7, 4
                   # set the system call number to (PrintString)
    ecall
                        # system call
    addi
            a7, x0, 1  # set system call number to 1 (PrintInt)
            t0, t0, 32 # i = 32 (traverse bits backwards)
    addi
            t1, t1, 1 \# keep 1 in t1 for the mask in loop
    addi
                        # enter loop routine
    j loop
    loop:
        addi t0, t0, -1 # decrement loop counter
        # (k & (1 << n)) >> n
        sll t2, t1, t0 # t2 = (1 << i)</pre>
        and t3, s1, t2 # t3 = num & (1 << i)
        srl a0, t3, t0 # a0 = (num & (1 << i)) >> i)
        ecall
                       # print extracted bit
        # restart loop, or exit if done
        bne t0, x0, loop
        beq t0, x0, loop_exit
    loop_exit:
           # print newline
        la a0, newline
        li a7, 4
        ecall
        # exit program with exit code 0
        addi
                a7, x0, 10
        ecall
```