MAINDEC-12-D3D8-D PRODUCT CODE! POPel2 TAPE DATA EXERCISER

PRODUCT NAME!

DIAGNOSTIC GROUP FEB. 4,1972

MAINTAINER

DATE

AUTHORI

RAYMOND SHOOP

Ti: with the state of the state		
(		
Continue of the second of the		

1. ABSTRACT

THE PDP-12 TAPE EXERCISER PROGRAM IS A DYNAMIC TEST OF THE LINCETAPE CONTROL AND TAPE TRANSPORTS, IT MAY BE USED TO TEST A CONTROLLER WITH FROM 1 TO 8 TAPE TRANSPORT UNITS. AND A PDP-12 WITH UP TO 32-K OF MEMORY.

2. MACHINE REQUIREMENTS

- A: A STANDARD PDP=12A OR B COMPUTER.
- B. PDP-12 LINC-TAPE CONTROLLER.
- C. A L'INC-TAPE TRANSPORT
- D. AN ASR-33 TELETYPE OR EQUIVALENT

2.1 STORAGE

THIS PROGRAM MAY ONLY BE RUN IN MEMORY FIELD & AND OCCUPIES VIRTUALLY ALL OF THE LOWER HALF OF FIELD & LOCATIONS 0-3377 INCLUSIVE. LOCATIONS 3400-7777 ARE USED FOR INPUT-

2.2 PRELIMINARY PROGRAMS

ALL POP-8 AND LINCOMODE BASIC INSTRUCTION DIAGNOSTIC AND EXERCISERS INCLUDING TAPE CONTROL TEST MUST HAVE SUCCESSFULLY RUN PRIOR TO RUNNING TAPE EXERCISER TEST.

- 2,3 COADING PROCEDURE
- 3.1 METHOD

THIS PROGRAM CAN BE LOADED INTO MEMORY WITH THE BINARY LOADER. IT MAY ALSO BE LOADED INTO MEMORY BY USING LAPS-DIAL.

# 4. STARTING PROCEDURE

THE PROCEDURE TO SETUP THE TAPE PROCESSOR FOR DIAGNOSIS IS CRITICAL, ANY ERROR IN THE STARTING PROCEDURE MAY RESULT IN AN ERROR.

#### A. TAPE TRANSPORT

- 1. MOUNT A CERTIFIED PDP=12 TAPE (WHICH HAS BEEN MARKED WITH "MARK 1000") ON ALL DRIVES TO BE TESTED.
- 2. SET THE UNIT SELECTOR SWITCH ON EACH TRANSPORT TO AN INCREMENTING NUMBER STARTING WITH UNIT Ø.
- 3. SET THE LOCAL/REMOTE SHITCH TO REMOTE ON EACH DRIVE.
- 4. SET WRITE ENABLE SHITCHES ON EACH DRIVE.
- B. SCOPE (VR 14)
  - 1. PLACE CHANNEL SELECTOR TO 1 8 2.
- C. DATA TERMINAL PANEL
  - 1. ROTATE ANALOG CHANNEL # TO 4 COUNTER-GLOCKHISE TO THE END OF ROTATION. THESE ARE USED ONLY TO CONTROL THE POSITION OF THE DISPLAY.

#### D. COMPUTER

- 1. SET THE LEFT SHITCHES TO 0200.
- 2. SET THE RIGHT SWITCHES TO XOXX. (REFER TO SECTION 4.1)
- 3. SET THE MODE SWITCH TO LINC-MODE.
- 4. DEPRESS I/O PRESET.
- 5. DEPRESS START LEFT SHITCHES (LS).

THE PROGRAM IS NOW RUNNING, TAPE UNIT Ø SHOULD START MOVING IN THE REVERSE DIRECTION. WHEN THE COMPUTER IS TRANSFERRING DATA IN NO-PAUSE MODE, THE PDP-12 MAINDEC NUMBER (D3D8) WILL BE DISPLAYED ON THE DISPLAY SCREEN.

## 4.1 CONTROL SWITCH SETTINGS

#### A. RIGHT SWITCHES

RSW ME1 DELETE RECOVERABLE ERROR HALTS, AND RESTART CURRENT PASS.

RSW 1=1 DELETE ERROR MESSAGE.

RSW 6=8= NUMBER OF EXTRA TAPE TRANSPORT UNITS.

RSW 9=11=NUMBER OF EXTRA 4K MEMORY FIELDS.

# 4.2 STARTING ADDRESS

FINC=WODE 0500

LINC-MODE MOVE TOWARD BLOCK (MTB) TEST. UPON COMPLETION OF THIS TEST ON UNIT & EXIT TO THE DATA TEST.

201 LINC-MODE DATA TEST ENTRY ADDRESS.

ONLY THESE TWO ADDRESSES ARE VALID STARTING ADDRESSES FOR THIS PROGRAM.

### 5. ERRORS

THE ERROR TYPE-OUT MESSAGE IS THE VALUE OF THE PROGRAM COUNTER ERROR LOCATION. THIS LISTING MUST BE CONSULTED TO FIND THE TYPE OF ERROR (I.E. ER1): THE ERRORS ARE:

- FR 11 SKIP ON TAPE DONE FAILED.
- ER 21 TAC IN ERROR, AC CONTAINS THE BAD VALUE OF THE TAC.
- ER 3: BAD SEARCH, AC CONTAINS THE BAD VALUE OF THE TAC.
- ER AT TAPE INTERRUPT FAILED TO CAUSE AN INTERRUPT.
- ER EI UNEXPECTED INTERRUPT, FROM AN UNWANTED SOURCE.
- ER 61 MOTION ERROR.
- ER 71 DATA ERROR, NON-GROUP TAPE INSTRUCTION.
- R BE DATA ERROR: A GROUP TAPE INSTRUCTION.

WHEN A DATA ERROR IS DETECTED, LOCATIONS 3400-3777 CONTAIN THE EXPECTED DATA AND THE VALUE OF LOCATION 0015 CONTAINS THE ADDRESS OF THE DATA IN ERROR, REFER TO 10, FOR ERROR DESCRIPTIONS.

### e RESTRICTIONS

- A. PROGRAM MUST BE EXECUTED IN FIELD 8.
- 8. STANDARD PDP-12 A OR B.
- C. TAPE TRANSPORTS MUST BE SELECTED SEQUENCIALLY, STARTING WITH UNIT 8. WRITE ENABLED AND REMOTE.
- D. THE RIGHT SWITCHES SET TO ONLY EXISTING TRANSPORTS AND/OR MEMORY AVAILABLE.
- E. NO DEVICE WHICH CAUSES UNEXPECTED INTERRUPTS.
- P. THE DATA IN BLOCKS 770 TO 1007 WILL BE DESTROYED ON ALL TRANSPORTS USED.

## 7. EXECUTION TIME

THE EXECUTION TIME IS VARIABLE TO THE NUMBER OF TRANSPORTS AND AMOUNT OF EXTRA MEMORY. THE MINIMUM AMOUNT OF TIME SHOULD BE CONSIDERED 15 MINUTES PER TRANSPORT.

8. ERROR EXAMPLES

PC XXXX=REFER TO LOCATION XXXX IN THE LISTING TO FIND THE TYPE OF ERROR ENCOUNTERED.

bell rings @ 12 minute intervals using 2 transpars & 8 K memory

### 9. OVERNIGHT RUNS!

IF RSW 00 IS SET TO A ONE, THE TEST WILL TYPE OUT ANY RECOVERABLE ERROR CONDITION ENCOUNTERED AND RESTART THE CURRENT PASS. ITIS IS DUE TO THE FACT THAT SEARCH AND DATA ERRORS ARE IN GENERAL NONREGOVERABLE.

# 10. ERROR DEFINITIONS

- A. ERROR 1 SKIP ON TAPE FAILED. EXECUTED A MTB TO BLOCK 0000 IN PAUSE MODE. THE PROCESSOR WILL WAIT WHILE THE TAPE IS IN MOTION. AT THE COMPLETION OF THE INSTRUCTION THE TAPE DONE FLAG SHOULD BE SET. THE PROCESSOR DID NOT DETECT THIS FLAG AND MALTED.
- P. ERROR 2 TAC IN ERROR AFTER A TAPE INSTRUCTION EXCEPT A WRI. EXECUTED A TAPE INSTRUCTION, AT 17'S COMPLETION THE TAC SHOULD CONTAIN THE VALUE 7777. THE AC CONTAINS THE VALUE READ FROM THE TAC IN ERROR.
- C. ERROR 3 SEARCH ERROR OBTAIN A BLOCK NUMBER FROM A RANDOM NUMBER GENERATOR AND EXECUTE A MOVE TOWARD THAT BLOCK.

  DURING THE EXECUTION OF THE MTB: EACH BLOCK IS TESTED FOR PROPER SEQUENCE AND ABSOLUTE VALUE.
  - LOC. 0122 EXECUTED A MTB TO BLOCK 0 IN PAUSE MODE. THE AC CONTAINS THE BLOCK NUMBER READ AND LOC. 0031 CONTAINS THE EXPECTED BLOCK NUMBER.
  - LOC. 0150 EXECUTED A MTB TO BLOCK 777 IN NO PAUSE MODE. THE AC CONTAINS THE BLOCK NUMBER READ AND
  - LOC: 0031 CONTAINS THE EXPECTED BLOCK NUMBER:
    LOC: 1077 EXECUTED A MTB TO A RLOCK NUMBER (LOC: 1573):
    THE AC CONTAINS THE BLOCK NUMBER READ AND

LOC: 1076 CONTAINS THE EXPECTED BLOCK NUMBER:

- D. ERROR 4 TAPE INTERRUPT FAILED, AC CONTAINS THE TAPE INTERRUPT BIT AT THE XOBHD, (2100). THE PROGRAM WAITED FOR A TAPE DONE FLAG. AFTER DETECTING TAPE DONE, AN INTERRUPT SHOULD HAVE OCCURRED BUT IT DID NOT. (I.E. FALSE TAPE DONE, TAPE INTERRUPT FLIP-FLOP NOT SET)
- E. ERROR 5 UNEXPECTED INTERRUPT

  \*### OBTAINED AN 8 MODE INTERRUPT, NO SUCH
  - INTERRUPT IS LEGAL

    #0041 LINC MODE INTERRUPT
    THE PROGRAM DID NOT EXPECT A PROGRAM INTERRUPT, THE
    XOB WORD (BIT 5) WAS 0 THEREFORE NO INTERRUPT WAS
    EXPECTED.
  - #0046 LINC MODE INTERRUPT
    THE PROGRAM DID EXPECT A PROGRAM INTERRUPT FROM THE
    TAPE CONTROL BUT IT WAS NOT FROM THE TAPE DONE FLAG.
    SKIP ON TAPE DONE MAY HAVE FAILED.

- F'. ERROR 6 MOTION ERROR EXECUTED A TAPE INSTRUCTION, WHEN COMPLETED, A TEST OF THE STATE OF THE MOTION FLIP-FLOP WAS MADE. SET THE LINK TO THE EXPECTED STATE OF THE MOTION FLIP-FLOP. IF THE LINK OF THE MOTION SHOULD BE A P. IF THE LINK OF THE MOTION SHOULD BE A P. IF THE LINK OF THE MOTION SHOULD BOUND EQUAL A 1. AC WILL CONTAIN EITHER A 10 OR A P.
- G. ERROR 7 DATA ERROR = RDC; RDE EXECUTED A READ OR READ AND CHECK INTO MEMORY
  - 1: THE DATA FIELD REGISTER CONTAINS THE MEMORY FIELD IN ERROR:
  - 2. LOCATION 0015 is A 10 BIT ADDRESS OF THE BAD DATA LOCATION (REFER TO SECTION 1).
  - 3; LOCATION 0016 IS A 10 BIT ADDRESS IN LDF1 WHERE THE GOOD DATA IS STORED (3400 THRU 3777 CONTAINS THE GOOD DATA).
  - 4. THE AC CONTAINS THE GOOD DATA PATTERN; (REFER to 11. FOR PATTERNS WRITTEN ON TAPE)
  - 5. THE LOCATION MTINST + 1 (#1973) CONTAINS THE BLOCK NUMBER ON THE TAPE IN ERROR.
- H. ERROR = 8 DATA ERROR = RCG EXECUTED A READ AND GHECK GROUP (RCG)
  - 1: THE DATA FIELD REGISTER CONTAINS THE MEMORY FIELD IN ERROR.
  - 2. LOCATION 2015 IS A 10 BIT ADDRESS OF THE BAD DATA LOCATION (REFER TO SECTION 1).
  - 3. LOCATION 0016 IS A 10 BIT ADDRESS IN LOF 1 WHERE THE GOOD DATA IS STORED (3488=3777 CONTAINS THE GOOD DATA):
  - 4. THE AC CONTAINS THE GOOD DATA PATTERN.
  - 5. THE LOCATION MTINST +1 (#1573) CONTAINS THE GROUP COUNT AND THE BLOCK NUMBER ON THE TAPE IN ERROR.

- 1. TO DETERINE THE MEMORY ADDRESS OF A DATA ERROR AND IT'S VALUE AFTER THE MACHINE HAS COMPLETED TYPING THE ERROR REPORT.
  - A. THE GOOD DATA IS IN THE AC.
  - B. EXAMINE ABSOLUTE LOCATION 8015.
  - C. SET THE LEFT SWITCH BITS 2-11 EQUAL TO THE VALUE OF LOCATION \$015 BITS 2-11.
  - D. SET LEFT SWITCH BITS 0-1 EQUAL TO THAT OF BITS 3-4 OF THE DATA FIELD LIGHTS.
  - E. SET THE INST. FIELD SWITCHES EQUAL TO THAT OF BITS 002 OF THE DATA FIELD LIGHTS.
  - F. DEPRESS EXAM.
  - G. THE BAD DATA WILL NOW APPEAR IN THE MEMORY BUFFER.

# 11: DATA PATTERNS

A: 0000

B. 7777

C. 0000 AND 7777

D. 7777 AND 9808

E. 7070

F. 0707

. 7070 AND 9707

H. 0707 AND 7070

5252

1. 2525

K: 5252 AND 2525

L. 2045 AND 9132

M. COUNT PATTERN

#### APPENDIX A

#### PDP=8 MODE PERFORATED = TAPE LOADER

READIN MODE LOADER

THE READIN MODE (RIM) LOADER IS A MINIMUM LENGTH, BASIC. PERFORATED-TAPE PROGRAM FOR THE 33 ASR. IT IS INITIALLY STORED IN MEMORY BY MANUAL USE OF THE OPERATOR CONSOLE KEYS AND SHITCHES. THE LOADER IS PERMANENTLY STORED IN 18 LOCATIONS OF PAGE 37.

THE RIM LOADER CAN ONLY BE USED IN CONJUNCTION WITH THE 33 ASR READER (NOT THE HIGH-SPEED PERFORATED-TAPE READER): BECAUSE A TAPE IN RIM FORMAT [8] IN EFFECT, TWICE AS LONG AS IT NEED BE; IT IS SUGGESTED THAT THE RIM LOADER BE USED ONLY TO READ THE BINARY LOADER WHEN USING THE 33 ASR: (NOTE: SOME PDP=12 DIAGNOSTIC PROGRAM TAPES ARE IN RIM FORMAT):

THE COMPLETE POP-12 RIM LOADER (SA # 7756 IS AS FOLLOWS!)

ABSOLUTE	OGTAL		
ADDRESS	CONTENT TAG	INSTRUCTION LE	COMMENTS
7796 7797	6832 BEG 6831	KCC KSP	/CLEAR AC AND FLAG /SKIP IF FLAG # 1
7760	5397	<b>NbeT</b>	/LOOKING FOR CHARACTER
7761 7762	6936 7106	KRB CLL RTL	/READ BUFFER
7763	7806	RTL	CHANNEL 8 IN ACO
7764 7765	7519	SPA	CHECKING FOR LEADER
7766	5357 7886	JMP BEG 41 RTL	/POUND LEADER /OK; CHANNEL 7 :N LINK
7767	6031	KSF	
7770 7771	5367	JMP=1	And the same of th
7772	5 <b>0</b> 34 5 <b>42</b> 0	KRS SNL	/READ: DO NOT CLEAR /CHECKING FOR ACORESS
7773	3776	DCA ! TEMP	STORE CONTENT
7774	3376	DCA TEMP	/STORĘ ADDRESS
7775	5356	AME BEC	/NEXT WORD
7776	u temp i Sxxx	JMP X	/TEMP STORAGE /JMP START OF BIN LOADER

PLACING THE RIM LOADER IN CORE MEMORY BY MAY OF THE OPERATOR CONSOLE KEYS AND SWITCHES IS ACCOMPLISHED AS FOLLOWS:

- A. SET THE STARTING ADDRESS 7756 IN THE LEFT SHITCHES.
- B. SET THE FIRST INSTRUCTION (6032) IN THE RIGHT SHITCHES.
- C. PRESS THE PILL SWITCH.
- D. SET THE NEXT INSTRUCTION (6831) IN THE RIGHT SHITCHES.
- F. PRESS THE FILL STEP SHITCH.
- F. REPEAT STEPS D AND E UNTIL ALL 16 INSTRUCTIONS HAVE BEEN DEPOSITED:

TO LEAD A TAPE IN RIM FORMAT, PLACE THE TAPE IN THE READER, SET THE LEFT SWITCHES TO THE STARTING ADDRESS 7756 OF THE RIM LOADER (NOT OF THE PROGRAM BEING READ), PRESS THE START LE KEY, AND START THE TELETYPE READER.

#### APPENOIX B

#### POPE12 CONTROL WORD FORMAT

WD1	LOCATION 8021
	n n n n n n n n n n n n n n n n n n n
1 = 2 3 4 5 6	NOT USED EXTENDED UNIT GROUP EXTENDED ADDRESS OPERATION NOT USED TAPE INTERRUPT (ONLY IF 680) PAUSE "I" BIT "U" BIT TAPE INSTRUCTION FUNCTION
MD5	LOCATION 0022
0=6 7=9 10=11 WD3	NOT USED EXTENDED MEMORY FIELDS LINC MEMORY FIELDS LOCATION 0023
8=11	NOT USED QUARTER NUMBER NOT USED BLOCK NUMBER (ADD 770) LOCATION 5524
் குழு வைவையை வ	EXTENDED ADDRESS (USED IN XA MODE ONLY)
XOB	LOCATION 8826
Л <b>в</b> 2 3 <b>в</b> 4 5 6 7 8	EXTENDED MEMORY BITS NOT USED ENABLE TAPE INTERRUPTS MAINT: MODE ENABLE EXTENDED ADDRESS MODE DO NOT PAUSE HOLD UNIT MOTION EXTENDED UNIT GROUP

20eJANo71

/PDP=12 TAPE DATA EXERCISER MAINDEC-12-0308 /COPYRIGHT 1971, DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

```
ISTARTING ADDRESSES
                                               MOVE TOWARD BLOCK TEST
              / 200 LINC MODE.
                                               DATA TEST
              / 201 LINC-MODE.
                                               DELETE RECOVERABLE ERROR HALT, RESTART CURRENT PASS.
              /RSW
                      001
              /RSW
                                               DELETE ERROR MESSAGE
                      1=1
                                               NUMBER OF EXTRA TRANSPORTS
              /RSW
                      6 = 8 E
                                               GREATER THAN 0
                                               NUMBER OF EXTRA MEMORY BANKS
              /RSW
                      9-118
                                               GREATER THAN B
              01
      0001
      3888
                                               /coc ER 5 ccc IN 6 MODE
0001
                      LHLT
                                               / OOO ER 5 OOO IN 8 MODE
      7402
                      HLT
0002
              K0002.
      0002
                      0002
0003
              XXXAC: 0000
0004
     0900
                                               TYPE OUT POINTER
      C 828
              020
              ISTORAGE AREA FOR SOME COMMONLY USED VARIABLES
              MASTER, 0
                                               /MASTER WORD
0020
      0000
                      Ø
                                               /WORD1
0021
      2000
              WD1.
                      Ø
                                               /WORD2
2022
      0000
              MD2,
                      Ø
                                               /WORDS
              WD3,
0023
      2000
ØØ24
      2000
              WD4,
                      2
                                               /WORD4
0025
     3000
              UNIT.
                      0
                                               /UNIT BITS (IN 6,7,8)
                                               /EXTENDED OPERATIONS BUFFER WORD
                      Ø
0026 0000
              YOBWO!
              FIELDN, Ø
                                               /FIELD NUMBER (ETTHER 3 BITS OR 5)
      1000
0027
                      0
                                               /AC
0030
     JØ00
              AC.
     .000
              STAC.
                                               /SAVED TAPE AC
0031
                      Ø
                                               /QUARTER NUMBER, BLOCK NUMBER SAVE
     0000
              QNBN.
ØØ32
0033 0000
              CTEM10 0
                                               /QN BITS
              CPEM3,
                      Ø
                                               /BN 3=11 BITS
3834 1888
                                               /STARTING ADDRESS OF "LITTLE PROGRAM"
     1000
              CSTART. Ø
0035
0036 1100
              KØ100, 100
              K0200, 200
2237 J200
```

#### /LINC ENTERRUPT HANDLER

	0040	*4 <i>0</i>			
0040	0000	LINTER,	Ø		
0041	9 <b>616</b>		LNOP		/AN LNOP MAYBE AN / LJMP XXX FOR INTERRUPT / HANQLING ROUTINE
0042 0043	0002 7200	TSTMOR,	PDP Clā		CHANGE TO POP-8 MODE
0044	1036		TAD	K9199	
0045	6151		6151	•	/SKIP IF TAPE DONE SET
0046	7402		HLT		/ 668 ER 3 666
0047	7200		CLĀ		
0050	1037		TAD	K@\$@@	
0051	6151		6151		/CLEAR TAPE DONE
0052	7200		CLA	<b></b>	
0053	1936		TAD	K0100	
8054	6151		6151		DID TAPE DONE CLEAR?
0055	7410		SKP		/YES
9056	7402		HLT		/NO.TAPE DONE DID NOT CLEAR
0057	7200		CLĀ		
0060	6141	_	LINC		/CHANGE BACK TO LINC MODE
0061	6061	MAGTAP,	FAMP	ē	/EXIT

#### /CHECK THE INSTRUCTION HTB ISTART TAPE MOVING TOWARD BLOCK 000

ØØ62	2011	MTBTST,	CLR		
0063	0001		AXO		/CLEAR XOB
0064	Ø723	BKWRD,	HT8+20		MOVE TOWARD BLOCK BOB, DON'T STOP
0065	2 <b>829</b>		Ø		PROCESSOR WILL PAUSE UNTIL A
0066	U 416		STO		/BLOCK NUMBER IS FOUND
ØØ67	7733		LJMP	XXX	FROR, TAPE DONE FLAG IS NOT SET ER 1
0070	4030		STC	A C	STORE AC
0071	6 <b>90</b> 3		TAC	100	FREAD TAPE AG
0072	1940		STA		/SAVE
0073	0031		STAC		) ~ ~ ~ V
0074	1440		SAE		/TACRAC?
0075	0830		AC		A Character and A
0076	7733			XXX	IND. TAC DOES NOT EQUAL AC, ERROR *** ER 2 ***
0077	0451		LIMP		SKIP IF AC POSITIVE (SHOULD BE MINUS OR 8)
0100	6194		LJMP	L00P01	/OK SO FAR
0101	0450		AZE		/IS ACRO?
0102	7733		LJMP	XXX	INO. AC GREATER THAN B ER 2
0103	6124		LJMP	FOSWRO	FOUND BLOCK B. GO ON TO SOMETHING ELSE
0104	1920	LOOPØ1,	LDA+28		/LOAD AC
0105	0001		1		/WITH 1
0106	1148		ADM		/ADD 1 TO TAC
0107	0031		STAC		
0110	1468		SAE+20		/SKIP IF 1
0111	2001		\$		
0112	0456		LSKP		/NOT ONE
0113	6124		LAMP	FOBWRD	/GO TO FORWARD TEST
0114	Ø <b>723</b>		MT8+20		/MOVE TOWARD & (DON'T STOP)
0115	3 <b>888</b>		Ø,		
0116	9 <b>691</b>		LIP	1	
0117	7066		LJMP	TTOF	TEST THE DONE FLAG
0120	1440		SAE		/COMPARE EXPECTED DISTANCE TO D
0121	0031		STAC		
0122	7733		LJMP	XXX	/ERROR: BAD "SEARCH" COMPUTATION 600 ER 3 000
0123	6104		LJMP	LOOPØ1	

#### /AFTER FINDING BLOCK 000, "SEARCH" FOR BLOCK 777 = FORWARD

		/AFTER	FINDING	BLOCK NND: "SEAK	CH" FOR BLOCK 777 = FORWARD
0124	0723	FOBWRD,	-		MOVE TOWARD BLOCK 0010
Ø125	0010		0010		
0126	0450		AZE		Ben iikken D B D
0127	6124	645 <b>5</b> 5	LJMP	FOBWRD	/WAIT UNTIL IT IS FOUND
0130	1929	PURMED,	LDA+20 0766		
0131 0132	0766 4031		STC	STAC	STORE IN EXPECTED TAPE BLOCK
0133	1020		LDA+20	3 I W A	/LOAD AC WITH 10
a134	0818		10		APAME WA MILL ON
0135	0001		AXO		/SET XOB FOR NO-PAUSE
0136	6011		CLR		
0137	0723		MT8+28		MOVE TOWARD SLOCK 777
0140	Ø <b>777</b>		777		
0141	J453		185	_	/WAIT FOR INTERBLOCK ZONE
0142	6141		FAMB	, 01	ALLEN MAN THE STATE OF THE STAT
0143	0416		STD	_	/WAIT FOR TAPE DONE FLAG
0144	6143		LAMP	. = 1	.DPAR GARE AR
0145	0003		TAC SAE		/READ TAPE AC // // // // // // // // // // // // //
0146 0147	1440 0031		STAC		LARUGEAL GRUSSUS
017/ 0150	7733		LJMP	xxx	/NO 888 ER 3 888
0151	9479		VEE+58	^^^	FOUND BLOCK 777?
0152	6155		LJMP	. * 3	YYES
0153	7766		LJMP	SUBTI	NO. SUBTRACT 1 FROM NUMBER EXPECTED
0154	6132		LAMP	FORWRD+2	/GO BACK AND DO IT AGAIN
Ø155	1020		LDA+20	DATUM	SET UP TO TEST TAPE DONE
0156 01 <b>5</b> 7	6202 4061		LJMP STC	MAGTAP	SET UP RETURN ADDRESS
6150	6842		LJMP	TSTMOR	/TEST TAPE DONE
6100	A IP		-		
		/CLEAR	THE INPU	T BUFFER IN FIEL	D 0
0161	ტ <b>0</b> 02	CLEAR	PDP		
0162	7300		CLA CFF		. The after the
0163	1175		TAD	K4901	SET UP A COUNTER
0164	3016		DCA	16	/ LOCATION
0165	1174 3017		TAD DCA	M4000 17	SET UP A POINTER
0166 0167	3417		DCA I	17 17	LOCATION
0170	2016		152	16	/DONE ?
0171	5167		JMP	. = 2	/NO. MORE TO DO
Ø172	6141		LING	# · ·	- 11 we y
8173	6900		LJMP	Ø	INOW GO DO SOMETHING
2174	4666	M4000.	=4000		
0175	4001	K4021.	4001		
anaa	:200 63 <b>6</b> 2	#200	ı lum	LTRTCT	
8280 8381	6161		LJMP LJMP	MTBTST CLEAR	
6281	OFOT	•	FAWL	CLEAR	

STC

LJMP

LJMP

STC

STC

MDS

WD3

WD4

RANDOM

RANDOM

0204

0223 4022

0224 7637

0225 4023

0226 7637 0227 4024

```
ITHIS SECTION DEGINS THE DATA TEST PORTION
              10F THE PROGRAM
              THE TEST IS BUILT AROUND 4 PARAMETER WORDS
              THE FIRST WORD IS THE MAG TAPE "COMMAND" HORD
              VIT DEPINES THE INSTRUCTION, UI I PAUSE, TAPE INTERRUPT
              YOUNLY IF PAUSE IS TRUE!, EXTENDED OPERATION, AND EXTENDED UNITS
              ITHE SECOND WORD DEFINES THE MEMORY FIELD (EITHER LING OR a)
              THE THIRD WORD DEFINES QUARTER NUMBER AND BLOCK NUMBER
              19HE FOURTH WORD DEPINES THE EXTENDED ADDRESS
              YNOT ALL WORDS, OR ALL BITS OF A WORD ARE NECESSARILY USED
0202 N011
              DATUM: CLR
                      STC
                              MASTER
                                              /INITIALIZE MASTER WORD TO B
0203 4020
     3641
              RESTAR, LDF 1
                      LDA+29
                                              /INITIAL [ EE
0205 1020
0206 6303
                              PAT1
                      LJMP
                                              /PATTERN
0207 1040
                      STA
                                              /ROUTINE
0210 2257
                      PATPNT
0211 0011
                      CLR
                      SET+20 6
                                              /CLEAR OUT BLOCK PATTERN TABLE
Ø212 0066
0213 3177
                      BLKTBL=1
0214 0067
                      SET+20 7
                      7377
Ø215 7577
                      STARZO
0216 1866
0217 0227
                      XSK+2B
                             7
0220 6216
                      LJMP
                              . = 2
              DATLUP, STC
                                              SET UP WORD 1
0221 4021
                              WO1
                      LJMP
Ø222 7637
                              RANDOM
```

/FORH WORD 2

/AND WORD 4

/WORD 3

			CODING TAKES	CARE OF THE EXTENDED UNITS (MORE THAN 1)
0230	1000	EXTUNT, LDA		/GET WORD 1
n231	0021	MD1		•
0232	1560	BCL +20		MASK TO EXTENDED UNIT
0233	4777	4777	_	
0234	3305	ROR	5	/POSITION TO NEXT TO "U" BIT
0235	4025	STC	UNIT	
0236	2021	ADD	WD1	/GET WD1
0237	1560	8CL+20		/MASK TO BIT 7
0240	7767	7767		
0241	2825	ADD	UNIT	/ADD TO CURRENT UNIT
0242	4025	STC	UN17	ARESTORE NEW UNIT
0243	0516	RSW		READ THE RIGHT SWITCHES
0244	1966	8CT+S8		/CLEAR ALL BUT UNITS BITS
0245	7707	7707		
0246	ø <b>017</b>	COM		/COMPLEMENT
8247	2025	ADD	UNIT	/ADD GURRENT UNIT NUMBER
0230	0471	AP0+28		/AC MINUS
0251	6466	LJMP	INCR	/NO, BAD UNIT NUMBER: GO TO INCREMENT WOL
0252	1000	LOA HOS		an em fel de de Maria
0253	2521	WO3	100	/GET WORD 1
0254	0243	ROL	3	MOVE 3 LEFT
9255	1260	BCC+58		/CLEAR ALL BUT 2 LSB'S
g 256	7774	7774	to 40 St 1 5 180	a 40° 10° da em 10° - a de em 10° - a de 10°
0257	4026	STC	XODKO	/STORE IN XOB WORD

#### ITHIS SECTION OF CODING SETS UP FOR EXTENDED ADDRESS OPERATIONS

		•			
0260	1666	EXTEND,	LDA		GET HORD 1 INTO AC
0261	6 <b>821</b>		WQ1		
0262	1560		BCT + SB		/MASK TO BIT 3
0263	7377		7377		. Mark of the state of the stat
0264	0470		VSE+50	A CONTRACT - TO	VEXTENDED ADDRESS OPERATIONS?
M265	6344		L JMP ROR	NONEXT	/NO /YES, MOVE TO BIT 7
0266 02 <b>6</b> 7	0394 2926		ADO	XOBND	COMBINE WITH OTHER BITS
0270 0270	4926		STC	XOBWD	/AND STORE
0271	2822	ExT0,	ADD	MQ5	GET WORD 2
0272	1960		BCL+S&	led a see	MASK TO FIELD BITS
0273	7743		7743		
0274	4027		STC	ETETON	/SAYE
0275	2027		ADD	FIELDN	/GET FIELD
0276	U450		AZE	en transmi	/NON-ZERO?
0277	6316	20 V 20 4	LAMP	EXT3	/YES /GET WORD 4
0300 0301	2 <b>024</b> 3716	EXT1,	ADD ADD	WU4 K4000	JULI NURU N
0302	9471		APO+20	CA MAN HOUSE	/AC POSITIVE?
0303	6307		LJMP	EXTZ	YES, OK SO FAR
g3g4	7637		LJMP	RANDOM	/NO. ADDRESS 18 3777 OR BELOW
0305	4024		STC	HD4	-
0306	6300		FAMB	EXTI	
0307	1900	EXT2,	LDA		/GET WORD 4 AGAIN
0310	Ø Ø 2 4		ND4		488 -8466
0311	1120		ADA • 20 0377		/ADD =7488
0312 0313	ค <b>377</b> ย <b>471</b>		V60+SB		/AC MINUS?
0313 0314	6384		LJMP	EXT2=3	/NO. ADDRESS IS ABOVE 7409
0315	6331		LJMP	EXTA	YES, ADDRESS IS OK
ø316	9 <b>916</b>	EXT3,	RSH	65	READ RIGHT SHITCHES
0317	1560		8CL+58		/MASK TO FIELD BITS
0320	7770		7778		
0321	8242		ROL 2		/2 [[ ]
0322	0017		COM	P T P I NAI	/MAKE NEGATIVE
0323 0324	2 <b>027</b> 6 <b>451</b>		ADD APO	FIELDN	JOO WE HAVE THE MEMORY?
0325	6307		LJMP	EXT2	YES. CHECK THE ADDRESS
0325 0326	7637		LJMP	RANDOM	/NO. GET A NEW FIELD NUMBER
0327	4022		STC	MDS	
0330	6271		LJMP	EXTØ	
0331	1000	EXT4.	LDA		/GET FIELD AGAIN
0332	<b>8</b> 827		FIELDN	_	
0333	×305		ROR	5	/MOVE 5 RIGHT
2334	2026		ADD	XOBMD	COMBINE WITH OTHER BITS
0335	4026		STC	MD2	/AND STORE /GET WORD 3
0336 0337	2 <b>023</b> 1 <b>560</b>		BCT+58 VDD	иñл	/MASK TO BITS 8 TO 11
0337	7760		7760		فيتستماع بم تساءً بم م زود توانده
0341	2411		ADD	K0770	
0342	4932		STC	QNBN	STORE IN ONBN SAVE
0343	6414		LJMP	PAUSEB	

#### /THIS SECTION OF CODING SETS UP FOR NON-EXTENDED ADDRESS OPERATION

9344	1000	NONEXT,			/GET WORD 2
0345	0922		MDS		
Ø346	1560		8CT + 50		/MASK TO LINC MEMORY FIELD
0347	7740		7740		
0350	4827		STC	FIELDN	/AND SAVE
0351	2027		ADD	FIELDN	AGEL PING WEMORA LIEFD
0352	1120		ADA + 20		
0353	7776		7775		
0354	0471		AP0+28		/IS IT NOT 0 OR 17
0355	6361		LJMP	8 # <del>4</del>	/YES
0356	7637	NONEXI,	LAMP	RANDOM	/NO. IT IS B OR 1, GET ANOTHER
0357	4622	-	STC	MDS	/STORE
0360	6344		LJKP	NONEXT	/GO BACK AND TRY AGAIN
0361	Ø <b>516</b>		RSW		/READ RIGHT SHITCHES
0362	1566		BCT.Sa		MASK TO FIELD BITS
2363	9770		7778		
9364	0242		ROL	2	/LEFT 2
0365	2377		ADD	KØØØ3	
0366	0017		COM		THAKE NEGATIVE
0367	2827		ADŌ	FIELON	
0370	G471		APO+20		100 HE HAVE THE MEMORYS
0371	6356		LJMP	NONEXT	/NO
6372	1906		LDA		/GET WORD 1
0373	0021		HD1		
<b>63</b> 74	1560		BCL +20		/CLEAR TO FUNCTION BITS
0375	7778		7770		407
0376	1468		SAE+20		/SKIP IF MTB
0377	0983	K0903.	E.		
0400	6486		LJMP	NONEXS	/NOT MT8
3481	1900		LDA		/GET WORD 3
0482	0 N S 3		w D 3		
0403	1560		BCF + 50		/MASK TO BITS 3 TO 11
0404	7080		7000		
0405	6413		LJMP	NONEX3	
0406	1000	NONEXS,	LDA		JGET HORD 3
0407	0023		WD3		
0410	1569		8CF + 50		ACLEAR TO GN, BN (0 TO 2, 9 TO 11)
0411	3 <b>77</b> 9	K3776,	0770		
8412	2411		ADD		/ADD 770
0413	4032	MONEXS!	SYC	QNBN	STORE IN GNEN SAVE

/AND STORE

```
ITHIS SECTION OF CODING SETS UP THE "PAUSE" BIT
              /IF "NO PAUSE" IS SPECIFIED, CONTROL WILL THEN GO
             170 THE TAPE INTERRUPT ENABLE BIT HANDLER
                                             /GET WORD 1
             PAUSEB, LDA
0414 1000
0415 6021
                      WD1
0416 6017
                      CCM
                                             /COMPLEMENT AC
                                             /MASK TO "PAUSE" BIT
0417 1560
                      BCL+29
0420 7737
                     7737
                                             /2 RIGHT
0421 0302
                      ROR
                      ADM
                                             /COMBINE WITH XOB WORD
0422 1140
0423 0026
                      CMBOX
0424 1560
                                             /MASK TO "DON'T PAUSE" BIT
                      8CL+28
g425 7767
                      7767
0426 0470
                     VSE+50
                                             /SKIP IF SET
0427 6436
                     LJMP
                             DISPCH
             /TAPE INTERRUPT ENABLE BIT HANDLER
              ITHIS SECTION OF CODING IS ENTERED ONLY IF
             THE "NO PAUSE" BIT IS TRUE
             TPINEN: LDA
0430 1000
                                             /GET WORD 1
                      WD1
0431 0021
0432 1560
                     BCL+20
                                             /MASK TO BIT 5
                     7677
0433 7677
0434 2026
                      ADD
                             XOBMD
                                             /COMBINE WITH OTHER BITS
```

XOBMD

STC

0435 4026

17HIS SECTION OF CODING DISPATCHES THE PROGRAM /TO THE APPROPRIATE SECTION OF CODING TO HANDLE /THE PARTICULARS RELATING TO EACH MAG TAPE INSTRUCTION

Ø436	8 <b>011</b>	DISPCH,	CLR		/GET WORD 1
0437	2021		ADD	WD1	
0440	1560		BCL+29		MASK TO FUNCTION BITS
0441	7770		7790		tituming ton i delan i Entra me in
,	1120		ADA+20		/ADD IN "MASTER JUMP"
0442				* A D : E**	YAUU IN "MASIER JUMP"
0443	6446		FAMB	TABLES	. B S A m F
0444	4445		STC	. + 1	/STORE
0445	6445		LJMP	6	/EXECUTE
9446	6456	TABLE1,	LJMP	RDSUB	/READ AND CHECK (Ø)
0447	6 <u>4</u> 6Ø		LJMP	RCKSUB	/READ AND CHECK GROUP (1)
0450	6456		LJMP	ROSUB	/READ (Z)
Ø451	6462		LJMP	MOVSUB	/MOVE TOWARD BLOCK (3)
Ø452	7106		LJMP	WRITE	/WRITE AND CHECK (4)
0453	7332		LJHP	HRĈKGP	/WRITE AND CHECK GROUP (5)
Ø454	7106		LUMP	WRITE	/WRITE (6)
g 455	6464		LJMP	CHKSUB	/GHECK (7)
	6504	RDSUB,		READ	1 8 M P P 14
0456		RUSUBI	LJMP	INCR	
Ø457	6466	56461.5	LJMP		
0460	6796	RCKSUB,	LAMP	ROCKGP	
0461	6466		LJMP	INCR	
Ø462	7023	MOVSUB,	LJMP	MOVE	•
0463	6466		FAMP	INCR	
0464	7454	CHKSUB,	LUMP	CHECK	
Ø465	6466		LJMP	INCR	
9466	1020	INCR,	LDA+20		/INCREMENT MASTER WORD
0467	0001		1		
0470	2020		ADD	MASTER	
0471	9471		APO+20		
0472	6501		LJMP	INCRA	
0473	Ø6Ø1		LIF	1	
0474	7131		LJMP	BELL	
0475	1020		LDA+28	Present Chin (Mil	
	6 <b>05</b> 0		0030		
0476					
0477	6004		ESF	-	
0500	0011	T N: 6 6 4	CLR		
0501	1040	INCRAD	STA		
0502	0020		MASTER		
0503	6221		LAMP	DATLUP	/GO BACK AGAIN
					•

PAL10

g562 7511

LJMP

MOVPRO

/TAPE 2

/MOVE "LITTLE PROGRAM", THEN EXECUTE IT

#### /THIS SECTION OF CODING HANDLES THE INSTRUCTIONS "READ" /AND "READ AND CHECK BLOCK" 2000 0504 READ. ADD REXIT 0505 4701 STC /SAVE RETURN ADDRESS 1020 LDA+20 /SET UP RETURN JUMP 9596 0507 7610 LJMP STC TOPLAG 5575 AMULA /PROM INSTRUCTION EXECUTION 0510 1020 LDA+28 /SET UP FOR RETURN 0511 RCHK a512 6610 LJMP 7540 0513 LJMP MTSET /FROM FLAG HANDLING /MASK XOBHO TO EXTENDED ADDRESS MODE BIT 0514 1560 BCL+28 Ø515 7757 7757 0476 AZE+20 VEXTENDED ADDRESS MODE? 0516 0517 6531 LJMP REDNEX INO /YES 9520 LDA 1399 WØ32 ONBN /GET GN=BN 0521 9601 Ø522 LIF LJMP WRITEN /HAS BLOCK BEEN WRITTEN? 6722 0523 0524 6781 LJMP REXIT INO. EXIT Ø525 4644 STC PATJMP YES, OK, SAVE PATTERN WORD 2024 ADD WD4 /GET EXTENDED ADDRESS 0526 Ø 623 THA /LOAD THA SETUP REGISTER 0527 MTXEQT VEXECUTE "RDE OR RDC BN" 0530 7567 LJMP /HERE IF NOT EXTENDED ADDRESS MODE 2032 REDNEX, ADD CNBN /CET GN=BN a531 1560 BC: +20 /CLEAR TO BLOCK NUMBER 0532 0533 7000 7000 0601 LIF 0534 0535 6722 LJMP WRITEN THAS BLOCK BEEN WRITTEN INO. EXIT LJMP 0536 6701 REXIT 4644 a537 STC PATJMP YES, OK, SAVE PATTERN WORD 2032 0540 ADD GNBN /GET GN=BN 1560 BCL+S@ /MASK TO GN 0541 777 0542 Ø777 /DF OR IF 0543 9451 APO REDDF 0544 6563 LJMP /DF /IF. Q8? 0545 6459 AZE /NOT QU 2546 6552 LJMP . . 4 LDA+20 **U547** 1020 /GB: INSTRUCTION 0400 400 /WILL BE STORED IN Q1 0550 9456 LSKP 0551 3011 0552 CLR INOT GO, INSTRUCTION WILL BE STORED IN GO 0553 4035 STC CSTART FIELDN /GET FIELD BITS 2027 ADD 0554 Ø555 2631 ADD LDFCON 4561 STC LDFRD1 /AND STORE Ø556 /GET LDF INSTRUCTION 0557 2561 REDNX1, ADD LDFRD1 7657 LJMP COMON7 /SET UP "MOVLIF" AND "MOVLDF" 0560 3000 LOFRD1, Ø ISTORAGE FIELD LOF GETS STORED HERE 0561

V141

200UAN=71

23:48

PAGE 12

#### /RETURN HERE IF FLAGS OK UPON INSTRUCTION COMPLETION

2618	1000	RCHK,	LDA		/GET INSTRUCTION EXECUTED
0611	1972		MTINST		
0612	1560		8C[*58		/CLEAR ALL BUT INSTRUCTION EXECUTED
Ø613	7770		7770		LAPRIM L. L. P. B. C. R. I. F. L. B. C. L. B. C. L. B. C. B.
	6450		AZE		/"READ AND CHECK" INSTRUCTION?
9614				+ <b>4</b>	
0615	6621		FAMB	, 44	/NO
Ø616	9 <b>993</b>		TAC		YES, READ TAPE AC
0617	0 <b>450</b>		AZE		/ZEROT
Ø62Ø	7733		LUMP	XXX	/NO. ERROR *** ER 2 ***
0621	1000		LDÃ		/GET XOB WORD
9622	6026		XOBMD		
Ø623	1560		BCT + 30		MASK TO EXTENDED ADDRESS BIT
0624	7757		7757		
0625	0450		AŚE		/EERO?
0626	6702		LJMP	EXTOCH	/NO
Ø627	2927		ADD	FIELDN	/YES, CALCULATE
Ø63Ø	1120		ADA+28		/WHERE
Ø631	6 <b>646</b>	LDFCON.	LDF		/DATA
0632	4667	•	STC	DATCHK	/IS STORED
9633	3573		ADÔ	MTINSTOS	/GET GN=BN
ø634	1560		BC[*SØ		/MASK TO 2 QUARTER BITS
0635	4777		4777		र राज्य-भागाः । प्राप्तः था मस्यक्षाराभागां स्वयक्षारं स्वर्णिः । विश
				4	RIGHT 1 PLACE TO FORM FIRST DATA ADDRESS
0636	0361		ROR	*	
Ø637	4646		SŤC	DATADD	/STORE AWAY ADDRESS

```
3649 1929
                      LDA+20
0641 1400
              K1400. 1400
0642 2601
                      LIF
0643 U641
              LD1CON, LOF
                                              /CHANGE DATA FIELDS
                              1
              PATJMP, LJMP
                                              STORE NEW DATA THERE
2644
     6644
9645
                      LDA+20
                                              /SET UP ADDRESSES TO CHECK DATA
     1920
              DATADD, Ø
                                              /ADDRESS OF DATA READ
     0000
0646
Ø647 776Ø
                      LJMP
                              SUBT1
                                              JSUBTRACT 1 FROM THE AC
8658 1628
                      BSE+20
                                              ISET BIT DE OF THE AC
                      2000
a651
    2999
                                              /SET 8815 TO STARTING ADDRESS OF THE DATA READ
0652 4015
                      STC
                              15
                      SET+20 16
                                              SET 0016 TO THE STARTING ADDRESS OF THE EXPECTED DATA
0653 0076
                      3377
0654 3377
                      SE++20 17
                                              /SET DOIT TO A COUNT
0655 0077
8656 7377
                      7377
                                              / LOCATION
                                              /LOAD THE AC WITH A "GOF Nº INSTRUCTION
0657 1000
                      LDA
                      DATCHK
9668 9667
                      STA
                                              /SAVE IT
9661
    1848
                      SAVA
9662 3913
9663 9917
                      COM
                                              /SET THE AC TO 7777
                                              SET THE LINK
2664
     a261
                      ROL+20 1
                                              /IT WILL BE USED IN "TET1"
0665 Ø641
                      LOF
                      LDA+20 16
                                              /CHECK DATA EXPECTED
8666 1836
                                              /CHANGE DAYA FIELD
2667 3648
              DATCHK, LDF
2670 1475
                      SAE+20
                              15
                                              /AGAINST DATA READ
                      LDA
                                              /DATA ERROR *** ER 7 ***
9671 7733
                              XXX
                                              /LOAD THE AC WITH THE VALUE IN LOC 0015
9672 1999
9673 9915
                      0015
2674 2621
                      LIF
                              1
                      LJMP
                              TST1
                                              /TEST THE LIMIT OF LOC 15
6675 6771
                                              TEST MORE DATA TO TEST ?
0676 0237
              DATING, XSK+20
                              17
                      LUMP
8677 6665
                              DATCHK=2
                                              YES, GO DO IT
                      LJMP
0988 6161
                              CLEAR
              REXITO LJMP
                                              / NO, EXIT
9701 6701
8702 8601
              EXTOCH, LIF
0703 6210
                      LJMP
                              COMON4
                                              /SET UP FOR EXTENDED ADDRESSING MODE DATA
                                              ISTORE PROPER "LOF" FOR ACCESSING DATA
                              DATCHK
2794 4667
                      STC
2725 6640
                      LJMP
                              PATJMP64
```

ITHIS SECTION OF CODING HANDLES THE INSTRUCTION "READ AND CHECK GROUP"

	-755	55 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5		2	
0706	5000	RDCKGP,	ADD	Ø	
0707	5022		STC	RGEXIT	/SAVE RETURN ADDRESS
ØĪĪØ	0601		LIF	1	
0711	6020		LJMP	COMON1	/CHECK EXTENDED ADDRESSING TAPE/MEMORY HRAPAROUND: ETC:
0712	7022		LJMP	RGEXIT	/ILLEGAL OPERATION EXIT JUMP
0713	Ø6Ø1		LIF	1	
0714	6137		LJMP	COMONS	SET UP TO COUNT BLOCKS (RETURN WITH BN IN AC)
0715	8681	RGCON1,	LIF	<b>1</b>	
0716	6722	-	LJMP	HRITEN	/HAS BLOCK (NUMBER IN AC) BEEN WRITTEN?
0717	7022		LUMP	RGEXIT	NO, EXIT
0720	1020		LDA+20		YES, SET AC TO 1
Ø <b>721</b>	មេ <b>២២1</b>		1		
0722	1148		ADM		/ADD TO BLOCK NUMBER
0723	9934		CTEM3		
Ø724	Ø <b>234</b>		X5K+20	14	/DONE TESTING BLOCKS?
ø725	6715		LJMP	RGCON1	/NO
0726	1929	RGCONZ,	LDA+20		/SĒT UP RETURN JUMP
Ø727	7610		LJMP	TOPLAG	
Ø73Ø	5575		STC	RJUMP	/FROM INSTRUCTION EXECUTION
g 731	1929		LDA+20		/SET UP FOR RETURN
0732	6744		LJMP	RCCHK	
Ø733	7548		LJMP	MÝSÉT	/FROM FLAG MANDLING
0734	1000		LDA		/GET FIELD
0735	0027		FIELDN		
Ø736	2631		ADD	LDFCON	
Ø737	1948		STA	•	/AND STORE AS STORAGE FIELD
0740	0742		LDFRG1		
0741	7657		LJMP	COMON7	SET UP "MOVLIF" AND "MOVLDF"
	8648	LDFRG1.	LDF		/STORAGE FIELD GETS STORED HERE
0742	7511		LUMP	MOVPRO	/MOVE "LITTLE PROGRAM", THEN EXECUTE IT

#### PRETURN HERE IF FLAGS OK UPON INSTRUCTION COMPLETION

0744	0003	RGCHK:	TAC		/READ TAPE AC
Ø745	2450		AZE		/EERO?
g746	7733		LJMP	xxx	/NO, ERROR *** ER 2 ***
Ø747	Ø <b>6</b> Ø <b>1</b>		LIF	1	Such a such as a
0750	6137		LJMP	COWONS	SET UP TO COUNT BLOCKS
Ø751	0011		CLR	# # / · · · · · · · ·	र चक्का था । संचित्र च के चार्गा अस्ति के चारण
Ø752	2034		ADD	CTEM3	JGET BLOCK NUMBER
Ø753	Ø601	RGCON3,		1	Age: Appoint it all age.
Ø754	6722	MACCHA!	LJMP	WRITEN	/FIND OUT BLOCK PATTERN ADDRESS
Ø755	0000		LHLT	**** <b>6</b> : ********	THIS RETURN SHOULD NOT BE USED
g755	4762		STC	PATERM	STORE AWAY
Ø757	2641		ADD	K1400	FOICH MANE
0760	Ø 6 Ø 1		LIF	1	
Ø761	Ø 641	LDFRG2,		1	STORAGE FIELD "LOF" IS STORED HERE
9762	6762	PATERM.			PATTERN JUMP IS STORED HERE, RETURN WITH DATA STORED
ø/0 <u>6</u> ø763	1000	PAIFBUR	LOA	•	VEEL BLOCK NAMBEE
Ø764	2034		CTEMS		spipet napolitation is position poist.
0765	9691		LIF	1	
9765 9766	6162		LJMP	COMON3	COMPUTE DATA FIELD TO ACCESS DATA
0767 0767	5006		STC	LDFRG3	/STORE "LOF" INSTRUCTION (IN AC FROM COMONS)
Ø77Ø	2034		ADD	CTEM3	VEEL BLOCK HAMBER VEVILOR AT A LINCH ACHAINS
0771	1960		BC[+50	A. 2010	/MASK TO BN 10:11
0771 0772	7774		7774		THESK ID DIE SEEST
0773	Ø394		ROR	4	/4 RIGHT TO FORM ADDRESS
0774	7760		LJMP	SUBT1	/SUBTRACT 1
0775	1620		856+20	25219	SET DATA FIELD BIT
a776			2000		LAPI ANIM LIBBA SE:
Ø 7 7 9 Ø 7 7 7	2000 4015		STC	15	/STORE IN 15 (DATA READ)
1000	0076		SET+20	16	/SET UP 16 FOR CHECK DATA
1001	3377		3377	* 7	THE BE THE MINERAL MENTER
1002	0 <b>077</b>		SET+20	17	/SET UP 17 FOR COUNT (400)
1002	7377		7377	1,	SEL AL TELON CORAL LABOR
1003	0641		LÖF	1	/DATA EXPECTED "LDF"
1005	1036		FDV+5R	16	VEL CHECK DATA
1006	0640	LDFRG3,	- · · · · · · · · · · · · · · · · · · ·	* <u>*</u>	/DATA READ FIELD "LDF"
	1475	Phikasi	SAE+20	15	COMPARE AGAINST DATA READ
1007	7733			XXX	/NO: DATA ERROR see ER 8 see
1010	6237		XSK+20	17	/COMPARED 4009
	7004		LUMP	LDFRG3=2	NO, GO BACK FOR NEXT DATA HORD
1012			40 -0	PD1 446-5	YES, INCREMENT
1013	1020	WORDS AND	FDV+SQ		1 8 m 1 - የ14 P L E L E 14 1
1014 1015	0001 1140	K0001.	1 ADM		/BLOCK NUMBER
1010	0034		CTEM3		र लेखीं काम कर नाम किया किया
1017	d234		XSK+20	14	/DONE ALL BLOCKS?
101/	6753		LAMB	RGCON3	IND. REPEAT FOR NEXT BLOCK
1020	6161		LJMP	CLEAR	tishs important the or dentity
1022	7022	AGEXIT,			/EXIT
1066	10.66	MACKILI	FAUL	8	/ 5. A & 1

### THIS SECTION OF CODING HANDLES THE INSTRUCTION "MOVE"

		7 / 1120 00			Man 1 11 888 8 1 April 1 Captable 1 of carry 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1023	2000	MOVE,	ADD	Ø	
1024	5105		STC	MEXIT	SAVE RETURN ADDRESS
1025	1020		LDA+20		SET UP RETURN JUMP
1026	7610		LJMP	TDFLAG	
1027	5575		STC	RJUMP	/FROM INSTRUCTION EXECUTION
1030	3572		ADD	MTINST	INO. GET THE LAST TAPE INST.
1031	641		LDF	1	/FIELD 1
1032	5247		ROL	7	<b>}</b>
1033	1848		STA		SAVE THE VALUE IN "IBIT"
1034	3112		IBIT		/SAVE THE PREVIOUS I BIT
īø35	0471		APO+30		/ BIT_8 #1 ?
1936	7104		LAMP	MEXIT-1	/ NO EXIT
1037	1828		FDV+50		YES EXECUTE THIS HTO
1040	7044		LJMP	MCH	AND III. AND III.
1041	7540		LJMP	MTSET	SET UP A RETURN ADD.
1042	7766		LJMP	MPAC	SET THE "IM BIT IN THE MTB
1043	7567		FAMB	MTXEQT	/EXECUTE TATET
1044	0003	MCH,	TAC AZE+20		RETURN HERE, TACBO ?
1045	0470 7104		LJMP	MEXIT=1	YES EXIT
1046 1047	0640		LOP	0	A A A A A A A A A A A A A A A A A A A
1050	96 <b>01</b>		LIP	1	
1051	7100		LJMP	TSIGN\$	/NO TEST THE LIMITS
1052	1920	MCCH,	LDA+20	[ m & m : 1 dg	* *** *** *** *** *** *** *** *** ***
1053	7861	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	LJMP	MCHK	
1054	7540		LJMP	MTSET	FROM FLAG HANDLING
1055	0070		SETOZB	10	/SET 10 TO =1 (1'S COMP)
1056	7 <b>7</b> 76		7776		
1057	7766		LUMP	MPAC	SET BIT "7"
1060	7567		LJMP	MTXEQT	VEXECTUE "MTB ON"
		PETURN	HERE IF	FLAGS OK UPON	INSTRUCTION COMPLETION
1061	0 <b>903</b>	MCHK,	TAC		/READ BACK THE TAPE AC
1062	g 47g		VSE+S0		/EEROT
1063	7101		LJMP	MCHK1	/YES
1064	0230		XSK+20	10	/NO. FIRST NUMBER READ BACK?
1065	7075		LJMP	MCOMP	/NO
1966	ø 451	MBUMP,	APO	_	/YES, POSITIVE AC?
1067	7072		LJMP	, * Ž	/NO, NEGATIVE
1070	7760		LJMP	SUBT1	/YES, DECREMENT
1071	Ø 456		LSKP	140004	
1072	3014		ADD	K0001	/FAVE
1073	5976		STC	MEXPT	/SAVE
1074	7101	MCOMP.	LJMP SAE+20	MCHK1	/IS THE NUMBER READ EQUAL
1075	1460 0000	MEXPT.	SWEACA		TO THE NUMBER EXPECTED?
1076 1077	7733	ITS AFTE	LJMP	xxx	/NO, ERROR *** ER 3 ***
1100	7966		LUMP	MBUMP	YES, SET UP FOR NEXT NUMBER
1101	: 903 : 903	MCHK1,	TAC	TENCHARTET.	READ TAC AGAIN
1102	3450	₩K.#.	AZE		/ZERO?
1103	7567		LJMP	MTXEQT	
1104	0011		CLR		
1105	7105	MEXITO	LJMP	•	/EXIT

#### /THIS SECTION OF CODING HANDLES THE INSTRUCTIONS "WE " VAND "WRITE AND CHECK BLOCK"

1106	1020	WRITE:	LDA+20		/SET UP RETURN JUMP
1107	761ø		LJMP	TOFLAG	
1110	5975		STC	RJUMP	/FROM INSTRUCTION EXECUTION
1111	1828		LDA+28		SETUP FOR RETURN
1112	7241		LJMP	MCHK	
1113	7540		LJMP	HTSET	/FROM FLAG HANDLING
1114	1560		8CF + 38		MASK KOBHO TO EXTENDED ADDRESS MODE BIT
1115	7757		7797		
1116	0476		AZE+20		/EXTENDED ADDRESS MODE?
1117	7143		LJMP	HRINEX	/NO
1120	0601		LIF	1	
1121	6210		LJMP	COMON4	YES, SET UP FOR EXTENDED ADDRESS MODE DATA
1122	5125		STC	LDFWRS	STORE PROPER "LOF" FOR STORING DATA
1123	2646		ADD	DATADD	GET ADDRESS WHERE DATA SHOULD BE STORED
1124	Ø 6 0 1		LIF	1	
1125	Ø64Ø	LDFWR1.	DF		/CHANGE DATA FIELD
1126	6254	P 111( )	LJMP	PATERN	PUT DATA PATTERN IN MEMORY
2127	5317		STC	WPAT	SAVE PATTERN TYPE (IN AC UPON RETURN)
1127 1130	3573		ADD	MTINST+1	/GET QN-BN
1131	0601		LIF	1	
1132	6236		LJMP	COMONS	/CALCULATE BLOCK STATUS WORD ADDRESS
1133	1940		STA		/SAVE
1134	1322		UNBNSV		
1135	5137		STC	. *2	STORE FOR EXECUTION
1136	1848		STĂ	•	CLEAR STATUS HORD
1137	6666		9		
1140	2024		ADD	WD4	GET EXTENDED ADDRESS
1141	ØØ23		TMA		/LOAD TMA SETUP REGISTER
1142	7567		LJMP	MTXEQT	VEXECUTE WHRI OR WRC BN"
				· · · · · · · · · · · · · · · · · · ·	The state of the s

/MOVE "LITTLE PROGRAM". THEN EXECUTE IT

PAGE 19

/PDP-12 TAPE DATA EXERCISER MAINDEC-18-0308

1213 7511

LJMP

MOVPRO

PALID

V141

29 JAL

/SET UP QUARTER STORAGE ADDRESS

/GO EXECUTE LITTLE PROGRAM (EVENTUALLY)

23 48 AGE 20

/PDP=12 TAPE DATA EXERCISER MAINDEC=12=D3DB

1237 4035

1249 7212

STC

LUMP

CSTART

LDPWR3

p.ord

.

PRETURN HERE IF FLAGS OK UPON INSTRUCTION COMPLETION

1241	1000	WCHK,	LDA		GET INSTRUCTION EXECUTED
1242	1572		MTINST		
1243	1560		BCL +20		/CLEAR I AND U
			0030		
1244	0030		STÀ		SAVE FOR PUTURE REFERENCE
1245	1040				LAWAE AND SAIANE UPSEURIAR
1246	1305		WINST		THE TOT AND GUERY THOUSAND
1247	1460		SAE+20		/HRITE AND CHECK INSTRUCTION?
1250	0704		MRC		
1251	7255		LJMP	, * 4	/NO. WRITE INSTRUCTION
1252	9 <b>993</b>		TAC		/READ TAPE AC
1253	Ø450		AZE		/EERO?
1254	7733		LJMP	XXX	/NO.ERROR ER &
1255	1000		LDÄ		/GET XOB WORD
1256	Ø Ø 26		XOBMD		
1257	ø325		ROR+20	5	MOVE EXTENDED ADDRESS BIT INTO LINK
			LDA		JGET GN-BN
1260	1000			1	1.44 i #15.00 ft.
1261	1573		MTINSTO:	<b>L</b>	CAMP FOR PHOUNT SPEEDS NOT
1262	1969		STA+20		SAVE FOR FUTURE REFERENCE
1263	6968	HINST1,	Ø		
1264	3814		ADD	K0001	
1265	0472		PSE+S0		/EXTENDED ADDRESS MODE?
1266	7301		LJMP	WCONTS	/NO. GO DIRECTLY TO EXECUTE "MTB BN+1"
1267	1040		STÄ		/YES, SAVE
1278	1300		HTEMP		
1271	1120		ADA+20		/SUBTRACT 1007
1272	6770		6770		
1273	Ø451		APO		VLEGITIMATE NEXT BLOCK?
12/9	7277		LJMP	, \$3	YES
1274			CLR	8 ± 84	INO. NEXT BLOCK IS B
1275	0011			UPANT4	राबद गक्रमा सिक्षकार हैक क
1276	7301		LJMP	WCONT1	

TAPE 3 ITHIS SECTION OF CODING HANDLES THE INSTRUCTION "WRITE AND CHECK GROUP"

1332	0601	WRCKGP,	1 18	1	
1333	6020	KITOROI \$	LJHP	COMONS	/CHECK EXTENDED ADDRESSING; TAPE/MEMORY HRAPAROUND, ETC.
1334	7453		LJHP	WGEXIT	VILLEGAL OPERATION EXIT JUMP
1335	1900		LDA	र रेक्ट कार र रेक्ट	VSET UP INSTRUCTION FIELD
1336	9927		FIELDN		
1337	2631		ADD	LDPCON	
1340	7657		LJMP	COMON7	SET UP "MOVLIF" AND "MOVLOF"
1341	86 <b>01</b>		LIF	1	Seminary Transfer of the seminary management
1342	6 <b>137</b>		LJMP	COMONZ	SET UP TO COUNT BLOCKS, (RETURN WITH BLOCK NUMBER! IN AC)
1343	Ø <b>601</b>	WGCON1;		1	
1344	6165	he for ext For 14 cm %	LJMP	COMONS	COMPUTE DATA PIELD TO STORE DATA
1345	5353		STC	LDFWGI	STORE "LOF" INSTRUCTION (IN AC FROM COMONS)
1346	2034		ADD	CTEMS	/GET BLOCK NUMBER
1347	1960		BCL +20		/MASK TO BN 18.11
1350	7774		7774		, the second of the factor of the second of
1351	0304		ROR	4	/4 RIGHT TO FORM ADDRESS
1352	0601		LIP	1	
1353	Ø64Ø	LOFWG1;		_	/CHANGE DATA FIELD TO STORE DATA
1354	6254		LJMP	PATERN	/PUT PATTERN IN MEMORY
1355	5363		STC	WGPAT	/SAVE PATTERN ADDRESS
1356	2034		ADD	CTEM3	/GET BLOCK NUMBER
1357	0601		LIP	1	
1360	6236		LJMP	COMONS	COMPUTE BLOCK STATUS WORD ADDRESS
1361	5366		STC	. +3	/STORE
1362	1120		ADA+28	•	JGET PATTERN ADDRESS
1363	0000	HGPAT.	Ø		
1364	Ø <b>641</b>		LDř	1	
1365	1040		STÀ		STORE AHAY
1366	0000		Ø		
1367	1020		LDA+20		/INCREMENT
1370	9001		1		
1371	1140		ADM		/BLOCK NUMBER
1372	Ø <b>Ø34</b>		CTEM3		
1373	<b>234</b>		X2K+50	14	/DONE ALL BLOCKS (AND QUARTERS)?
Ĩ3 <b>Ž</b> 4	7343		LJMP	WGCON1	/NO, GO BACK TO DO NEXT BLOCK(QUARTER)
Ĩ375	1020		LDA+20		/SET UP RETURN JUMP
1376	7412		LJMP	WGRET	
1377	5975		STC	RJUMP	/FROM INSTRUCTION EXECUTION
1400	1020		LDA+20		SET UP FOR RETURN
1401	7430		LJMP	WGCHK	
1402	7540		ΓŽMΒ	MTSET	FROM FLAG HANDLING
1403	1000		LDA		/GET TLITTLE" PROGRAM INSTRUCTION FIELD
1484	1534		MOVLIE		
1405	1120		ADA+28		/MAKE AN
1406	294g		40		/"LOF" INSTRUCTION
1407	5410		STC	LDFWG2	/STORE AWAY
1410	0640	LDFHG2.			PLANE THE LOP
1411	7511		LJMP	MOVPRO	/MOVE "LITTLE PROGRAM", THEN EXECUTE IT

### PRETURN HERE AFTER EXECUTING THE "LITTLE PROGRAM"

1412	1020	WGRET.	LDA+28		
ï413	07 <b>73</b>		773		
1414	0601		LIF	1	
1415	6722		PAMP	WRITEN	/GET BLOCK PATTERN ADDRESS FOR 83
1410	7427		LJMP	Q3PAT +1	733 NEED NOT BE RELOADED
1417	5426		STC	QSPAT	/SAVE
1420	3410		ADD	LOFHGE	/GET "INSTRUCTION FIELD"
1421	5425		STC	Q3PAT=1	STORE FOR EXECUTION
1422	1020		LDA+20		/GET STORAGE ADDRESS
1423	1488		1400		
1424	0601		LIF	4	
1425	0640	_	LDF		PEXECUTE THE LDF
1426	6090	G3PAT,	LAMP		/FÎLL Q3 AGAIÑ ("LITTLE" PROGRAM WAS STORED /ON THE DATA ORIGINALLY STORED THERE)
1427	7619		LJMP	TOPLAG	/GO TO TAPE DONE ROUTINE APTER LOADING MEMORY
		/RETURN	HERE IF	PLAGS OK UPON	INSTRUCTION COMPLETION
1430	0003	ACCHK.	TAC		/READ TAPE AC
1431	⊌ <b>45</b> @		AZE		/agro?
1432	7733		<b>LAMB</b>	XXX	/NO, ERROR *** ER 2 ***
1433	3573		ADO	MTINSTOL	/GET QN-BN
1434	1040		STÁ		/SAVE
1435	1450		MCGNBN		
1436	2933		ADD	CTEM1	/ADD GN
1437	2003		ADO	K0005	And the same of th
1440	7576		LAMP	COMON6	SET UP AND EXECUTE "MTB BN+QN+1"
1441	1980		LDA		/GET MORD1
1442	0921		WD1		A CONTRACTOR OF THE CONTRACTOR
1443	1560		BCF+50		/CLEAR OUT FUNCTION BITS
1444	0007		7	0.000	
1445	3014		ADD	K0001	4 th 1 th
1446	4821		STC	WD1	/PUT BACK
1447	1020	1:66timb:	LDA+20		GET
1450	0000	WGGNBN;	Ø	A 4 (B 4 )	/QN-BN OF WRG INSTRUCTION
1451	4032		STC	GNBN	/PLACE IN QN=BN
1452	6706	1100000	LJMP	RDCKGP	PEXECUTÉ A "ROG ONBN"
1453	6466	WGEXIT,	LAMP	INCR	/EXIT

ITHIS SECTION OF CODING HANDLES THE INSTRUCTION "CHECK"

1454	2000	CHECK.	ADD	Ø	
1455	5510		STC	CEXIT	
1456	1929		LDA+2B	<b>9</b>	SET UP RETURN JUMP
1457	7610		LAMP	TOFLAG	sadi a cata sa
1460	5575		STC	RJUMP	/FROM INSTRUCTION EXECUTION
1461	1020		LDA+20	u Beille	SET UP FOR RETURN
	7502		PAMB	CCHK	LAR INDICATE TO SECURE
1462 1463	7548		FAMB	MTSET	/FROM FLAG HANDLING
	• •			5	
1464	0325	-	ROR+20	7	MOVE EXT. ADDRESS BIT INTO THE LINK
1465	1000		LDA		/GET THE BLOCK NUMBER
1466	0932		BNBN		AP LAMPHAR LONGEROSTIA S
1467	Ø <b>452</b>		rse_		PEXTENDED ADDRESSING ?
1470	7474		LJMP	, • 4	/YE\$
ī 471	1568		8CF + 50		/NO. MASK TO BITS 3=11
1472	7000		7000	_	<b>_</b>
1473	7476		LJMP	, e 3	THEN CHECK IT
1474	1560		BCL + 20		PEXTENDED ADDRESSING, MASK TO BITS 2-11
1475	6989		6000		
1476	0601		LIP	1	/THEN CHECK IT IF IT HAS BEEN WRITTEN IN
1477	6722		LAMP	WRITEN	
1500	7506		LJMP	CEXITOR	INO. THE BLOCK HAS NOT BEEN WRITTEN IN. EXIT
1501	7567		LJMP	MTXEGT	/EXECUTE "CHECK BN"
		4 50 50 mm \ 4 50 a.s.		m. 400 0 110 at	THERESIATERS DANSER PREPAR
			-	FLAGS OK OPON	INSTRUCTION COMPLETION
1502	0003	CCHK,	TAC		/READ TAPE AC
1503	Ø45Ø		AZE		/2ER0?
1504	7733	CCHKA	LJMP	XXX	/NO. ERROR eee ER 2 eee
1505	7701		LJMP	CHECKI	CHECK TAPE MOTION
1506	9911		CLR		
1507	5572		STC	MTINST	CLEAR MTINST
1510	7510	CEXIT.	LJMP	•	/EXIT

/ROUTINE TO MOVE "LITTLE PROGRAM" TO APPROPRIATE PLAC. MEMORY /THEN EXECUTE IT /ENTER TITH DATA FIELD SET FOR STORAGE /"LITTLE PROGRAM" WILL BE MOVED FROM MINST, THEN EXECUTED

1511	0011	MOVPRO,	CLR		
1512	2035		ADD	CSTART	
1513	7760		LJHP	SUBTS	/SUBTRACT 1 FROM THE AC
1514	1626		85E+20		/SET DATA FIELD BIT
1515	2000		2000		A A W I
1516	4011		STC	11	STORE DESTINATION ADDRESS IN 11
1517	0072		SET+20	12	SET ORIGIN ADDRESS INTO 12
1520	1966		MTKEGTOS	1	
1521	0073			13	SET COUNT (=7) INTO 15
1522	7770		7770		•
1523	1032		LDA+20	13	MOVE THE PROGRAM
1524	1071		STA+2D	4.4	
1525	Ø233		XSK+20	13	
1526	7523		LJMP	. a 3	
1527	1900		LDA		JGET STARTING ADDRESS OF THE PROGRAM
1530	0935		CSTART		
1531	1620		BSE+29		/FORK LJMP INSTRUCTION
1532	6005		LJMP		
1533	5537		STC	MOVJMP	/STORE FOR EXECUTION
1534	0000	HOAP 16	0		CHANGE INSTRUCTION FIELD
1535	8006	MOVLDF,	Ø		CHANGE DATA FIELD
1536	Ø <b>Ø</b> Ø6	_	DÅR		
1537	7537	" GWTAOM	LAMP	0	/JUMP TO "LITTLE PROGRAM"

/SUBROUTINE TO SET UP MAGTAPE INSTRUCTIONS
/SUBROUTINE IS ENTERED WITH "WHERE TO GO IF INTERRUPT OCCURS AS EXPECTED" IN AC
/SUBROUTINE EXITS WITH CONTENTS OF XOR HORD IN AC AND IN XOB

20-JAN-71

```
INSTRUCTION WHERE HE HOPE IT WILL STAY
                               MAGTAP
1540
      4061
              HTSET, STC
      2000
5566
1541
                       ADD
                       STC
                               MTEXIT
                                                /SAVE RETURN ADDRESS
1542
1543
      2026
                       ADÓ
                               XOBMD
                                                /GRT XOB WORD
                                                /MASK TO TAPE INTERRUPT BIT
                       BCL+20
1544
      1968
1545
      7677
                       7677
                       ARE
                                                /BIT SET?
1546 Ø45Ø
                               , ø3
                                                YES, SET LOCATION TO A LNOP
      7552
                       LJMP
1547
                               CCHKA
1550
      3504
                       ADD
                                                / IN GASE INTERRUPT OCCURS
      7554
                       LJMP
                               , 43
1551
                       LDA+28
                                                /ERRONEOUSLY
1552
      1020
                       LNOP
1553
      ØØ16
                               TSTMOR=1
1554
      4941
                       STC
                               WD1
1555
      2021
                       ADD
                       BCL+28
                                                /MASK TO INSTRUCTION BITS
1556
    1560
                       7740
1557
      7740
1560 3673
                               RDCCON
                       ADÖ
      5572
                       STC
                               MTINST
                                                1STORE
Ĭ 561
                               GNBN
      2032
                       ADD
1562
      5573
                       STC
                               MTINST#1
                                                /MOVE ON-BN INDICATOR
1563
                       ADD
                               XOBMD
                                                JGET KOB WORD
1564
      2926
                                                /LOAD XOB
                       AXO
1565
      0001
1566
     7566
              MTEXIT, LUMP
                                                /EXIT
              ITHIS IS THE "LITTLE PROGRAM"
              VEXECUTE THE FOLLOHING MAGTAPE INSTRUCTIONS BY JUMPING HERE
              MTXEGT, CLR
1567
      0011
                       108
1570
      0590
1571
      6881
                       ION
              MTINST. 0
                                                /MAGTAPE INSTRUCTION
ĩ 5 7 2
      0000
                                                /GN=BN
      0000
1573
                                                /SET INSTRUCTION FIELD BACK TO Ø
      Ø 9 Ø Ø
1574
1575 7610
               RJUMP, LJMP
                               TOPLAG
                                                NORMALLY THIS LOCATION WILL CONTAIN
                                                VAN "LIMP TOFLAG" TO PROCESS TAPE DONE FLAG
                                                MONEYER, THIS LOCATION WILL CONTAIN
                                                /"LJMP WGRET" IF A "WRG" INSTRUCTION
                                                /IS BEING EXECUTED
```

```
ITHIS SECTION OF CODING HANDLES SOME OF THE CALCULATE 'S
COMMON TO THE "WRITE" AND "WRCKGP" SUBROUTINES
/IN PARTICULAR, THIS ROUTINE SETS UP AND EXECUTES A "MO. .. INSTRUCTION
VENTER WITH BLOCK NUMBER OF BLOCK TO BE "MOVED TO" IN AC
```

1576	4032	COMONO,	STC	GNBN	/\$90	RE	BN	1 N	GN=8N	FOCALION	4
1577	2000		ADD	Ø							
1600	5607		STC	CSEXIT							
1601	2021		ADD	MDS							
1602	1560		BCF+S0								
1603	Ø <b>ØØ7</b>		7								
1604	2377		ADD	K@002							
1605	4021		STC	WD\$							
1606	7023	# # 5 L 2 F	LJMP	MOVE							
1607	7667	COEXIT,	LJMP	8							

## PROUTINE TO HANDLE "TAPE DONE" FLAG IF NO INTERRUPT OCCURS

1610	1000	TOPLAG.	LDĀ		/GET XOB WORD
1611	Ø <b>Ø26</b>		XOBMD		
1612	1560		BCL +20		/MASK TO PAUSE BIT
1613	7767		7767		State of the state
1019					A ALLO E A
1614	0450		AZE		/PAUSE?
1615	7621		LJMP	6 4 4	/NO. NOT PAUSE
1616	0416		STD		YES, PAUSE, IS TAPE DONE SET?
1617	7733		LJMP	XXX	/NO, NOT SET, ERROR ** ER 1 ***
1620	7625			TLAG	and the state of t
1621	Ø436	TFLAGA	LJMP Std+20	, <b>p</b> , , , ,	HERE IF NO-PAUSE MODE
7057		IFWAGE	AID A Print	21 AC	Nighter & HALLINGAM HARB
1622	7625		T AWB	TLAG	
1623	0601		LIF	1	
1624	7145		LJMP	DDISP	
1625	0016	TLAG,	LNOP		WAIT 1 MORE CYCLE TO ALLOW PI TO OCCUR
1626	0500		108		
1627	6002		IOF		/TURN OFF PI
1630	1000		LDA		/GET XOB WORD
1000	gg26		XOBMD		AMP: WAR LAND
1631					ALLEGA DE ALECTANICA DES
1632	1560		BCF*Sb		/MASK TO TAPE INTERRUPT BIT
1633	7677		7697		
1634	0450		AZE		/IS TAPE INTERRUPT BIT SET?
1635	7733		LJMP	XXX	YES, ERROR, NO INTERRUPT OCCURRED *** ER
1636	6942		LJMP	ŤŠŤMOR	/ALL OK, SO FAR, CHECK "TAPE DONE" IN 8-MO

/RANDOM NUMBER GENERATOR . EXIT WITH RANDOM NUMBER IN AC

```
1637 1000
              RANDOM, LDA
1640 0000
                      Ø
1641
     5656
                      STC
                             RANXIT
                              HALFX
1642 3654
                      ADD
                      ADD
                              HALFY
1643
     3655
                      ROL+20
1644 0261
                             HALFY
                      STC
1645 5655
                      ADD
                              HALFY
1646 3655
                             HALFX
                      ADO
1647
     3654
                      ROL+20
1650 0261
                              HALFX
1651 5654
                      STC
1652 3655
                      ADD
                             HALFY
1653 7656
                      LJMP
                              . 43
1654
     0001
              HALFXO
                     0001
              HALFY. 0001
1655 6001
             RANKIT, JMP
                                              /EXIT
1656 5256
              THIS SECTION OF CODING HANDLES SOME OF THE CALCULATIONS
              /COMMON TO "READ", "ROCKOP", "WRITE", "WRCKGP" SUBROUTINES
             IN PARTICULAR, THIS SUBROUTINE SETS UP LOCATIONS "MOVLIF" AND "MOVLOF"
              VENTER WITH FIELD WHERE PROGRAM IS STORED IN AC
                                             /SAVE AC
1657
                             CTTEMP
     5663
              COMON7, STC
                      ADD
                              Ø
1660 2000
     5700
                      STC
                             CPEXIT
                                              /SAVE RETURN
1661
1662 1929
                                              /GET LOF FOR PROGRAM STORAGE
                      F0V+50
1663 0000
              CTTEMP. 0
                      ADA+20
1664
     1120
                                              /SUBTRACT 48
1665
                      7737
     7737
                                              INSTRUCTION FIELD INSTRUCTION
1666 1848
                      STA
1667 1534
                      MOVLIF
                                              /ADD 41
1670 1120
                      ADA+20
                      41
1671 0041
                      SAE+28
                                              /700 FAR?
1672 1460
1673 0700
              RDCCON, 780
                      LJMP
                              , #3
                                             IND
1674
     7677
                                              /YES, FORM LDF2
1675 1020
                      LDA+20
1676 0642
                      LDF
                             2
1677
                             MOVLDE
                                              INSTRUCTION INSTRUCTION
     5535
                      STC
1700 7700
                                              /EXIT
              CTEXIT, LUMP
```

/SUBROUTINE TO HANDLE "I" BIT OF MAG TAPE INSTRUCTION /(CHECKS TAPE MOTION AFTER INSTRUCTION EXECUTION) /RETURNS TO LOC+1 IF ALL OK, OTHERWISE...

1701	1000	CHECK!,			/GET CONTENTS OF P
1702 1703	9888 5 <b>73</b> 2		Ø Stc	CIEXIT	SET UP EXIT LOCATION
1784	2641		ADD	K1400	-
1705 1706	4003 D223		XSK+S0	3 3	/SHORT DELAY
1707	7786		LAMP	e & £	v writeria. was the control of the c
1710	3572		ADD	MTINST	AMPAIR BIR BIR THEN I THE
1711	0325 1020		ROR+20 LDA+20	5	/MOVE "I" BIT INTO LINK /SET UP AC
1713	5000		5000		
1714	0900		108		/10
1715 1716	6151 4006	K4000;	6191 STC	Ø	/LOAD THE TAPE MAINT: REG /CLEAR AC:
1717	0500	Lf 1-204	108	**	
1720	6154		6194		READ-UNITS AND MOTION INTO AC
1721 1722	1560 7767		BCL+20 7767		/mask to motion bit
1723	6452		LZC		\rinkaa;
1724	7736		LAMP	, * 4	IND EXPECT MOTION TO EQUAL 1
1725 1726	0450 7 <b>733</b>		l jap	XXX	/YES, DOES MOTIONES? /NO: ERROR *** ER 6 ***
ī 9 2 7	7732	,	LJMP	CIEXIT	/YES. OK
1730	8478		AZE+20	XXX	/DOES MOTIONe1 /NO ERROR *** ER 6 ***
1731	7733		LJMP	A A A	THU PAMEN WAS TA SI MAN
1732		CIEXIT.	~ •		
1732	7732	CIEXIT,	LJMP	8	YES, EXIT ROUTHE
1732	7732	/COMMON	LJMP ERROR H	ALT SUBROUTINE	
1732 1733	7732		LJMP ERROR HA	8	
1732 1733 1734	7732	/COMMON	ERROR HA	ALT SUBROUTINE	
1732 1733 1734 1735 1736	7752 4004 0508 6002 2800	/COMMON	LJMP ERROR HA STC IOS IOF ADD	ALT SUBROUTINE  XXXAC	YYES, EXIT ROUTHE
1732 1733 1734 1735 1736 1737	7752 4004 0508 6002 2800 5757	/COMMON	LJMP ERROR HA STC IOB IOF ADD STC	ALT SUBROUTINE	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS
1732 1733 1734 1736 1737 1740	7752 4004 0508 6002 2800	/COMMON	LJMP ERROR HA STC 108 10F ADD STC RSH	ALT SUBROUTINE  XXXAC	YYES, EXIT ROUTHE
1732 1733 1736 1736 1736 1737 1741 1742	7752 40500 40500 40500 5751 40500 40000 40	/COMMON	ERROR HASTC TOB TOP ADD STC RSH ROL APO	ALT SUBROUTINE  XXXAC  Ø  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SHITCHES  /RSW 1=1
1733 17334 17336 17336 17367 1741 1742 1743	77 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	/COMMON	ERROR HASTC STC STC STC STC STC STC STC STC STC	ALT SUBROUTINE  XXXAC  Ø  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SHITCHES  /RSW 1=1 /YES DELETE TYPE OUT
1732 1733 1736 1736 1736 1737 1741 1742	7752 40500 40500 40500 5751 40500 40000 40	/COMMON	ERROR HASTC TOB TOP ADD STC RSH ROL APO	ALT SUBROUTINE  XXXAC  Ø  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SHITCHES  /RSW 1=1
3 3 4 9 6 7 Ø 1 2 3 4 9 6 9 6 9 6 9 6 9 6 9 6 9 6 9 6 9 6 9	7 4 5 2 8 7 5 1 1 1 5 6 2 5 7 5 2 4 5 2 8 7 5 1 1 1 5 6 2 7 5 2 4 7 8 7 5 2 4 7 8 7 5 8 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 1	/COMMON	ERROR HASTON POLITICALIF	ALT SUBROUTINE  XXXAC  Ø XXXPC  1 XXR  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SHITCHES  /RSW 1=1 /YES DELETE TYPE OUT
3 49 67 Ø 1234 9 67 9 11111111111111111111111111111111	7 4 5 5 8 8 8 2 8 7 5 1 1 1 6 8 2 8 7 5 1 1 1 6 8 7 5 8 8 8 7 8 7 8 8 8 8 8 8 8 8 8 8 8	/GOMMON	ERROR HARDER STORE	ALT SUBROUTINE  XXXAC  Ø XXXPC  1 XXR  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SWITCHES  /REW 1=1 /YES DELETE TYPE OUT /NO: TYPE OUT THE MESSAGE
3 4 5 6 7 0 1 2 3 4 5 6 7 0 1 2 3 4 5 6 7 0 1 2 3 4 4 4 4 4 4 4 4 4 4 5 5 7 7 7 7 7 7 7 7	7 4 5 2 8 7 5 1 1 1 5 6 2 5 7 5 2 4 5 2 8 7 5 1 1 1 5 6 2 7 5 2 4 7 8 7 5 2 4 7 8 7 5 8 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 5 6 1 1 1 1	/COMMON	ERROR HASTON POLITICALIF	ALT SUBROUTINE  XXXAC  Ø XXXPC  1 XXR  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SHITCHES  /RSW 1=1 /YES DELETE TYPE OUT
2 3 4 5 6 7 0 1 2 3 4 5 6 7 0 1 2 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	7 4 6 2 0 7 6 1 1 6 0 5 7 6 0 1 5 0 0 0 0 0 7 6 1 1 6 0 0 7 6 0 0 5 4 5 0 0 0 6 1 5 0 0 0 6 1 5 0 0 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6 1	/GOMMON	H P R C B F I C D F I D C D F I D C D C D C D C D C D C D C D C D C D	ALT SUBROUTINE  XXXAC  Ø XXXPC  1 XXR  XXXPC	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SWITCHES  /REW 1=1 /YES DELETE TYPE OUT /NO: TYPE OUT THE MESSAGE
2 34967012345670123 777777777777777777777777777777777777	7 4 6 2 0 7 6 1 1 6 0 7 1 4 6 1 4 0 1 6 2 5 6 0 8 7 5 2 4 7 0 7 6 0 8 4 6 2 0 6 1 5 6 0 8 6 1 5 6 0 8 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6	/GOMMON	H P R C B F D C D F D C D C D C D C D C D C D C D	ALT SUBROUTINE  XXXAC  Ø XXXPC  1.  XXR  XXXPC  1.  XXR	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SWITCHES  /READ RELETE TYPE OUT /NO, TYPE OUT THE MESSAGE  /READ RIGHT SWITCHES
2 3 4 5 6 7 0 1 2 3 4 5 6 7 0 1 2 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	7 4 6 2 0 7 6 1 1 6 0 5 7 6 0 1 5 0 0 0 0 0 7 6 1 1 6 0 0 7 6 0 0 5 4 5 0 0 0 6 1 5 0 0 0 6 1 5 0 0 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6 1 6 1	/GOMMON	H P R C B F I C D F I D C D F I D C D C D C D C D C D C D C D C D C D	ALT SUBROUTINE  XXXAC  Ø XXXPC  1.  XXR  XXXPC  1.  XXR	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SWITCHES  /READ RELETE TYPE OUT /NO, TYPE OUT THE MESSAGE  /READ RIGHT SWITCHES
2 349670123456701234 777777777777777777777777777777777777	7 4 6 2 6 7 6 1 1 6 6 2 6 7 6 1 4 6 1 4 6 4 6 1 6 6 1	/GOMMON	HP R C B F I C C C C C C C C C C C C C C C C C C	ALT SUBROUTINE  XXXAC  Ø XXXPC  1.  XXR  XXXPC  1.  XXR	/YES, EXIT ROUTHE  /DISABLE INTERRUPTS  /READ RIGHT SWITCHES  /READ RELETE TYPE OUT /NO, TYPE OUT THE MESSAGE  /READ RIGHT SWITCHES

23148 PAGE 30-1 20-JAN-71 /PDP-12 TAPE DATA EXERCISER MAINDEC-12-0308 PALIB VI41 /COMMON ROUTINE TO SUBTRACT / 1 FROM THE NUMBER IN THE AC SUBT1, STC , 44 1760 5764 1761 0011 CLR COM 1762 0017 LAM+28 1763 1220 1764 9900 LJMP 1765 6000 /A ROUTINE TO SET BIT "7" OF THE /TAPE INSTRUCTION LDA 1766 1000 MPAC. 1767 1572 MTINST 1770 1620 85E+28

MTINST

2007 \*2007

1771 0020 1772 5972

1773 6888

2007 0000 XAC, 0000

0020

STC

LJMP

/STORAGE

)

```
2020
               $2020
               /THIS SECTION OF CODING HANDLES SOME OF THE CALCULATIONS
               ACOMMON TO THE "READ AND CHECK GROUP" AND "WRITE AND CHECK GROUP" INSTRUCTIONS
               /IN PARTICULAR, THIS SECTION CHECKS FOR I
                       1) EXTENDED ADDRESSING MODE
                       2) TAPE OR MEMORY WRAP-AROUND
               /COMPUTES STARTING ADDRESS OF "LITTLE PROGRAM"
               /AND CHECKS FOR TRANSFER INTO NON-EXISTANT MEMORY
               COMON1, LDA
2020
     1999
2021
      0000
                               C1EXIT=2000
2022
      4135
                       STC
2023
      4640
                       LDF
                                                JGET XOB WORD
                       ADA
2024
      1100
                       XOBMD+2000
2025
      2026
                                                /MASK TO EXTENDED ADDRESS BIT
2026
      1560
                       BCF +50
2027
      7757
                       7797
                                                /BIT SETT
2030
      0.450
                       品簽筐
                       LJMP
                                                /YES, ILLEGAL OPERATION
2031
      6133
                                C1ExIT=2
                       LDA
                                                /GET GN-BN
2032
      1000
                       ONDN+2500
2033
      2032
                       BCL +20
                                                /CLEAR TO QUARTER BITS
2034
      1560
2035
      6777
                       777
      0243
                                                13 LEPT
2036
                       ROL
                       STA
                                                /SAVE
2037
      1040
                       CTEM1+2000
2040
      2033
                                                /GET GNOBN
                       LDA
2041
      1000
                       GNBN+2060
2942
      2032
                       BCL +29
                                                /CLEAR TO BLOCK BITS
      1560
2043
                       7770
2044
      7770
                               CTEM2=2000
2045
      4102
                       STC
                                                /SAVE
2046
      2182
                       ADD
                                CTEM2
                                                /NON-ZERO?
2047
      2470
                       A 2 E + 2 0
                       LJMP
                                CCON1
                                                /NO, ZERO
2950
      A961
                                                YES: COMBINE WITH QUARTER BITS
2051
      1102
                       ADA
                       CTEM102000
2052
      2033
2053
      1120
                       ADA+28
                                                /ADD=7
      7770
                       7770
2054
                                                /QN+BN<101
2055
      0471
                       AP0+20
2056
      6133
                       LJMP
                                CIEXIPO2
                                                /NO. EXIT
2057
                       CLA
      8911
                                                 SET UP STARTING ADDRESS OF PROGRAM OF B
2060
      6977
                       LJMP
                                CCONS+2
               CCON1
                       ADA
                                                /GET ON
2061
      1166
      2033
                       CTEM1+2000
20162
                                                /ADD=2
2063
      1120
                       ADA+20
2064
      7775
                       7775
2065
      p451
                       APO
                                                /QN<3
                                                 YES, SET UP STARTING ADDRESS OF PROGRAM OF 1400
      6075
                       LJMP
                                CCONS
2066
                                                 INC. QN=3 OR MORE
                       LDA
2067
      1600
                       XOBAD+580R
                                                /GET XOB WORD
2070
      2826
                       BSE+20
                                                /SET "DO NOT PAUSE" BIT
2071
      1620
2072
      2010
                       10
                                                ISTORE BACK
2677
      1646
                       STA
                       X08MD+8888
21
      2026
```

PALID

V141

2075	1850	CCON2,	LDA+20	
	-	APAULES		
2076	1400		1400	A POR LINE - DA MORELA LA CAMPARA POR PORPARALI
2877	1040		STA	/SET UP STARTING ADDRESS OF PROGRAM
2100	2935		CSTART#2000	
2101	1020		TDV+SB	/GET ON BITS 9-11
2102	0000	CTEM2.	3	
2103	1100		ADA	/ADD QN BITS
2104	2033		C7EM1+2000	
2105	1120		ADA+20	/ADD≈¾
2106	7774		7774	
2107	0451		APO	/4 OR GREATER?
2110	6127		LJMP CCONS	/NO. ALL OK
2111	1900		LDA	GET CONTENTS OF FIELD
2112	2027		FIELDN-8000	
2113	2131		ADD K0001A-2000	ADD 1
2114	4136		STC CTEM4-2000	/STORE
2115	Ø <b>516</b>		RSW	/READ RIGHT SWITCHES
2116	1560		9C[ + 2B	MASK TO EXTENDED MEMORY SHITCHES
2117	7776		7790	
2120	ø242		ROL 2	/2 LEFT
2121	1120		NOX+20 "	/ADD 3
2122	0003	K0093A,	3	<i>∤ Pt ⊎j we</i> w
2123	Ø <b>Ø17</b>	11222	COM	/MAKE MINUS
2124	2136		ADD CTEM4	COMBINE WITH WFIELD41"
2125	0471		APO+28	/DOES NEXT FIELD EXIST?
2126	6133		TAMB CZEXILOS	NO! EXIT
2127	1828	CCON3:	FDY+SQ CTEXIL=S	/INCREMENT EXIT LOCATION
				MANDELL PYET PARTIEN
2130	9891	K6991A.	1	
2131	1140		ADM	
2132	0135		C1EXIT=2000	
2133	0641		LOP 1	
2134	8 6 8 B		LIP	. P. u. ž m
2135	6135	C1EXIT,	LJMP .	/EXIT
2136	6 <b>6 6 6</b>	CTEM4:	0	/TEMP STORAGE OF UPPER MEMORY BANK NUMBE

```
ITHIS SECTION OF CODING MANDLES SOME OF THE CALCULATION
              ACOMMON TO THE TREAD AND CHECK GROUPS AND TWRITE AND CHEC GROUPS INSTRUCTIONS
              /IN PARTICULAR, THIS SECTION SETS UP TO COUNT BLOCKS BY
              /SETTING UP 14 TO COUNT, CTEMS TO BN 3 TO 11, AND EXITS WITH BN3 TO 11 IN AC
              COMONS: LDA
2137 1000
2140
      6999
                      Ø
                      STC
                               CSEXITOROGO
2141
      4161
2142
      0648
                      LOF
2143
      1100
                      ADA
                                               /GET GN BITS
                      CTEM1+2000
2144
      2033
     0017
2145
                      COM
      6757
                      LJMP
                               SUBT1A
                                               /SUBTRACT 1
2146
2147
      1848
                      STA
                                               /STORE IN 14
2150
      2814
                      2014
2151
      1000
                      LDA
                                               /GET GN=BN
2152
      2032
                      QNBN+2688
2153
      1560
                      BCL+20
                                               /MASK TO BN BITS 3 TO 11
2154 7000
                      7000
2155
     1040
                                               /STORE
                      STA
                      CTEM3=2000
2156
      2034
2157
      0641
                      LDF
                      LIP
2160
      4600
2161 6161
              CZEXÍT: LUMP
                                               /EXIT
              /THIS SECTION OF CODING MANDLES SOME OF THE CALCULATIONS
              /COMMON TO THE "READ AND CHECK GROUP" AND "WRITE AND CHECK GROUP" INSTRUCTIONS
              /IN PARTICULAR, THIS SECTION DETERMINES THE DATA FIELD INSTRUCTION
              /TO ACCESS DATA IN MEMORY (FOR EITHER STORAGE OR CHECKING)
              VENTER WITH BLOCK NUMBER IN AC
              YEXIT WITH "LOF" INSTRUCTION IN AC
2162 4207
              COMONY, STC
                               CSTEMA=2000
                                               /SAVE AC
2163
      2000
                       ADD
                      STC
                               CJEXIT-2008
2164
      4206
                                               /SAVE EXIT ADDRESS
2165
      0640
                      LOF
2166
      2207
                       ADD
                               CSTEMA
                                               /GET BLOCK NUMBER
2167
      1560
                      BCL +20
                                               /MASK TO BN 9-11
2170
      7778
                      7770
2171
      1120
                      ADA=20
                                               /ADD =3
2172
      7774
                      7774
2173
      2451
                      APO
                                               /BN<4
2174
      6200
                      LJMP
                                               /YES
                               6 44
2175
      1990
                      LDA
                                               /NO, GET LOF INSTRUCTION
                      MOYLDF + 2000
2176
      3535
2177
     6204
                      LJMP
                               CSEXITOR
                      LDA
2200
      1900
                                               /GET LIF INSTRUCTION
     3534
2201
                      MOVLIF#2000
2202
     1120
                      85+VOV
                                               /ADD 40 TO MAKE LOP
2203
     9849
                      40
2204
      2641
                      LDF
                      LIF
2205
      0690
                               Ø
      6206
              CSEXIT, LUMP
                                               /EXIT
2206
2202 0000
              COTEMA. 0
                                               TEMP STORAGE
```

/EXIT

LJMP

0

2253 6800

```
/TAPE 4
/SUBROUTINE TO PUT A PATTERN IN MEMORY
/SUBROUTINE IS ENTERED WITH ADDRESS FOR STORAGE IN THE AC
/SUBROUTINE EXITS WITH "PATTERN ADDRESS" IN AC AS A "LJMP ZEE"
/DATA FIELD IS SET PREVIOUS TO ENTERING THIS ROUTINE
```

2254	4274	PATERN,	STC	PSAVE=2000	/SAVE STORAGE ADDRESS
2255	g <b>g</b> g6		DAR		
2256	1020		LDA+20		GET NEXT PATTERN ADDRESS
2257	6303	PATPNT:	LJMP	PAT1	
2260	4276		STC	PJMP-2008	STORE IN JUMP LOCATION
2261	1829		LDA+20	•	/INCREMENT PATTERN POINTER
2262	ø <b>9</b> 02		2		
2263	1140		ADM		
2264	ú257		PATPNT	2000	
2265	1460		SAE+20	•	/GONE TOO FAR?
2266	6335		LJMP	ZEROES	
2267	6273			, 64	/N0
2270	1920		PDV+SB		YES, RESET
2271	6303		LJMP	PAT1	simas Um Sant
2272	4257		6 P P	PATPNT-2000	
2273	1020		STC LDÄ+20	1 M CL. 14 L Co. m.	/GET STORAGE ADDRESS
2274		PSAVE	0		/SAVED ADDRESS
2275	9 <b>999</b> 9 <b>95</b> 6	CONVE	DAB		LOWATE WASHINGS
		a ime			A ILAM PIEMM
2276	6276	PJMP,	LJMP	8 - 114 m	JMP THERE
2277	2276		ADD	PJMP	/PICKUP THE JUMP
2300	g 641		LDF	1	
2301	Ø <b>6</b> Ø Ø		LSF	Ø	
2302	6302	PEXIT,	LJMP	8	/£x17

/PDP=12 TAPE DA	TA EXERC	ISER MAÎ	VDEC=12=	0308 PAL10	V141	20-JAN-71	23148	PAGE	36
2303	£006	PATI:	DJR						
2304	6335		LJMP	ZEROES	/ZEROS S'	TORED			
23ø5	ស្øø6		DJR						
2306	6355		LJMP	ONES	ONES ST	ORED			
2307	0006		DJR						
2310	6377		LJMP	ZERONE	/EEROES /	AND ONES STORED			
2311	M 9 9 6		DJR	A11#7PA	ALIES ALI	. 750000 000050			
2312	6422		LAMP	ONERER	JUNES ANI	D ZEROES STORED			
2313	0006 6443		DJR LJMP	SEVZER	/7070 ST	- Pen			
2314	0996		DUR	251254	71010 011	SUED			
2315 2316	6466		LJMP	ZERSEV	/0707 ST	naro			
2317	0006		DIR	4 100 100 100 100 100 100 100 100 100 10	<i>,</i> ,	7 · · · · · · ·			
2320	6911		LJMP	SEVALT	/7070 B	707 ALTERNATING	STORED		
2321	ØØØ6		DJR		•				
2322	6535		LJMP	ZERALT	10707. 70	878 ALPERNATING	STORED		
2323	Ø <b>ØØ6</b>		DJR						
2324	6961		LJMP	FIVTWO	/5252 ST	ORED			
2325	88 <b>86</b>		DAM						
2326	6604		LAMP	TWOFIV	/2525 570	DKED			
2327	0006		DAR	FIVALT	.5050. 2i	325 ALTERNATING	STAPED		
2330 2331	6627 Ø <b>9</b> 06		DJR DJR	LIVALI	126361 6	SES WPIELINALTIAA	SIGUER		
233 <u>2</u>	6653		P N B	THOALT	/964B. 5	132 ALTERNATING	STARFO		
2333	ØØØ6		DJR	INUNE	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	ுகுற் வணிர <i>ி</i> ப்பர்கார் ∳ர்சன்			
2334	6677		LJMP	COUNT	COUNT P	ATTERN STORED			
2504	•••				,				
		/STORE	EROES					*	
2335	4341	ZEROES;	-	. + 4 = 2000	SUBTRAC	7 1			
2336	0011		CLR						
2337	0017		COM						
2340	1220		0 ************************************						
2341 2342	0000 1620		BSE+20		ART DATA	A PIELO BIT			
2343	2000		2000		1 (2 (L.) (1 (L.))	1 4 per 600 per, per 4 1			
2344	4006		STC	6	/SET POI	NTER			
2345	2000		ADD	Ø		TURN ADDRESS			
2346	4302		STC	PEXIT-2000		, , , , , , , , , , , , , , , , , , , ,			
2347	Ø <b>Ø67</b>		SET+20	7	ISET 7 TO	0 =400			
2350	7377		7377						
2351	6765		LUMP	<u> 1</u> 51	/STORE				
2352	Ø227		X2K+50	7	COUNT				
2353	6351		LJMP		/L00P				
2354	6277		LJMP	PJMP+1	/EXIT				

## STORE ONES

2355	4361	ONES.	STC	. +4-2000	/SUBTRACT 1
2356	0011		CLR		
2357	0917		COM		
2360	1220		LAM+20		
2361	0 B B B		Ø		
2362	1650		BSE+2P		SET DATA PIELD BIT
2363	2888		2000		
2364	4866		STC	6	SET POINTER
2365	2000		ADD	Ø	SAVE RETURN ADDRESS
2366	4302		STC	PEX17-2000	_
2367	p <b>967</b>		SET+S&	7	/SET ? TO -400
2370	7377		7377		
2371	4817		COM		ISET AC TO 7777
2372	6765		LJMP	TST	/STORE
2373	Ø <b>227</b>		X2K+50	7	/COUNI
2374	6372		LAMP	. = 2	/L00P
2375	Ø <b>Ø11</b>		CLR		/CLEAR AC
2376	6277		LAMP	PJMP+1	/EXIT
		40 E + 0 E	~ ~ ~ ~ ~ ~ .		S. M

## ISTORE BEROES AND ONES ALTERNATELY

2377	4403	BERONE;	STC	. +4=2000	/SUBTRACT 1
2499	Ø <b>Ø11</b>		CLR		
2401	0017		COM		
2402	1220		LAH+20		
2483	3000		2		
2404	1628		BSE+20		SET DATA FIELD BIT
2465	2600		2000		Age main the may be
2496	4996		STC	6	SET POINTER
	- "				
2407	2000		ADD	Ø	/SAVE RETURN ADDRESS
2410	4302		STC	PEXIT-2000	
2411	ØØ67		SET+20	7	/SET 7 TO =400
2412	7377		7377		
2413	Ø456		LSKP		/SKIP WITH 0000 AC
2414	0917		COM		/COMPLEMENT AC
2415	6765		LJKP	†ST	/STORE
2416	g227		X8K+20	7	/COUNT
2417	6414		LJMP	. 22	/LOOP
2420	0611		CLR	a	ZELEAR AC
	2 7 8 6 4 7 9 9			PJMP+1	
2421	6277		LJMP	L A Library	/EXIT

## STORE ONES AND BEROES ALTERNATELY

2422	4426	ONEZER, STC	. • 4 - 2900	/SUBTRACT 1
2423	0011	CLR		
2424	0017	COM		
2425	1220	LAM+28	•	
2426	0000	Ø		
2427	1620	BSE+20		SET DATA FIELD BIT
2430	2000	2000		, , , , , , , , , , , , , , , , , , , ,
2431	4886	STC	6	SET POINTER
2432	2600	ADD	Ø	SAVE RETURN ADDRESS
2433	4302	STC	PEXIT-2000	
2434	0067	SEŤ+2Ø		/SET 7 TO -400
2435	7377	7377	•	
2436	3917	CÔM		/COMPLEMENT AC
2437	6765	LJMP	TST	/STORE
2440	Ø227	X2K+38		COUNT
2441	6436	LJMP	, <sub>=</sub> 3	/L00P
2442	6277	PAMB 2911	PJMP+1	, # A A .
2475	9677	₽ Au L	. Aur	
		/STORE 7070		
2443	4447	SEVEER, STC	. +4-2000	/SUBTRACT 1
2444	Ø <b>Ø11</b>	CLR		
2445	0917	COM		
2446	1226	LAM+28		
2447	0000	ø		
2450	1620	856*29		SET DATA FIELD BIT
2451	2000	2000		
2452	4006	STC	6	/SET POINTER
2453	2000	ADÓ	Ø	/SAVE RETURN ADDRESS
2454	4302	STC	PEXIT-2200	
2455	0067	SET+20	7	/SET 7 TO =400
2456	7377	7377		•
2457	1020	_DA+20		ISET AC TO 7070
2460	7070	7070		
2461	6765	LJMP	TST	/STORE
2462	Ø227	X2K+S8		COUNT
2463	6461	LJMP	. = 2	/L00P
2464	0011	ĊĹR		/CLEAR AC
2465	6277	LJMP	PJMP+1	/EXIT
2405	- m / /	. be 147 (*) f	· 😝 : (1) 📅	r

1	37	'n	Q	Ē	Ø	7	Ø	7	
---	----	----	---	---	---	---	---	---	--

2466 4472 ZERSEV, STC , *4=2888 2467 0011 CLR 2478 0017 COM 2471 1228 LAM+28	SUBTRACT 1
2474 2000 2000	SET DATA FIELD BIT
2476 2000 ADD 0	/SET POINTER /Save return address
	/SET 7 TO -400
	/SET AC TO 0707
2504 6765 LJMP TST 2505 0227 XSK+20 7 2506 6504 LJMP .=2	/STORE /COUNT /LOOP
	/CLEAR AC /Exit
STORE 7070,0707 ALTERNATING	
2512 ØØ11 CLR 2513 ØØ17 COM 2514 122Ø LAM+2Ø	SUBTRACT 1
2515 0000 0 2516 1620 9\$E+20 2517 2000 2000	/SET DATA FIELD BIT
252Ø 4ØØ6 STC 6	/SET POINTER /Save return address
2523 0967 SET+20 7 2524 7377 7377	/SET 7 TO =400
2525 1020 LDA+20 2526 0707 0707	SET AC TO 0707
2531 0227 XSK+20 7	/COMPLEMENT AC /Store /Count
2533 Ø <b>911</b> CLR	/LOOP /CLEAR AC /Exit

## 20-JAN-71

## STORE 0707,7070 ALTERNATING

2535	4541	ZERALT,	STC	. +4=2000	/SUBTRACT 1
2536	0011		CLR	•	
2537	0017		COM		
2540	1220		LAM428		
2541	Ø Ø Ø Ø		Ø		
2542	1620		BSE+28		SET DATA FIELD BIT
2543	2000		2000		
2544	4006		STC	6	SET POINTER
2545	2000		ADD	Ø	/SAVE RETURN ADDRESS
2546	4302		STC	PEXIT-2000	
2547	0067		SE 1 + 20	7	/SET ? TO =400
2550	7377		7377		
2551	1020		PDY+50		/SET AC TO 7070
2552	7878		7070		
2553	Ø <b>Ø17</b>		COM		/COMPLEMENT AC
2554	6765		LAMP	757	/STORE
2555	Ø <b>227</b>		X2K+58	7	/CQUNT
2556	6553		LJMP	, = 3	/L00P_
2557	0011		CLR		CLEAR AC
2560	6277		LAMP	PJMP+1	/EXIT
		STORE S	5252		
<b>2561</b>	4565	/STORE !	5252 STC	. 44=2880	/SUBTRACT 1
			STC	<u>_</u> *4=2590	/SUBTRACT 1
2561 2562 2563	0011		STC CLR COM	. * 4 = 2897	/SUBTRACT 1
2562			STC CLR	· • 4 = 2 8 9 0	/SUBTRACT 1
2562 2563	0011		STC CLR COM	· • 4 = 2 5 9 7	
2562 2563 2564	0011 0017 1220		STC CLR COM LAM+28 0 BSE+20	. * 4 = 2 # 9 Ø	/SUBTRACT 1 /SET DATA FIELD BIT
2562 2563 2564 2565	00117 00120 1220 1620 1620 200		STC CLR COM LAM+28 8 85E+20 2800	. * 4 = 2 # 9 Ø	SET DATA PIELD BIT
2562 2563 2564 2565 2566 2567 2570	117 8 8 9 1 1 2 8 8 1 1 2 8 8 1 1 2 8 8 1 1 2 8 8 1 1 2 1 1 2 8 1 1 2 1 1 2 1 1 2 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 1 1 1 1 1 1		STC CLR COM LAM+28 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	6	SET DATA FIELD BIT
2562 2563 2564 2565 2567 2577 2571	00117 00120 1020 1030 1000 1000 1000 1000 100		STC CLR COM LAM+28 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	6 Ø	SET DATA PIELD BIT
2563 25664 2566 2566 2567 2577 2577 2577	00117 00120 10220 10220 1000 1000 1000 1		STC CLR COM + 28 9 8 E + 20 28 00 STC ADD STC	6 0 PEXIT-2000	/SET DATA FIELD BIT /SET POINTER /SAVE RETURN ADDRESS
2563 25664 25667 25772 25772 25772 25772 25773	00117 00120 10220 10220 10200		STC CLAM + 20 CCAM + 20 BSE0 BSE0 STC STC STC STC	6 Ø	SET DATA FIELD BIT
255645 55665 255667 25577 2577 2577 2577 2577	00117 00120 10220 10200 10000		STC CLR COM + 28 BSE 90 BSE 90 STC ADD STC + 20 STC + 20 STC + 20 STC + 20 STC + 20 STC + 20	6 0 PEXIT-2000	/SET DATA PIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO -400
255666667 2555556667 255555555777 2557777777777	00117000001170000000000000000000000000		STC CLR CCOM + 20 DSE00 STC STC STC - 20 STC - 20 STC - 20 STC - 20 STC - 20	6 0 PEXIT-2000	/SET DATA FIELD BIT /SET POINTER /SAVE RETURN ADDRESS
23456 6666667 7777777777777777777777777777	001100000 117000000 12000000 12000000 171000000 1710000000 1710000000 1710000000 17100000000		STC CLR CCOM + 20 BSE40 BSEC STC STC STC STT 7 2 SET 7 7 2 SET 7 7 2 SET 7 2 S	6 Ø PEXIT=2000 7	/SET DATA PIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO -400 /SET AC TO 5252
234567 55666667 55555555577777777777777777	00110000000117000000000000000000000000		STC LØ B Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø Ø	6 Ø PEXIT=2000 7	/SET DATA PIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO -400 /SET AC TO 5252 /STORE
234567 5566667 555555555577777777777777777	0011812820000077925 1788000000077925 17880000000779925 178800000000779925 178800000000000000000000000000000000000		STLOM + + 20 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	6 Ø PEXIT=2000 7 TST	/SET DATA PIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO -400 /SET AC TO 5252 /STORE /COUNT
234567 55555555577777777777777777777777777	00110000000011700000000000000000000000		STCC LØ B B B B B B B B B B B B B B B B B B	6 Ø PEXIT=2000 7	/SET DATA PIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO -400 /SET AC TO 5252 /STORE /COUNT /LOOP
234567 5566667 555555555577777777777777777	0011812820000077925 1788000000077925 17880000000779925 178800000000779925 178800000000000000000000000000000000000		STLOM + + 20 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	6 Ø PEXIT=2000 7 TST	/SET DATA PIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO -400 /SET AC TO 5252 /STORE /COUNT

# /STORE 2525

2604 2605 2606 <b>2607</b> <b>2610</b>	4610 0011 0017 1220 0000	TWOF!Y,	STC CLR COM LAM+20	. 44-2908	/SUBTRACT 1
2611 2612 2613	1620 2000 4006		8SE+20 2000 STC	6	/SET DATA FIELD BIT
2614 2615 2616	2000 4302 0067		ADO STC SET-20	0 PEXIT-2000 7	/SAVE RETURN ADDRESS /SET 7 TO =400
2617 2620 2621	7377 1920 2525 6765		7377 LDA+28 2525	<b>\$</b>	/SET AC TO 2525
2622 2623 2624 2625	0705 0227 6 <u>6</u> 22 0011		CPB FAMB Xak+Sb Famb	TST 7 , = 2	/STORE /COUNT /LOOP /CLEAR AC
2626	6277	/STORE S	LJHP	PJMP+1 B ALTERNATING	ZEXIT
		saidine .		s u@ i ≥ ⊌ ī € @	
2627 2630 2631 2632	4633 0811 0817 1228	FIVALT	STC CLR COM LAK+29	. +4-2888	/SUBTRACT 1
2638 2631 2632 2633 2634 2635	0911 0017 1220 000 1620 200	-	STC CLAM + 26 CLAM + 26 CLAM + 28 CLAM + 28 CL	, +4=2559	SET DATA FIELD BIT
2630 2631 2632 2633 2634	0911 0017 1220 0000 1620	-	STC RM 88 89 89 88 88 88 88 88 88 88 88 88 88	,	
265334567 266334567 266334567 26633444 26644234	00117000000000117000000000000000000000	-	STC RM # 2 8 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	. +4-2888 6 8 PEXIT-2000	/SET DATA FIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO 5460 /SET AC TO 2525
265334 265334 2663334 266336 26633 26633 26633 26644 26643	00117000000001170000000000000000000000	-	STC RM + + 2 P P P P P P P P P P P P P P P P P	. +4-2888 6 8 PEXIT-2000	/SET DATA FIELD BIT /SET POINTER /SAVE RETURN ADDRESS /SET 7 TO 6488

## STORE 2645, 5132 ALTERNATING

2653	4657	THOALT.	STC	. *4 = 2000	/SUBTRACT 1
2654	2011		CLR	•	
2655	Ø <b>Ø17</b>		COM		
2656	1220		LAM+28		
2657	6000		Ø		
2660	1620		BSE+20		SET DATA FILED BIT
2661	2000		2000		
2662	4006		STC	6	SET POINTER
2663	2000		ADD	Ø	/SAVE RETURN ADDRESS
2664	4302		STC	PEX17-2000	
2665	0067		SET+20	7	/SET 7 TO =400
2666	7377	* *	7377		
2667	1020		LDA+20		/SET AC TO 5132
2670	5132		5132		
2671	0917		COM		/COMPLEMENT AC
2672	6765		LJMP	TST	STORE
2673	Ø <b>227</b>		X\$K+28	7	∕COUNŢ
2674	6671		LJMP	, = 3	/L00P
2675	0011		CLR		CLEAR AC
2676	6277		LJMP	PAMP+2	/EXIT
		/STORE	COUNT PA	TTERN	
2697	4703	COUNT.	STC	. 44=2000	/SUBTRACT 1
2700	Ø <b>Ø</b> 11	•	CLR	•	-
2701	0017		COM		
2702	1220		LAM+28		
2703	9999		Ø		
2784	1620		88E+58		SET DATA FIELD BIT
2705	2909		2000		
2706	4886		STC	6	SET POINTER
2707	2000		AQD	Ø	/SAVE RETURN ADDRESS
2710	4302		STC	PEXIT=2900	
2711	0967		SEŤ+20	7	/SET 7 TO -400
2712	7377		7377		
2713	1126		ADA+28		/INCREMENT AC
2714	0901		1		
2715	6765		LJMP	TST	/STORE
2716	0227		XSK+20	7	COUNT
2717	6713		PAMB	, = 4	/LOOP
2720	0011		CLR_		CLEAR AC
2721	6277		LJMP	PJMPel	/EXIT

/SUBROUTINE TO CHECK TO SEE IF BLOCK "N" HAS BEEN WRI? WINTO IN IS IN AC, TAPE DRIVE NUMBER IS IN LOCATION "UNIT! /ROUTINE EXITS TO LJMP+1 IF UNWRITTEN, LJMP+2 IF WRITTEN

```
2722 4756
              WRITEN. STC
                              WSAVE-2000
                                               /SAVE AC
2723
      2000
                                               /GET CONTENTS OF 0
                      ADD
                                               JAND SAVE
2724
      4755
                      STC
                              WNEXIT-2000
2725
      0640
                      LDF
     2956
                      ADÖ
                              WSAVE
                                               /GET BLOCK NUMBER
2726
                      ADA+29
                                               /SUBTRACT 770
2727
      1120
                      7007
2730 7007
2731
      4756
                      STC
                              MSAVE-2806
                                               /SAVE
2732 1969
                      LDA
                                               /GET UNIT NUMBER
2733 2025
                      UNIT+2000
      0241
                      ROL
                                               /ROTATE 1 LEFT
2734
2735
                      ADD
                              WSAVE
                                               /ADD IN "TRIMMED" BLOCK NUMBER
      2756
2736
                      ADA+20
      1120
                                               /ADD IN TABLE ENTRY ADDRESS
2937
      3200
                      ADD
                              BLKTBL
                      STC
2749 4741
                              GET-2000
                                               /STORE AWAY
2741 2741
              GET,
                                               /GET CONTENTS OF BLOCK STATUS WORD
                      ADD
2742 4756
                      STC
                              HSAVE-2008
2743
      2756
                      ADD
                              HSAVE
                      ARE+20
2744
      0470
                                               /NON-BERO?
2745 6753
                      LUMP
                              WNEXIT-2
                                               /NO. ZERO, EXIT
2746 1828
                      LDA+20
                                              YES. INCREMENT EXIT POINT
2747 0001
                      ADD
2750
     2755
                              WNEXIT
                                               /THEN
2751 4755
                      STC
                              WNEXIT=2000
2752 2756
                      ADD
                              WSAVE
                                               /GET STATUS WORD
2753
     4641
                      LDF
2754
      0690
                              Ø
2755 6755
              WNEXIT, LUMP
                                               /EXIT
2756 8000
              WSAVE:
                      Ø
              /SUBROUTINE TO SUBTRACT 1
              SUBTIA, STC
2757 4763
                              SUBT18=2000
2760
      0011
                      CLR
2761 8917
                      COM
2762 1220
                      LAM+20
     0000
              SUBTIB,
2763
                      Ø
2764 6000
                      LJMP
```

## PROUTINE TO CHECK ACROSS LINK MEMORY PAGE BOUNDRY

2765	1966	757,	STA = 20	6	
2766	5015		STC	SAV=2000	/SAVE A.C.
2767	0011		CLR		
2770	2006		ADD	6	
2771	1568	TST1,	BCF + 5 B	-	
2772	6000	1 4 . 4 . 5	6999		
2773	2006		DJR		
2774	1460		SAE+20		/TEST FOR 17779
2775	1777		1777		
2776	7014		LJMP	SAV=1	/NO. EXIT
2777	4001		STC	1	the same t
3000	0500		IOB	100	YES, CHANGE LDF ROUTINE
3001	6214		RDF		
3002	0301		ROR	1	
3003	1129		ADA+20	efe	
3004	9641		641		
3005	£472		ZE+20		TEST LINK
3006	7012		LJMP	. • 4	/READING RESTORE
3007	0640		LDP	Ø	/DATCHK LOCATION
3010	1040		STA	v	LAWIAIL PASKITAI
3011	2667		DATCHK	2000	
3012	5013		STC	. +1=2000	
		SAVA.	9	1.000000	CHANGE DATA FIELD
3013 3014	9996 1 <b>92</b> 9	JATA:	LDA+20		RESTORE A.C.
3015	2000	SAV.	Ø		LUEALAND WEAT
3016	2996	GW 11	DAR		
			F\$E+58		READING OR WRITING
3017	8472			Ø	WRITING, EXIT TO THIS FIELD
3020	6000		LJMP LIF		/READING, EXIT TO FIELD Ø
3g21	9699 4474			Ø	LUENTHAL ENTI IN LICER D
3022	6676		LJMP	DATING	

/BLOCK PATTERN TABLE

3200 0000 BLKTBL, 0

3400 \*BLKTBL +200

/DATA BUFFER = 400 LOCATIONS

## /LINC INSTRUCTION DEFINITIONS

0.000	155-6666
2000	VDD#S600
1106	ADAB1100
1140	ADM#1140
1200	LAMB1300
1240	MULEIZAD
-	
1999	LDAS1000
1300	LDHe1300
4000	STC04900
1040	STAD1048
1340	STH01348
0249	ROLEGŽAD
0300	RORESSES
0340	SCREGSAG
9 <b>999</b>	LHLTEDOOD
8916	LNOPEDG16
0011	CLR=0011
9848	SETHORAG
6999	LIMPEGGO
2006	DJR=0006
9904	ESF 80004
8824	SFARØØ24
training 2	was early was a few as

GACED005 0005 1540 BCL=1548 1600 BSE = 1600 1640 BC0=1640 COMESS17 6617 SAES1460 1440 1400 SH0=1400 6448 SNS#0440 £456 LSKPED456 0450 AZENDADO 0451 AP048451 0452 LEEBØ452 0453 182=0493 0454 FL090454 0455 QL2 80455 SXL=0460 9400 KS750415 0415 SR0=1500 1500 XSKEBZ88 0200 ATRED014 0014 9915 RTABBB15 0100 SAMED100 0140 DIS-0160 1740 DEC81740 0516 RSW99916 0517 LSW89517 108=0500 0500 0600 LIFESSES 8648 LDF=0640 0702 RDE=0702 RDC=0700 Ø700 RCG=0701 0701 WRI . 0786 0706 0704 WRC=0784 WCG # 07 05 0705 CHK#Ø7Ø7 0707 0703 MT8=0703 0001 AX090001 XOASSB21 Ø 821 0023 TMASDD23 STD##416 0416 0417 TWC=0417 2002 PDP=0002 6141 LINCE6141 0003 TAC=0003

```
3145
              03145
              /ROUTINE TO DISPLAY A MESSAGE
              YON THE VR14 DISPLAY
                                           /SET 7 TO
              DDISP. SET+20 7
3145 8067
                                             /TABLE ENTRY ADDRESS
                      DDTABL=2000-1
3146 1161
                                             /SAMPLE CHANNEL 4
                     SAM
3147 0154
                                             SAVE IN LOC 1
3150 4091
                     STC
                                             /SAMPLE CHANNEL B
                      SAM
3151 0100
                     DSC+20 7
                                             /DSC DISPLAY
3152 1767
                     L DÃ
3153 1000
3154 0007
                                             /LOAD THE A.C.
                      SAE+28
                                             /IS IT THE END?
3155 1460
                     TAG=2000
3156 1177
                      LJMP
                              . =6
                                             INO. REMEXECUTE
3157 7151
                     LIF
3160 0690
                             Ø
                                             /YES. EXIT
3161 7621
                      LJMP
                              TFLAG
              /TABLE OF CURRENT VERSION OF THIS
              /PROGRAM TO BE DISPLAYED
3162 4177
              DOTABL. 4177
                                             10
3163 3941
                      3641
                      9999
                                             /SPACE
3164 6666
                      0000
3165 0000
                                             /3
3166 4122
                      4122
                      2651
3167 2651
                                             /SPACE
3170 0000
                      9999
3171 0000
                      9999
3172 4177
                      4177
                                             10
3173
     3641
                      3641
3174 0000
                      0000
                                             /SPACE
                      0000
3175 0000
3176 5177
                      5177
                                             /END OF THE MESSAGE
3177 2651
              PAG,
                      2651
```

```
3024
              03024
              /PDP=12 LINK MODE ERROR
              /HANDLER
3024 0077
              XXa
                      SET+28 17
                      7773
3025 7773
3026 1960
                       BCF+58
3027
      6000
                       6000
                               TEMP-2000
                      STC
3030 5045
3031 1828
3032 4328
                       LDA+20
                       0320
3033 7121
                      LJMP
                               PRINTR
3034 1020
                       LDA+20
3035 6303
                      0303
3036 7121
                               PRINTR
                       LUMP
3037 3120
                       ADD
                               K240
3040 7121
                       LJMP
                               PRINTR
3041 3045
                       ADD
                               TEMP
3042 6757
                      LJMP
                               SUBTIA
3043 0243
                      ROL
                               3
3044 1060
3045 0000
                      STAORB
              TEMP,
                      0000
3046 1560
                       BCL+20
3047 7779
                      7778
                       ADÃ+20
3050 1120
                       6595
3051
      0260
3052 7121
                      LUMP
                               PRINTR
3053 3045
                               TEMP
3054
      0237
                      X8K458
                               17
3055 7043
                      LJMP
                               SedW31
                                               /LOAD THE A.C.
3956 1020
              CRLF.
                      LDA+20
                      0215
                                               /HITH 0215
      Ø215
3057
                                               PRINT IT
                      LJMP
                               PRINTR
3060 7121
                      LDA420
                                               /LOAD THE A.C.
3061 1020
3062 6212
                      0212
                                               /WITH 8212
                                               /PRINT IT
                      LJMP
                               PRINTR
3063 7121
3064
      3600
                      LIF
                               XXR
3065 7750
                      LJMP
```

## ITEST THE DONE PLAG IN 8 HODE

```
3055 5075
               PPDF.
                         STC
                                  . * 7 = 2 0 0 0
3257
      1820
                        LDA+28
      2100
                         6100
3070
      មទី១០
3071
                         108
3072
      6151
                         6151
3073
      0990
                        LHLT
                                                    / 400 ER 1 000
      1020
3074
                        LDA+28
3075
      3999
                         0000
                        LIF
      3600
                                 Ø
3076
3077
      6000
                        LUMP
                                 Ø
```

#### /A ROUTINE TO BUFFER THE MTB BY 3 BLOCKS

```
3199
     1969
              TSIGN1, STA+20
3101
      9699
              TSIGNA
                       Ø
3102
      0471
                       APO+20
                                                 /TAC = ?
3103
      0017
                       COM
                                                 INO COMPLEMENT IT
                                                 FADD 3
3104
      2122
                       ADD
                               KØØØSA
      9451
3105
                       APO
                                                 /WITHIN 3
3106 7113
                               101708
                                                 /NO. ALL OK
                       64MP
3107 1000
                       LDA
3110
     1101
                       TS 1 GN = 2000
                                                 /XOR TSIGN
3111
3112
                       8C0+29
      1660
                                                 FAND
               ibir.
                                                 /1817
      9999
                       Ø
3113 0941
                               1
                       LDF
                       LIF
3114
      0600
                               9
      9451
3115
                       APO
                                                 ABEAOND THE BPOCK &
3116
      7852
                       LUMP
                               MCCH
                                                 INO. ALL OK, DO THE NEXT BLOCK
3117
                               MEXIT = $
      7104
                                                 /YES, FORGET IT
                       LJMP
3120 0240
               K240.
                       9246
3121 0002
              PRINTR, POP
3122
      6946
                       6946
                       6041
3123
      6041
3124
     5323
                       JMP
                               , 01
3125
      6942
                       6842
                       FINC
3126
      7200
3127
      6141
3130
     6000
                       LUMP
                               Ø
3131 1020
              BELL.
                       LDA+20
3132
      0207
                       0207
3133
      7121
                               PRINTA
                       LUMP
3134 0600
                       LIF
                               INCRAGA
3135 6475
                       LJMP
```

S

/PDP=12	TAPE C	ATA	EXERCISER	MAINDEC=12=D3DB	PAL18	V141	28=JAN=71	23   48	PAGE 49-1

0200   1111111   1111111   1111111   1111111	0 <b>0</b> 0 010		00000 <b>000</b>	11111111	18111111	111111111111111111111111111111111111111	111111111111111111111111111111111111111	11111111	111111111111111111111111111111111111111
		0 11111111					•••		
1						-			
1100   1111111   11111111   11111111   111111									
1208							,,		** -
1400	120	0 1111111	11111111	1111111	11111111	1111111	1211111	1111111	11111111
1600	140	9 11111111	1111111	1111111	11111111	1111111	11111111	11111111	11111111
2100 1111111 1111111 1111111 1111111 111111		0 11111111							
2200 11111111 11111111 11111111 11111111									
2400 1111111 1111111 1111111 1111111 111111	220	0 11111111	11111111	1111111	1111111	1111111	11111111	1111111	11111111
2656 1111111 1111111 1111111 1111111 111111	240	Ø 1111111	11111111	1111111	1111111	1111111	1111111	11111111	11111111
3600 1111111 1111111 1111111 1111111 111111	260	0 11111111	11111111	11111111		1111111	11111111	11111111	1111111
3200 10ନ୍ତ୍ରତ ଅବଶ୍ରତ୍ତ୍ତ ଅବସ୍ତ୍ରତ୍ତ ଅବସ୍ତ୍ରତ୍ତ ଅବସ୍ତ୍ରତ୍ତ୍ର ଅଧିତ୍ରତ୍ତ୍ରତ ଅଧିତ୍ରତ୍ତ୍ରତ ଅବସ୍ତର୍ଶ୍ୱର ଅଧିତ୍ରତ୍ତ୍ରତ ଅଧିତ୍ରତ୍ତ୍ରତ୍ତ ଅଧିତ୍ରତ୍ତ୍ରତ ଅଧିତ୍ରତ୍ତ୍ରତ୍ତ ଅଧିତ୍ରତ୍ତ୍ରତ ଅଧିତ୍ରତ୍ତ୍ୱର ଅଧିତ୍ରତ୍ତ୍ୱର ଅଧିତ୍ରତ୍ତ୍ୱର ଅଧିତ୍ରତ୍ତ୍ୱର ଅଧିତ୍ରତ୍ତ୍ୱର				-					
3400	320	0 10000000	60000000	000 <b>000</b> 000	Ø <b>ØØØ</b> ØØØØ	20000000	ବରଷର ବଳ <b>ବ</b> ଷ	00000000	000000000
	340	Ø	7 <b>2 2 3 5 2 5 5</b>		~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	~ {	ជក្ខាស្តិស្ស ជា		

4699

52000 5100

62.00 63.00

66688 6788 4420

7600

23546

200

/PDP=12	TAPE DA	TA EXERCISER H	=S1=D3ON jap	0308	PAL10	V241	20-JAN-71	23148	PAGE 49-3
	AC	n Ø 3 Ø	DATCHK	0667		LDFR61	0742	PATTAM	0762
	ADA	1200	DATING	6676		LDFRG8	0761	PATJMP	8644
	ADD	2800	DATLUP	0221		LOFRGS	1906	PATPNT	2297
	ADM	1140	DATUM	0202		LDFHGI	1353	PAUSEB	0414
	APO	0491	DDISP	3145		LDFWGZ	1410	POP	0002
	ATR	6814	DDTABL	3162		LOFHRI	1125	PEXIT	2305
	OXA	2001	DIS	0140		LDFHRZ	1157	PJMP	2276
· ·	ARE	6450	DISPCH	0436		LDPWRS	1212	PÄINTR	3121
	BCL	1540	DJR	0006		LDH	1300	PSAVE	2274
	8CO	1649	DSC	1740		LHLT	0000	GJPAT	1426
1	BELL	3131	ESF	0004		LIF	0600	GAC	0005
	BKWRD	0864	EXTØ	0271		LINC	6141	QL3	0955
	BLKTBL	3200	EXT1	0300		LINTER	0040	ONDN	0032
J	9 <b>\$</b> E	1600	EXTŽ	0307		LJMP	6000	RANDOM	1637
	CLEXIT	2 <b>135</b>	EXT3	0316		LNOP	0016	RANXIT	1696
		2161	EXTA	0331		LOOPES	0104	RCO	0701
1	CZEXIT	5506	EXTOCH	0702		LSKP	0456	RCHK	0610
	CSEXIT	2207	EXTEND	0260 0		LSH	8517	RÇKSUB	0 4 <b>6</b> 0
	CSTEMA C4EXIT	2235	EXTUNT	0230		LEC	0452	RÔC	0700
			FIELDN	0027		M4888	0174	RDECON	1673
	CATEMA	2246	PIVALT	2627		MAGTAP	0061	ROCKGP	0706
	COEXIT	1607 1700	FIVTWO	2561		MASTER	0020	ROE	0702
	CZEXIT			9494		MBUMP	1966	ห้อัฐบุธ	0456
	C7TEMP	1663	FLO	0124		MCOH	7988	READ	0504
	CCHK	1902	POBURD				1844 1844	REDDF	0563
*	ÇCHKA	1504	FORWRD	0130		MCH	1861	REONEX	8931
	CCONS	2061	GET	2741		MCHK	1707 7507	REDNXS	0557
	CCONS	2075	HALFX	1684		MCHK1 MCOMP	1075	RESTAR	0204
1	CCONS	2127	HALFY	1655			1105	REXIT	0701
	CEXIT	1518	IBIT	3112		HEXIT	7765	<b>BOCHK</b>	8744
	CHECK	1454	198	0493		HEXPT	1976	RGCONS	0715
1	CHECKI	1701	INCR	Ø466		MOVE	1023 1537	AGCONS	0726
	CHK	0767	INCRA	0 <b>501</b> 0 <b>500</b>		MOATD WOATD WOATU	1939	RĞÇONĞ	0793
	CHKSUB	8464	108				1534	RÖEXIŤ	1655
	CIEXIT	1732	K0001	1014		MOVLIF	1511	RJUMP	1575
	CLEAR	ខ <b>161</b>	K0001A	2130 0003		MOVPRO MOVSUB	0495 1517	ROL	0340
	CLR	2011	K0002 K0003	0377		MPAC	1766	ROR	0300
	COM	ଅ <b>ଡ17</b> 2 <b>020</b>	K0003A	2122		MTB	0703	RSW	0516
	COMON1			0036			0068	RTA	0015
	COMONS	2137	K0198	0037		MIBIST	1366		1448
	COMON3	2162	K0300			MTEXIT		SAE Sam	
	COMON4	2210	K0770	0411 0641		HTINST	1572 1540	SAV	0100 3015
	COMONS	2236	K240 K1400	2150		MTSET MTXEQT	1567	SAVA	3013
	COMON6	1976						3CR	0240
	COMON7	1657	K4000	1716		MUL	1240 0356	SET	ប្សូ <b>ងស្</b> ស្ទុ <b>ះស</b>
	COUNT	2677	K4001	0175 0415		NONEXS NONEXS	0390 04 <b>86</b>	SEVALT	2511
	CRLF	3056	KŞT			NONEXS	0413	SEVZER	5442
	CSTART	0035	LAM	1200				SFA	0024
	CTEM1	0033	PD1CON	0643 - 000		NONEXT	9344	* * * * * * * * * * * * * * * * * * * *	
	CTEM2	2102	LDA	1000		ONES	2355	SHD	1400
	CTEM3	0034	LDF	0640		ONEZER	2422	SNS	0440
	CTEM4	2136	LOFCON	9631		PAT1 PATERN	2303	SRO	1500
	DATADD	<b>⊍646</b>	LDFR01	0561		PAIRKI	2254	SIA	1040

WRINEX 1143

PALLO

V141

200-

BEIGE PAGE GOLD

280JAN071

ERRORS DETECTEDI Ø

LINKS GENERATED! 0

AUN-TIME! IB SECONDS

3K CORE USED

				· Primarile
				"Case
				•
				7
				The state of the s
				Maria and Maria