




V450-A




V530-A




V710-A




B530-A




B695-A




Y590-A




Y610-A




Y670-A




Y780-A







R780-A




FSC-A




FSC-H




FSC-W




SSC-A




### SSC-H






### SSC-W




### V450-A\_Gain







### B695-A\_Gain




### Y590-A\_Gain




### Y610-A\_Gain




### Y670-A\_Gain




### Y780-A\_Gain




### R660-A\_Gain




### R780-A\_Gain




### FSC-A\_Gain




### SSC-A\_Gain




### Violet\_LaserDelay




### Blue\_LaserDelay




### Yellow\_LaserDelay




**Red\_LaserDelay**




**Violet\_AreaScalingFactor**




**Blue\_AreaScalingFactor**




### Yellow\_AreaScalingFactor






### Red\_AreaScalingFactor




### V450-A-% rCV







B695-A-% rCV




Y590-A-% rCV




Y610-A-% rCV




Y670-A-% rCV










Y780-A-% rCV



R660-A-% rCV







# SSC-W-% rCV

