






**B530-A****B585-A****B695-A**


B780-A





R670-A




R780-A







FSC-H




FSC-W




SSC-A




### SSC-H




### SSC-W




### B530-A\_Gain




### B585-A\_Gain




### B695-A\_Gain




### B780-A\_Gain




### R670-A\_Gain




### R780-A\_Gain




### FSC-A\_Gain




## SSC-A\_Gain




## Blue\_LaserDelay




## Red\_LaserDelay




### Blue\_AreaScalingFactor




### Red\_AreaScalingFactor




### B530-A-% rCV




### B585-A-% rCV




### B695-A-% rCV




### B780-A-% rCV




### R670-A-% rCV




### R780-A-% rCV




### FSC-A-% rCV




FSC-H-% rCV



FSC-W-% rCV



SSC-A-% rCV



### SSC-H-% rCV

