




V450-A






V530-A




V710-A




**B530-A****B695-A****Y590-A**


Y610-A




R660-A




R780-A




FSC-A




FSC-H




FSC-W




SSC-A




### SSC-H




### SSC-W




### V450-A\_Gain




### V530-A\_Gain




### V710-A\_Gain




### B530-A\_Gain




### B695-A\_Gain




### Y590-A\_Gain




### Y610-A\_Gain




Y670-A\_Gain




Y780-A\_Gain




R660-A\_Gain




### R780-A\_Gain




### FSC-A\_Gain




### SSC-A\_Gain



### Violet\_LaserDelay




### Blue\_LaserDelay




### Yellow\_LaserDelay




## Red\_LaserDelay




## Violet\_AreaScalingFactor




## Blue\_AreaScalingFactor




## Yellow\_AreaScalingFactor




## Red\_AreaScalingFactor




## V450-A-% rCV




V530-A-% rCV




V710-A-% rCV




B530-A-% rCV




B695-A-% rCV




Y590-A-% rCV




Y610-A-% rCV




Y670-A-% rCV




Y780-A-% rCV




R660-A-% rCV




### R780-A-% rCV




### FSC-A-% rCV




### FSC-H-% rCV




### FSC-W-% rCV



### SSC-A-% rCV



### SSC-H-% rCV



# SSC-W-% rCV

