

# CH552 USB Multi-Protocol Programmer Product Brief


Universal Programmer for AVR, ARM (CMSIS-DAP), and CPLD (MAX II)

Version: 1.0 Modified: 2025-06-13 17:41

#### Introduction

The CH552 USB Multi-Protocol Programmer is a compact and versatile USB programming tool powered by the WCH CH552 microcontroller. Designed for developers, educators, and hobbyists, it supports programming and debugging across three key domains: AVR microcontrollers, ARM Cortex-M processors, and Intel/Altera CPLDs.

With multiple firmware profiles, this device can seamlessly switch between USBasp, CMSIS-DAP, and USB-Blaster compatible JTAG modes. Its hardware voltage selector ensures compatibility with target boards operating at 3.3V or 5V. The built-in USB bootloader simplifies firmware flashing, and compatibility with tools like 'avrdude', 'OpenOCD', and Quartus Programmer makes it an ideal choice for embedded development in diverse environments.



#### **Functional Description**

- USB Full-Speed interface (CDC or HID, depending on firmware)
- Programmable firmware profiles: AVR, CMSIS-DAP, and CPLD
- CH552G / CH552E microcontroller
- Selectable target voltage: 3.3V or 5V
- Bootloader mode for firmware flashing

#### **Electrical Characteristics**

- The target voltage can be toggled between 3.3V and 5V using a physical switch.
- Programming interfaces include JTAG (TCK, TMS, TDI, TDO, nTRST) via a 2x5 1.27mm header, SWD (SWDIO, SWCLK) via a standard or JST connector, and SPI (MISO, MOSI, SCK, CS) via an inline header.
- A dedicated JST 1.0mm connector provides SWDIO, SWCLK, VCC, and GND for quick connections.

#### **Features**

- Multiple firmware modes: AVR, ARM CMSIS-DAP, CPLD JTAG
- Standard USB HID/CDC communication
- Compatible with major programming tools (avrdude, OpenOCD, Quartus)
- Small footprint, easy to integrate into projects
- SDCC-compatible source code
- Support for Linux, and macOS

#### **Applications**

- AVR programming via USBasp and UPDI
- ARM Cortex-M debugging via CMSIS-DAP (OpenOCD, PyOCD)
- JTAG programming for Intel/Altera MAX II CPLDs
- Universal compact programmer for educational kits
- Embedded development and prototyping

Product Brief 1 — 4



# **Settings**

#### **Interface Overview**

| Interface  | Signals / Pins            | Typical Use  |
|------------|---------------------------|--|
| JTAG       | TCK, TMS, TDI, TDO, nTRST | Full chip programming, in-circuit test, debug      |
| SPI        | MOSI, MISO, SCK, CS       | Flash memory programming, peripheral data exchange |
| SWD        | SWCLK, SWDIO              | Cortex-M programming and debugging                 |
| JST Header | SWCLK, SWDIO, VCC, GND    | Quick-connect to target board for SWD and power    |

### **Supported Pins**

| Symbol | I/O   | Description                         |  |  |
|--------|-------|-------------------------------------|--|--|
| VCC    | Input | Power supply (3.3V or 5V)           |  |  |
| GND    | -     | Ground                              |  |  |
| BOOT   | Input | Enter bootloader mode               |  |  |
| P3.0   | I/O   | General purpose (protocol-specific) |  |  |
| P3.1   | I/O   | General purpose (protocol-specific) |  |  |
| P3.2   | Input | BOOT button                         |  |  |

# **Firmware Modes: AVR Programmer**

| Feature         | Description                    |  |
|-----------------|--------------------------------|--|
| Protocols       | USBasp, Serial UPDI            |  |
| Targets         | ATmega, ATtiny, other AVR MCUs |  |
| Tools Supported | avrdude, PlatformIO            |  |
| USB Mode        | HID (USBasp), CDC (UPDI)       |  |
| Voltage Output  | 3.3V / 5V selectable           |  |

## Firmware Modes: CMSIS-DAP Debugger

| Feature                      | Description                             |  |
|------------------------------|---|--|
| Protocols                    | SWD, JTAG (CMSIS-DAP v1)                |  |
| Targets                      | ARM Cortex-M (STM32, nRF52, SAMD, etc.) |  |
| Tools Supported              | OpenOCD, PyOCD, Keil μVision, SEGGER    |  |
| USB Mode                     | USB Mode HID + optional CDC UART        |  |
| Drivers Native (Linux/macOS) |   |  |

#### **Firmware Modes: CPLD Programmer**

| Feature  | Description                        |  |
|--|------------------------------------|--|
| Protocol   | JTAG via USB-Blaster emulation     |  |
| Targets  | Intel/Altera MAX II (e.g., EPM240) |  |
| Tools Supported  | Tools Supported Quartus Programmer |  |
| USB VID/PID Safe: 0x16C0:0x05DC, Compatible: 0x09FB:0x6001 |                                    |  |
| Voltage Output   | 3.3V / 5V selectable               |  |

# **Pin & Connector Layout**


| Color  | Signal Type   | Description              |
|--------|---------------|--------------------------|
| Red    | Power         | Supply voltage (VCC)     |
| Green  | Ground        | Common ground (GND)      |
| Blue   | SWD           | SWDIO and SWCLK signals  |
| Teal   | SPI           | SPI interface signals    |
| Orange | JTAG          | JTAG interface signals   |
| Gray   | Not Connected | Unused or reserved lines |
| Color  | Signal Type   | Description              |

Product Brief 2 — 4



# **Block Diagram**


# Multi-Protocol Programmer



Product Brief 3 — 4



## **Dimensions**



# Usage

- Arduino AVR
- Raspberry Pi RP2040
- STM32
- NRF
- PY32
- MAX II

#### **Downloads**

· Schematic PDF

# **Purchase**

• Buy from UNIT Electronics

Product Brief 4 — 4