# **CSC 411**

Computer Organization (Spring 2024)
Lecture 11: RISC-V load/store


Prof. Marco Alvarez, University of Rhode Island

## **Disclaimer**

Some figures and slides are adapted from:

Computer Organization and Design (Patterson and Hennessy)

The Hardware/Software Interface



#### So far ...

Addition / subtraction

add rd, rs1, rs2
sub rd, rs1, rs2

Add immediate

addi rd, rs1, imm

#### **Data transfer instructions**


- RV32I is a load-store architecture
  - only load and store instructions access memory
  - arithmetic instructions only operate on CPU registers
- Memory is byte-addressed
  - each address identifies an 8-bit byte
  - RISC-V is Little Endian
  - RISC-V and x86 do not require words to be aligned in memory (alignment strongly encouraged)
    - alignment restriction forces words to start at addresses that are multiples of the word size

## Loading and storing data

Values can be loaded from memory



Values can be stored in memory



### **Loading words**

The lw instruction loads a 32-bit value from memory into rd

destination register gets memory word from address (base + offset)

## **Storing words**

► The sw instruction stores a 32-bit value from rs2 to memory

memory at address (base + offset) gets the value in source register

#### **Practice**

- C code
  - assume all are int variables

$$g = h + A[8];$$

- ► RISC-V code
  - index 8 requires offset of 32 (4 bytes)
  - assume g in x1, h in x2, and base address of A in x3

#### **Practice**

- C code
  - assume all are int variables

$$A[7] = h + A[5];$$

- ► RISC-V code
  - assume h in x1 and base address of A in x2
  - can use an additional register x3

## **Loading and storing bytes**

- Instructions for transferring individual bytes from/to memory
- Use same format as lw and sw
  - load byte: lb
    - loads a 8-bit value from memory, then sign-extends to 32-bits before storing in rd
  - load unsigned byte: <a href="li>lbu">lbu</a>
    - loads a 8-bit value from memory but then zero-extends to 32-bits before storing in rd
  - store byte: sb
    - stores 8-bit value from the low bits of register rs2 to memory

#### **Practice**

- What are the resulting values in x3 and x4 respectively?
  - express the values using 32-bits (in hexadecimal notation)

```
addi x1, x0, 0x80AB

sw x1, 0(x2)

lb x3, 1(x2)

lbu x4, 0(x2)
```

#### **Practice**

- Translate the following C code into RISC-V
  - can use an additional register x3

```
// assume x, y are integer pointers
// stored in x1 and x2 respectively
*x = *y;
```

# **ASCII** representation

ASCII value	Char- acter										
32	space	48	0	64	@	80	Р	96	`	112	р
33	!	49	1	65	Α	81	Q	97	а	113	q
34	"	50	2	66	В	82	R	98	b	114	r
35	#	51	3	67	С	83	S	99	С	115	S
36	\$	52	4	68	D	84	Т	100	d	116	t
37	%	53	5	69	Е	85	U	101	е	117	u
38	&	54	6	70	F	86	V	102	f	118	V
39	'	55	7	71	G	87	W	103	g	119	w
40	(	56	8	72	Н	88	Х	104	h	120	х
41	)	57	9	73	- 1	89	Υ	105	i	121	у
42	*	58	:	74	J	90	Z	106	j	122	z
43	+	59	;	75	K	91	]	107	k	123	{
44	,	60	<	76	L	92	\	108	I	124	
45	-	61	=	77	М	93	]	109	m	125	}
46		62	>	78	N	94	٨	110	n	126	~
47	/	63	?	79	0	95	_	111	0	127	DEL

## **Registers vs memory**

- Operating on memory data requires loads and stores
  - consider memory latency
  - registers are a fast read/write memory right on the CPU that can hold values
  - memory is byte-addressable but \( \frac{1}{W} \) and \( \frac{sW}{SW} \) can transfer entire words
- Compiler must use registers for variables as much as possible
  - only spill to memory for less frequently used variables
  - register optimization is important!