Copies are Uncontrolled



Revision: 1.0.0 Date: 01/21/2020

# **Command Handbook**

For the HuskySat-1 Mission



#### **Table of Contents**

Table of Contents	2
Commands	3
CMD IGNORE FSW	3
CMD_PPT_SINGLE_FIRE	3
CMD_PPT_TIME_UPD	3
CMD ROLLCALL	4
GCMD_AUTOSEQ_ADD_1	4
GCMD_AUTOSEQ_ADD_2	4
GCMD_AUTOSEQ_ENABLE	4
GCMD_AUTOSEQ_GET_INDICES	4
GCMD_AUTOSEQ_GET_MET	5
GCMD_AUTOSEQ_REMOVE_CAN_ID	5
GCMD_AUTOSEQ_RM_AT_INDEX	5
GCMD_BATT_SET_HEATER_CHECK	5
GCMD_BDOT_CONTROL	5
GCMD_BDOT_MAG_CONTROL	6
GCMD_BDOT_MAX_TUMBLE	6
GCMD_BDOT_POLE_OVERRIDE	6
GCMD_BDOT_SPAM	7
GCMD_COM1_MODE_CAMERA	7
GCMD_COM1_MODE_HEALTH	8
GCMD_COM1_MODE_REALTIME	8
GCMD_COM1_MODE_SAFE	8
GCMD_COM1_TRANSPONDER_OFF	8
GCMD_COM1_TRANSPONDER_ON	8
GCMD_COM2_RUN	8
GCMD_DIST_AUTOSHUTOFF	8
GCMD_DIST_RESET_MISSION	10
GCMD_DIST_SELF_RESTART	10
GCMD_DIST_SET_PD_OVC_BDOT	10
GCMD_DIST_SET_PD_OVC_COM2	10
GCMD_DIST_SET_PD_OVC_EPS	10
GCMD_DIST_SET_PD_OVC_ESTIM	10
GCMD_DIST_SET_PD_OVC_PPT	10
GCMD_DIST_SET_PD_OVC_RAHS	10
GCMD_DIST_SET_PD_STATE	11
GCMD_EPS_BATT_FULLDEF	12
GCMD_GEN_SET_PT_STATE	12
GCMD_MTQ_PMS	13
GCMD_MTQ_POP	13
GCMD_MTQ_PWM_TIME	14
GCMD_PPT_HALT	14
GCMD_PPT_MULTIPLE_FIRE	14
GCMD_RESET_I2C	15
GCMD_RESET_MINMAX	15
GRND_EPOCH	15
TLE_1	15
TLE_2	15
TLE_3	16
TLE_4	16
TLE_5	16



# Commands

# CMD\_IGNORE\_FSW

Item Name	Description	Description		Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_IGNORE_FSW_IGNORE	ignore the bdot commands from fsw		0	1	0	224	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							

# CMD\_PPT\_SINGLE\_FIRE

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_PPT_SINGLE_FIRE_WITH_PULSE	Do we fire or just	charge?	0	1	0	224	1	UINT	
	State	Value							
	FALSE 0	0							
	TRUE	1							
CMD_PPT_SINGLE_FIRE_OVERRIDE	Do we fire or just	charge?	0	1	0	225	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
CMD_PPT_SINGLE_FIRE_OVERRIDE_SMT	Whether the Sch checked	midt Trigger is	0	1	0	226	1	UINT	
	State	Value							
	FALSE 0								
TRUE 1		1							

# CMD\_PPT\_TIME\_UPD

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_PPT_TIME_UPD_CHARGE	PPT Main Capacitor Charge Time	0	65535	0	224	16	UINT	2^-15s
CMD_PPT_TIME_UPD_IGN_DELAY	PPT Main Igniter Delay	0	65535	0	240	16	UINT	2^-15s
CMD_PPT_TIME_UPD_IGN_CHARGE	PPT Igniter Charge Time	0	65535	0	256	16	UINT	2^-15s



CMD\_PPT\_TIME\_UPD\_COOLDOWN PPT Cooldown Time 65535 0 272 16 UINT 2^-15s

## CMD\_ROLLCALL

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_ROLLCALL_MSP		0	255	0	224	8	UINT	
CMD_ROLLCALL_MET	Mission Elapsed Time	0	1099511627775	0	232	40	UINT	2^-8 s
CMD_ROLLCALL_TYPE	Rollcall Type (Unused for now)	0	255	0	272	8	UINT	

## GCMD\_AUTOSEQ\_ADD\_1

propertires of autosequencer entry

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_ADD_1_CAN_ID	the CAN Id of the message to add	0	536870911	0	224	29	UINT	
GCMD_AUTOSEQ_ADD_1_MET	the MET of the entry to add	0	4294967295	0	253	32	UINT	2^- 15s
GCMD_AUTOSEQ_ADD_1_SENDFLG	whether the CAN packet should send	0	1	0	285	1	UINT	

## GCMD\_AUTOSEQ\_ADD\_2

data of CAN packet to be added to the autosequencer

Item Name	Description	Min	Мах	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_ADD_2_DATA	the data of the CAN packet to be added to the autosequencer	0	18446744073709600768	0	224	64	UINT	

## GCMD\_AUTOSEQ\_ENABLE

Item Name	Descript	ion	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_ENABLE_ENABLE			0	255	0	224	8	UINT	
00.1510.00141.0011.001_	State Value  FALSE 0  TRUE 1  NULL 2			· ·		· ·	0211		
	State Value								
	TRUE	1							
	NULL	2							

## GCMD\_AUTOSEQ\_GET\_INDICES

get indices of the specified packet in the autosequencer

**Item Name** Description Min Max **Default Bit Offset Bit Size Data Type** Units



GCMD\_AUTOSEQ\_GET\_INDICES\_ID the CAN Id 0 536870911 0 224 29 UINT

## GCMD\_AUTOSEQ\_GET\_MET

get MET of the item at the specified index of the autosequencer

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_GET_MET_INDEX	the index	0	255	0	224	8	UINT	

## GCMD\_AUTOSEQ\_REMOVE\_CAN\_ID

remove all occurrence of the specified CAN Id in the autosequencer

Item Name	Description	Min	Max	Default	Bit Offset		Data Type	Units
GCMD_AUTOSEQ_REMOVE_CAN_ID_ID	remove all occurrences of the specified CAN Id in the autosequencer	0	536870911	0	224	29	UINT	

#### GCMD\_AUTOSEQ\_RM\_AT\_INDEX

remove the autosequencer entry at the specified index

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_RM_AT_INDEX_INDEX	the index	0	255	0	224	8	UINT	

## GCMD\_BATT\_SET\_HEATER\_CHECK

enables/disables battery heater automation

Item Name	<b>Description</b> the state of heater automation		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BATT_SET_HEATER_CHECK_STATE	the state of heater automation		0	3	0	224	2	UINT	
	•								
	FALSE	0							
	TRUE	1							
	NULL	2							

## GCMD\_BDOT\_CONTROL

Description			Max	Default	Bit Offset	Bit Size	Data Type	Units
Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE		0	3	0	224	2	UINT	
State	Value							
NORMAL_MODE	0							
	Chooses mode that bdot is in: 0 = NORM = SLEEP_MODE  State	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE  State  Value	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 0 = SLEEP_MODE  State  Value	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 0 3 = SLEEP_MODE  State  Value	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 0 3 0 = SLEEP_MODE  State  Value	Description     Min     Max     Default     Offset       Chooses mode that bdot is in: 0 = NORMAL_MODE, 1 = SLEEP_MODE     0     3     0     224       State     Value	Description     Min     Max     Default     Offset     Size       Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE     0     3     0     224     2       State     Value	Description     Min     Max     Default     Offset     Size     Type       Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE     0     3     0     224     2     UINT       State     Value



SLEEP\_MODE 1
SPAM\_MAG\_SELF\_TEST 2
SPAM 3

Date: 01/21/2020

# GCMD\_BDOT\_MAG\_CONTROL

Item Name	Description		Min	Max	Default	Bit Offset		Data Type	Units
GCMD_BDOT_MAG_CONTROL_MODE	Choose the best fit magnetometer from ground. 0 = Auto, 1 = BDOT, 2 = SP1, 3 = SP2		0	3	0	224	2	UINT	
	State	Value							
	BDOT_MODE	0							
	SP1_MODE	1							
	SP2_MODE	2							

# GCMD\_BDOT\_MAX\_TUMBLE

Item Name	Description	Min	Max	Default	Offset	Size	Data Type	Units
GCMD_BDOT_MAX_TUMBLE_TIME	Chooses the maximum time bdot is tumbling continuously. If bdot tumbles for longer than this time, will automatically go into sleep mode. Units: Minutes	0	65535	0	224	16	UINT	minutes

# GCMD\_BDOT\_POLE\_OVERRIDE

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BDOT_POLE_OVERRIDE_GAIN_X	Percentage dipole gain on x axis		0	255	0	224	8	UINT	pct
GCMD_BDOT_POLE_OVERRIDE_GAIN_Y	Percentage dipole	Percentage dipole gain on y axis		255	0	232	8	UINT	pct
GCMD_BDOT_POLE_OVERRIDE_GAIN_Z	Percentage dipole	Percentage dipole gain on z axis		255	0	240	8	UINT	pct
GCMD_BDOT_POLE_OVERRIDE_X	Flips the dipole signs on bdot x axis before sending command to mtq			2	0	248	2	UINT	
	State	State Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD BDOT POLE OVERRIDE Y	Flips the dipole sign	ns on bdot y axis before	0	2	0	250	2	UINT	

sending command to mtq



State	Value
FALSE	0
TRUE	1
NULL	2

 ${\sf GCMD\_BDOT\_POLE\_OVERRIDE\_Z}$ 

Flips the dipole signs on bdot  $\boldsymbol{z}$  axis before sending command to  $\boldsymbol{mtq}$ 

State	Value
FALSE	0
TRUE	1
NULL	2

0 2 0 252 2 UINT

# GCMD\_BDOT\_SPAM

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BDOT_SPAM_TIME_ON	Chooses the amount of minutes in between SPAM	0	65535	0	224	16	UINT	minutes
GCMD_BDOT_SPAM_TIME_OFF	Chooses the amount of time SPAM should be on for	0	65535	0	240	16	UINT	minutes
GCMD_BDOT_SPAM_MAGNITUDE_X	What magnitude the magnetorquer should spam on x axis	-100	100	0	256	8	INT	
GCMD_BDOT_SPAM_MAGNITUDE_Y	What magnitude the magnetorquer should spam on y axis	-100	100	0	264	8	INT	
GCMD_BDOT_SPAM_MAGNITUDE_Z	What magnitude the magnetorquer should spam on z axis	-100	100	0	272	8	INT	
GCMD_BDOT_SPAM_CONTROL	Turn spam on or off	0	2	0	280	2	UINT	

State	Value
FALSE	0
TRUE	1
NULL	2

## GCMD\_COM1\_MODE\_CAMERA

Commands COM1 to switch to Camera Mode

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_COM1_MODE_CAMERA_TIME	The timeout for camera mode, in minutes. 0 minutes means use last time.	0	255	0	224	8	UINT	minutes



#### GCMD\_COM1\_MODE\_HEALTH

Commands COM1 to switch to Health Mode

## GCMD\_COM1\_MODE\_REALTIME

Commands COM1 to switch to Real-Time Mode

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_COM1_MODE_REALTIME_TIME	The timeout for realtime mode, in minutes. 0 minutes means use last time.	0	255	0	224	8	UINT	minutes

#### GCMD\_COM1\_MODE\_SAFE

Commands COM1 to switch to Safe Mode

## GCMD\_COM1\_TRANSPONDER\_OFF

Commands COM1 to disable the transponder

## GCMD\_COM1\_TRANSPONDER\_ON

Commands COM1 to enable the transponder

#### GCMD\_COM2\_RUN

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units		
GCMD_COM2_RUN_FILENO	Which file to run		Which file to run		0	255	0	224	8	UINT	
GCMD_COM2_RUN_JUMP	Do you want to jump	p the queue?	0	1	0	232	1	UINT			
	State	Value									
	FALSE	0									
	TRUE	1									
GCMD_COM2_RUN_CLEAR	Do you want to clear	Do you want to clear the queue and run?		1	0	233	1	UINT			
	State	Value									
	FALSE	0									
	TRUE	1									

## GCMD\_DIST\_AUTOSHUTOFF

Set the status of dist autoshutoff for each power domain

Bit Bit Data

Date: 01/21/2020



Item Name	Description		Min	Max	Default	Offset	Size	Туре	Units
GCMD_DIST_AUTOSHUTOFF_COM2	Whether autoshutoff i domain	s enabled on the power	0	3	0	224	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_RAHS	Whether autoshutoff is domain	s enabled on the power	0	3	0	226	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_BDOT	Whether autoshutoff is domain	s enabled on the power	0	3	0	228	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_ESTIM	Whether autoshutoff i	s enabled on the power	0	3	0	230	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_EPS	Whether autoshutoff is domain	s enabled on the power	0	3	0	232	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_PPT	Whether autoshutoff i domain	s enabled on the power	0	3	0	234	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							



NULL 2

## GCMD\_DIST\_RESET\_MISSION

Resets MET and autosequencer, also sets the autosequencer to be reinitialized on next powerup

## GCMD\_DIST\_SELF\_RESTART

Causes dist to self-restart

## GCMD\_DIST\_SET\_PD\_OVC\_BDOT

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_BDOT_OVC	Set PD overcurrent BDOT	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_COM2

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_COM2_OVC	set PD Overcurrent Com2	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_EPS

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_EPS_OVC	Set PD Overcurrent EPS	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_ESTIM

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_ESTIM_OVC	Set PD overcurrent ESTIM	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_PPT

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_PPT_OVC	Set PD overcurrent PPT	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_RAHS

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_RAHS_OVC	Set PD overcurrent RAHS	0.0	15.0	0.0	224	32	FLOAT	Α



# GCMD\_DIST\_SET\_PD\_STATE

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_STATE_COM1	Enables or disables power domain	the power switch to com1	0	3	0	224	2	UINT	
	State	Value							
	NO-OP	0							
	ENABLE	1							
	DISABLE	2							
	TOGGLE	3							
GCMD_DIST_SET_PD_STATE_COM2	CMD_DIST_SET_PD_STATE_COM2 Enables or disables the power switch to com2 power domain		0	3	0	226	2	UINT	
	State	Value							
	NO-OP	0							
	ENABLE	1							
	DISABLE	2							
	TOGGLE	3							
GCMD_DIST_SET_PD_STATE_RAHS	power domain  State	the power switch to rahs  Value	0			228	2		
	NO-OP	0							
	ENABLE	1							
	DISABLE	2							
	TOGGLE	3							
GCMD_DIST_SET_PD_STATE_BDOT	Enables or disables power domain	the power switch to BDOT	0	3	0	230	2	UINT	
	State	Value							
	NO-OP	0							
	ENABLE	1							
	DISABLE	2							
	TOGGLE	3							
GCMD_DIST_SET_PD_STATE_ESTIM Enables or disables the power switch to the estimator power domain	0	3	0	232	2	UINT			
	estimator power do	main							



Husky								
	NO-OP	0						
	ENABLE	1						
	DISABLE	2						
	TOGGLE	3						
GCMD_DIST_SET_PD_STATE_WHEELS		Enables or disables the power switch to the reaction wheels (empty power domain)			0	234	2	UINT
	State	Value						
	NO-OP	0						
	ENABLE	1						
	DISABLE	2						
	TOGGLE	3						
GCMD_DIST_SET_PD_STATE_EPS	Enables or disables the pow power domain	er switch to the EPS	0	3	0	236	2	UINT
	State	Value						
	NO-OP	0						
	ENABLE	1						
	DISABLE	2						
	TOGGLE	3						
GCMD_DIST_SET_PD_STATE_PPT	Enables or disables the pow power domain	er switch to the PPT	0	3	0	238	2	UINT
	State	Value						
	NO-OP	0						

# GCMD\_EPS\_BATT\_FULLDEF

DISABLE

TOGGLE

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_EPS_BATT_FULLDEF_CONST_VOLT	Limits for detecting a full state on the battery (voltage must be greater than this value)	0.0	8.0	0.0	224	32	FLOAT	V
GCMD_EPS_BATT_FULLDEF_CHG_CURR	Limits for detecting a full state on the battery (current must be less than this value)	0.0	1.0	0.0	256	32	FLOAT	Amps

2

# GCMD\_GEN\_SET\_PT\_STATE



Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_GEN_SET_PT_STATE_1	enables or dis	ables Power Tracker #1	0	3	0	224	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_GEN_SET_PT_STATE_2	enables or dis	ables Power Tracker #2	0	3	0	226	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_GEN_SET_PT_STATE_3	enables or dis	ables Power Tracker #3	0	3	0	228	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							

# GCMD\_MTQ\_PMS

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_MTQ_PMS_X	Sets permamenent dipole strength		-100	100	0	224	8	INT	
GCMD_MTQ_PMS_Y	Sets permamenen	Sets permamenent dipole strength		100	0	232	8	INT	
GCMD_MTQ_PMS_Z	Sets permamenen	Sets permamenent dipole strength		100	0	240	8	INT	
GCMD_MTQ_PMS_ENABLE	turns on permane	ent magnet setting	0	2	0	248	2	UINT	
	State	Value							
	FALSE	0							

State	Value
FALSE	0
TRUE	1
NULL	2

# GCMD\_MTQ\_POP

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_MTQ_POP_X	flips the polarity on mtq x axis		0	2	0	224	2	UINT	
	State	Value							



FALSE	0
TRUE	1
NULL	2

GCMD\_MTQ\_POP\_Y

flips the polarity on mtq y axis

State	Value
FALSE	0
TRUE	1
NULL	2

0

2

0

226

2

UINT

GCMD\_MTQ\_POP\_Z

flips the polarity on mtq z axis

State	Value
FALSE	0
TRUE	1
NULL	2

O 2 0 228 2 UINT

# GCMD\_MTQ\_PWM\_TIME

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_MTQ_PWM_TIME_ACTUATION		0	255	0	224	8	UINT	seconds
GCMD_MTQ_PWM_TIME_MEASUREMENT		0	255	0	232	8	UINT	seconds

# GCMD\_PPT\_HALT

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_PPT_HALT_CONFIRM	Are you sure you want to halt the ppt?		0	1	0	224	1	UINT	
	State	Value							
	FALSE 0	0							
	TRUE	1							

# GCMD\_PPT\_MULTIPLE\_FIRE

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_PPT_MULTIPLE_FIRE_COUNT	How many times to fire	0	255	0	224	8	UINT	
GCMD_PPT_MULTIPLE_FIRE_OVERRIDE	Ppt fire override	0	1	0	232	1	UINT	
	State Value							



FALSE 0 TRUE 1

# GCMD\_RESET\_I2C

Commands all boards to reset their I2C

# GCMD\_RESET\_MINMAX

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_RESET_MINMAX_BDOT	Whether to reset the subsystem	0	1	0	224	1	UINT	
GCMD_RESET_MINMAX_PPT	Whether to reset the subsystem	0	1	0	225	1	UINT	
GCMD_RESET_MINMAX_DIST	Whether to reset the subsystem	0	1	0	226	1	UINT	
GCMD_RESET_MINMAX_GEN	Whether to reset the subsystem	0	1	0	227	1	UINT	
GCMD_RESET_MINMAX_BATT	Whether to reset the subsystem	0	1	0	228	1	UINT	
GCMD_RESET_MINMAX_ESTIM	Whether to reset the subsystem	0	1	0	229	1	UINT	
GCMD_RESET_MINMAX_MPC	Whether to reset the subsystem	0	1	0	230	1	UINT	
GCMD_RESET_MINMAX_SENSORPROC	Whether to reset the subsystem	0	1	0	231	1	UINT	
GCMD_RESET_MINMAX_MTQ	Whether to reset the subsystem	0	1	0	232	1	UINT	

## GRND\_EPOCH

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GRND_EPOCH_VAL		0	1099511627775	0	224	40	UINT	2^-8 s

# $\mathsf{TLE}\_1$

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_1_BSTAR	TLE BSTAR drag term	-3.4e+38	3.4e+38	0.0	224	32	FLOAT	
TLE_1_MNA	TLE ID and Mean anomaly	-3.4e+38	3.4e+38	0.0	256	32	FLOAT	degrees

# TLE\_2

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_2_DAY	TLE ID and Days since J2000 TT	-1.7e+308	1.7e+308	0.0	224	64	FLOAT	



TLE\_3

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_3_INC	TLE Orbital inclination	-3.4e+38	3.4e+38	0.0	224	32	FLOAT	degrees
TLE_3_ECC	TLE ID and Eccentricity	-3.4e+38	3.4e+38	0.0	256	32	FLOAT	

TLE\_4

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_4_RAAN	TLE Rt ascension of the asc. node	-3.4e+38	3.4e+38	0.0	224	32	FLOAT	degrees
TLE_4_AOP	TLE ID and Argument of perigee	-3.4e+38	3.4e+38	0.0	256	32	FLOAT	degrees

TLE\_5

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_5_MNM	TLE ID and mean motion	-1.7e+308	1.7e+308	0.0	224	64	FLOAT	revolutions/day