
# Physical assembly



## Print in PLA

- 1x Cybershell left
- 1x Cybershell right
- 1x Cybershell pin
- 2x hingeplate
- 1x main body
- 4x motor holder
- 1x swivel
- 1x enclosure
- 1x turner
- 4x wheel internal

All 80 percent infill except for wheel internal that on 15 percent infill

## Print in TPU 95A

- 4x nonpneumatic wheel
- 4x motor holder insert

## 80 percent infill

## Other parts needed

- 1x Raspberry pi + ai kit with all the code on it
- 2x joy-IT SBC-MotoDriver2
- 1x 5000mAh 11.1-volt LiPo
- 1x SG90 Servo
- Reely Micro-servo Digitale servo Materiaal (aandrijving): Kunststof Stekkersysteem: JR
- 1x Reely 1:10 Hydraulische schokdempers Zwart-blauw Met veren Zwart 1 stuk(s)
- 1x Arducam 5MP OV5647DS PTZ Camera for Raspberry Pi 4/3B+/3
- 1x usb a to c cable
- 1x plug for LiPo
- Cables
- Nuts bolts and

#### Locomotion




- 1. Fit a wheel internal on each motor with a hammer and then take it out. This is to make the connection fit
- 2. Then solder a wire to each motor
- 3. Insert the motor holder insert into the motor holder make sure all holes line up.
- 4. Insert the motor and bolt it down tight. Use these m3 bolts:



- 5. Guide the wires though the hole of the Hingeplate.
- 6. Bolt the shock dampers to the motor holder with m3 bolts and m3 locking nuts.
- 7. Then bolt it all to the hingeplate.
- 8. Then fit the nonpneumatic wheels over the wheel internal.
- 9. Place the wheels on the motors.
- 10. Screw the hingeplates to the main body.


#### Pan tilt

1. glue the Cybefrshell together with superglue like this:



- 2. take the turner and insert a bearing might need a vice to put it in
- 3. take the turner and mount the hingeplate to it with m3 locking nut and m3 bolt

- 4. place the reely servo and screw it into the hingeplate with the included screw from the sevo.
- 5. Screw in the sevo to the to the swivel



6. Take the camera parts and make sure they line up like the picture. Use only 4 of the included



bolts to connect the this to the white offsets. Connect the rest with these bolts again directly to the hingeplate.

- 7. Take the blue servo and cut off the screw in flap closest to the white turning thing.
- 8. Screw in the servo.
- 9. Put the assembly into the pin of the Cybershell make sure the blue servo is inserted into the hole of the pin might need to drill out the hole a bit.
- 10. Screw blue servo to the Cybershell pin.
- 11. Screw the enclosure to the Turner

#### electronics

- 1. Solder the LiPo plug in that it splits to the two motor controllers.
- 2. Add a ground from the LiPo to the raspberry pi.
- 3. Connect the motors to the motor controllers. Back wheels to the same and front wheels to the same
- 4. Connect the motor controllers to the raspberry pi. (there will come a update with all connections mapped out.

## Final assembly

- 1. Plug in the motor controllers and the raspberry pi
- 2. Place the power bank in the main body. Then the LiPo on top.
- 3. Connect the camera through ribbon cable and pint to the raspberry pi through the hole.
- 4. Fit everything into the main body.
- 5. Screw on the Cybershell to the Hingeplates
- 6. Done.