
Unit-1 Basic Electrical Terms and Units

Prepared by:
Dr.Dharmesh Dabhi
M & V Patel Department of Electrical Engineering
CHARUSAT
dharmeshdabhi.ee@charusat.ac.in



Content

Ohm's law

Resistor and its coding

Temperature co-efficient of resistance

Resistance variation with temperature

Examples

Ohm's Law

I + V -

➤ Ohm's law states that the current through a conductor between two points is directly proportional to the voltage across the two points.

- The formula for Ohm's law is **I=V/R**.
- where I is the current through the conductor in units of amperes, V is the voltage measured across the conductor in units of volts, and R is the resistance of the conductor in units of ohms. More specifically, Ohm's law states that the R in this relation is constant, independent of the current.
- The law was named after the German physicist Georg Ohm.

Limitations of Ohm's Law

- ➤ Ohm's law is not applicable to unilateral networks.
- Note:- Unilateral networks allow the current to flow in one direction. Such types of network consist elements like a diode, transistor, etc.
- ➤ Ohm's law is also not applicable to non linear elements.

Note:- Non-linear elements are those which do not have current exactly proportional to the applied voltage that means the resistance value of those elements changes for different values of voltage and current. Examples of non — linear elements are the thyristor.

Resistors

- A resistor is an electrical component that limits or regulates the flow of electrical current in an electric and electronic circuit.
- Resistors are one of the important blocks of electrical circuits.
- They are made up of the mixture of clay or carbon, so they are not only good conductors but good insulators. too.



Resistors

- Components that are specifically designed to have a certain amount of resistance.
 - 2 main categories
 - - resistance value are <u>set</u> during manufacturing and cannot be changed.
 - ★ variable resistors



* resistance values *can be changed* easily with a manual or an automatic <u>adjustment</u>.






- Carbon-composition resistors
 - constructed by molding mixtures of powdered carbon and insulating materials into cylindrical shape.
 - ★ an outer sheath of insulating material affords mechanical and electrical protection.
 - ★ copper connecting wires are provided at each end.





Carbon-composition resistors








- Carbon-composition resistors
 - small in size and inexpensive but less accurate and less rugged, the most common type used in electronics.
 - generally used in low current circuits with relatively low power ratings.
 - ★ values available from 20mW to 1W.





→ Carbon-composition resistors






- Wire-wound resistors
 - ★ large in size but more accurate and more rugged.
 - ★ often used in high current circuits with relatively high power ratings.
 - values available from less than 1W to several 100W.



→ Wire-wound resistors



low power rating



high power rating






- Film resistors
 - ★ similar to wire-wound resistor.
 - wire replace by a resistive material and is deposited evenly onto a high-grade ceramic rod.
 - the resistive film may be carbon (carbon film) or nickel chromium (metal film).
 - ★ small in size having performance in-between carbon-composition and wire-wound resistors.



Film resistors (spiraling technique)

insulating insulation
base coating



metal metal or carbon end cap film scribe helix






→ Film resistors (resistor network)


insulation coating







→ Film resistors







Variable Resistors


- Manual
 - ★ potentiometer ...
 - ★ rheostat .
 - Automatic
 - ★ thermistor temperature.
 - → photoconductive cell light intensity.
 - Examples are the volume controls on our TV receivers and radios.



Variable Resistors









Resistor Color Coding




STEPS IN DETERMINING THE VALUE OF THE COLOR CODED RESISTOR

• Hold the resistor. Look for the 3 colors which they are near on each other. Place it on your **left side**.








COLOUR	1 ST BAND	2 ND BAND	3 RD BAND	4 TH BAND/ TOLERANCE
BLACK	0	0	0	
BROWN	1	1	1	1%
RED	2	2	2	2%
ORANGE	3	3	3	
YELLOW	4	4	4	
GREEN	5	5	5	
BLUE	6	6	6	
VIOLET (Purple)	7	7	7	
GRAY	8	8	8	
WHITE	9	9	9	
GOLD				± 5%
SILVER				± 10%

NOTE:

Only Gold and Silver are the 2 colors that can be found in the 4th band

4th band: TOLERANCE




GREEN

BLACK

ORANGE

000 OHMS ±10%

SILVER




GREEN BLACK ORANGE SILVER

ACTUAL VALUE

50000 OHMS ±10%


REVERSE









Resistor Colour Code









Resistor Colour Code

- Normal resistors
 - ★ colour coded with 4 bands
 - ★ start from the end that does not begin with a gold or silver band (banded end).
 - ★ <u>first</u> band is the *first digit* of the resistance value.
 - * second band is the second digit.
 - ★ third band is the multiplier.
 - * fourth band indicates the tolerance.




Resistor Colour Code

- Precision resistors
 - ★ colour coded with 5 bands
 - ★ <u>first</u> band is the *first digit* of the resistance value.
 - * second band is the second digit.
 - * third band is the third digit.
 - * fourth band is the multiplier.
 - ★ <u>fifth</u> band indicates the *tolerance*.



Example 1




yellow = 4
blue = 6
orange =
$$10^3$$

silver = 10%

$$\Psi$$
 R = 46 x 10³ Ω = 46 000 Ω = 46 kΩ ± 10%
tolerance = 10% of 46 000 Ω = 4 600 Ω
R = (46 000 Ω - 4 600 Ω) to (46 000 Ω + 4 600 Ω)
= 41 400 Ω to 50 600 Ω
= 41.4 kΩ to 50.6 kΩ



Example 2



$$green = 5$$
 $red = 2$
 $orange = 3$
 $yellow = 10^4$
 $brown = 1\%$

$$R = 523 \times 10^4 \Omega = 5230000 \Omega = 5.23 M\Omega \pm 1\%$$
 $tolerance = 1\% \text{ of } 5.23 M\Omega = 0.0523 M\Omega$
 $R = (5.23 M\Omega - 0.0523 M\Omega)to (5.23 M\Omega + 0.0523 M\Omega)$
 $= 5.177 M\Omega \text{ to } 5.2823 M\Omega$

What is the value of the resistor?

- 1.Blue, Green, Black, Orange, Gold
- 2.Yellow, White, Red, Silver
- 3.Brown, Black, Brown, Silver

Ans.1-6,17,500 to 6,82,500

Ans.2-4410 to 5390

Ans.3-90 to 110

What is the set of colors of this given 4 Band resistance?

- 1. $10\Omega \pm 5\%$
- 2. $850,000 \Omega \pm 10\%$
- 3. $70,000,000 \Omega \pm 5\%$

Ans.1-BROWN,BLACL,BLACK,GOLD Ans.2- GRAY,GREEN,YELLOW,SILVER Ans.3- PURPLE,BLACK,BLUE,GOLD

EVALUATION

- A. Identify the value of resistor with the given set of colors.
 - 1. Brown, Black, Brown, Gold
 - 2. Red, Green Black, Silver
 - 3. Brown, Green, Orange, Silver
 - 4. White, Yellow, Yellow, Silver
 - 5. Green, Violet, Blue, Gold
- B. Determine the colors of the 4 band resistor.
 - 1. 12 ± 5%
 - 2. 47 ± 5%
 - $3. 100 \pm 10\%$
 - 4. 37, $000 \pm 5\%$
 - 5. 22,000,000 ± 10%




Wattage Rating

- The <u>maximum</u> amount of power that a <u>resistor can</u> dissipate <u>without</u> being damaged by excessive heat buildup.
 - Not related to the <u>ohmic value</u> (resistance).
 - Determined mainly by the <u>physical size</u> and <u>shape</u> of the resistor.










Wattage Rating

The larger the surface area of a resistor, the more power it can dissipate.

```
surface area
of a cylindrically = (l x c)
shaped resistor
```





Wattage Rating

- Carbon-composition resistors
 - ★ from 20mW to 1W.
 - Wire-wound resistors
 - ★ less than 1W to several 100W.
 - → Film resistors
 - ★ up to 10W.



Resistance Factors

- Resistance of resistor is affected by 4 factors
 - environmental
 - * temperature (temperature coefficient).
 - ★ manufacturer
 - * diameter (cross-sectional area, A).
 - * length (I)
 - ***** *type of material* (resistivity, ρ).

$$R = \frac{\rho l}{A}$$



Resistance Factors

- Temperature coefficient
 - ★ indicates the change in resistance with temperature
 - ⋆ positive proportional.
 - ★ negative inversely proportional.



Applications

- Limit/reduce current.
 - Divide voltage to produce a desired voltage drop.
 - Generate heat in certain cases.

• Resistance of the conducting material is calculated using

$$R=rac{
ho L}{A}$$
 $P={
m resistivity} \ L={
m length} \ A={
m cross sectional area}$

- The resistance of a conducting material is found to
- 1. be directly proportional to the length L of thematerial.
- 2. be inversely proportional to the cross-section are A of the material.
- 3. depend on the nature of the material.
- 4. depend upon the temperature.

Temperature co-efficient of resistance

- Resistance of almost all the materials changes with the change in the temperature.
 - R_0 = Resistance of the material at 0 degree Celsius
 - R_t = Resistance of the material at t degree Celsius
- Then the change in resistance is found to be

$$\Delta R = R - R$$
 $t = 0$

- I. directly proportional to its initial resistance, and
- II. directly proportional to the change in temperature.
- Thus,

$$\Delta R \alpha R_0 t \qquad \Rightarrow \qquad (R_t - R_0) \alpha R_0 t \qquad \Rightarrow \qquad (R_t - R_0) = \alpha R_0 t$$

 α = constant know as the temperature co-efficient of resistance.

Continue....

• The variation of resistance with change in temperature of any material is governed by this property.

$$\alpha = \frac{(R_t - R_0)}{R_0 t} \tag{1}$$

- Temperature co-efficient of resistance α is defined as the change in resistance per unit rise in temperature per ohm original resistance.
- Usually temperature co-efficient is taken at a particular reference temperature which is normally taken as o degree Celsius.
 - It is denoted by α_0
 - Rewriting the equation (1), $R_t = R_0 * [1 + \alpha_0 * t]$

Resistance at different temperatures

- If at a standard temperature of 'o' degree Celsius a material has a resistance of Ro ohms,
- >at t1 degree Celsius resistance of R1 ohms and
- >at t2 degree Celsius resistance of R2 ohms, then

$$R_1 = R_0 * [1 + \alpha_0 * t_1]$$
and
 $R_2 = R_0 * [1 + \alpha_0 * t_2]$

$$\frac{R_2}{R_1} = \frac{[1 + \alpha_0 * t_2]}{[1 + \alpha_0 * t_1]}$$

Continue....

• If temperature co-efficient α_0 and resistance R_0 are not given then the relation between the known resistance R_{t1} and t_1 degree Celsius and the unknown resistance R_{t2} and t_2 degree Celsius can be found as follows:


 R_{t1} = resistance at t_1 degree Celsius R_{t2} = resistance at t_2 degree Celsius

• Suppose,

 α_{t1} = temperature co-efficient of resistance at t_1 degree Celsius

 α_{t1} = Slope of the graph / resistance at t_1 degree Celsius Slope of the graph= $\alpha_{t1} * R_{t1}$

Resistance at Different temperature



Continue....

Slope of the graph=AB/BC
$$= \frac{R_{t2} - R_{t1}}{t_2 - t_1}$$

$$\alpha_{t1} * R_{t1} = \frac{R_{t2} - R_{t1}}{t_2 - t_1}$$


$$R_{t2} - R_{t1} = \alpha_{t1} * R_{t1} * (t_2 - t_1)$$

$$R_{t2} = \alpha_{t1} * R_{t1} * (t_2 - t_1) + R_{t1}$$

$$= R_{t1}[1 + \alpha_{t1}^*(t_2 - t_1)]$$

Effect of temperature on Resistance

Metals	Alloys	Insulators, Semi- Conductors & Electrolytes
metals increases with the rise in temperature. The increase in resistance is large and regular. Metals have a positive temperature co-efficient of resistance.	rise in temperature. > But the increase in resistance is irregular and small. > Alloys have a very low value of positive temperature co-efficient of	Semi-Conductors & Electrolytes decreases with the rise in temperature. > As temperature is increased, many free electrons are created. > So there is a drop in the
Aluminium		efficient of resistance. > E.g. Rubber, Oil, Plastic



1. A wire has a resistance of 2 ohms. It has been stretched to the length 3 times that of original, what will be the resistance of wire?

Solution:-

We know that

$$R = \frac{g \times l}{a}$$

$$= \frac{g \times l}{a} \times \frac{l}{l} \quad (\because \text{ Multiply and divide by 'l'})$$

$$= \frac{g l^2}{a l}$$

$$= \frac{g l^2}{V} \quad [\because V = al]$$

By stretching the wire, volume remains unchanged

$$R \propto l^2$$

In other words

$$\frac{R_2}{R_1} = \left(\frac{l_2}{l_1}\right)^2$$
Now $R_1 = 2 \Omega$ $l_2 = 3 l_1$

$$\therefore R_2 = 2 \left(\frac{3 l_1}{l_1}\right)^2$$

$$= 2 (3)^2$$

$$= 18 \Omega$$

2. Calculate the resistance of 100 m length of a wire having a uniform cross section area of 0.1 mm² if the wire is made of Manganin having a resistivity of 50*10e³-8 ohm*m. If the wire is drawn out to three times its original length, find out new resistance.

Solution:

/ = 100 m

$$a = 0.1 \text{ mm}^2 = 0.1 \times 10^{-6} \text{ m}^2$$

 $g = 50 \times 10^{-8} \Omega \text{m}$
(i) $R = \frac{g/}{a}$
=500 ohm

(ii)
$$R = \frac{QI}{a}$$

= $R = \frac{QI}{a} \times \frac{I}{I}$ (multiply by I to the numerator and denominator)
= $\frac{QI^2}{V}$ ($\because V = a \times I$)

As wire is drawn its length I and cross section a may vary but the volume remains constant.

As length is increased 3 times

$$l_2 = 3 l_1$$

$$\therefore \frac{R_2}{R_1} = \left(\frac{l_2}{l_1}\right)^2 = \left(\frac{3}{1}\right)^2$$

$$\therefore \quad \mathsf{R}_2 = 9 \; \mathsf{R}_1$$

R2=9*500=4500 ohm