Controllability and Observability

Chong-Jin Ong

Department of Mechanical Engineering, National University of Singapore

Outline

Introduction

2 Controllability

Reachability

Introduction

- This chapter deals with two concepts that are not found in classical or frequency analysis.
- Controllability and Observability are two unique features of the state space analysis.
- These concepts were first introduced by E.G. Gilbert and R.F. Kalman in the 1960s.
- Explain why cancellation of unstable poles are undesirable even if perfect cancellation is possible.
- The concepts are first illustrated via several motivating examples.

Example 1: Consider the system

$$\dot{x}_1 = u$$
$$\dot{x}_2 = u$$

If $x_1(0) = x_2(0)$, then $x_1(t) = x_2(t)$ for all time and all control u(t).

Example 2: Consider the system

$$\dot{x}_1 = x_2$$

$$\dot{x}_2 = 0$$

$$y = x_2$$

Then y(t) = constant for all choices of $x_1(0)$ and $x_2(0)$. Observing y(t) does not tell us what x_1 is doing.

Motivating Example

A more interesting example is one given by the following diagram. It consists of two carts coupled by a spring. A force f is applied onto both carts via some means within the system.




Figure: The Two cart example

The equations of motion of the system are

$$\dot{x}_1 = x_3, \qquad \dot{x}_2 = x_4$$

$$\dot{x}_3 = -\frac{k}{m_1}(x_1 - x_2) - \frac{f}{m_1}, \quad \dot{x}_4 = -\frac{k}{m_2}(x_2 - x_1) + \frac{f}{m_2}$$

Motivating Example

Rewritten in standard state space representation, the state equation is

$$\dot{x} = \begin{pmatrix} 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \\ -\frac{k}{m_1} & \frac{k}{m_1} & 0 & 0 \\ \frac{k}{m_2} & -\frac{k}{m_2} & 0 & 0 \end{pmatrix} x + \begin{pmatrix} 0 \\ 0 \\ -\frac{1}{m_1} \\ \frac{1}{m_2} \end{pmatrix} f$$

From law of physics, f can change the relative distance between the two carts $(x_2 - x_1)$ but it cannot change x_1 and x_2 independently.

Example 4: Consider the system given below,




Figure: The uncontrollable system

The equations describing the system are;

$$\dot{v}_1 = -\frac{1}{C_1} \left(\frac{1}{R_1} + \frac{1}{R_3} \right) v_1 + \frac{1}{C_1 R_3} v_2 + \frac{1}{C_1 R_1} V$$

$$\dot{v}_2 = \frac{1}{C_2 R_3} v_1 - \frac{1}{C_2} \left(\frac{1}{R_2} + \frac{1}{R_3} \right) v_2 + \frac{1}{C_2 R_2} V$$

Consider the voltage across R_3 , $\bar{v} = v_1 - v_2$ then

$$\dot{\bar{v}} = -\left[\frac{1}{C_1}(\frac{1}{R_1} + \frac{1}{R_3}) + \frac{1}{C_2R_3}\right]v_1 + \left[\frac{1}{C_1R_3} + \frac{1}{C_2}(\frac{1}{R_2} + \frac{1}{R_3})\right]v_2 + \frac{R_2C_2 - R_1C_1}{C_1C_2R_1R_2}V$$

If the bridge is balanced, then $R_1C_1 = R_2C_2$, the coefficient of V vanishes and

$$\dot{\bar{v}} = -(\frac{R_1 + R_2 + R_3}{C_1 R_1 R_3}) \bar{v}$$

which implies that \bar{v} is not influenced by V and the voltage \bar{v} decays from $\bar{v}(0)$ to zero, i.e., \bar{v} is not controllable.

Controllability and Observability

- The above shows practical examples of uncontrollable and unobservable systems.
- This chapter studies analysis tools that checks for controllability and observability.
- Given (A, B, C, D), answer the questions:
 - ▶ Can we drive x(t) wherever we desire using u(t)?
 - ▶ Can we track x(t) by observing y(t)?
- \bullet We assume complete knowledge of (A,B,C,D) in answering these questions.

- **Definition**: A LTI system (A, B, C, D) (or more precisely (A, B)) is controllable if there exists an input $u(t), 0 \le t \le t_1$ that drives the system from **any** initial state $x(0) = x_0$ to **any** other state $x(t_1) = x_1$ in a **finite** time t_1 . Otherwise, (A, B) is said to be uncontrollable.
- Possible to define the above for time-varying systems (more complicated since reaching x_1 may depend on t_0). The above assumes $t_0 = 0$ WLOG.
- Theorem 4.1 The *n*-dimensional LTI system with matrices (A, B) is controllable if and only if any of the following condition is satisfied:
 - The Controllability Grammian

$$W(0,t) = \int_0^t e^{A\tau} B B^T e^{A^T \tau} d\tau = \int_0^t e^{A(t-\tau)} B B^T e^{A^T (t-\tau)} d\tau$$

is nonsingular for all $t \geq 0$.

2 The $n \times nr$ matrix

$$U = \left[B \ AB \ \cdots \ A^{n-1}B \right]$$

is full row rank.

The $n \times (n+r)$ matrix $[A - \lambda I B]$ has full row rank at every eigenvalue λ of A.

Case 1: (\Rightarrow) Suppose W(0,t) is non-singular for all t>0 and $x(t_1)=x_1$. Choose the input as

$$u(t) = -B^{T} e^{A^{T}(t_{1}-t)} W^{-1}(0, t_{1}) (e^{At_{1}} x_{0} - x_{1})$$

Using this input on the system, the state

$$x(t_1) = e^{At_1} x_0 + \int_0^{t_1} e^{A(t_1 - \tau)} Bu(\tau) d\tau$$

$$= e^{At_1} x_0 - \int_0^{t_1} e^{A(t_1 - \tau)} BB^T e^{A^T (t_1 - \tau)} W^{-1}(0, t_1) (e^{At_1} x_0 - x_1) d\tau$$

$$= e^{At_1} x_0 - (e^{At_1} x_0 - x_1) = x_1$$

(\Leftarrow) Suppose W(0,t) is singular for some $t_1 > 0$, and that the system is controllable. We show that this leads to a contradiction. Since $W(0,t_1)$ is singular, there exists a non-zero α such that

$$\alpha^{T}W(0, t_{1})\alpha = \int_{0}^{t_{1}} \alpha^{T} e^{A(t_{1} - \tau)} BB^{T} e^{A^{T}(t_{1} - \tau)} \alpha d\tau = 0$$
Or,
$$\int_{0}^{t_{1}} \|\alpha^{T} e^{A(t_{1} - \tau)} B\|_{2}^{2} d\tau = 0$$

Since $\|\cdot\|$ is a non-negative function, this means that

$$\alpha^T e^{A(t_1 - \tau)} B = 0 \text{ for all } t > \tau > 0 \tag{1}$$

Since the system is controllable, this means that any state is reachable by an appropriate control in finite time. Suppose we want to reach the state $x(t_1) = \alpha + e^{At_1}x_0$ at time t_1 . Then

$$x(t_1) = \alpha + e^{At_1} x_0 = e^{At_1} x_0 + \int_0^{t_1} e^{A(t_1 - \tau)} Bu(\tau) d\tau$$
or, $\alpha = \int_0^{t_1} e^{A(t_1 - \tau)} Bu(\tau) d\tau$

This also means that

$$\alpha^T \alpha = \int_0^{t_1} \alpha^T e^{A(t_1 - \tau)} Bu(\tau) d\tau = 0$$

from (1) which then implies that $\alpha = 0$ which contradicts that $\alpha \neq 0$.

Case (2) (\Rightarrow and \Leftarrow): Various ways of showing this exist and this one given here is more intuitive but less rigorous. It shows a clear connection to Caley-Hamilton Principle. Recall that

$$x_{1} = e^{At_{1}}x_{0} + \int_{0}^{t_{1}} e^{A(t_{1}-\tau)}Bu(\tau)d\tau$$

$$e^{-At_{1}}x_{1} - x_{0} = \int_{0}^{t_{1}} e^{-At_{1}}e^{A(t_{1}-\tau)}Bu(\tau)d\tau = \int_{0}^{t_{1}} e^{-A\tau}Bu(\tau)d\tau$$
 (2)

and from CH Principle,

$$e^{-A\tau} = \sum_{k=0}^{n-1} \alpha_k(\tau) A^k$$

Using this into (2),

$$e^{-At_1}x_1 - x_0 = \sum_{k=0}^{n-1} A^k B \int_0^{t_1} \alpha_k(\tau) u(\tau) d\tau = \sum_{k=0}^{n-1} A^k B \beta_k$$

where $\beta_k = \int_0^{t_1} \alpha_k(\tau) u(\tau) d\tau$.

• The above equation can only be satisfied identically for any x_0, x_1 and t_1 if and only if $\begin{bmatrix} B & AB \cdots A^{n-1}B \end{bmatrix}$ is full row rank

Case (3) (\Rightarrow) We want to show that

U is full rank $\Rightarrow \{[A - \lambda I B] \text{ has full row rank at every } \lambda \text{ of } A.\}$

Suppose this is not true i.e., there exists a λ_1 and a non-zero q s.t.

$$q^T[A - \lambda_1 I B] = 0$$

This implies that

$$q^T A - q^T \lambda_1 = 0$$
 and $q^T B = 0$,

$$q^{T}[B AB \cdots A^{n-1}B] = [q^{T}B q^{T}AB \cdots q^{T}A^{n-1}B]$$
$$= [q^{T}B \lambda_{1}q^{T}B \cdots \lambda_{1}^{n-1}q^{T}B] = 0$$

Hence, U is not full row rank.

Case (3) (\Leftarrow) We want to show that

$$\{[A-\lambda I\ B] \text{ has full row rank at every } \lambda \text{ of } A.\} \Rightarrow \{U \text{ is full rank }\}$$

Need an additional result that controllability is invariant under similarity transformation, a result to be shown later. Using that, and suppose rank U = n - m for some integer $m \ge 1$, (A, B) can be expressed as

$$\bar{A} = PAP^{-1} = \begin{pmatrix} \bar{A}_c & \bar{A}_{12} \\ 0 & \bar{A}_{\bar{c}} \end{pmatrix} \bar{B} = PB = \begin{pmatrix} \bar{B}_c \\ 0 \end{pmatrix}$$

where $\bar{A}_{\bar{c}}$ is $m \times m$. Let λ_1 be an eigenvalue and q_1 be the left eigenvector of $\bar{A}_{\bar{c}}$ i.e., $q_1^T \bar{A}_{\bar{c}} = \lambda_1 \bar{A}_{\bar{c}}$ or $(q_1^T - \lambda_1 I) \bar{A}_{\bar{c}} = 0$. We form the n vector q as $q^T = [0 \ q_1^T]$ where 0 is a (n-m) row vector. Then, we have

$$q^{T}[\bar{A} - \lambda_{1}I \ \bar{B}] = \begin{pmatrix} 0 & q_{1}^{T} \end{pmatrix} \begin{pmatrix} \bar{A}_{c} - \lambda_{1}I & \bar{A}_{12} & \bar{B}_{c} \\ 0 & \bar{A}_{\bar{c}} - \lambda_{1}I & 0 \end{pmatrix} = 0$$

This implies that $[A - \lambda I B]$ is not full rank at eigenvalue λ_1 . (q.e.d.)



- The $n \times nr$ matrix $U := [B \ AB \ \cdots \ A^{n-1}B]$ is commonly known as the controllability matrix.
- In the case of single-input system, r=1 and U is a square matrix with controllability ensured when U is non-singular.
- Controllability is a concept on the ability of a system to move from one point to another under the influence of u(t).
- It does NOT take into account physical constraint.
- Knowing that a system is controllable does not mean that it can be controlled in practice.
- However, knowing that a system is not controllable means one should not try
 to move system state arbitrarily.

Consider the system given below:




Figure: The Beam example

The equation of the system is

$$\left(\begin{array}{c} \dot{x}_1 \\ \dot{x}_2 \end{array}\right) = \left(\begin{array}{cc} -0.5 & 0 \\ 0 & -1 \end{array}\right) \left(\begin{array}{c} x_1 \\ x_2 \end{array}\right) + \left(\begin{array}{c} 0.5 \\ 1 \end{array}\right) u$$

Note that the zero-input system is asymptotically stable.

- Questions: Is there an input u(t) such that, when applied, brings the platform system to equilibrium in 2 seconds starting from $x_1(0) = 10$ and $x_2(0) = -1$?
- Answer: First check that $rank[B AB] = rank(\begin{pmatrix} 0.5 & -0.25 \\ 1 & 1 \end{pmatrix}) = 2.$
- Hence, it is possible to bring the system to the origin in 2 second. The expression is

$$u(t) = -B^{T} e^{A^{T}(t_{1}-t)} W^{-1}(0,t_{1}) (e^{At_{1}} x_{0} - x_{1}) \text{ with}$$

$$W(0,2) = \int_{0}^{2} \begin{pmatrix} e^{-0.5\tau} & 0\\ 0 & e^{-\tau} \end{pmatrix} \begin{pmatrix} 0.5\\ 1 \end{pmatrix} \begin{pmatrix} 0.5 & 1 \end{pmatrix} \begin{pmatrix} e^{-0.5\tau} & 0\\ 0 & e^{-\tau} \end{pmatrix} d\tau$$

$$= \begin{pmatrix} 0.2162 & 0.3167\\ 0.3167 & 0.4908 \end{pmatrix}$$

• The corresponding $u(t) = -58.82e^{0.5t} + 27.96e^t$.

Consider two cases: (1) no constraint on u; and (2) $-10 \le u(t) \le 10$,




Figure: Plots of $x_1(t), x_2(t)$ and u(t) for transfer from $x(0) = (10, -1)^T$ in 2 seconds.




Figure: Plots of $x_1(t), x_2(t)$ and u(t) for transfer from $x(0) = (10, -1)^T$ in 4 seconds.

Controllability under Similarity Transformation

- What happens to Controllability of a system when it undergoes a coordinate change?
- Consider the case of $x = T\bar{x}$, the new state equations are

$$\dot{\bar{x}} = T^{-1}AT\bar{x} + T^{-1}Bu$$
$$y = CT\bar{x} + Du$$

The new controllability matrix is

$$\bar{U} = \left[T^{-1}B \, T^{-1}AB \cdots T^{-1}A^{n-1}B \right] = T^{-1} \left[B \, AB \cdots A^{n-1}B \right] = T^{-1}U$$

• Hence, rank of $\bar{U}=\mathrm{rank}$ of U (why?) and Controllability is not affected by similarity transformation.

Reachable States and Controllability Grammian

- A closely related concept to Controllability is Reachability.
- Reachability has the same definition of Controllability except that x(0) = 0.
- A state x_{ℓ} is reachable if there exists a u(t) such that

$$x_{\ell} = \int_{0}^{\ell} e^{A(\ell - t)} Bu(t) dt$$

- The set of reachable state, \mathcal{R} , is the collection of all x_{ℓ} over all possible u.
- Note that \mathcal{R} is a linear subspace of \mathbb{R}^n : for all $\alpha, \beta \in \mathbb{R}$,

$$x_a, x_b \in \mathcal{R} \Rightarrow \alpha x_a + \beta x_b \in \mathcal{R}$$

• Recall $W(0,\ell) = \int_0^\ell e^{A(\ell-\tau)} BB^T e^{A^T(\ell-\tau)} d\tau$. We claim that

$$\mathcal{R}$$
 = Range space of $W(0, \ell)$

Proof is omitted.

Controllability Grammian is time-independent

 \bullet We now show that rank W is independent of the terminal time $\ell.$ To do so, we note that

$$\operatorname{rank}(W(0,\ell)) = \operatorname{rank}\left[B A B \cdots A^{n-1} B\right] = \operatorname{rank}(U)$$

The special case when U is square full rank is already established earlier.

- The proof is given in the next page. However, here is an intuitive reasoning.
- Since controllability requires that $W(0,\ell)$ to be non-singular for all $\ell > 0$ and the full rank condition of U is independent of ℓ . This provides plausible reason to the validity of the above.

Controllability Grammian is time-independent

Proof: (Optional) (\Rightarrow)

$$q^{T}W(0,\ell) = 0 \Rightarrow \int_{0}^{\ell} q^{T} e^{A(\ell-\tau)} B B^{T} e^{A^{T}(\ell-\tau)} q d\tau = 0$$
$$\Rightarrow q^{T} e^{A(\ell-\tau)} B = 0, \text{ for all } \tau \in [0,\ell].$$
(3)

Let $\tau = \ell$ then the above implies $q^T B = 0$. Differentiate (3) once yields

$$(-1)q^T A e^{A(\ell-\tau)} B = 0$$

which implies, when $\tau = \ell$,

$$(-1)q^T A B = 0$$

Repeating the differentiation n-1 times yields

$$q^{T} \left[B (-1)AB \cdots (-1)^{k} A^{k} B, \cdots (-1)^{n-1} A^{n-1} B \right] = 0$$

which implies that $q^T [B AB \cdots A^{n-1}B] = 0$. This means $rank(W(0, \ell)) \leq rank(U)$. (\Leftarrow) Let q^T be in the left nullspace of U. Then

$$q^T [B AB \cdots A^{n-1}B] = 0 \Rightarrow q^T W(0, \ell) = 0 \text{ for any } \ell > 0$$

This implies $rank(U) < rank(W(0, \ell))$.

- Using (\Rightarrow) and (\Leftarrow) , $rank(W(0,\ell)) = rank(U)$.
- Since U is independent of ℓ , so is rank(U) and rank(W).
- WLOG, denote $W = W(0, \infty)$.

Computation of Controllability Grammian

- The expression of $W = \int_0^\infty e^{A(t-\tau)} B B^T e^{A^T(t-\tau)} d\tau$ is hard to compute.
- \bullet There is another expression that allows easy computation. Note that the W satisfies the Lyapunov Equation

$$AW + WA^T = -BB^T$$

such that the solution of the above yields W.

ullet This follows because (assuming A is stable)

$$AW + WA^{T} = \int_{0}^{\infty} \frac{d}{dt} (e^{At}BB^{T}e^{A^{T}t})dt = -BB^{T}$$