

Vivid User Manual

Contents

1. FTUE (First Time User Experience).....	3
1-1. Get Permissions	3
1-2. Change System Language	4
1-3. Consent Agreement	5
1-4. Connect to Wi-Fi hotspot.....	5
1-5. Vivid Activation.....	6
1-6. Vivid Account Login (Optional).....	6
2. Home Page	7
2-1. Upgrade preference.....	7
2-2. Upgrade prompt	7
2-3. Home page	8
2-4. Address search.....	9
2-5. Home/Work Shortcut	11
2-6. Date and Weather	12
2-7. Smart map view	13
2-7-1. 2D/3D map.....	13
2-7-2. Route information	14
2-8. Media Card.....	15
2-8-1. Media Control	15
2-8-2. Media Recommendation	18
2-9. Card Layout	19
2-9-1. Open Card Layout (Beta)	19
2-9-2. Default cards	20
2-9-3. Change cards position	20
3. Media	21
3-1. Local Music.....	21
3-1-1. Local music home page.....	21
3-1-2. Playlist.....	21
3-2. Radio	23

3-2-1. Radio Stations	23
3-2-2. Tuning	24
3-3. Bluetooth Music	25
3-3-1. Bluetooth Connection	25
3-3-2. Play Bluetooth music	27
4. Phone	27
4-1. Bluetooth Connection	27
4-2. Contacts Synchronization	29
4-2-1. Contacts sorted alphabetically	29
4-2-2. Call history	31
4-2-3. Favorite Contacts	31
5. Apps View	33
5-1. All Apps display	33
5-2. Uninstall App	33
5-3. Search apps	34
5-3. Sort apps	35
6. Domain Bar	36
6-1. Default apps	36
6-2. Edit apps	37
7. Control Center	37
7-1. Control Center entrance	38
7-2. Main interface	38
8. Setting	39
8-1. Theme	39
8-1-1. Desktop	40
8-1-2. Wallpaper	41
8-2. Display	42
8-2-1. Dark mode	42
8-2-2. Unit	44
8-3. General	44
8-3-1. About	44
8-3-2. Update	45
8-3-3. Language	46

8-3-4. Reboot.....	46
8-3-5. Reset	47
8-4. Feature	47
 8-4-1. General.....	47
 8-4-2. Music.....	48
8-5. Car	49
8-6. User	49
 8-6-1. Account.....	49
 8-6-2. Valet Lock.....	51
 8-6-2. User Feedback.....	54
8-7. Connections	54

1. FTUE (First Time User Experience)

When users activate Vivid for the first time, FTUE page will be ran that user can Activate/Login Vivid and do some basic setup.

1-1. Get Permissions

Allow the permissions required by the system, otherwise some functions will be restricted.

Permission

VIVID Launcher will need below permissions to work properly, there are detailed description of why we need them



Notification Access

We need to access "Notification", so that you can use "play/pause/previous/next" to control the 3rd party media player, e.g. S...

Allow Access

1-2. Change System Language

CHOOSE YOUR LANGUAGE

中文 (简体中文,中国)

中文 (繁體中文,台灣)

中文 (繁體中文,香港)

English (United States)


English (United Kingdom)

Français (France)

Deutsch (Deutschland)




1-3. Consent Agreement




1-4. Connect to Wi-Fi hotspot

Click the hotspot which user want to connect and input the password, the connection will succeed.




1-5. Vivid Activation

Vivid activation successful, and user can proceed to the next step.



1-6. Vivid Account Login (Optional)


Users can log in the account by email. Or you can click the “Next” button directly to skip the account login.



2. Home Page

2-1. Upgrade preference


User can select the upgrade preference once Vivid started for the first time.



2-2. Upgrade prompt


An upgrade prompt will pop up once Vivid was launched and a new release was detected.

User can click "Update" button to start updating or click "Skip" button to ignore the update prompt for this version.



2-3. Home page


The home page will be displayed once Vivid was launched.



2-4. Address search

Click the search box in the left smart view in home page, a quick address search screen will be displayed.

There are three parts listed here:





- **Recent**

1. Historical destinations were listed in Recent, User can click on these destinations to make a quick routing.
2. These destinations can be deleted by user manually.

- **Keywords search**


Click the search box, keywords search screen will be displayed.

1. User can input any keyword for keyword search.
2. Historical search keywords were listed, User can click on these historical search keywords for a quick search.
3. Historical search keywords could be deleted.




- **POI**


1. Some Hot Categories and Favorite icons were shown in POI part.
2. User can do quick category search by clicking the category icons.
3. User can add, delete, or modify Home/Work and favorite address in Favorites.



2-5. Home/Work Shortcut

Home and Work shortcuts were listed in left smart porch view, user can make a quick routing to Home or Work address directly. If you don't have a Home or Word address, clicking on these two buttons takes you to the Home /Work Settings page.







2-6. Date and Weather

Current location's date and weather information was also shown in in left smart porch view.

Full weather information page can be shown by tapping the weather area.






2-7. Smart map view


2-7-1. 2D/3D map

Smart map view can be switched between 2D and 3D mode by clicking map indicator button.

- 2D map view




- 3D map view



2-7-2. Route information

After calculating the route in Google map, the route information includes Turn information / Estimated time of arrival / Route distance / Estimated travel time will be shown in split map view.



2-8. Media Card


Slide up or down in right smart porch view, user can switch between media control and media recommendation pages.

2-8-1. Media Control


Slide down in right smart porch view, media control page will be shown. User can perform operations such as switching songs, play/pause music for current music source.

User can switch current playing music source by selecting the different music sources from the drop-down list.


User can select Local music, Radio, BT music and some Third-party music sources which Vivid supports.




- Local music



- Radio




- Bluetooth music



- 3rd-party Music


When users use a third-party music application, user can also perform music control on the home page.




2-8-2. Media Recommendation

Slide up in right smart porch view, there shows the music recommendation screen for different music sources. User can play recommended playlist or specific radio station here.

- Local music recommendation



- Radio recommendation




2-9. Card Layout

We provide user with a second desktop layout – Card Layout (Beta)


2-9-1. Open Card Layout (Beta)

User can switch to card layout in Setting – Desktop.




2-9-2. Default cards

Navigation, Media, Weather, Like Radio, Like local (If have the resources), Speed, Shortcut were shown as default cards.



2-9-3. Change cards position

User can long press and move the card to change the position of the card.



3. Media


Click the music icon in domain bar, music main page will be shown. User can switch to different music source interfaces by clicking media buttons in the left of this page.

3-1. Local Music

3-1-1. Local music home page

There are several folders displayed in local music's home page.


- Recent: All the local music that was once played will be displayed in it.
- Favorite: All the local music that was added to favorite will be displayed in it.
- All Music: All the music in internal or external storage will be displayed in it.
- Folders: All the music folders will be displayed below as a playlist.



3-1-2. Playlist


Click any music folder, it will show a specific music playlist.

User can click "Play All" button to play all the songs in the list in sequence or click on any song to play specific music.




3-1-2-1. Add music to queue

Click the “Option” button for any music in the playlist, user can add the music to queue as the next one to play.



3-1-2-2. Open music's details page

Click on any music in the playlist, it will show the music's details page.




3-2. Radio

Click the Radio button in left music page, it will switch to Radio page.

3-2-1. Radio Stations

There are several sections in radio stations page.

- Recent Played: All the radio stations that was once played will be displayed here.
- Favorite: All the radio stations that was added to favorite will be displayed here.
- Nearby: All the radio stations near the current location will be displayed here.



3-2-2. Tuning

User can search the radio stations here. In the meantime, you can add them to favorite.



3-3. Bluetooth Music

Click the Bluetooth button in left music page, it will switch to Bluetooth music page.

3-3-1. Bluetooth Connection


User can search and connect to this Bluetooth device from phone side when Bluetooth music page was opened.



- Bluetooth paired and connected with phone:



- Clicked the Bluetooth connection's option icon, user can disconnect Bluetooth or cancel the pairing.



3-3-2. Play Bluetooth music

Play music from the music app on your phone, the music will be played on the device and music information will be shown in mini player.

Users can also play/pause or switch the music in mini player.




4. Phone


Click the Phone icon in domain bar, Phone page will be shown.

4-1. Bluetooth Connection


User can search and connect to this Bluetooth device from phone side when Phone page was opened.



- Bluetooth paired and connected to phone:




- Clicked the Bluetooth connection's option icon, user can disconnect Bluetooth or cancel the pairing.



4-2. Contacts Synchronization


4-2-1. Contacts sorted alphabetically

Contacts will be sorted alphabetically. Clicked any contacts name, it will show specific contacts details.



4-2-1-1. Contacts details

Users can make a phone call directly or add it to contacts favorite list.




4-2-2. Call history

Call records were displayed here with different status flags. Users can make a phone call directly by clicking any contacts.



4-2-3. Favorite Contacts


All favorite contacts will be listed. User can make a phone call or remove the contacts from the favorite list.



5. Apps View


5-1. All Apps display

All the applications can be shown in apps page, the app could be opened by clicking the app icon.




5-2. Uninstall App

Long press on any app and click the Uninstall button, the app can be uninstalled.




- PS: The uninstall button of a system application cannot be clicked.




5-3. Search apps

User can search apps by name keyword so that they can quickly find the app.



5-3. Sort apps


User can sort apps by either alphabet, recent used and user defined order, so that they can browse all the apps per favorite.




6. Domain Bar

6-1. Default apps

Home, Navigation, Music, Apps, Setting, Phone icons were shown in domain bar by default.




The app in apps page can be added to domain bar by “Pin App” button.



The app can be deleted from domain bar by clicking “Unpin App” button.

Home, Map, Apps icons were fixed in domain bar and cannot be unpinned.



6-2. Edit apps


- Long pressing on any app in domain bar will make it draggable, and user can be able to drag to change the apps' position.

7. Control Center

Control panel is to provide quick controls to those frequently used features such as Volume control, Turn on/off Wi-Fi and so on.


7-1. Control Center entrance

There has an entrance in domain bar that user can open the Control Center easily.



7-2. Main interface

Time area and quick controls area




Screen saver screen provide a simplest UI for users, they can slide up to exit this interface.




8. Setting

8-1. Theme





8-1-1. Desktop

Users can set different desktop layouts which provided by the system.



8-1-2. Wallpaper

User can set different wallpapers provided by the system.





8-2. Display



8-2-1. Dark mode

User can change the system theme between day and night mode manually or follow system.

- Day mode:




- Night mode:



8-2-2. Unit


User can change the Time Format between 12 Hour and 24 Hour and Unit between Metric and Imperial.



8-3. General

8-3-1. About


The system information was shown here.



8-3-2. Update

An updatable status was displayed if a new version was detected.

User can also change the previous upgrade preferences.




8-3-3. Language

User can switch the system language.




8-3-4. Reboot

A Reboot button was provided here which user can restart the device quickly.



8-3-5. Reset

A Reset button was provided here which user can reset Vivid back to the original factory settings.




8-4. Feature


8-4-1. General

8-4-1-1. Auto return home page

User can be brought back to home page automatically if this setting is enabled.



8-4-2. Music



8-4-2-1. Auto resume media after reboot


Music can be resumed playing automatically after the vehicle starts if this setting is enabled.

8-4-2-2. Show Vivid music widget

Vivid widget can be shown in “non-vivid screen” if this setting is enabled.

8-5. Car

Here provides an entrance for the user to set the car model.




8-6. User


8-6-1. Account

Here provides an entrance for the user to login the account.

- Before login the account




- After login the account




8-6-2. Valet Lock

Valet lock screen mode is to protect your head unit private information when in any valet scenario.




8-6-2-1. Set privacy password

User can set a six-digit number for privacy mode password.




8-6-2-2. Valet lock is in effect

Valet lock screen mode is in effect after user set a password.




8-6-2-3. Change valet password

User can change the valet password to a new one.




8-6-2-4. Open valet lock screen

The device was locked after user opened the valet lock screen.




8-6-2-5. Unlock valet lock screen

The valet lock screen can be unlocked by correct password.



8-6-2. User Feedback

Star the product and give feedback



8-7. Connections

User can enable/disable Wi-Fi switch and connect to a hotspot here.

